


JVC

SERVICE MANUAL

COMPACT COMPONENT SYSTEM

MX-D501T

COMPACT
disc
DIGITAL AUDIO



This Service manual have not "Location of Main Parts", "Out line of Main IC", "Analytic Drawing for CD traverse mechanism and Cassette mechanism etc.", "Block Diagram" and so on. These item should be used in conjunction with service manual for MX-D401T all version(Issue No. 10039).

Area Suffix

A	Australia
B	U.K.
C	Canada
E	Continental Europe
EN	North Europe
G	Germany
J	U.S.A.
UB	Hong.Kong
UP	Korea
US	Singapore
UT	Formosa
U	Other Areas
VX	Eastern Europe

Contents

1. Safety Precautions.....	Page 1-1	8. Wiring Connections	8-1
2. Safety Precaution about MX-D501T	2-1-3	9. Analytic Drawing and Parts List	9-1-5
3. Instructions	3-1-18	10. Block Diagram	10-1
4. Location of Main Parts	4-1	11. Standard Schematic Diagram	11-1-10
5. Removal of Main Parts	5-1-17	12. Location of P.C. Board Parts	12-1-6
6. Main Adjustment	6-1-4	13. Electrical Parts List	13-1-12
7. Out Line of Main IC	7-1	14. Packing	14-1-2

1. Safety Precautions


1. The design this product contains special hardware and many circuits and components specially for safety purposes. For continued protection, no changes should be made to the original design unless authorized in writing by the manufacturer. Replacement parts must be identical to those used in the original circuits. Service should be performed by qualified personnel only.
2. Alterations of the design or circuitry of the product should not be made. Any design alterations of the product should not be made. Any design alterations or additions will void the manufacture's warranty and will further relieve the manufacture of responsibility for personal injury or property damage resulting therefrom.
3. Many electrical and mechanical parts in the product have special safety - related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in the parts list of service manual. Electrical components having such features are identified by (\triangle) on the schematic diagram and parts list in the service manual. The use of a substitute replacement which does not have the same safety characteristics as the recommended replacement part shown in the parts list of service manual may create shock, fire, or other hazards.
4. The leads in the products are routed and dressed with ties, clamps, tubings, barriers and the like to be separated from live parts, high temperature parts, moving parts and or sharp edges for the prevention of electric shock and fire hazard. When service is required, the original lead routing and dress should be observed, and it should be confirmed that they have been returned to normal, after reassembling.
5. Leakage current check (Electrical shock hazard testing)

After re - assembling the product, always perform an isolation check on the exposed metal parts of the product (antenna terminals, knobs, metal cabinet, screw heads, headphone jack, control shafts, etc.) to be sure the product is safe to operate without danger of electrical shock. Do not use a line isolation transformer during this check.

- Plug the AC line cord directly into the AC outlet, using a "Leakage current tester", measure the leakage current from each exposed metal part of the cabinet, particularly any exposed metal part having a return path to the chassis, to a known good earth ground. Any leakage current must not exceed 0.5mA AC(r.m.s.)

- Alternate check method

Plug the AC line cord directly into the AC outlet. Use an AC voltmeter having 1,000 ohms per volt or more sensitivity in the following manner. Connect a 1,500 ohms 10W resistor paralleled by a 0.15 μ F AC type capacitor between an exposed metal part and a known good earth ground. Measure the AC voltage across the resistor with the AC voltmeter. Move the resistor connection to each exposed metal part, particularly any exposed metal part having a return path to the chassis, and measure the AC voltage across the resistor. Now, reverse the plug in the AC outlet and repeat each measurement. Any voltage measured



Warning (Except to C/J/U version)

1. This equipment has been designed and manufactured to meet international safety standards.
2. It is the legal responsibility of the repairer to ensure that these safety standards are maintained.
3. Repairs must be made in accordance with the relevant safety standards.
4. It is essential that safety critical components are replaced by approved parts.
5. If mains voltage selector is provided, check setting for local voltage.

CAUTION

Burrs formed during molding may be left over on some parts of the chassis. Therefore, pay attention to such burrs in the case of performing repair of this system.


2.Safety Precaution about MX-D501T

IMPORTANT FOR LASER PRODUCTS PRECAUTIONS (For B/E/EN/G/VX/US Version)

1. CLASS 1 LASER PRODUCT
2. **DANGER:** Invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to beam.
3. **CAUTION:** Do not open the rear cover. There are no user serviceable parts inside the unit; leave all servicing to qualified service personnel.
4. **CAUTION:** The compact disc player uses invisible laser radiation and is equipped with safety switches which prevent the emission of radiation when the CD holder is open. It is dangerous to defeat the safety switches.
5. **CAUTION:** Use of controls for adjustments and the performance of procedures other than those specified herein may result in exposure to hazardous radiation.
6. **CAUTION:** The laser is able to function, if safety switches out of function. The laser light is invisible, avoid exposure, do not disassemble the laser unit, but replace the complete unit.


IMPORTANT FOR LASER PRODUCTS REPRODUCTION OF LABELS

- ① CLASSIFICATION LABEL, PLACED ON REAR ENCLOSURE



- ② WARNING LABEL, PLACED INSIDE THE UNIT

<p>DANGER: Invisible laser radiation when open and interlock failed or defeated. AVOID DIRECT EXPOSURE TO BEAM. (e)</p>	<p>VARNING: Osynlig laserstrålning när denna del är öppen och spärren är urkopplad. Beträkta ej strålen. (e)</p>	<p>ADVARSEL: Usynlig laserstrålning ved åbning, når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling. (f)</p>	<p>VARO: Avattaessa ja suo- jalukitus ohjeltaessa olet alittiina näkymättömälle lasersäteilylle. Älä katso säteeseen. (f)</p>
--	---	---	--



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.




The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

**IMPORTANT FOR LASER PRODUCTS
PRECAUTIONS (For C/J/U Version)**


1. CLASS 1 LASER PRODUCT
2. **DANGER:** Invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to beam.
3. **CAUTION:** Do not open the rear cover. There are no user serviceable parts inside the unit; leave all servicing to qualified service personnel.
4. **CAUTION:** The compact disc player uses invisible laser radiation and is equipped with safety switches which prevent the emission of radiation when the CD holder is open. It is dangerous to defeat the safety switches.
5. **CAUTION:** Use of controls for adjustments and the performance of procedures other than those specified herein may result in exposure to hazardous radiation.
6. **CAUTION:** The laser is able to function, if safety switches out of function. The laser light is invisible, avoid exposure, do not disassemble the laser unit, but replace the complete unit.

**IMPORTANT FOR LASER PRODUCTS
REPRODUCTION OF LABELS**



Notes:

- * 1 The date of manufacture.
- * 2 The ID code of manufacturing plant.




The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

**■ IMPORTANT (For C/J Version)
: Fuse Replacement Marking Check**



MX-D501T C/J

Full Fusereplacement Marking

Graphic symbol mark (This symbol means fast blow type fuse.)



should be read as follows:

FUSE CAUTION

F999 : FOR CONTINUED PROTECTION AGAINST RISK OF FIRE, REPLACE ONLY WITH SAME TYPE 1.0-A, 250-V FUSE.

F998 : FOR CONTINUED PROTECTION F997 AGAINST RISK OF FIRE, REPLACE ONLY WITH SAME TYPE 1.25 -A, 250° V FUSE.

MX-D501T C/J

Marquage Pour Le Remplacement Complet De Fusible

Le symbole graphique (Ce symbole signifie fusible de type à fusion rapide.)



doit être interprété comme suit:

PRECAUTIONS SUR LES FUSIBLES

F999: POUR UNE PROTECTION CONTINUE CONTRE DES RISQUES D'INCENDIE, REMPLACER SEULEMENT PAR UN FUSIBLE DU MEME TYPE 1.0°A, 250°V.

F998: POUR UNE PROTECTION CONTINUE F997CONTRE DES RISQUES D'INCENDIE, REMPLACER SEULEMENT PAR UN FUSIBLE DU MEME TYPE 1.25 °A, 250 V°

3. Instructions

Warnings, Cautions and Others
Avisos, precauciones y otras notas
Advertências, precauções e outras notas
警告，注意及其他須知事項
تحذيرات، تنبيهات وإشياء اخرى

Caution — POWER switch
 Disconnect the mains plug to shut the power off completely. The POWER switch in any position does not disconnect the mains line. The power can be remote controlled.

¡Atención — Interruptor POWER!
 Desconectar el cable de alimentación para desactivar la alimentación totalmente. Cualquier que sea la posición de ajuste del interruptor POWER, la alimentación no es cortada completamente. La alimentación puede ser controlada remotamente.

Atenção — Interruptor POWER!
 Desconecte o cabo de alimentação para interromper a alimentação completamente. Qualquer que seja a posição de ajuste do interruptor POWER, a alimentação não é completamente controlada. A alimentação pode ser controlada remotamente.

IMPORTANT for the U.K.
 DO NOT cut off the mains plug from this equipment. If the plug lead is not suitable for the power points in your home or country, please contact your dealer for an appropriate safety approved extension lead or consult your dealer.
BE SURE to replace the fuse only with an identical approved type, as originally fitted.
 If nonetheless the mains plug is cut off ensure to remove the fuse and dispose of the plug immediately, to avoid possible shock hazard by inadvertent connection to the mains supply.
 If this product is not supplied fitted with a mains plug then follow the instructions given below.
IMPORTANT.
DO NOT make any connection to the terminal which is marked with the letter E or by the safety earth symbol or coloured green or green-and-yellow.
 The wires in the mains lead on this product are coloured in accordance with the following code:
 Blue : Neutral
 Brown : Live
 As these colours may not correspond with the coloured markings identifying the terminals in your plug proceed as follows:
 The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.
 The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.
IF IN DOUBT - CONSULT A COMPETENT ELECTRICIAN.

注意

為了降低雷電、火災等危險：
 1. 請勿擅自卸下插絲釘，蓋子或線路。
 2. 切勿讓本機受雨淋或受潮濕環境中。

تحذير

لتجنب خطر الحريق، الصدمات الكهربائية، الخ:
 1. لا تقم بفتح الغطاء أو الحزاة.
 2. لا تقم بتعرض هذا الجهاز للطرر أو للرطوبة.

CAUTION


To reduce the risk of electrical shocks, fire, etc.:
 1. Do not remove screws, covers or cabinet.
 2. Do not expose this appliance to rain or moisture.

PRECAUCIÓN

Para reducir riesgos de choques eléctricos, incendio, etc.:
 1. No extraiga los tornillos, las cubiertas ni la caja.
 2. No exponga este aparato a la lluvia o a la humedad.

PRECAUÇÃO

Para reduzir riscos de choques elétricos, incêndio, etc.:
 1. Não remova parafusos e tampas ou desmonte a caixa.
 2. Não exponha este aparelho à chuva nem à umidade.




COMPACT COMPONENT SYSTEM
SISTEMA DE COMPONENTES COMPACTO
SISTEMA DE COMPONENTE COMPACTO


CA-D501T/MX-D401T/MX-D301T

Consists of CA-D401T and SP-D401
 Consiste del CA-D401T e SP-D401
 Consta do CA-D401T e SP-D401


CA-D501T



MX-D401T




CA-D401T




SP-D401

MX-D301T



CA-D301T




SP-D311



For Customer Use:
 Enter below the Model No. and Serial No. which are located either on the rear, bottom or side of the cabinet. Retain this information for future reference.
 Model No. _____
 Serial No. _____

PART No. FMUN9002-181M
 (U, UT, US, UB)

INSTRUCTIONS
MANUAL DE INSTRUCCIONES
INSTRUÇÕES




IMPORTANT FOR LASER PRODUCTS / IMPORTANTE PARA PRODUCTOS LÁSER / IMPOTANTE PARA PRODUTOS LASER / 雷射產品的重要說明 / 雷射產品的重要說明 / 雷射產品的重要說明

REPRODUCTION OF LABELS / REPRODUÇÃO DE ETIQUETAS / REPRODUCCIÓN DE ETIQUETAS / 標籤內容說明 / 標籤內容說明 / 標籤內容說明

- ① CLASSIFICATION LABEL, PLACED ON REAR ENCL...
② WARNING LABEL, PLACED INSIDE THE UNIT
③ ETIQUETA DE CLASIFICACIÓN, PEGADA EN LA PARTE POSTERIOR DE LA CAJA
④ ETIQUETA DE ADVERTENCIA LOCALIZADA NA PARTE INTERNA DA UNIDADE.
⑤ 警告標籤，貼於機內。

① لاصق التصنيف، موضوعه على الرق الخلفي
② لاصقة التحذير، موضوعه بداخل الجهاز

Table with 4 columns: CAUTION, WARNING, DANGER, and a small table with Chinese characters.



- 1. CLASS 1 LASER PRODUCT
DANGER: Invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to beam.
CAUTION: Do not open the top cover. There are no user serviceable parts inside the Unit; leave all servicing to qualified service personnel.

- 1. PRODUCTO LÁSER CLASE 1
PELIGRO: En el interior hay radiación láser invisible. Evite el contacto directo con el haz.
PRECAUCIÓN: No abra la tapa superior. En el interior de la unidad no existen piezas reparables por el usuario; deje todo servicio técnico en manos de personal calificado.

- 1. PERIGO: O laser emite uma radiação invisível que é perigosa, caso o aparelho esteja aberto e a trava inoperante ou danificada. Evite exposição direta ao feixe dos raios.
CUIDADO: Não abra a caixa do aparelho. Não existem peças reparáveis pelo usuário na parte interna da unidade. Solicite assistência técnica somente a pessoal técnico qualificado.


Caution: Proper Ventilation
To avoid risk of electric shock and fire, and to prevent damage, locate the apparatus as follows:
1. Front: No obstructions and open spacing.
2. Side/ Top/ Back: No obstructions should be placed in the areas shown by the dimensions below.
3. Bottom: Place on the level surface. Maintain an adequate air path for ventilation by placing on a stand with a height of 10 cm or more.

Precaución: el aparato debe estar bien ventilado
Para evitar posibles riesgos de descargas eléctricas e incendios y prevenir cualquier posible daño, coloque el aparato del modo siguiente:
1 Parte delantera: No ponga nada delante, deje el espacio libre.
2 Laterales/ parte superior/ parte trasera: No se debería colocar nada en las áreas y las distancias que se detallan a continuación.
3 Parte inferior: Coloque el aparato sobre una superficie recta. Debe haber buena circulación de aire; para ello, coloque el aparato sobre una base a una altura mínima de 10 cm.

Precaução: Ventilação adequada
Para evitar riscos de choques elétricos e incêndios, e prevenir avarias, instale o aparelho como segue:
1 Parte frontal: Sem obstruções e espaços abertos.
2 Partes laterais/Tampo/Posterior: Nenhuma obstrução deverá ser colocada entre as áreas cujas dimensões são indicadas abaixo.
3 Parte inferior: Instale-o sobre uma superfície plana. Deverá ser mantido espaço suficiente para a ventilação se este for instalado numa posição que tenha uma altura de 10 cm ou mais.

警告: 正確通風
為避免發生電擊、火警及損壞設備之危險，應按下列方法安裝：
1 前面: 請勿在前方設置任何障礙物，並保持適當間距。
2 側面/頂部/背面: 請勿在圖中所示之區域及距離內設置任何障礙物。
3 底部: 將設備置於水平面上。應確保設備下方有足夠之通風空間，為此應將設備置於高度至少為 10 公分之底座上。

تحذير: التهوية الصحيحة
لتفادي وقوع الصدمة الكهربائية وخطر الحريق والتلف المحتمل، قم بتثبيت الجهاز كما هو موضح أدناه:
1 الجهة الأمامية: عدم وجود العوائق وعدم وضع العوائق في المجالات الموضحة بالأبعاد أدناه.
2 الجهات الجانبية والعلوية والخلفية: ينبغي عدم وضع العوائق في المساحات المستوية، احتفظ بمسار الهواء، لتأمين بوضع الجهاز على حامل بارتفاع 10 سم أو أكثر.



Thank you for purchasing the JVC Compact Component System. We hope it will be a valued addition to your home, giving you years of enjoyment. Be sure to read this instruction manual carefully before operating your new stereo system. Here you will find all the information you need to set up and use the system. For questions that are not answered in the manual, please contact your dealer.

Features

- Here are some of the things that make your System powerful and easy to use.
- The controls and operations have been redesigned to make them very easy to use, so you can spend your time listening to music.
 - With the One Touch Operation feature of JVC's **COMPU PLAY** you can turn on the System and start the radio, the Cassette Deck, or the CD Player with a single touch.
 - To get such great sound from such a compact package the System has:
 - Programmed sound mode includes five surround effects **D. CLUB, HALL, and STADIUM.** It also includes **S.E.A. (Sound Effect Amplifier)** effects **ROCK, CLASSIC, and POP.**
 - CD changer function can operate 3 discs.
 - Discs can be changed during play using the **TRIPLE TRAY**.
 - Continuous, random or program play of 3 discs.
 - Includes a timer for recording broadcasts while you are out, and an easy-to-use Sleep timer.
 - You can use conventional tapes and CDs for **Karaoke** with the voice masking system. With an optional microphone, you can replace the lead singer's voice on your favorite songs with your own.
 - Digital Echo** applied to your voice through the microphone gives you a professional sound.

How This Manual Is Organized

- In this manual we have incorporated some special features:
- Basic information that is the same for many different functions is grouped in one place, and not repeated in each procedure. For instance, in the section on playing a CD, we do not repeat the information about setting the volume and the sound conditions, which are discussed in the Common Operations section.
 - Name of buttons and controls are written in all capital letters like this: **SOUND MODE, BUTTON or DISPLAY**, only the first letter is capitalized.
- The manual has a table of contents to help you quickly look up what you want to know. We've enjoyed making this manual for you, and hope you will use it to enjoy the sound and many features built into your System.

IMPORTANT CAUTIONS

- Installation of the Unit**
 - Select a place which is level, dry and neither too hot nor too cold. (Between 5°C and 35°C or 41°F and 95°F)
 - Leave sufficient distance between the Unit and a TV.
- Power cord**
 - Do not use the Unit in a place subject to vibrations.
 - Do not handle the power cord with wet hands!
 - Some power (12 watts) is always consumed as long as the power cord is connected to the wall outlet.
 - When unplugging the Unit from the wall outlet, always pull the plug, not the power cord.
- Malfunctions, etc.**
 - There are no user serviceable parts inside. If anything goes wrong, unplug the power cord and consult your dealer.
 - Do not insert any metallic object into the Unit.

Easy operation


COMPU PLAY

Great sound

Triple Tray

Sing Along

Mains (AC) Line Instruction (not applicable for Europe, U.S.A., Canada, Australia, and U.K.)
Instrucción sobre la línea de la red (CA) (no aplicable para Europa, EE.UU., Canadá, Australia, ni el Grã-Bretanha)
Instrução sobre a tensão da rede elétrica (CA) (não aplicável para a Europa, os E.U.A., o Canadá, a Austrália e o Reino Unido)
主 (AC) 電源線路説明 (不適用於歐洲、美國、加拿大、澳洲及英國型號)
تعليمات التيار الرئيسي (التردد) (لا ينطبق لأوروبا وأمريكا وكندا والملكة المتحدة)



有關主 (AC) 電源線路的注意事項
 接駁電源以前，請先檢查後面的主 (AC) 電源線路開關是否處於關閉位置。如果不在關閉位置，則可能導致電壓不穩定，造成損壞。如果重新安裝電源線路時，請確保開關處於關閉位置，以免損壞設備。請注意，此開關不能用於防止火災或電擊的危險。

IMPORTANT for mains (AC) line BEFORE PLUGGING IN. do check that your mains (AC) line voltage corresponds with the position of the voltage selector switch provided on the outside of this equipment and, if different, reset the voltage selector switch, to prevent from a damage or risk of fire/electric shock.

هام من أجل خط التيار المتردد (AC) الرئيسي قبل الربط الكهربائي. تأكد من أن فولتية خط التيار المتردد (AC) الرئيسي لديك تتوافق مع موضع مفتاح اختيار الفولتية الخارج على المعدات. وإذا اختلف، فقم بإعادة ضبط مفتاح اختيار الفولتية. لمنع التلف أو الصدأ الكهربائي أو خطر الحريق.

IMPORTANTE para la línea de la red (CA) ANTES DE ENCHUFAR EL EQUIPO, compruebe si la tensión de la línea de la red (CA) corresponde con la posición del selector de tensión situado en la parte exterior del equipo, y si es diferente, reajuste el selector de tensión para evitar el riesgo de incendios/descargas eléctricas.

IMPORTANTE para a ligação à tensão da rede (CA) ANTES DE LIGAR O APARELHO A UMA TOMADA DA REDE, verifique se a tensão da rede-CA corresponde à posição do seletor de voltagem localizado na parte externa deste equipamento. Caso não corresponda, reajuste o seletor de voltagem a fim de evitar avarias ou riscos de incêndio e choque elétrico.

Table of Contents

Features.....	1	Repeating a Selection or the Discs	17
How This Manual Is Organized.....	1	Tray Lock Function	17
IMPORTANT CAUTIONS	1	Locking the Electronic Lock	17
		Unlocking the Electronic Lock	17
Getting Started	3		
Accessories	3	Using the Cassette Deck	18
Set the VOLTAGE SELECTOR Switch	3	(Listening to a Tape)	18
How To Put Batteries In the Remote Control	3	One Touch Play	18
Using the Remote Control	3	Regular Play	18
Connecting the FM Antenna	4	Fast Left and Fast Right	19
Connecting the AM Antenna	4	Music Scan	19
Connecting the Speakers (CA-D501T)	5	To Find the Beginning of the Current Selection	19
Connecting the Speakers (MX-D4017/MX-D301T)	5	To Find the Beginning of the Next Selection	19
Connecting Auxiliary Equipment	6	Reverse Mode	19
COMPU PLAY	6		
Common Operations	7	Using the Cassette Deck (Recording)	20
Turning the Power On and Off	7	Things To Know Before You Start Recording	20
Turning the System On	7	Standard Recording	21
Turning the System Off	7	To Record Any Sound Source To Tape	21
Adjusting the Volume	8	CD Direct Recording	22
Reinforcing the Bass Sound	8	Tape to Tape Recording (Dubbing)	22
Sound Modes	8	How to Use the DUBBING Button	22
Listening to Auxiliary Equipment	9		
Using the Tuner	10	Using the Timer	23
Setting the AM Tuner Interval Spacing	10	Setting the Clock	23
One Touch Radio	10	Setting the Timer	24
Switching between Frequency Bands	11	Setting the SLEEP Timer	25
Three ways to select a station	11		
Presetting Stations	11	Using the Microphone	26
To Change the FM Reception Mode	11	Karaoke (Sing Along)	26
		Singing Along with Karaoke	26
Using the CD Player	12	Digital Echo	27
The Quickest Way To Start a CD Is With the		To Record Your Singing	27
One Touch Operation	13	Microphone Mixing	28
To Insert Discs	13	To Record Microphone Mixing	28
Basics of Using the CD Player — Normal Play	14	Playing the Microphone Sound through	
To Play a Disc	14	the Speaker	28
To Select a Disc, Track Or Passage		Recording from the Microphone	28
Within a Track	14		
Locating a Track With the Remote Control		Care And Maintenance	29
Directly	14	Troubleshooting	30
To Change Discs While Playing	14	Specifications	31
Continuous Play	15		
Programming the Playing Order of the Tracks	15		
Random Play	16		

Getting Started

Accessories

Check that you have all of the following items, which are supplied with the System.

- AM Loop Antenna (1)
- Remote Control (1)
- Batteries (2)
- FM Wire Antenna (1)
- AC Plug Adaptor (except for Hong Kong) (1)

If any of these items is missing, contact your dealer immediately.


Set the VOLTAGE SELECTOR Switch

- To avoid damaging the System, set the voltage before plugging in the Unit.
- Set the correct voltage for your area with the VOLTAGE SELECTOR switch on the back panel of the System. Use a screwdriver to rotate the selector so the number the arrow is pointed at is the same as the voltage.



How To Put Batteries In the Remote Control

Match the polarity (+ and -) on the batteries with the + and - markings in the battery compartment.




CAUTION: Handle batteries properly.

- To avoid battery leakage or explosion:
 - Remove batteries when the Remote Control will not be used for a long time.
 - When you need to replace the batteries, replace both batteries at the same time with new ones.
 - Don't use an old battery with a new one.
 - Don't use different types of batteries together.

Using the Remote Control


The Remote Control makes it easy to use many of the functions of the System from a distance of up to 7m (23 feet) away. You need to point the Remote Control at the remote sensor on the System's front panel.




CAUTION: Make all connections before plugging the Unit into an AC power outlet.

Connecting the FM Antenna

Using the Supplied Wire Antenna




Using an FM 75-Ohm Antenna Wire (Not Supplied)



CAUTION: To avoid noise, keep antennas away from metallic parts of the System, connecting cord and the AC power cord.

Connecting the AM Antenna


AM antenna wire (Not supplied) If reception is poor, connect the outside antenna.



CAUTION: Make all connections before plugging the Unit into an AC power outlet.

Connecting the Speakers (CA-D501T)


- Please refer to instructions for speakers as well when you connect speakers.
- For each speaker, connect one end of the speaker wire to the speaker terminals on the back of the CA-D501T and the other end to the speaker.
- Open each of the terminals and insert the speaker wires firmly (be sure to remove the insulation at the end of each wire first), then close the terminals.
- Connect the red (+) and black (-) terminals of the right side speaker to the red (+) and black (-) terminals marked **RIGHT** on the CA-D501T.
- Connect the red (+) and black (-) terminals of the left side speaker to the red (+) and black (-) terminals marked **LEFT** on the CA-D501T.



IMPORTANT: Use speakers with the correct impedance only. The correct impedance is indicated on the back panel.
CAUTION: If a TV is installed near speakers, the TV may display irregular colours. In this case, set the speakers away from the TV.

Connecting the Speakers (MX-D401T/ MX-D301T)


- Please refer to instructions for speakers as well when you connect speakers.
- For each speaker, connect one end of the speaker wire to the speaker terminals on the back of the System.
- Open each of the terminals and insert the speaker wires firmly, then close the terminals.
- Connect the red (+) and black (-) terminals of the right side speaker to the red (+) and black (-) terminals marked **RIGHT** on the System.
- Connect the red (+) and black (-) terminals of the left side speaker to the red (+) and black (-) terminals marked **LEFT** on the System.



IMPORTANT: Use speakers with the correct impedance only. The correct impedance is indicated on the back panel.
CAUTION: If a TV is installed near speakers, the TV may display irregular colours. In this case, set the speakers away from the TV.

Connecting Auxiliary Equipment

VCR or other equipment
To listen to this source, press the AUX button.



Now you can plug the AC power cord into the wall outlet, and your System is at your command!


COMPU PLAY

COMPU PLAY is JVC's feature that lets you control the most frequently used functions of the System with a single touch.
One Touch Operation starts playing a CD, turns on the radio, plays a tape, etc. with a single press of the play button for that function. What One Touch Operation does for you is to turn the power on, then start the function you have specified. If the Unit is not ready, such as no CD or tape in place, the Unit still powers on so you can insert a CD or tape.
How One Touch Operation works in each case is explained in the section dealing with that function.
The COMPU PLAY buttons are:

- On the Unit**
- CD \rightarrow /II button
 - CD Player DISC-1 to DISC-3 buttons
 - CD Player Open/Close (Δ) buttons
 - FM/AM button
 - \leftarrow TAPE \rightarrow button
 - AUX button

- On the Remote Control**
- FM/AM button
 - AUX button
 - CD control \rightarrow /II button
 - CD control DISC 1 to DISC 3 buttons
 - CD control Open/Close (Δ) buttons
 - Deck control \leftarrow \rightarrow buttons

Common Operations



When the System is being used, the display shows other items as well. However, we have only shown the items described in this section.

Turning the Power On and Off

Turning the System On

Press the POWER button.

- The display comes on and the STANDBY indicator goes out.
- The System comes on ready to continue in the mode it was in when the power was last turned off.
- If the last thing you were doing was listening to a tape in Deck B, you are now ready to listen to a tape again in Deck B, or you can change to another source.
- If you were listening to the Tuner last, the Tuner comes on playing the station it was last set to.


Turning the System Off

Press the POWER button again.

- The STANDBY indicator lights up and the display is blank, except for the clock display.
- Some power (12 watts) is always consumed even though power is turned off (called Standby Mode).
- To switch off the Unit completely, unplug the AC power cord from the AC outlet. When you unplug the AC power cord, the clock will be reset to 0:00 immediately, and preset Tuner stations will be erased after a few days.

Adjusting the Volume

Turn the VOLUME control clockwise to increase the volume or anticlockwise to decrease it. Turning the VOLUME control quickly also adjusts the volume level quickly. When using the Remote Control, press the VOLUME + button to increase the volume or press the VOLUME - button to decrease it. You can adjust the volume level between 0 and 50.



VOLUME 0

CAUTION: The Volume cannot be adjusted while the Unit is in STANDBY mode. DO NOT turn on the Unit and/or start playing any source without setting the VOLUME control to 0; otherwise, the sudden blast of sound can damage your hearing, speakers and/or headphones.

For private listening
Connect a pair of headphones to the PHONES jack. No sound comes out of the speakers. Be sure to turn down the volume before connecting or putting on headphones.

Reinforcing the Bass Sound


The richness and fullness of the bass sound is maintained regardless of how low you set the volume. You can use this effect only for playback.

To get the effect, press the ACTIVE BASS EX. (Active Bass Extension) button.

A.BASS EX

To cancel the effect, press the button again. The frame around the "A. BASS EX" indicator goes out.

A.BASS EX



Sound Modes

The System has some preset sound effects that give you control of the way your music sounds, so you can tailor it for your room and for the quality of the source. We can give you some idea of how each one affects the music, but the only way to really tell is to try them yourself.

- The preset sound modes include modes using surround effects and modes using S.E.A. effects.
- Sound Mode effects cannot be recorded.

Surround effect modes

- D. CLUB (Dance Club) Increases resonance and bass.
- HALL Adds depth and brilliance to the sound, like in a concert hall.
- STADIUM Adds clarity and spreads the sound, like in an outdoor stadium.

S.E.A. effect modes

- ROCK Boosts low and high frequencies.
- CLASSIC Set for wide and dynamic sound stereo systems.
- POP Good for vocal music.

KARAOKE mode

The vocal on tapes or CDs is masked for karaoke.

To get an effect, press the SOUND MODE button repeatedly until the Sound Mode you want appears in the display. The frame around the "S.MODE" indicator lights up.

Each time you press the SOUND MODE button, the display changes as shown below:

→ D. CLUB → HALL → STADIUM → ROCK → CLASSIC → POP → KARAOKE → FLAT → (back to the beginning)

To cancel an effect, press the SOUND MODE button until "FLAT" appears on the display. The frame around the "S. MODE" indicator goes out.

S.MODE

To recall the previous Sound Mode, press the SOUND MODE button again.



Listening to Auxiliary Equipment

By playing the sound from auxiliary equipment through the System, you can gain control over how the music or program sounds. Once the connected equipment is playing through the System, you can apply the sound effects.

- First make sure that the optional equipment is properly connected to the System. (See page 5).

1. Set the VOLUME control to 0.

2. Press the AUX button.

When System is in Standby mode, the Unit is automatically turned on and "AUX" appears on the display.

AUX


3. Start playing the equipment.

4. Adjust the VOLUME control to the desired listening level.


5. Select a sound effect mode, if you wish.

To Cancel the Setting


Change the source by starting any one of the System's built-in sound sources, such as the Tuner or CD Player.



Using the Tuner




Number keys



Display

Band display, Frequency display, Preset channel



When the System is being used, the display shows other items as well. However, we have only shown the items described in this section.

You can listen to both FM and AM stations. Stations can be tuned in manually, automatically, or from preset memory storage.

- Before listening to the radio:
- Check that both the FM and AM antennas are firmly connected. (See page 4).


Setting the AM Tuner Interval Spacing

Some countries space AM stations 9 kHz apart, and some countries use 10 kHz spacing. Europe, the U.K., Australia, and some other areas use 9 kHz spacing, while Canada, the United States, and some other Western Hemisphere countries use 10 kHz spacing.

- When shipped, the System is set to 9 kHz spacing.
- In case of Brazil, the System is set to 10 kHz spacing.
- To select the 10 kHz interval, be sure that the Unit is in STANDBY mode. Turn on by pressing the POWER button while pressing the TUNING UP button on the Unit. "AM -- 10" appears on the display.
- To change back to 9 kHz, be sure that the Unit is in STANDBY mode. Turn on by pressing the POWER button while pressing the TUNING DOWN button on the Unit. "AM -- 9" appears on the display.

One Touch Radio

- Just press the FM/AM button to turn on the Unit and start playing the most recent station tuned in.
- You can switch from any other sound source to the radio by pressing the FM/AM button.




COMPUTERPLAY

Tuning In a Station

Press the FM/AM button to turn on the radio. The Frequency of the previously selected channel appears on the display.

Switching between Frequency Bands


Press the FM/AM button. Each time you press the button, the band alternates between FM and AM.



Three ways to select a station


Press the TUNING DOWN or TUNING UP button repeatedly to move from frequency to frequency until you find the one you want. (Manual Tuning).

OR



Press and hold the TUNING DOWN or TUNING UP button for a few seconds, the frequency starts changing on the display. When a station is tuned in, the frequency stops changing. (Auto Tuning).


OR



Possible only after presetting stations. Press once and release the P, DOWN or UP button to go to the next preset station.

You can also use the Remote Control to tune in preset channels:

- Press the FM/AM button so that you can receive the most recent station tuned in.
- Select the station by entering the preset number in the number keys of the Remote Control.
 - Example: for channel 5, press 5. For channel 15, press +10 then 5. For channel 20, press +10, then 10. For channel 30, press +10 twice then 10.



- After you have selected the preset number and the number is displayed, the broadcast frequency of the selected channel is displayed.

Presetting Stations

You can preset up to 30 FM stations and up to 15 AM stations for the preset numbers. Note: In some cases, test frequencies have been already memorized for the tuner since the factory examined the tuner preset function before shipment. This is not a malfunction. You can preset the stations you want into memory by following the presetting method.

- Select a band by pressing either the FM/AM button.
- Press the TUNING DOWN or TUNING UP button to tune into a station.
- Setting the preset number by pressing the number keys on the Remote Control continuously.

For preset numbers 1 to 10: Press the number key for the preset number you want to set. For preset numbers 11 to 20: Press the 1 to 10 buttons after pressing the +10 button. For preset numbers 21 to 30: Press the 1 to 10 buttons after pressing the +10 button twice.

The preset number appears in the display after you have pressed the number keys. If the key is pressed continuously, the preset number display blinks. Release the button after the number starts to blink. This completes the preset setting.

- Repeat steps 1 - 3 for each station you want to store in memory with a preset number.

CAUTION: If the Unit is unplugged or if a power failure occurs, the preset stations will be erased after a few days. If this happens, preset the station again.


To Change the FM Reception Mode

When an FM stereo broadcast is hard to receive or noisy, press the FM MODE button on the Remote Control so that the "MONO" indicator lights up in the display. Reception improves, but there is no stereo effect.


To restore the stereo effect, press the FM MODE button on the Remote Control so that the "MONO" indicator goes off. In this stereo mode, the "ST" indicator lights up and you can hear stereo effects, when a program is broadcast in stereo.



Using the CD Player



Display



When the System is being used, the display shows other items as well. However, we have only shown the items described in this section.

The System's CD Player has an Automatic Changer with 3 disc trays. You can use Continuous, Random, Program or Repeat Play for the discs in DISC-1, DISC-2 and DISC-3. Repeat Play can repeat all the tracks on all the CD's, the tracks on one of the CD's or one track on one CD. There is also the Tray Lock function, which safely keeps discs in the trays.


Here are the basic things you need to know to play a CD and locate the different selections on it. Each selection is called a track, so when we are talking about locating a track, we are also talking about how you find a certain song or performance.

Disc display
A red marker lights on the disc display for the disc number you have selected. This disc display blinks while a CD is being played. The centre of the disc display is not lit while the CD Player is checking that there is no disc in the disc tray for the corresponding disc number.

The Quickest Way To Start a CD Is With the One Touch Operation


- Press the CD >/< IN button (or the >/< IN button on the Remote Control).
- For Normal Play (Play mode indicator is not lit):**
 - If there is a CD in the disc tray for the selected disc number, the power is automatically turned on and the CD is played from the first track.
 - If there is no CD in the disc tray for the selected disc number, the power is automatically turned on and "NO DISC" appears on the display. The CD Player is in stop mode.
- For Continuous Play or Random Play in Display mode (CONT. or RANDOM indicator is lit):**
 - If there is a CD in the disc tray for the selected disc number, the power is automatically turned on and the CD is played continuously from the first track or the tracks are played in random order.
 - If there is no CD in the disc tray for the selected disc number, the power is automatically turned on and other tray containing a CD is selected and is played continuously from the first track or the tracks are played in random order.
 - If there are no CDs in CD player, the power is automatically turned on and "NO DISC" appears on the display in Normal Play mode. The CD Player is in stop mode.
- Press a DISC button (1 to 3).
 - If there is a CD in the disc tray for the selected disc number, the power is automatically turned on and playback starts from the selected CD.
 - If there are no CDs in CD Player, the power is automatically turned on and "NO DISC" appears on the display in Normal Play mode. The CD Player is set to stop mode.
- Press the >/< IN button.
 - The power turns on, and the tray opens automatically.

To Insert Discs



- 1. Press the >/< IN button on the left of the Disc button you want to insert the disc into.**
The disc tray slides out automatically.
- 2. Place a CD, with its label side up, onto the tray.**

ATTENTION: To avoid malfunctions when you play a CD, please set the CD in the right place at the centre of the tray.




- 3. Press the >/< IN button to close the tray.**
- 4. Repeat steps 1 to 3 to insert other discs into other trays.**
 - To continue putting discs into other trays, even if a tray is open, by pressing the >/< IN button of another disc tray, the open tray will close automatically, and the new disc tray will slide out.

- To put an 8 cm CD into a tray, insert it so that it is aligned with the groove in the tray's centre.
- If a tray is open when the System switches to Standby mode, the tray is closed automatically.

Basics of Using the CD Player — Normal Play

To Play a Disc

- 1. Prepare the discs.**
- 2. Press the CD Δ /II or DISC button (1-3) of the disc you want to play.**
When using the Remote Control, press the Δ /II button or the DISC (1 to 3) buttons. The first track of the selected disc will begin playing.
The CD Player automatically stops when the playback finishes the last track of the CD.
 - If these buttons are pressed while the tray is open, the tray is automatically closed and playback starts.




Note: If the CD cannot be read correctly (due to scratches etc.), "00 0000" appears on the display.

To stop playing the disc, press the CLEAR button (or the Δ /II button on the Remote Control).
To stop playing and removing the disc, press the Δ button for the disc being played.
To pause, press the Δ /II button (or the Δ /II button on the Remote Control). The Disc display will blink.
To cancel pause, press the Δ /II button again (or press the Δ /II button on the Remote Control). Play continues from the point where it was paused.

To Select a Disc, Track Or Passage Within a Track

- 1. Press the DISC button (1-3) for the disc tray containing the track you want to listen to.**
 - Example: for the third disc, press 3.
- 2. Press the Δ P.DOWN or Δ P.UP button to select the track.**
The selected track starts playing.



Each time you briefly press and release the Δ P.DOWN or Δ P.UP button, the track changes by one.

- Press and release the Δ P.UP button to go ahead one track at a time.
- Press and release the Δ P.DOWN button to go back one track at a time.

Holding down the Δ P.DOWN or Δ P.UP button, during playback, will fast forward/backwards the CD so you can quickly find a particular passage in the selection you are listening to.

When using the Remote Control, press the Δ or Δ button.


Locating a Track With the Remote Control Directly

Using the number keys on the Remote Control allows you to go directly to the beginning of any track.

- 1. Press the DISC button (1-3) for the disc tray containing the track you want to listen to.**
 - Example: for the third disc, press 3.
- 2. Enter the number of the track you want to listen to with the number keys.**

The selected track starts playing.

- Example: for track 5, press 5. For track 15, press +10 then 5. For track 20, press +10, then 10. For track 32, press +10 three times, then 2.



To Change Discs While Playing

You can replace a CD in a tray not being used, while another CD is playing.

- 1. Press the Δ button of the tray not being used.**
The tray opens.
- 2. Replace the disc in the tray.**
- 3. Press the Δ button to close the tray.**

Continuous Play

This function plays the disc in the Unit continuously.

- 1. Prepare the discs.**
- 2. Select Continuous mode.**

On the Unit

Press the CONTINUE button.
The playback automatically starts from the selected CD.


- "CONT" on the Play mode indicator lights up.

You can press the CONTINUE button while a CD is playing to switch to Continuous mode.

On the Remote Control

- 1. Press the PLAY MODE button while the CD player is stopped, to select "CONTINUE".**

- "CONT" lights in the Play mode indicator.
- The display changes with each press of the PLAY MODE button as shown below.



\rightarrow PROGRAM \rightarrow RANDOM \rightarrow CONTINUE \rightarrow No display \rightarrow (back to the beginning)

- 2. Press the DISC button (1 to 3) or Δ /II button.**
Playback starts from the selected CD.

Playing order of the CDs

The selected CDs are played continuously in the following order.
 \rightarrow DISC 1 \rightarrow DISC 2 \rightarrow DISC 3 \rightarrow (back to the beginning)


To cancel Continuous play, press the CONTINUE button again. The "CONT" indicator on the display goes out and Normal Play is resumed. When using the Remote Control, press the PLAY MODE button while the CD Player is stopped to select a different Play mode. The "CONT" indicator goes out and the next Play mode is selected.

Programming the Playing Order of the Tracks

You can change the order in which the discs and tracks play, and select only the discs and tracks you want from among those loaded in the CD Player.

- You can program up to 20 steps in any desired order from among the discs in the player.
- You can only make a program when the CD Player is stopped.
- Use the Remote Control.


- 1. Press the PLAY MODE button to select "PROGRAM".**
The display changes with each press of the PLAY MODE button as shown below.




\rightarrow PROGRAM \rightarrow RANDOM \rightarrow CONTINUE \rightarrow No display \rightarrow (back to the beginning)


- The "PRGM" play mode indicator light up.
- If a program is already in progress, the last step of the program is displayed.

- 2. Select a disc with the DISC buttons (1-3).**
The display changes to the Program Entry display.





3. Press the number keys (1 to 10 and +10) to select the track to program.
 Example: for track 5, press 5. For track 15, press +10 then 5. For track 20, press +10 then 10.



4. Repeat steps 1 to 3 to select the other tracks for the program.

5. Press the >/II button.

The Unit plays the tracks in the order you have programmed them.

- If you try to program a disc tray that is empty, or a track number that does not exist on a disc (for example, selecting track 14 on a disc that only has 12 tracks), the selected disc or track are skipped when the program is played.
- You can skip to a particular program step by pressing the < or > button during program play.
- To play the programmed tracks over and over, press the REPEAT button. The Repeat mode indicators light up in sequence with each press of the REPEAT button.

To stop playing, press the ■ button (or the ■/CLEAR button on the Remote Control) once.
To delete all the tracks in a program, press the ■ button on the Unit or the ■/CLEAR button on the Remote Control while the CD Player is stopped. The program is deleted and the "PRGM" play mode indicator goes out and Normal Play is resumed.

To cancel program play, press the PLAY MODE button on the Remote Control while the CD Player is stopped to select a different Play mode. The "PRGM" indicator goes out and the next Play mode is selected.

Note: If you press the CONTINUE or RANDOM button on the unit while a program is playing, the play mode changes to that mode.

Random Play

The tracks will play in no special order when you use this mode.

On the Unit

- Press the RANDOM button.
 The playback automatically starts from the selected CD.
- "RANDOM" on the Play mode indicator lights up.



You can press the RANDOM button while a CD is playing to switch to Random play mode.

On the Remote Control

1. Press the PLAY MODE button while the CD Player is stopped, to select "RANDOM".
 • "RANDOM" lights in the Play mode indicator.

The display changes with each press of the PLAY MODE button as shown below.

→ PROGRAM → RANDOM → CONTINUE → No display → (back to the beginning)

2. Press the >/II button.

Playback starts from the selected CD.

Note: Random Play cannot be activated with the DISC button (1 to 3).

To skip to the next track, press the > button during playback. The next track is jumped to with each press of the button. Press the < button to jump to the start of the track being played.

- Press the REPEAT button before or during random play to instruct the System to continue with a different random track selection after the last selection is played.

To cancel random play, press the RANDOM button again. The "RANDOM" play mode indicator goes out and Normal Play is resumed. When using the Remote Control, press the PLAY MODE button while the CD Player is stopped to select a different Play mode. The "RANDOM" indicator goes out and the next Play mode is selected.

Repeating a Selection or the Discs

You can have all the discs, the program or the individual selection currently playing repeat as many times as you like.

Press the REPEAT button.

The display changes with each press of the button, as shown below.

→ < → ALL → blank display → (back to the beginning)

< : Repeats one track on a CD.

< ALL : For Normal Play, repeats all the tracks on the current CD.
 For Continuous Play or Random Play, repeats all the tracks on all the CDs in the CD Player.

For Program Play, repeats all the tracks in the program.

To exit Repeat Mode, press the REPEAT button until the Repeat mode indicator on the display goes out.

Tray Lock Function

In order to safely keep the discs in the CD Player, the three trays can be electronically locked in a single operation.

When the electronic lock is on, the trays cannot be opened even if the > button is pressed.

This function can only be accessed by using the buttons on the Unit itself.

Locking the Electronic Lock

1. Put the System's power into STANDBY mode.
2. While pressing the ■ button, press the > button for DISC 1's tray on the Unit.

"LOCK ON" appears on the display to let you know that the trays have been locked.

LOCK ON

When the CD Player trays are locked, pressing the > buttons displays the message "LOCK ON" on the display and the trays do not open. Also, the > button cannot be used to automatically turn on the power.

Unlocking the Electronic Lock



1. Put the System's power into STANDBY mode.
2. While pressing the ■ button, press the > button for DISC 1's tray on the Unit.

When the unlock operation is done, "LOCK OFF" appears in the display to show that the lock has been taken off.


LOCK OFF

The trays can now be opened by pressing the > buttons.
 The > button can also be used to automatically turn on the power.

Using the Cassette Deck (Listening to a Tape)



Display



- ▶ : Tape Direction indicator
- (A) (B) : DECK A, B indicator
- (↔) : Reverse Mode indicator

The Cassette Deck allows you to play, record and dub audio tapes.

- With Automatic Tape Detection, you can listen to type I or II tapes without changing any settings.

The use of tapes longer than 120 minutes is not recommended, since characteristic deterioration may occur and these tapes easily jam in the pinch-rollers and the capstans.


One Touch Play

By pressing the ◀ TAPE ▷ button (or the ◀ or ▶ button on the Remote Control), the Unit will come on, "TAPE" appears in the display, and if a tape is in the deck, it will start to play. If no tape is loaded, the Unit will come on and wait for you to insert a tape, or select another function.


Regular Play

When the power is already on, you can use this basic procedure:

1. Press the ▲ EJECT button for the deck you want to use.
2. When the cassette holder opens, put the cassette in, with the exposed part of the tape down, toward the base of the System.
 - If the cassette holder does not open, turn the Unit off, then back on and press the ▲ EJECT button again.



3. Close the holder gently. When both Deck A and Deck B contain a tape, the last deck to have a tape inserted is selected. To change the selected deck, press the DECK A/B button. When using the Remote Control, press the A or B button.



4. Press the ◀ TAPE ▷ button (or ◀ or ▶ button on the Remote Control). The tape is played in the direction of the button pressed for the selected deck.
 - The Cassette Deck automatically stops when one side of a tape has finished playing.

To stop playing, press the ■ button.

To remove the tape, stop the tape, and press the ▲ EJECT button.

To change deck while playing a tape, press the ◀ TAPE ▷ button after pressing the DECK A/B button on the Unit or press the ◀ or ▶ button after pressing the A or B button on the Remote Control.



Fast Left And Fast Right


■ While the tape is stopped, press the ◀ P.DOWN button (or ◀ button on the Remote Control) and the tape will wind rapidly onto the left side of the cassette without playing.

■ While the tape is stopped, press the ▶ P.UP button (or ▶ button on the Remote Control) and the tape will wind rapidly onto the right side of the cassette without playing.

Note: Deck A and Deck B cannot be used for playback at the same time.

Music Scan

To find the beginning of a music track during play, use the Music Scan function. Music Scan searches for blank portions that usually separate selections, then plays the next selection.



To Find the Beginning of the Current Selection— Press the ◀ P.DOWN or ▶ P.UP button (or the ◀ or ▶ button on the Remote Control) during play.

■ Make sure that you press the ◀ P.DOWN or ▶ P.UP button (or the ◀ or ▶ button on the Remote Control) in the opposite direction to that in which the tape is playing. Searching stops at the beginning of the current selection, and the current selection starts automatically.

To Find the Beginning of the Next Selection— Press the ◀ P.DOWN or ▶ P.UP button (or the ◀ or ▶ button on the Remote Control) during play.

■ Make sure that you press the ◀ P.DOWN or ▶ P.UP button (or the ◀ or ▶ button on the Remote Control) in the same direction as that in which the tape is playing. Searching stops at the beginning of the next selection, and the next selection starts automatically.

Music Scan works by detecting a 4-second long blank at the beginning of each selection, so it won't work well if your tape has:

- No blank at the beginning of a selection.
- Noise (often caused by much use or poor quality dubbing) which fills the blank with noise.
- Long, very soft passages or pauses in a selection. The scan will detect these as 4-second long blanks. If this happens, just scan again until you reach the selection you want.

Reverse Mode

You can play both sides of a cassette, or play both the tapes in the two Cassette Decks continuously.

Press the REVERSE MODE button to switch to Reverse Mode.





↔ : (back to the beginning)

▶ : The Cassette Deck automatically stops after playing one side of the tape.


▶ : The Cassette Deck automatically stops after playing both sides of the tape being played (or set to play).

▶ : After playing both sides of the tape being played (or set to play), the Unit always checks to see if a tape is in the other deck. If there is, it automatically starts playing that tape. This Continuous Play function works regardless of which deck starts first. The tapes are played continuously until the ■ button is pressed.

Using the Cassette Deck (Recording)



Display



REC indicator

When the System is being used, the display shows other items as well. However, we have only shown the items described in this section.

Recording onto a cassette from any of the sound sources is simple. Just place a tape in Deck B, have the source ready, make one or two settings, and you're ready to record. For each source the procedure is a little bit different and now we'll explain just what to do for each one. If you forget, just come back to the section which has the specific procedures you need. But first, here are a few things to make your recordings better.

Things To Know Before You Start Recording

- It may be unlawful to record or play back copyrighted material without the consent of the copyright owner.
- When you want to record onto both sides of a tape, you can set Reverse mode on to do so. However, recording automatically stops after recording in the ◀ direction in Reverse mode. Therefore, make sure that the tape direction is ▶ when recording with Reverse mode on.
- The recording level, which is the volume at which the new tape is being made, is automatically set correctly, so it is not affected by the VOLUME control on the System. Thus, during recording you can adjust the sound you are actually listening to without affecting the recording level.
- Two small tabs on the back of the cassette tape, one for side A and one for side B, can be removed to prevent accidental erasure or re-recording. To record on a cassette with the tabs removed, you must cover the holes with adhesive tape first.
- However, when a type II tape is used, only cover part of the hole as shown, since the other part of the hole is used to detect the tape type.
- When recording, you can hear Sound Mode effects through the speakers or headphones. However, the sound is recorded without Sound Mode effects.
- Type I and Type II tapes can be used for recording.



Note: At the start and end of cassette tapes, there is leader tape which cannot be recorded onto. Depending on the recording source, the first part of the recording may be missing because of the leader. When recording CDs or radio broadcasts, to get the beginning of the recording on the tape, first wind on the leader before beginning recording.

CAUTION: If recordings you have made have excessive noise or static, the UNIT may be too close to a TV which was on during the recording. Either turn off the TV or increase the distance between the TV and the System.

Standard Recording

This is the basic method for recording any source. The System also has special ways for recording CD to tape, and tape to tape, which save you time and effort, as well as give you some special effects. However, when you need to add a selection to a tape you have made, or are combining selections from several sources on one tape, use the method described below; just substitute the source you want into this procedure, such as a tape in Deck A, a CD, or the Tuner. You can also record from auxiliary source with this procedure.

To Record Any Sound Source To Tape

Follow these steps to record from any sound source onto a tape in Deck B.

Using the Unit

1. Insert a blank or erasable tape into Deck B.
2. Press the REVERSE MODE button if you want to record on both sides of the tape.
 - Press the button until the "◀▶" or "▶◀" indicator is lit.
 - When using Reverse Mode, insert the tape so that it will be recorded in the forwards ▶ direction.
3. Check the recording direction for the tape.
 - Check that the Tape Direction indicator is the same as that for the tape in the tape deck. If the directions are different, press the ■ button after pressing the ◀ TAPE ▷ button to set the tape direction.
 - When using Reverse Mode to record both sides of a tape, check that the Tape Direction indicator is in the forwards ▶ direction. If the direction indicator is not in the forwards ▶ direction, press the ◀ TAPE ▷ button then press the ■ button.
4. Prepare the source, by, for example, tuning in a radio station, loading CDs, or turning on connected equipment.
5. Press the REC START/STOP button.

The "REC" indicator light comes on and the System begins recording.

Using the Remote Control


1. Insert a blank or erasable tape into Deck B.
2. Press the REC PAUSE button.
 - The "REC" indicator blinks.
3. Press the REVERSE MODE button on the Unit if you want to record on both sides of the tape.
 - Press the button until the "◀▶" or "▶◀" indicator is lit.
 - When using Reverse Mode, insert the tape so that it will be recorded in the forwards ▶ direction.
4. Prepare the source by, for example, tuning in a radio station, loading CDs, or turning on connected equipment.
5. Press the ◀ or ▶ button.
 - Recording starts in the direction of the button pressed.
 - When using Reverse Mode to record both sides of a tape, press the ▶ button.



Notes for using Reverse Mode for recording

When recording in Reverse Mode, the System automatically stops when it reaches the end of the reverse ◀ direction. To record on both sides of a tape, make sure that the recording direction for the tape inserted into Deck B is forwards ▶, and that the Tape Direction indicator is also forwards ▶, before you start recording.

Using the Timer



When the System is being used, the display shows other items as well. However, we have only shown the items described in this section.


The timers let you control listening and recording functions automatically. Use the Remote Control to set the clock and timers.

Setting the Clock

The timers depend on the clock; the clock must be right for the timers to work as you expect. You can set the clock whether the Unit is on or off.

Note that the clock must be set, otherwise the timers cannot be set.

1. Press the **SHIFT** button.
2. Press the **1 CLOCK** button.
The "CLOCK" indicator on the display light up and the clock time blinks.
3. Press the **SELECT 5 +** or **4 -** button to set the time.
Pressing the 5 + button increases the time and pressing 4 - decreases the time. Pressing the button continuously advances or decreases the time in 10 minute intervals.
4. Press the **8 SET** button.
The blinking time display changes from a blinking display to a steady display and the clock timer starts from 0 seconds.



CAUTION: if there is a power failure, the clock loses its setting. The display shows "0:00", and the clock must be reset.

To Pause at Any Time During the Recording Process
Press the REC PAUSE button on the Remote Control. Then press either the ◀ or ▶ button on the Remote Control or REC START/STOP button on the Unit to restart recording.

To Stop at Any Time During the Recording Process
Press the REC START/STOP button on the Unit again, or press the ■ button.

Recording AM station to tape

When recording an AM broadcast, beats may be produced which are not heard when listening to the broadcast. In this case, press the CONTINUE button on the CD Player to eliminate the beats.

1. Set to AM station and start recording.
2. Press the CONTINUE button to eliminate the beats.
Each time you press the button, the display changes as shown below:
→ CUT 2 → CUT 3 → CUT 1 → (back to the beginning)

CD Direct Recording

Everything on the CD goes onto the tape in the order it is on the CD, or according to the order you have set in a program.

1. **Prepare CDs.** (See page 13.)
Check that the CD Player is not playing a CD.
2. **Insert a cassette in Deck B to record on.**
When you want to record on both sides of a tape, press the REVERSE MODE to turn Reverse Mode on. Check that the recording direction for the tape and the Tape Direction indicator is correct. (See page 21 "Notes for using Reverse Mode for recording".)
3. **Press the CD REC START button.**
The "REC" indicator light comes on and the System begins recording.

If you make a recording with Reverse Mode on, the Unit will record the last song at the end of the first side at the beginning of the next side.

To stop at any time during the recording process, press the ■ button.

Note: When making SLEEP timer settings while doing CD Direct recording, set the time so that there is enough leeway to finish the recording before the power goes off. If the time is set to about the length of the CD, the power may go off before recording finishes.

For CD Direct Recording using more than one disc, use a blank tape. If you use a prerecorded tape, prerecorded material may not be erased between newly-recorded tracks.

Tape to Tape Recording (Dubbing)

Recording from one tape to another is called dubbing. You can dub tapes simply, with just a single button.

- When dubbing tapes, make sure that the playback direction of Deck A and Deck B are the same.
- When you want to record both sides of a tape, press the REVERSE MODE button to turn Reverse mode on.
- It is preferable that the type of tape (Type I or Type II) you record from be the same as the type you record onto.

How to Use the DUBBING Button

1. **Insert the source cassette you want to copy from into Deck A for playback.**
2. **Insert the blank or erasable cassette you want to copy onto into Deck B for recording.**
Insert the cassette so that it will be recorded in the forwards ▶ direction.
3. **Press the DUBBING button.**
Deck A and Deck B will start simultaneously.

To stop dubbing, press the ■ button or REC START/STOP button.

- When doing dubbing with the DUBBING button, you can hear Sound Mode effects through the speakers or headphones. However, the sound is dubbed without Sound Mode effects.

Setting the Timer

- You can set the Timer whether the Unit is on or off.

Procedure For Setting the Timer


- Press the **SHIFT** button.
- Press the **2 TIMER** button.




- Set the time you want the Unit to come on. Press the **SELECT 5 + or 4 -** button to set the On Time.




- Press the **8 SET** button. "TIMER OFF" blinks on the display, and the display changes to the Off Time setting display.




- Set the time you want the Unit to be turned off. Press the **SELECT 5 + or 4 -** button to set the Off Time.



- Press the **8 SET** button. The name of the source blinks in the display.



- Press the **SELECT 5 + or 4 -** button to select the source. The display changes with each press of the button as shown.




↔ **TUNER** ↔ **TUNER REC** ↔ **CD** ↔ **TAPE** ↔


- TUNER:** Selects the last station you were listening to.
- TUNER REC:** Records the last station you were listening to.
- CD:** Plays the last CD you were listening to.
- TAPE:** Plays the last tape you were listening to.

- In the source "TUNER", "CD", or "TAPE", the timer acts as a Daily timer. Once the Daily timer has been set, it will be activated at the same time every day until the setting is turned off. In the source "TUNER REC", the timer acts as a Once timer. After the Once timer has been performed, the details of the setting remain stored but the Timer status is set to off.

- Press the **8 SET** button. The volume level blinks on the display.



- Press the **SELECT 5 + or 4 -** button to set the volume level.



- Press the **8 SET** button.



The display returns to the display before you set the timer.

Before Turning the Unit Off

- Check that the selected source is ready.
- If you will be recording a source while you are out, set the volume to 0.

To turn the Timer off, press the **2 TIMER** button while pressing the **SHIFT** button. The Timer indicator on the display goes out.


Setting the SLEEP Timer

Use the Sleep Timer to turn the Unit off after a certain number of minutes when it is playing. By setting this timer, you can fall asleep to music and know your Unit will turn off by itself rather than play all night.

- You can only set the Sleep Timer when the Unit is on and a source is playing.

To set the SLEEP Timer, follow this procedure:

- With the System on and a source playing, press the **SLEEP** button on the Remote Control.



- Set the length of time you want the source to play before shutting off.

- Each time you press this button, it changes the number of minutes shown on the display in this sequence:

→ 10 → 20 → 30 → 60 → 90 → 120 → Cancelled → (back to the beginning)

When the number of minutes you want shows on the display, just wait 5 seconds until the number of minutes stops blinking, and is lighted steadily.

The Unit is now set to turn off after the number of minutes you set.

To Change the SLEEP Timer Setting





Press the **SLEEP** button until the number of minutes you want appears on the display.

To Cancel the SLEEP Timer Setting

Press the **SLEEP** button until the "SLEEP" indicator goes off on the display.

Turning off the Unit also cancels the SLEEP Timer.

Using the Microphone



When the System is being used, the display shows other items as well. However, we have only shown the items described in this section.

The System includes two microphone terminals, MIC 1 and MIC 2. By attaching a microphone to one or both of these terminals, you can use the System for Karaoke or microphone mixing. You can also add an echo to the microphone's sound.

- The MIC LEVEL control adjusts the volume for both MIC 1 and MIC 2 at the same time.
- When you will not be using the microphone, keep the MIC LEVEL control set to MIN, and disconnect the microphone.

CAUTION: Always set the MIC LEVEL control to MIN when connecting or disconnecting the microphone.

Karaoke (Sing Along)

The Vocal Masking function lets you use regular tapes, CDs, or records as sources for Karaoke. When you select Karaoke mode, the lead vocal volume of the source is reduced, and you can replace it by singing into the microphones as the music plays.

Singing Along with Karaoke

1. Turn the MIC LEVEL control to MIN.
2. Connect the microphone (not supplied) by plugging it into the MIC jack on the front panel.

3. Press the SOUND MODE button repeatedly until "KARAOKE" appears in the display. The "K" indicator comes on.
4. Start the source CD, tape or other equipment.
5. Adjust the VOLUME control and the MIC LEVEL control, as you sing into the microphone.

Important Information on Karaoke

- Because a radio signal is not as reliable as signals coming from a tape or CD, you may not always get satisfactory results using the radio as a source for Karaoke.
- Some tapes and CDs are better sources for Karaoke than others.
 - Mono sources are not suitable for Karaoke.
 - The lead vocals may not be completely reduced for sources with duets, strong echo, a chorus, or only a few instruments.
 - Poorly dubbed tapes may not be suitable for Karaoke.

Digital Echo

You can get an echo effect to apply to your voice.

1. Press the SHIFT button on the Remote Control.
2. Press the 7 ECHO button on the Remote Control.

The Echo indicator comes on.

No echo is applied.

An echo is applied.

To prevent howling and squealing (feedback) when using the microphone, adjust the MIC LEVEL control and the VOLUME control. Also, try to avoid pointing the microphone towards the speakers.

- When two microphones are connected, turn the microphone ON/OFF switch for the microphone that is not being used to OFF.
- When recording sound from the microphone, the digital echo effect is also recorded.

To Record Your Singing

1. Follow the steps in "Singing Along with Karaoke" above.
2. Follow the steps in "Standard Recording" (See page 21) to record your singing.

Microphone Mixing

When using special Karaoke sources for karaoke, use the following procedure:



1. Set the **MIC LEVEL** control to **MIN**.
2. Connect the microphone (not supplied) by plugging it into the **MIC jack** on the front panel.
3. Start the source **CD, tape, or other equipment**.
4. Adjust the **VOLUME** control and the **MIC LEVEL** control, as you sing into the microphone.
To apply echo to the microphone sound, follow the steps in "Digital Echo". (See page 27.)

To Record Microphone Mixing

1. Follow the steps in "Microphone Mixing" above.
2. To record, follow the steps in "Standard Recording". (See page 21.)

Playing the Microphone Sound through the Speakers



1. Set the **MIC LEVEL** control to **MIN**.
2. Connect the microphone (not supplied) by plugging it into the **MIC jack** on the front panel.
3. Adjust the **VOLUME** control and the **MIC LEVEL** control as you sing into the microphone.
To apply echo to the microphone sound, follow the steps in "Digital Echo". (See page 27.)

Recording from the Microphone

1. Follow the steps in "Playing the Microphone sound through the Speakers" above.
2. To record, follow the steps in "Standard Recording". (See page 21.)

Care And Maintenance

Compact Discs

Handle your compact discs, cassette tapes, and Cassette Deck carefully, and they will last a long time.

- Remove the CD from the case by holding it at the edges while pressing the centre hole lightly.
- Do not touch the shiny surface of the CD, or bend the CD.



- Put the CD back in its case after use to prevent warping.
- Be careful not to scratch the surface of the CD when placing it back in the case.
- Avoid exposure to direct sunlight, temperature extremes, and moisture.



- A dirty CD may not play correctly. If a CD does become dirty, wipe it with a soft cloth in a straight line from centre to edge.



CAUTION: Do not use any solvent (for example, conventional record cleaner, spray thinner, benzine, etc.) to clean a CD.

Moisture Condensation

Moisture may condense on the lens inside the Unit in the following cases:

- After starting the heating in the room.
- In a damp room.
- If the unit is brought directly from a cold to a warm place.

Should this occur, the Unit may malfunction. In this case, leave the unit turned on for a few hours until the moisture evaporates, unplug the AC power cord, and then plug it in again.



General Notes

In general, you will have the best performance by keeping your tapes, CDs, and the mechanism clean.

- Store tapes and CDs in their cases, and keep them in cabinets or on shelves.
- Keep the Cassette Deck's tape doors and the CD trays closed when not in use.

Cassette Tapes



- If the tape is loose in its cassette, take up the slack by inserting a pencil in one of the reels and rotating.
- If the tape is loose, it may get stretched, cut, or caught in the cassette.
- Do not touch the tape surface.




- Do not store the tape:
 - In dusty places
 - In direct sunlight or heat
 - In moist areas
 - On a TV or speaker
 - Near a magnet

Cassette Deck

If the heads, capstans, and pinch-rollers of the Cassette Deck become dirty, the following will occur:

- Loss of sound quality
- Discontinuous sound
- Fading
- Incomplete erasure
- Difficulty recording

- Clean the heads, capstans, and pinch-rollers using a cotton swab moistened with alcohol.



- If the heads become magnetized, the Unit will produce noise or lose high frequencies.

- To demagnetize the heads, turn off the Unit, and use a head demagnetizer (available at electronics and record shops).

Troubleshooting

- If you are having a problem with your System, check this list for a possible solution before calling for service.
- If you cannot solve the problem from the hints given here, or the Unit has been physically damaged, call a qualified person, such as your dealer, for service.

Symptom	Possible Cause	Action
No sound is heard.	Connections are incorrect, or loose.	Check all connections and make corrections. (See pages 4 - 5.)
Unable to record.	Cassette record protect tabs are removed.	Cover holes on back edge of cassette with tape.
Poor radio reception	<ul style="list-style-type: none"> • The antenna is disconnected. • The AM Loop Antenna is too close to the Unit. • The FM Wire Antenna is not properly extended and positioned. 	<ul style="list-style-type: none"> • Reconnect the antenna securely. • Change the position and direction of the AM Loop Antenna. • Extend FM Wire Antenna to the best reception position.
The CD skips.	The CD is dirty or scratched.	Clean or replace the CD.
Unable to operate the Remote Control.	<ul style="list-style-type: none"> • The path between the Remote Control and the sensor on the Unit is blocked. • The batteries have lost their charge. 	<ul style="list-style-type: none"> • Remove the obstruction. • Replace the batteries.
The CD tray cannot be opened.	The main AC power cord is not plugged in.	Plug in the AC power plug.
The CD does not play.	The CD is upside down.	Put the CD in with the label side up.
Operations are disabled.	The built-in microprocessor has malfunctioned due to external electrical interference.	Unplug the Unit then plug it back in.
The cassette door cannot be opened.	During tape playing, the power cord was unplugged.	Plug in the power cord, press the POWER button, and then press the EJECT button.

Specifications

Amplifier

CA-D501T/MX-D401T

Output Power (IEC 268-3/DIN)

27 watts per channel, min. RMS, both channels driven into 6 ohms at 1 kHz with no more than 0.9% total harmonic distortion.

MX-D301T

Output Power (IEC 268-3/DIN)

12 watts per channel, min. RMS, both channels driven into 4 ohms at 1 kHz with no more than 0.9% total harmonic distortion.

Input Sensitivity/Impedance (1 kHz)

AUX 300 mV/50 kohms

MIC 1 3 mV/2 kohms

MIC 2 3 mV/2 kohms

CA-D501T/MX-D401T

Speaker terminals

6 - 16 ohms

Speaker terminals

Minimum 4 ohms

Cassette Deck

Frequency Response

50 - 14,000 Hz

Type II (C/O) :

50 - 14,000 Hz

Type I (NORMAL) :

0.15% (WRMS)

Wow And Flutter

Unmeasurable

CD Automatic Changer

CD Capacity

3 discs

Dynamic Range

85 dB

Signal-To-Noise Ratio

90 dB

Wow And Flutter

Unmeasurable

Tuner

FM Tuner

Tuning Range

87.5 - 108.0 MHz

AM Tuner

Tuning Range

531 - 1,602 kHz (at 9 kHz channel space)

530 - 1,710 kHz (at 10 kHz channel space)

CA-D501T/MX-D401T

Dimensions (W/H/D)

265 x 295 x 339 mm

(10-7/16 x 11-5/8 x 13-3/8 inches)

7.1 kg (15.7 lbs)

Mass

MX-D301T

Dimensions (W/H/D)

265 x 295 x 339 mm

(10-7/16 x 11-5/8 x 13-3/8 inches)

6.7 kg (14.8 lbs)

Mass

Speaker Specifications

SP-D401

Type

Speakers

Woofer

Mid Range

Tweeter

Power Handling Capacity

Impedance

Frequency Range

Sound Pressure Level

Dimensions (W/H/D)

Mass

3-way, 3-speaker bass-reflex type

16 cm (6-5/16 inches) cone x 1

5 cm (2 inches) cone x 1

2 cm (13/16 inches) dome x 1

80 watts

6 ohms

45 Hz - 20,000 Hz

90 dB(w, 1 m)

215 x 295 x 275 mm

(8-1/2 x 11-5/8 x 10-7/8 inches)

3.2 kg (7.1 lbs) each

SP-D311	
Type	3-way, 3-speaker bass-reflex type
Speakers	
Woofer	16 cm (6-3/16 inches) cone x 1
Mid Range	5 cm (2 inches) cone x 1
Tweeter	2 cm (13/16 inches) dome x 1
Power Handling Capacity	80 watts
Impedance	4 ohms
Frequency Range	45 Hz - 20,000 Hz
Sound Pressure Level	90 dB/w · m
Dimensions (W/H/D)	215 × 295 × 275 mm (8-1/2 × 11-5/8 × 10-7/8 inches)
Mass	3.2 kg (7.1 lbs) each
Accessories	
	AM Loop Antenna (1)
	Remote Control (1)
	Batteries R6P (SUM-3)/AA (15F) (2)
	FM Wire Antenna (1)
	AC Plug Adaptor (except for Hong Kong) (1)
Power Specifications	
CA-D501T/MX-D401T	
Power Requirements	AC 110/127/220/230 - 240 V ~, 50/60 Hz adjustable with the voltage selector
Power Consumption	85 watts 12 watts (in standby mode) 185 watts (Taiwan only)
Max. Power Consumption	
MX-D301T	
Power Requirements	AC 110/127/220/230 - 240 V ~, 50/60 Hz adjustable with the voltage selector
Power Consumption	55 watts 12 watts (in standby mode) 120 watts (Taiwan only)
Max. Power Consumption	

Design and specifications are subject to change without notice.

4. Location of Main Parts

Refer to MX-D401T (Issue No. 10039)

5. Removal of Main Parts

■ Removal of the Metal Cover (See Figs. 5-1,5-2)

1. Remove the six screws ① fastening the metal cover to the rear panel of the main unit. (See Fig. 5-1)
2. Remove the two screws ② fastening the metal cover to the side panel of the main unit. (See Fig. 5-1)
3. Spread both sides of the metal cover outward and remove from the back panel by lifting upward.




Fig.5-2




Fig.5-1.

■ Removal of the CD Traverse Mechanism Assembly (See Figs. 5-1 ~5-4)

1. Remove the metal cover.
2. Remove the two screws ② fastening the CD traverse mechanism assembly to the rear panel of the main unit. (See Fig. 5-1)
3. Remove the two screws ④ fastening the CD traverse mechanism assembly to the top panel of the main unit. (See Fig. 5-3)
4. Disconnect the card wires connected to the CD traverse mechanism assembly from connectors CN304, CN305 and CN306 on the main amplifier board on the right side of the main unit. (See Fig. 5-3)
5. Remove the plastic rivet ① fastening the main amplifier board and front panel assembly to the left side panel of the main unit. (See Fig. 5-4)
6. Tilt the front panel assembly slightly forward and remove the CD traverse mechanism assembly from the front panel assembly by shifting in the direction of the arrow and lifting upward. (See Fig. 5-3)




Fig.5-3




Fig.5-4

■ Removal of the Front Panel Assembly

(See Figs. 5-5~5-9)

1. Remove the metal cover.
2. Remove the CD traverse mechanism assembly.
3. Remove the four screws ⑤ fastening the front panel assembly to the side of the main unit. (See Fig. 5-5)
4. Use a screwdriver, etc., to disengage clips ③ and ④ from the side panels of the main unit. (See Figs. 5-6, 5-7)
5. Disconnect the card wires connected to the front panel assembly from connectors CN302 and CN303 on the main amplifier board. (See Fig. 5-8)
6. Remove the wire clamp holding the parallel wires protruding from the front panel assembly and the parallel wires protruding from the power supply board. (See Figs. 5-8, 5-9)
7. Disconnect connector CN904 on the power amplifier board and then disconnect the parallel wires protruding from the front panel assembly. (See Figs. 5-8, 5-9)
8. Remove the front panel assembly.




Fig.5-5




Fig.5-6




Fig.5-7




Fig.5-8









Fig.5-9

■ Removal of the Rear Panel Assembly

1. Remove the metal cover.
2. Remove the CD traverse mechanism assembly.
3. Remove the front panel assembly.
4. Remove the screw ⑥ fastening the main amplifier board and bottom chassis to the side panels of the main unit. (See Fig. 5-10)
5. Remove the screw ⑦ fastening the rear panel and bottom chassis to the rear panel of the main unit. (See Fig. 5-11)
6. Use a screwdriver, etc., to disengage the two engagements bottom chassis clips ③ and ④ from the bottom part of the side panels of the rear panel assembly. (See Figs. 5-12, 5-13)
7. Disconnect the parallel wires protruding from the power supply board from connector CN902 of the power amplifier board. (See Fig. 5-14)
8. Remove the rear panel assembly from the bottom chassis by disengaging the protrusion ⑤ of the main amplifier board from the cutout in the bottom chassis. (See Fig. 5-10)



■ Removal of the Main Amplifier Board

1. Remove the metal cover.
2. Remove the CD traverse mechanism assembly.
3. Remove the front panel assembly.
4. Remove the rear panel assembly.
5. Remove the four screws ⑧ fastening the main amplifier board to the rear panel.(See Fig. 5-15)
6. Disconnect the main amplifier board connectors CN307 and CN308 from the power amplifier board.(See Fig. 5-16)




Fig.5-15

■ Removal of the Power Amplifier Board

1. Remove the metal cover.
2. Remove the CD traverse mechanism assembly.
3. Remove the front panel assembly.
4. Remove the rear panel assembly.
5. Remove the main amplifier board.
6. Remove the two screws ⑨ fastening the rear cover to the rear panel assembly and then remove the rear cover. (See Fig. 5-17)
7. Remove the five screws (⑩ x 3, ⑪ x 2) fastening the power amplifier board to the rear panel assembly.(See Fig. 5-17)
8. Remove the two screws ⑬ fastening the voltage select board to the rear panel assembly. (See Fig. 5-17a For U version only)




Fig.5-16




Fig.5-17




Fig. 5-17a (For U version only)

■ Removal of the Power Transformer

(See Figs. 5-18,5-19)

1. Remove the metal cover.
2. Remove the CD traverse mechanism assembly.
3. Remove the front panel assembly.
4. Remove the rear panel assembly.
5. Remove the main amplifier board.
6. Remove the power amplifier board.
7. Remove the four screws ⑫ fastening the power transformer.
8. Disconnect the power amplifier board connector CN902 and then disconnect the parallel wire.
9. Either unsolder the power cord from the power supply board terminals TB001 and TB002 or remove the cord clamp inserted into the bottom chassis and remove.




Fig.5-18

■ Removal of the Mic & Echo amplifier board

(See Fig. 5-A For A/U version only)

Remove the screw ⑭ fastening the Mic & Echo amplifier board inside the front panel assembly.

■ Removal of the Headphone & Mic jack board

(See Fig. 5-A)

Remove the two screws ⑮ fastening the headphone & Mic jack board assembly inside the front panel




Fig.5-A




Fig.5-19

《Front Panel Assembly Sections》

■ **Removal of the Front Panel**

(See Figs. 5-20~5-23)

1. Remove the metal cover.
2. Remove the CD traverse mechanism assembly.
3. Remove the front panel assembly.
4. Remove the volume knob from the front of the front panel assembly. (See Fig. 5-20)
5. Remove the nut fastening the volume control from the front panel assembly. (See Fig. 5-20)
6. Remove the eight screws ① fastening the stay bracket inside the front panel assembly. (See Fig. 5-21)
7. Remove the nine screws ② fastening the system CPU board. (See Fig. 5-22)
8. Disconnect the card wires protruding from connector CN305 on the head amplifier & mechanism control board from connector CN700 on the system CPU board. (See Figs. 5-22,5-23)




Fig.5-20




Fig.5-21




Fig.5-22

■ **Removal of the Cassette Mechanism Assembly**

(See Fig. 5-23)

1. Remove the metal cover.
2. Remove the CD traverse mechanism assembly.
3. Remove the front panel assembly.
4. Remove the eight screws ③ fastening the cassette mechanism assembly to the inside of the front panel assembly.
5. Disconnect the card wires from connectors CN305 and CN306 on the head amplifier & mechanism control board.




Fig.5-23

Head amplifier & mechanism control board

《 Cassette Mechanism Section 》

■ **Removing the Playback, Recording and Eraser Heads**

1. While shifting the trigger arms seen on the right side of the head mount in the arrow direction, turn the flywheel R in counterclockwise direction until the head mount has gone out with a click (See Fig. 5-24).
2. When the flywheel R is rotated in counterclockwise direction, the playback head will be turned in counterclockwise direction from the position in Fig. 5-25 to that in Fig. 5-26.
3. At this position, disconnect the flexible P.C. board (outgoing from the playback head) from the connector CN301 on the head amp. & mechanism control P.C. board.
4. After dismantling the FPC holder, remove the flexible P.C. board.
5. Remove the flexible P.C. board from the chassis base.
6. Remove the spring @ from behind the playback head.
7. Loosen the reversing azimuth screw retaining the playback head.
8. Take out the playback head from the front of the head mount.
9. The recording and eraser heads should also be removed similarly according to Steps 1~8 above.




Fig.5-24 (Mechanism A side)




Fig.5-25 (Mechanism A side)

● **Reassembling the Playback, Recording and Eraser Heads**

1. Reassemble the playback head from the front of the head mount to the position as shown in Fig. 5-26.
2. Fix the reversing azimuth screw.
3. Set the spring @ from behind the playback head.
4. Attach the flexible P.C. board to the chassis base, and fix it with the FPC holder as shown in Fig. 5-26.
5. The recording and eraser heads should also be reassembled similarly according to Steps 1~4 above.




Fig.5-26 (Mechanism B side)

■ Removing the Head Amp. & Mechanism Control P.C. Board (See Fig. 5-27)

1. Remove the cassette mechanism assembly.
2. After turning over the cassette mechanism assembly, remove the five screws ① retaining the head amp. & mechanism control P.C. board.
3. Disconnect the connectors CN303 and CN304 on the P.C. board and the connectors CN1 on both the right and left side reel pulse P.C. boards.
4. When necessary, remove the 4pin parallel wire soldered to the main motor.




Fig.5-27

■ Removing the Capstan Motor Assembly

1. Remove the six screws ② retaining the capstan motor assembly (See Fig. 5-28).
2. While raising the capstan motor, remove the capstan belts A and B respectively from the motor pulley (See Figs. 5-28,5-29)

Caution 1: Be sure to handle the capstan belts so carefully that these belts will not be stained by grease and other foreign matter. Moreover, these belts should be hanged while referring to the capstan belt hanging method in Fig. 5-29,5-30.




Fig.5-28




Fig.5-29




Fig.5-30

■ Removing the Capstan Motor (See Figs. 5-31)

From the joint bracket, remove the two screws ③ retaining the capstan motor.




Fig.5-31

■ Removing the Flywheel (See Figs. 5-32,5-33)

1. Remove the head amp. & mechanism control P.C. board.
2. Remove the capstan motor assembly.
3. After turning over the cassette mechanism, remove the slit washers ① and ② fixing the capstan shafts R and L, and pull out the flywheels R and L respectively from behind the cassette mechanism.




Fig.5-32




Fig.5-33

■ Removing the Reel Pulse P.C. Board and Solenoid (See Figs. 5-34)

1. Remove the five pawls (c, d, e, f and g) retaining the reel pulse P.C. board.
2. From the surface of the reel pulse P.C. board parts, remove the two pawls (h) and (i) retaining the solenoid.




Fig.5-34

《CD Traverse Mechanism Sections》

■ **Removing the CD Servo control board**
(See Fig. 5-35).

1. Remove the Metal cover.
2. Remove the CD Traverse mechanism assembly.
3. From bottom side the CD Traverse mechanism assembly, remove the screw ① retaining the CD Servo control board.
4. From the connectors CN601, CN603, CN604 on the CD Servo control board, disconnect the card wire, from the connector CN602, disconnect the 6pin connector wire.
5. Disengage the two engagements "A", remove the CD Servo control board.




Fig.5-35

■ **Removing the CD tray assembly**
(See Figs. 5-36~5-38)

1. Remove the front panel assembly.
2. Remove the CD Traverse mechanism assembly.
3. Remove the CD Servo control board.
4. From the T. bracket section "B" and clamber base section "C", remove both of the edges fixing the rod (See Figs. 5-36 and 5-37).
5. Remove the screw ② retaining the Disc stopper (See Fig. 5-37).
6. Remove the three screws ③ retaining the T. bracket (See Fig. 5-37).
7. Remove the screw ④ retaining the clamber assembly (See Fig. 5-37).
8. From the left side face of the chassis assembly, remove the one screw ⑤ retaining both of the return spring and lock lever. (See Fig. 5-38)
9. By removing the pawl at the section "D" fixing the return spring, dismount the return spring (See Fig. 5-38).
10. Remove the three lock levers (See Fig. 5-38).




Fig.5-36




Fig.5-37




Fig.5-38

11. Check whether the lifter unit stopper has been caught into the hole at the section "E" of CD tray assembly as shown in Fig. 5-39.
 12. Make sure that the driver unit elevator is positioned as shown in Fig. 5-40 from to the second or fifth hole on the left side face of the CD Traverse mechanism assembly.
- [Caution]** In case the driver unit elevator is not at the above position, set the elevator to the position as shown in Fig. 5-41 by manually turning the pulley gear as shown in Fig. 5-42.
13. Manually turn the motor pulley in the clockwise direction until the lifter unit stopper is lowered from the section "E" of CD tray assembly (See Fig.5-42).
 14. Pull out all of the three stages of CD tray assembly in the arrow direction "F" until these stages stop (See Fig. 5-40).
 15. At the position where the CD tray assembly has stopped, pull out the CD tray assembly while pressing the two pawls "G and G'" on the back side of CD tray assembly (See Fig. 5-43). In this case, it is easy to pull out the assembly when it is pulled out first from the stage CD tray assembly.




Fig.5-39




Fig.5-40




Fig.5-41




Fig.5-42




Fig.5-43

Removing the CD mechanism assembly (See Fig. 5-44)

1. While turning the cams R1 and R2 assembly in the arrow direction "H", align the shaft "I" of the CD mechanism assembly to the position shown in Fig. 5-44.
2. Remove the four screws ⑥ retaining the CD mechanism assembly (See Fig. 5-44).

Removing the CD mechanism (See Figs. 5-45 and 5-46)

1. For dismantling only the CD mechanism without removing the CD mechanism assembly, align the shaft "J" of the CD mechanism assembly to the position shown in Fig. 5-45 while turning the cam R1 and R2 assembly in the arrow direction "K".
2. By raising the CD mechanism assembly in the arrow direction "L", remove the assembly from the lifter unit (Fig. 5-46).




Fig.5-44




Fig.5-45




Fig.5-46




Fig.5-47

Removing the CD pickup unit (See Fig.5-47)

1. Move the cam gear in the arrow direction ①. Then, the CD pickup unit will be moved in the arrow direction ②.
2. According to the above step, shift the CD pickup unit to the center position (See Fig.5-47).
3. While pressing the stopper retaining the shaft in the arrow direction ③, pull out the shaft in the arrow direction ④ (See Fig.5-47).
4. After dismantling the shaft from the CD pickup unit, remove the CD pickup unit.

■ Removing the actuator motor board

(See Figs. 5-48 and 5-49)

1. Absorb the four soldered positions "M" of the right and left motors with a soldering absorber (See Fig. 5-48).
2. Remove the two screws ⑦ retaining the actuator motor board (See Fig. 5-48).
3. Remove the two screws ⑧ retaining the tray select switch board (See Fig. 5-49).




Fig.5-48

■ Removing the cam unit

(See Figs. 5-50-5-52)

1. Remove the CD mechanism assembly.
2. While turning the cam gear L, align the pawl "N" position of the drive unit to the notch position (Fig. 5-50) on the cam gear L.
3. Pull out the drive unit and cylinder gear (See Fig. 5-51).
4. While turning the cam gear L, align the pawl "O" position of the select lever to the notch position (Fig. 5-52) on the cam gear L.
5. Remove the four screws ⑨ retaining the cam unit (cam gear L and cams R1/R2 assembly) (See Fig. 5-52).




Fig.5-49




Fig.5-50




Fig.5-51




Fig.5-52

■ Removing the actuator motor and belt

(See Figs. 5-53-5-56)

1. Remove the two screws ⑩ retaining the gear bracket (See Fig. 5-53).
2. While pressing the pawl "P" fixing the gear bracket in the arrow direction, remove the gear bracket (See Fig. 5-53).
3. From the notch "Q" section" on the chassis assembly fixing the edge of gear bracket, remove and take out the gear bracket (See Fig. 5-54).
4. Remove the belts respectively from the right and left actuator motor pulleys and pulley gears (See Fig. 5-53).
5. After turning over the chassis assembly, remove the actuator motor while spreading the four pawls "R" fixing the right and left actuator motors in the arrow direction (See Fig. 5-55).

[Note] When the chassis assembly is turned over under the conditions wherein the gear bracket and belt have been removed, then the pulley gear as well as the gear, etc. constituting the gear unit can possibly be separated to pieces. In such a case, assemble these parts by referring to the assembly and configuration diagram in Fig. 5-56.




Fig.5-53




Fig.5-54




Fig.5-55

Assembly and Configuration Diagram




Fig.5-56

■ Removing the cams R1/R2 assembly and cam gear L (See Fig. 5-57)

1. Remove the slit washer fixing the cams R1 and R2 assembly.
2. By removing the two pawls "S" fixing the cam R1, separate R2 from R1.
3. Remove the slit washer fixing the cam gear L.
4. Pull out the cam gear L from the C.G. base assembly.

■ Removing the C.G. base assembly (See Figs. 5-57 and 5-58)

Remove the three screws ⑪ retaining the C.G. base assembly.

[Caution] To reassemble the cylinder gear, etc. with the cam unit (cam gear and cams R1/R2 assembly), gear unit and drive unit, align the position of the pawl "N" on the drive unit to that of the notch on the cam gear L. Then, make sure that the gear unit is engaged by turning the cam gear L. (See Fig.5-58)




Fig.5-57






Fig.5-58

《 Speaker unit Section 》**■ Removing the Saran board (See Fig. 5-59.)**


Hold the Saran board by the two side edges and pull it toward the front in order to detach it from the joint holders.

**Fig. 5-59****■ Removing the joint holders (See Fig. 5-60)**

Insert a Phillips screwdriver into each joint holder and remove it by levering. To avoid damaging the wooden cabinet, place a piece of batten wood as shown in Fig. 5-60.

**Fig. 5-60****■ Removing the ornament panel (See Figs. 5-61 to 5-64.)**

1. Remove the Saran board.
2. Remove the joint holders.
3. Remove the four screws ① which retain the ornament panel from the front. (See Fig. 5-61.)

**Fig. 5-61**

4. Remove the two screws ② which retain the ornament panel from the rear. (See Fig. 5-62.)
5. Detach the ornament panel at the front of the speaker from the wooden cabinet by flipping it up from the lower edge. (See Fig. 5-63.)
6. Detach the ornament panel from the wooden cabinet from the rear and remove it. (See Fig. 5-64.)




Fig. 5-62




Fig. 5-63




Fig. 5-64

■ **Removing the speaker units**

1. Remove the Saran board.
2. Remove the joint holders.
3. Remove the ornament panel.
4. Remove each of the speaker units by referring to the exploded view of the speaker unit (page 9-5).

6. Main Adjustment

■ Measurement Instruments Required for Adjustment

1. Low frequency oscillator
This oscillator should have a capacity to output 0dBs to 600 Ω at an oscillation frequency of 50Hz~20kHz.
2. Attenuator impedance: 600 Ω
3. Electronic voltmeter
4. Distortion meter
5. Frequency counter
6. Wow flutter
7. Test tape
VTT 712: Tape speed and running unevenness (3kHz)
VTT 724: Reference level (1kHz)
TMT 7036: Head angle (10kHz), playback frequency characteristics (1kHz) and dubbing frequency characteristics (63, 1 and 10kHz)
Because of frequency - mixed tape with 63, 1, 10 and 14kHz (250nWb/m - 24dB), use this tape together with a filter.
8. Blank tape
TAPE I : AC-225
TAPE II : AC-514
9. Torque gauge: For play and back tension
FWD (TW2111A), REV (TW2121A) and
FF/REW (TW2231A)

■ Measurement Conditions

Power supply voltage.....AC120V(50Hz:CJ)
AC240V(50/60Hz:A)
AC230V(50Hz:B/E/EN/G/VX)
AC110~127V/220~240V(50/60Hz:UB/US/UT/U)

Reference output.....Speaker: 0.775V/3 Ω
Headphone: 0.245V/32 Ω

Reference frequency and input level · 1kHz, AUX: - 8dBs
Input for confirming recording and playback characteristicsAUX: - 28dBs

Measurement output terminalSpeaker CN192
※ Load resistance3 Ω

● Radio Input signal

AM modulation frequency 400Hz
Modulation factor 30%
FM modulation frequency 400Hz
Frequency displacement 22.5kHz

● Standard measurement positions of volume

Sound mode Flat position
Super-bas Off
Up and down adjustment of volume VOL. 23

Precautions for Measurement

1. Apply 30pF and 33kΩ to the IF sweeper output side and 0.082μF and 100kΩ in series to the sweeper input side.
2. The IF sweeper output level should be made as low as possible within the adjustable range.
3. Since the IF sweeper is a fixed device, there is no need to adjust this sweeper.
4. Since a ceramic oscillator is used, there is no need to perform any MPX adjustment.
5. Since a fixed coil is used, there is no need to adjust the FM tracking.
6. The input and output earth systems are separated. In case of simultaneously measuring the voltage in both of the input and output systems with an electronic voltmeter for two channels, therefore, the earth should be connected particularly carefully.
7. In the case of BTL connection amp., the minus terminal of speaker is not for earthing. Therefore, be sure not to connect any other earth terminal to this terminal. This system is of an OTL system.
8. For connecting a dummy resistor when measuring the output, use the wire with a greater core size.
9. Whenever any mixed tape is used, use the band pass filter (DV-12).

《 Arrangement of Adjusting Positions 》

● Cassette mechanism section (Mechanism A section)

● Cassette mechanism section (Back side)




Fig.6-1

■ Cassette Mechanism Unit Section




Fig.6-2

■ Tape Recorder Section

Items	Measurement conditions	Measurement method	Standard values	Adjusting positions
Confirmation of head angle	Test tape : TMT7036 (10kHz) Measurement output terminal : Speaker terminal Speaker R (Load resistance: 3 Ω) : Headphone terminal	① Play back the test tape TMT7036 (10kHz). ② With the playback mechanism or recording & playback mechanism, adjust the head azimuth screw so that the forward and reverse output levels become maximum. After adjustment, lock the head azimuth at least by half a turn. ③ In either case, this adjustment should be performed in both the forward and reverse directions with the head azimuth screw.	Maximum output	Adjust the head azimuth screw only when the head has been changed.
Confirmation of tape speed	Test tape : VTT712 (3kHz) or TMT7036 (3kHz) Measurement output terminal : Headphone terminal	《Constant speed》 Adjust VR301 so that the frequency counter reading becomes 3,010Hz ± 15Hz when playing back the test tape VTT712 (3kHz) with the playback mechanism or playback and recording mechanism after ending forward winding of the tape.	Tape speed of decks (A and B) : 3,010Hz ± 15Hz	VR301

■ Reference Values for Confirmation Items

Items	Measurement conditions	Measurement method	Standard values	Remarks
Double tape speed	Test tape : TMT7036 (10kHz) Measurement output terminal : Speaker terminal Speaker R (Load resistance: 3 Ω) measurement output terminal : Headphone terminal	① After setting to the double speed motor, confirm that the frequency counter reading becomes 4,800 +400/- 300Hz when the test tape VTT712 (3kHz) has been played back with the playback mechanism.	4,800 +400/- 300Hz	Playback mechanism side
Difference between the forward and reverse speed	Test tape : TMT7036 (10kHz) Measurement output terminal : Speaker terminal Speaker R (Load resistance: 3 Ω) measurement output terminal : Headphone terminal	When the test tape VTT712 (3kHz) has been played back with the playback mechanism or recording and playback mechanism at the beginning of forward winding, the frequency counter reading of the difference between both of the mechanisms should be 6.0Hz or less.	6.0Hz or less	Both the playback and recording & playback mechanisms
Difference between the playback mechanism and recording and playback mechanism speed	Test tape : TMT7036 (10kHz) Measurement output terminal : Speaker terminal Speaker R (Load resistance: 3 Ω) measurement output terminal : Headphone terminal	When the test tape VTT712 (3kHz) has been played back with the playback mechanism or recording and playback mechanism at the beginning of forward winding, the frequency counter reading of the difference between both of the mechanisms should be 6.0Hz or less.	6.0Hz or less	Both the playback and recording & playback mechanisms
Wow & flutter	Test tape : TMT7036 (10kHz) Measurement output terminal : Headphone terminal	When the test tape VTT712 (3kHz) has been played back with the playback mechanism or recording and playback mechanism at the beginning of forward winding, the frequency counter reading of wow & flutter should be 0.25% or less (WRMS).	0.25% or less (WRMS)	Both the playback and recording & playback mechanisms

■ Electrical Performance

Items	Measurement conditions	Measurement method	Standard values	Adjusting positions
Adjustment of recording bias current (Reference value)	<ul style="list-style-type: none"> • Mode: Forward or reverse mode • Recording mode • Test tape : AC-514 and AC-225 Measurement output terminal : Both recording and headphone terminals	<ol style="list-style-type: none"> ① With the recording and playback mechanism, load the test tapes (AC-514 to TYP II and AC-225 to TYP I), and set the mechanism to the recording and pausing conditions in advance. ② After connecting 100 Ω in series to the recorder head, measure the bias current with a valve voltmeter at both of the terminals. ③ After resetting the [PAUSE] mode, start recording. At this time, adjust VR101 for LcH and VR201 for RcH so that the recording bias current values become 4.0 μ A(TYP I) and 4.20 μ A (TYP II). 	AC-225 : 4.20 μ A AC-514 : 4.0 μ A	LcH :VR101 RcH :VR201
Adjustment of recording and playback frequency characteristics	Reference frequency : 1kHz and 10kHz (REF.: -20DB) Test tape : TYP II: AC-514 Measurement input terminal : OSC IN	<ol style="list-style-type: none"> ① With the recording and playback mechanism, load the test tape (AC-514 to TYP II), and set the mechanism to the recording and pausing conditions in advance. ② While repetitively inputting the reference frequency signal of 1kHz and 10kHz from OSC IN, record and play back the test tape. ③ While recording and playing back the test tape in TYP II, adjust VR101 for LcH and VR 201 for RcH so that the output deviation between 1kHz and 10kHz becomes -1dB ± 2dB. 	Output deviation between 1kHz and 10kHz : -1dB ± 2dB	LcH :VR101 RcH :VR201


■ Reference Values for Electrical Function Confirmation Items

Items	Measurement conditions	Measurement method	Standard values	Remarks
Recording bias frequency	<ul style="list-style-type: none"> • Recording and playback side forward or reverse • Test tape : TYP II: AC-514 • Measurement terminal: BIAS TP on P.C. board 	<ol style="list-style-type: none"> ① While changing over to and from BIAS 1 and 2, confirm that the frequency is changed. ② With the recording and playback mechanism, load the test tape (AC-514 to TYP II), and set the mechanism to the recording and pausing conditions in advance. ③ Confirm that the BIAS TP frequency on the P.C. board is 100kHz ± 6kHz. 	100kHz ± 6kHz	
Eraser current (Reference value)	<ul style="list-style-type: none"> • Recording and playback side forward or reverse • Recording mode • Test tape : AC-514 and AC-225 Measurement terminal: Both of the eraser head	<ol style="list-style-type: none"> ① With the recording and playback mechanism, load the test tapes (AC-514 to TYP II and AC-225 to TYP I), and set the mechanism to the recording and pausing conditions in advance. ② After setting to the recording conditions, connect 1W in series to the eraser head on the recording and playback mechanism side, and measure the eraser current from both of the eraser terminals. 	TYP II : 120mA TYP I : 75mA	

7.Out Line of Main IC

Refer to MX-D401T (Issue No. 10039)

8. Wiring Connections



6

7

8

9

10

■ A/UB/US/UP/UT/U Version Section

are shown below.

- Brown
- Red
- Orange
- Yellow
- Green
- Blue
- Violet
- Gray
- White
- Black
- Pink
- Light Blue







Fig.8-2

9. Analytic Drawing and Parts List



MX-D501T



1

2

3

4

5

■ Enclosure Assembly Part : Block No. **M1** (UB/US/UT/UP/U Version)

A


B

C

D

E

F




6

7

8

9

10



■ Enclosure Assembly Parts List


BLOCK NO. M1MM

△	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
	1	FMJC1015-002	FRONT PANEL		1	B,E,EN,G	
		FMJC1015-003	FRONT PANEL		1	U,UB,UP,US,J	
		E406971-001SM	JVC MARK		1		
	3	FMJK4013-001	STANDEBY INDICA		1		
	4	FMXP2009-001	CD BOTTON		1		
	5	E75896-001	SPACER		2		
	7	FMXP2004-005	POWER BUTTON		1	B,E,EN,G	
		FMXP2004-004	POWER BUTTON		1	U,UB,UP,US,J	
	8	FMXP3017-002	SOUND BUTTON		1		
	9	FMXP2003-001	CONTROL BUTTON		1		
	10	FMXP2010-00A	FUN.BUTT.ASSY		1		
	11	SDSF2608Z	SCREW		3		
	12	SDSF2610Z	TAPPING SCREW		2		
	13	GBSF2608Z	SCREW		3		
	14	SDSF2608Z	SCREW		11		
	15	SDSF2608Z	SCREW		1		
	16	E309495-002SM	STAY BKT		1		
	17	SDSF2608Z	SCREW		8		
	18	FMKL4011-001	BRACKET		1		
	19	FMYH4004-001	PLASTIC RIVET		1		
	20	E69777-003	REF PLATE		2		
	21	FMKL4014-001	PHONE BRACKET		1		
	22	SBST3006Z	TAPPING SCREW		1	U,UB,UP,US,J	
	23	FMJT2004-001	CASS HOLDER(L)		1		
	24	FMJT2004-002	CASS HOLDER(R)		1		
	25	FMJK2003-001	CASS LENS(L)		1		
	26	FMJK2003-002	CASS LENS(R)		1		
	27	FMXP3018-001	EJECT BUTTON(A)		1		
	28	FMXP3019-001	EJECT BUTTON(B)		1		
	29	FMKW4009-001	HOLDER SPRING A		1		
	30	FMKW4010-001	HOLDER SPRING B		1		
	31	FMKW4011-001	SPRING		1		
	32	FMKS3002-001	EJECT LEVER (A)		1		
	33	FMKS3003-001	EJECT LEVER (B)		1		
	34	VYH7779-00B	DUMPER ASS'Y		2		
	35	VKY4180-001	CASSETTE SPRING		4		
	36	FMKL4012-003	EJECT SAFETY(A)		1		
	37	FMKL4013-001	EJECT SAFETY(B)		1		
	38	FMKW4007-001	SPRING (A)		1		
	39	FMKW4008-001	SPRING (B)		1		
	40	-----	C. MECHA ASS'Y		1		
	41	FMKL2002-001	HOLDER BRACKET		1		
	42	SBSG3010Z	T.SCREW		2		
	43	SBSG3010Z	T.SCREW		2		
	44	SBSG3010Z	T.SCREW		4		
	45	SBSF3010Z	SCREW		4		
	46	-----	CHANGER MECHA A		1		
	55	SBSF3008Z	SCREW		1		
	57	E309662-001	DISC STOPPER		1		
	58	SBSF3008Z	SCREW		1		
	61	FMKL1004-002	CHASSIS BASE		1		
	62	E75896-006	FELT SPACER		2		
	63	FMMH3005-001	HEAT SINK		1		
	65	SBSG3014CC	T.SCREW		2		
	66	SBSG3014CC	SCREW		2		

BLOCK NO. M11MM

REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
67	FMKL4007-001	BRACKET		1		
68	FMKL4015-001	BRACKET		1		
69	FMPK4003-001	MICA SHEET		1		
70	E65389-002	SPECIAL SCREW		4		
71	FMMA4003-001	TRANS. SHIELD		1		
72	GBST3006Z	SCREW		1		
73	QMP5530-0085BS	POWER CORD		1	B,UB	
	QMP39E0-200	POWER CORD		1	E,EN,G,US,	
	QMP7520-200	POWER CORD		1	U,UT	
	EMP7000-200	POWER CORD		1	UP	
74	QHS3771-108BS	CORD STOPPER		1	B	
	QHS3771-108	CORD STOPPER		1	E,EN,G	
	QHS3771-108	CORD STOPPER		1	U,UB,UP,US,J	
79	VKZ4001-110	WIRE HOLDER		1		
80	FMT66M8-65A	POWER TRANS	T999	1	B,E,EN,G	
	FMT66U8-65A	POWER TRANS	T999	1	U,UB,UP,US,J	
81	QMF51E2-R80SBS	FUSE	T996	1	U,UB,UP,US,J	
82	QMF51E2-1R25	FUSE	F997	1		
83	QMF51E2-1R25	FUSE	F998	1		
89	QMF51E2-R80SBS	FUSE	F999	1		
90	VND4003-073	FUSE LABEL	FL999	1	U,UB,UP,US,J	
91	FMJC1016-013KP	REAR PANEL		1	B,E,EN,G	
	FMJC1016-012	REAR PANEL		1	U,UB,US,UT	
	FMJC1016-014KP	REAR PANEL		1	UP	
92	E207356-001SM	REAR COVER		1		
94	SBSG3008Z	T.SCREW		2		
95	E73273-003	SPECIAL SCREW		20		
97	E73273-003	SCREW		2	U,UB,US,UT	
98	FMJC1013-005	METAL COVER		1		
99	SDSG3006M	T.SCREW		2		
100	FMJD2003-001	CD FITTING		1		
101	FMJD2003-002	CD FITTING		1		
102	FMJD2003-003	CD FITTING		1		
103	FMXL3001-001	M.VOL KNOB		1		
104	FMJK2002-003	WINDOW SCREEN		1		
105	E408765-004SM	MIC.KNOB		1	U,UB,UP,US,J	
106	E70891-001	CLASS 1 LABEL		1		
107	E406709-001	CAUTION LABEL		1		
108	E408919-001	BEAB LABEL		1	B	
	FMND4008-001	SEMKO LABEL		1	E,EN,G	
112	EMND3007-007	RETING LABEL		1	UT	
113	LE40210-001A	CAUTION LABEL		1	UT	
114	FMND3008-004	RATING LABEL		1	U	

■ Speaker unit Section: Block No. M5




■ Speaker unit Section Parts List


BLOCK NO. M5MM

REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
1	EZC-SP-D5TR	WOOD CABINET		1		
2	EZC-SP-D5TL	WOOD CABINET		1		
3	E309698-003	ORNAMENT PANEL	RIGHT	1		
4	E309698-004	ORNAMENT PANEL	LEFT	1		
5	E75939-001	JVC MARK		1		
6	E407076-001	JOINT HOLDER		4		
7	E103105-005	SARAN BOARD	RIGHT	1		
8	E103105-006	SARAN BOARD	LEFT	1		
9	HSA1699-03N	CONE SPEAKER		1		
10	HSA0799-01L	CONE SPEAKER		1		
11	HSA0899-02H	CONE SPEAKER		1		
12	E409044-001	TWEETER ASSY		1		
13	E03823-092	SPK. TERMINAL		1		
14	SDSA4020Z	TAPPING SCREW		8		
15	SBSF4008Z	TAPPING SCREW		9		
16	SBSF1040Z	TAPPING SCREW		4		
17	SDSA4020M	SCREW		2		
18	E308987-001	SPACER		1		
19	E409191-001	SPEAKER NETWORK		1		
21	E309915-001	TOP COVER	RIGHT	1		
22	E309915-002	TOP COVER	LEFT	1		

《 MEMO 》


10. Block Diagram





11. Standard Schematic Diagram

Head Amplifier & Mechanism Control Circuit : Drawing No.VDH1033-001PV




STANDARD
REC CURRENT
NORM 30uA
CROD 35uA
BIAS CURRENT
NORM 220uA
CROD 250uA
ERASE CURRENT
NORM 750uA
CROD 1200uA

NOTES
1. VOLTAGES ARE DC-MEASURED WITH A DIGITAL VOLT METER OR OSCILLOSCOPE WITHOUT INPUT SIGNAL. I IS INVERT MODE.
2. UNLESS OTHERWISE SPECIFIED:
ALL RESISTANCE VALUES ARE IN OHM(Ω).
ALL CAPACITORS ARE CERAMIC CAPACITOR.
ALL CAPACITANCE VALUES ARE IN μF(μF).
ALL INDUCTANCE VALUES ARE IN mH(mH).
ALL E. CAPACITORS ARE SHOWN IN THE FORM OF CAPACITANCE (μF)/RATED VOLTAGE (V).
P PLYMPROPYLENE CAPACITOR

TABLE 1. DIGITAL TR LIST

PART-NO	CONSTRUCTION	REF. NO			
FA1L4H		Q315	FA1F4H		Q317
FA1A4C		Q101/Q201 Q104/Q204	FA1L4H		Q103 Q319 Q320
FA1L4Z		Q107/Q202 Q301			


Note : VDH103301pv1/s/G



	0317
	0103/0203
	0319
	0320/0321/0322

Tape/PB Signal
 REC Signal
 +B Line


■ CD Servo Control Circuit : Drawing No.FMDH9002-001CW



NOTES

1. VOLTAGES ARE DC-MEASURED WITH A DIGITAL VOLT METER
2. UNLESS OTHERWISE SPECIFIED, RESISTORS ARE 1/6W ±5% CARBON RESISTOR.
ALL RESISTANCE VALUES ARE IN Ω(M), K, OR M.
ALL CAPACITORS ARE CERAMIC CAPACITOR OR MYLAR CAPACITOR.
ALL CAPACITANCE VALUES ARE IN P(F), N, OR μ(F).
ALL E. CAPACITORS ARE SHOWN IN THE FORM OF CAPACITANCE [P/F]/RATED VOLTAGE (V).

Note : FMDH9002001CW(/s/g/)




6

7


8

9

10



■ Tuner Circuit : Drawing No.FMDH9002-005TW (B/E/EN/G Version)




* MARK

MODEL	CA-D301T	CA-D401T	CA-D501T
LOC.	CA-D351TR	CA-D451TR	CA-D551TR
C17	0.01	0.001	0.001

CONDITION	PIN NO.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
IC1	FM NO SIGNAL	2.0	0.5	0	2.0	5.2	5.2	0	0	0.2	5.2	5.2	1.0	1.0	4.6	3.8	3.8	1.4	0	1.9	1.1	2.0	2.0	5.2	2.0
	FM 60dB STEREO	2.0	0.5	0	2.0	5.2	5.2	1.1	0	0.2	0	0	1.0	1.0	4.5	4.1	3.9	1.4	0	1.2	1.1	2.0	2.0	5.2	2.0
	AM NO SIGNAL	2.0	0.5	0	2.0	5.0	5.2	0	0	0.2	5.2	5.2	1.0	1.0	4.8	2.2	6	1.4	1.4	1.5	1.6	2.0	2.0	5.2	2.0
IC2	FM NO SIGNAL	2.7	0	0	4.9	4.9	4.9	3.8	3.8	2.0	4.1	5.2	0	0	0	2.6	5.2	1.0	1.0	3.7	0	2.7			

Tr. NO.	
PIN NO.	
FM 87.5MHz NO	
AM 523kHz NO	
Tr. NO.	
PIN NO.	
AM 523kHz NO	
AM 144kHz NO	


Note : FMDH9002005TW1/s/g



NOTES

1. VOLTAGES ARE DC-MEASURED WITH A DIGITAL VOLT METER.
2. ALL RESISTORS ARE 1/6W 5% CARBON RESISTOR.
3. ALL RESISTANCE VALUES ARE IN OHM(Ω).
4. ALL CAPACITANCE VALUES ARE IN nF(p=pF).
5. ALL E-CAPACITORS ARE SHOWN IN THE FORM OF CAPACITANCE (nF)/RATED VOLTAGE (V).
6. SI-DIODES(▷) ARE ALL 1SS133T
7. PARTS NO. OF TRANSISTORS ARE AS FOLLOWS:
 Q1 2SC1923(D) Q2,6 DTA114YS
 Q3,4,15 2SC2785
 Q14 2SA1175(HFE)-T


B. INSIDE OF DIGITAL TRANSISTORS ARE SHOWN AS FOLLOWS:




- TUNER GND
- TUNER R
- TUNER L
- TUNER RB
- DATA
- MPX
- CLOCK
- PERIOD
- Vt/FM4B

- D. GND
- RDS. DATA
- RDS. CK

Tr. NO.	Q1			Q5			Q16		
	E	C	B	E	C	B	E	C	B
1 87.5MHz NO SIGNAL	0	8.3	0.8	9.8	9.7	0	1.0	3.5	1.6
1 523kHz NO SIGNAL	0	0	0	9.8	6	9.7	1.0	3.5	1.6
Tr. NO.	Q2			Q3			Q4		
	E	C	B	E	C	B	E	C	B
1 523kHz NO SIGNAL	2.0	2.0	0.1	0	0	0.7	0	0	0.7
1 144kHz NO SIGNAL	2.0	2.0	0.1	0	0	0.1	0	0	0.1




■ Tuner Circuit : Drawing No.FMDH9002-006TW (A/C/J/U/UB/UP/US/UT Version)



* MARK

	G-13 C49	G-13 C50	C-3 R93, R94	R12
J. C	0.039	0.039	2.2M 1/2W	--
A	0.027	0.027	--	56
U. UB- UR- US- UT	0.039	0.039	--	--
UP	0.039	0.039	--	56

- NOTES**
- VOLTAGES ARE DC-MEASURED WITH A DIGITAL VOLT METER
 - ALL RESISTORS ARE 1/8W 5% CARBON RESISTOR.
 - ALL RESISTANCE VALUES ARE IN OHM(Ω).
 - ALL CAPACITANCE VALUES ARE IN nF(pF).
 - ALL E-CAPACITORS ARE SHOWN IN THE FORM OF CAPACITANCE (nF)/RATED VOLTAGE (V).
 - SI DIODES (D) ARE ALL 1SS133T-77
 - PARTS NO. OF TRANSISTORS ARE AS FOLLOWS:
 O1 2SC1923(O)
 O4 DTA114YS
 - INSIDE OF DIGITAL TRANSISTORS ARE SHOWN AS FOLLOWS.



IC	FUNCTION	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
IC1	FM FRONT END	2.0	0.0	0.0	2.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
IC2	PLL	2.0	0.0	0.0	2.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
IC3	FM DEMOD	2.0	0.0	0.0	2.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
IC4	FM DEMOD	0.8	1.4	1.4	1.4	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8

Note : FMDH9002006TW(/s/g)

6


7

8

9

10

999-202 L3




2.4	IT#	NO.	01	04
2.4	PTN	NAME	E1	C1 B
2.4	FM	76.0MHz	0	0
2.4	AM	531kHz	0	0

+B Line

FM Radio signal
AM Radio signal

Function & Bass Boost Amplifier / Regulator Circuit : Drawing No.FMDH9003-006AV (1/3)


A
B
C
D
E
F



1) INDICATE THE VALUE FOR MODEL CA-D501TCA-D551TR
* MARK

MODEL	LOC	L302	L302/L304	L305	R6Kx/R6Kx/B	R119/R504	0316/0317	0303	0301/0302	0306	L303	0315/0321	C353/C354	R349	R403	R924	R330/R331	R103/R203	R348	0303/0303	0306/1	
CA-D401T	VER	9-H	10-K/17-L	17-L	3-G	5-E	12-N	19-F	14-L	8-1	11-E	12-d	470P	--	--	560	22 F. RES 1174W	5.6K	30K	100	0.02	3.3V
	J. C	0163	0106/0105	0107	--	USE	0103/0104	--	--	1500	2.2750	--	470P	--	--	0153	22 F. RES 1174W	5.6K	30K	100	--	--
CA-D501T1	U. UB-UP	0163	0106/0105	0107	USE	--	0103/0104	SS1331-77	--	1500	--	470P	--	--	--	560	22 F. RES 1174W	5.6K	30K	100	0.02	3.3V
	UR. US. UT	0163	0106/0105	0107	USE	--	0103/0104	--	--	1500	2.2750	--	470P	--	--	560	22 F. RES 1174W	5.6K	30K	100	--	14.7750
MX-D451TR CA-D551TR	B. L. EN. G	020048-009	020048-009	020048-009	--	USE	0103/0104	--	--	1500	2.2750	--	470P	--	--	560	22 F. RES 1174W	5.6K	30K	100	--	--
	A	0163	0106/0105	0107	--	USE	0103/0104	--	--	1500	2.2750	--	470P	--	--	560	22 F. RES 1174W	5.6K	30K	100	--	14.7750
MX-D451TR CA-D551TR	Vx	0163	0106/0105	020048-009	--	USE	0103/0104	--	--	1500	2.2750	--	470P	--	--	560	22 F. RES 1174W	5.6K	30K	100	--	--
	B. C. EN. G	020048-009	020048-009	020048-009	--	USE	0103/0104	--	020048-009	1500	2.2750	330P	--	10K	--	560	22 F. RES 1174W	5.6K	30K	100	--	4.7K

Note : FMDH9003006AV (/s/g) .003



03/C203	106/C206	C327	C130/C230	R130/R230	R118/R216
6-6	5-1	17-B	6-1	6-1	9-B
0.22	3.3/5.0	0.18	330	100k	120k
4.7/50	14.7/50	10.2/1	102P1	100k	1100k

NOTES


- VOLTAGE ARE DC-MEASURED WITH A DIGITAL VOLT METER OR OSCILLOSCOPE WITHOUT INPUT SIGNAL (CONDITION -- CD MODEL)
- VOLTAGE VALUE MARKED * IS IN TUNER SECTION.
- UNLESS OTHERWISE SPECIFIED, RESISTORS ARE 1/4W 5% CARBON RESISTORS.
- ALL RESISTANCE VALUES ARE IN OHMS.
- ALL CAPACITORS ARE CERAMIC CAPACITOR OR MYLAR CAPACITOR.
- ALL CAPACITANCE VALUES ARE IN PICO (P).
- ALL INDUCTANCE VALUES ARE IN MICRO (U).
- ALL C CAPACITORS ARE SHOWN IN THE FORM OF CAPACITANCE (P)/RATED VOLTAGE (V).
- ALL DIODES ARE 1SS133T-7.
- ALL NEW TRANSISTORS ARE 2SC3330G-11 OR 2SC2785E-F1.
- * MARK ARE FOR USE 07E/07E/VERSION

CD Digital signal
 CD Analogue signal
 Tape/PB Main signal
 FM Radio signal
 AUX IN Signal

■ Power Amplifier & Regulator Circuit : Drawing No.FMDH9003-006AV (2/3)

A
B
C
D
E
F

1 2 3 4 5




NOTE : () INDICATE THE VALUE FOR MODEL CA-D501T AND CA-D551TR

TO MAIN BOARD TO MAIN BOARD

※MARK

VERSION	C947/948/949/950	C971/C972	D908/909/910/911	IC900/901	L971/972	R921/922	R957	R964/965	R982	R973/R974
B-E-EN-G	18-B	18-B	18-H	6-B/13-B	17-B	6-C/13-C	9-E	17-D	12-H	19-B
U-UB-UP-UR US-UT-A-VX	--	--	1N5401TM	TDA7295	VQ02104-003	B125/126	1K	680	B120	--
J-C	--	--	10E2-FD	TDA7294	--	2.2K	10K	680 F.RES(1/4W)	22 F.RES(1/4W)	--

6 | 7 | 8 | 9 | 10




TO HEADPHONE BOARD
TO TRANSFORMER BOARD

i25-008R

NOTES

- VOLTAGES ARE DC-MEASURED USING AN OSCILLOSCOPE WITHOUT INPUT SIGNAL CONDITION.
- UNLESS OTHERWISE SPECIFIED
ALL RESISTORS ARE 1/8W ±5% CARBON RESISTOR.
ALL CAPACITORS ARE 50V CERAMIC CAPACITOR OR 50V MYLAR CAPACITOR.
ALL RESISTANCE VALUES ARE IN OHM(Ω).
ALL CAPACITANCE VALUES ARE IN pF(pF).
ALL E-CAPACITORS ARE SHOWN IN THE FORM OF CAPACITANCE(μF)/RATED VOLTAGE (V).
ALL DIODES ARE 1SS133T-77 TYPE
POLYPROPYLENE CAPACITOR
50V ±5% MYLAR CAPACITOR OR 50V ±5% THIN FILM CAPACITOR
- THOSE PART WITH BRACKET IS NOT USED.
FOR RESISTOR, IT WOULD BE A SHORT.
FOR CAPACITOR, IT WOULD BE AN OPEN.




1974
3

1 | 2 | 3 | 4 | 5


■ Power Transformer Circuit : Drawing No.FMDH9003-006AV (3/3)

A



POWER
E/EN


B



POWER
A

C

D



POWER
UP

E

F

Note : FMDH9003006AV1/s/g)

MX-D501T

6


7

8


9

10


POWER SUPPLY BLOCK



POWER SUPPLY BLOCK




POWER SUPPLY BLOCK



System CPU & Operation Switch Circuit : Drawing No.FMDH9002-006SV

FL701 QL.F0021-001

A
B
C
D
E
F



FMB-007-1
FMMW1025A

* MARK

MODEL	VERSIONS	R479 19-M	R59B 15-L	R699 15-M	S710/711/712/713 16-K	R491 16-F	R801 16-H	D411 19-C	Q711 18-G	R76B 11-F	MODEL	IC701 10-F	NOTES
CA-D301T	J. C	47K	--	--	--	--	B134	SLR-342VCA47	DTC-114ES	2.2K	MX-D301T	UPD78044F6F-067	1. VO C
	U. UB. UP. US. UT.	--	--	--	--	300	47K	SLA-380LT-TB	2S02144S	56			
CA-D401T	LR	--	--	75K	--	300	47K	SLA-380LT-TB	2S02144S	56	UR/UB/LP UR/US/UT	2. UA E F G H I J K L M N O P Q R S T U V W X Y Z	
	B. E. EN. G	47K	75K	B129	--	300	47K	SLA-380LT-TB	2S02144S	2.2K			
CA-D501T	A	--	B133	10K	--	300	47K	SLA-380LT-TB	2S02144S	2.2K	OTHERS	UPD78044F6F-055	
	VX	--	18K	10K	--	300	47K	SLA-380LT-TB	2S02144S	2.2K			
MX-D4S1TR CA-35S1TR	B. E. EN. G	47K	10K	10K	USE	300	47K	SLA-380LT-TB	2S02144S	2.2K			

Note : FMDH9002006SV (/s/g)


6

7

8

9

10



NOTES

- VOLTAGES ARE DC-MEASURED WITH A DIGITAL VOLT METER OR OSCILLOSCOPE WITHOUT INPUT SIGNAL. CONDITION --- TAPE FB MODE
- UNLESS OTHERWISE SPECIFIED
RESISTORS ARE 1/8W 5% CARBON RESISTOR.
ALL RESISTANCE VALUES ARE IN OHM (R).
ALL CAPACITORS ARE CERAMIC CAPACITOR OR MYLAR CAPACITOR.
ALL CAPACITANCE VALUES ARE IN nF (P) OR pF.
ALL INDUCTANCE VALUES ARE IN mH (mH).
ALL ELECTROLYTIC CAPACITORS ARE SHOWN IN THE FORM OF CAPACITANCE (μF)/RATED VOLTAGE (V).
ALL DIODES ARE 1SS133



■ CD Traverse Mechanism Control Circuit : Drawing No.FMDH9002-006MW




TABLE 1 CAM PATTERN LIST


CAM NO.	LCAM			RCAM				POSITION	
	0	1	2	3	4	5	6		7
MAIN TRAY1	0	1	1	1	0	1	1	0	EMERGENCY
SUB TRAY1	0	0	1	1	0	1	0	0	TRAY1 STAND-BY
CAMR 1	0	1	0	1	0	1	0	1	TRAY1 CHACKING
MAIN TRAY2	1	0	0	1	0	1	0	1	TRAY2 STAND-BY
SUB TRAY2	1	1	1	0	0	0	1	1	TRAY2 CHACKING
CAMR 2	1	0	1	0	0	0	1	0	TRAY3 STAND-BY
MAIN TRAY3	1	1	0	0	0	0	1	1	TRAY3 CHACKING
SUB TRAY3	1	0	0	0	0	0	0	0	
OFF	1	1	1	1	0	1	1	1	OFF

0=0V
1=5V

NOTES

- VOLTAGES ARE DC-MEASURED WITH A DIGITAL OR OSCILLOSCOPE WITHOUT INPUT SIGNAL. CONDITION --- DISC 1 CD STOP MODE
- UNLESS OTHERWISE SPECIFIED, RESISTORS ARE ALL RESISTANCE VALUES ARE IN OHM(Q). ALL CAPACITORS ARE CERAMIC CAPACITOR OR ALL CAPACITANCE VALUES ARE IN μF(P=pF). ALL INDUCTANCE VALUES ARE IN mH(m=mH). ALL E. CAPACITORS ARE SHOWN IN THE FORM


Note : FMDH9002006MW(/s/g)




- Ⓢ UNFLAMMABLE CARBON RESISTOR
- Ⓜ METAL FILM RESISTOR
- Ⓞ OXIDE METAL FILM RESISTOR
- Ⓛ ±20% LOW LEAK CURRENT ELECTROLYTIC CAPACITOR
- Ⓝ NON-POLARISED ELECTROLYTIC CAPACITOR
- Ⓟ POLYPROPYLENE CAPACITOR
- Ⓠ POLYSTYROL CAPACITOR

A DIGITAL VOLT METER
GNAL.
IODE

STORS ARE 1/6W ±5% CARBON RESISTOR.
-M(Ω).
ACITOR OR MYLAR CAPACITOR.
F (P=pF).
H(m=μH).
THE FORM OF CAPACITANCE (μF)/RATED VOLTAGE (V).




■ Mic Input Amplifier & Headphone Output Circuit : Drawing No.FMDH9003-006AX




Note : FMDH900306AX(/s/g)

6 | 7 | 8 | 9 | 10



12. Location of P.C.Board Parts







Fig.12-1

1 | 2 | 3 | 4 | 5

■ Main Amplifier Board : Block No. **01** (U/UB/UP/US/UT Version)

A
B
C
D
E
F



Fig

6

7

8

9

10





Fig.12-2

■ Power Supply & Power Amplifier Board : Block No. **02** (B/E/EN/G Version)







Fig.12-3


1 2 3 4 5

■ Power Supply & Power Amplifier Board : Block No. **02** (U/UB/UP/US/UT Version)

A
B
C
D
E
F





● Power Supply Board



← ● Voltage Select

FMMW1021C



Select Switch Board


Fig.12-4

1 | 2 | 3 | 4 | 5

■ System CPU & Operation Switch Board : Block No. **03** (B/E/EN/G Version)

A
B
C
D
E
F

● System CPU Board →






Fig.12-5


1 2 3 4 5

■ System CPU & Operation Switch Board : Block No. 03 (U/UB/UP/US/UT Version)

A
B
C
D
E
F

● Headphone & MIC Jack Board →

● System CPU Board →



6 | 7 | 8 | 9 | 10




Fig.12-6

13. Electrical Parts List

■ Main Amplifier Board (B/E/EN/G Version)

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
C 104	EETB1CM-226E	E-CAPACITOR		
C 106	QTE1H06-475Z	E-CAPACITOR	4.7MF 20% 50V	
C 108	QTE1V06-106Z	E-CAPACITOR		
C 110	QFV71HJ-124ZM	FILM CAPACITOR	.12MF 5% 50V	
C 111	QFV71HJ-124ZM	FILM CAPACITOR	.12MF 5% 50V	
C 112	QET41AM-107	E-CAPACITOR	100MF 20% 10V	
C 113	QTE1V06-106Z	E-CAPACITOR		
C 116	QETC1HM-106ZN	E-CAPACITOR	10MF 20% 50V	
C 122	QETN1HM-335Z	E-CAPACITOR	3.3MF 20% 50V	
C 150	QCS31HJ-820Z	E-CAPACITOR	82PF 5% 50V	
C 201	QCS11HJ-330	C-CAPACITOR	33PF 5% 50V	
C 202	QCS11HJ-100	C-CAPACITOR	10PF 5% 50V	
C 203	QTE1H06-475Z	E-CAPACITOR		
C 204	EETB1CM-226E	E-CAPACITOR		
C 206	QTE1H06-475Z	E-CAPACITOR	3.3MF 20% 50V	
C 210	QTE1V06-106Z	E-CAPACITOR		
C 210	QFV71HJ-124ZM	FILM CAPACITOR	.12MF 5% 50V	
C 211	QFV71HJ-124ZM	FILM CAPACITOR	.12MF 5% 50V	
C 212	QET41AM-107	E-CAPACITOR	100MF 20% 10V	
C 213	QTE1V06-106Z	E-CAPACITOR		
C 216	QETC1HM-106ZN	E-CAPACITOR	10MF 20% 50V	
C 222	QETN1HM-335Z	E-CAPACITOR	3.3MF 20% 50V	
C 230	QCS31HJ-820Z	C-CAPACITOR	82PF 5% 50V	
C 301	QCSB1HK-102Y	C-CAPACITOR	1000PF 10% 50V	
C 303	QETC1HM-225ZN	E-CAPACITOR	2.2MF 20% 50V	
C 305	QFLC1HJ-223ZM	M-CAPACITOR	.022MF 5% 50V	
C 306	EETB1HM-475E	E-CAPACITOR		
C 307	EETB1HM-475E	E-CAPACITOR		
C 308	EETB1CM-226E	E-CAPACITOR		
C 309	QCS11HJ-450	C-CAPACITOR	15PF 5% 50V	
C 310	QCSB1HK-471Y	C-CAPACITOR	470PF 10% 50V	
C 311	QCS11HJ-450	C-CAPACITOR	15PF 5% 50V	
C 312	QCSB1HK-451Y	C-CAPACITOR	150PF 10% 50V	
C 313	QCSB1HK-471Y	C-CAPACITOR	470PF 10% 50V	
C 314	QETC1HM-224Z	E-CAPACITOR	.22MF 20% 50V	
C 315	QFLC1HJ-403ZM	M-CAPACITOR	.010MF 5% 50V	
C 316	QFLC1HJ-393ZM	M-CAPACITOR	.039MF 5% 50V	
C 317	QFLC1HJ-473ZM	M-CAPACITOR	.047MF 5% 50V	
C 318	QFLC1HJ-403ZM	M-CAPACITOR	.010MF 5% 50V	
C 319	QFLC1HJ-593ZM	M-CAPACITOR	.039MF 5% 50V	
C 320	QFLC1HJ-473ZM	M-CAPACITOR	.047MF 5% 50V	
C 321	EETB1EM-106E	E-CAPACITOR		
C 322	EETB1AM-476E	E-CAPACITOR		
C 323	QET41EM-406	E-CAPACITOR	10MF 20% 25V	
C 324	EETC1CM-106ZJC	E-CAPACITOR		
C 325	EETB1HM-105E	E-CAPACITOR		
C 327	QFV41HJ-224ZM	M-M-CAPACITOR	.22MF 5% 50V	
C 329	QETB1HM-474N	E-CAPACITOR	.47MF 20% 50V	
C 332	QFLC1HJ-403ZM	M-CAPACITOR	.010MF 5% 50V	
C 334	QFLC1HJ-223ZM	M-CAPACITOR	.022MF 5% 50V	
C 335	QET41AM-107Z	E-CAPACITOR	100MF 20% 10V	
C 351	EETB1CM-476	E-CAPACITOR		
C 352	QET41EM-406	E-CAPACITOR	10MF 20% 25V	
C 362	QCSB1HK-151Y	C-CAPACITOR	1500PF 10% 50V	
C 363	QET41AM-108	E-CAPACITOR	1000MF 20% 10V	

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
C 1	QCC11EM-223V	C-CAPACITOR	.022MF 20% 25V	
C 2	QCB1CM-332Y	C-CAPACITOR	3300PF 20% 16V	
C 3	QCC11EM-473V	C-CAPACITOR	.047MF 20% 25V	
C 4	QCB1CM-103Y	C-CAPACITOR	.010MF 30% 16V	
C 5	QET41AM-107	E-CAPACITOR	100MF 20% 10V	
C 6	QCSB1HK-331Y	C-CAPACITOR	330PF 10% 50V	
C 7	QFBI1HZ-104Y	C-CAPACITOR	.10MF +80% -20%	
C 8	QCSB1HJ-150Y	C-CAPACITOR	15PF 5% 50V	
C 11	QCC11EM-473V	C-CAPACITOR	.047MF 20% 25V	
C 12	QCS11HJ-150	C-CAPACITOR	15PF 5% 50V	
C 13	QCB1CM-103Y	C-CAPACITOR	.010MF 30% 16V	
C 16	QFV41HJ-104ZM	FILM CAPACITOR	.10MF 5% 50V	
C 17	QCSB1HK-102Y	C-CAPACITOR	.010MF 20% 16V	
C 18	QCSB1HK-471Y	C-CAPACITOR		
C 19	QCSB1HK-471Y	C-CAPACITOR		
C 21	QCC11EM-473V	C-CAPACITOR	.047MF 20% 25V	
C 30	QEK41CM-476	E-CAPACITOR	47MF 20% 16V	
C 31	QCS31HJ-390Z	C-CAPACITOR	39PF 5% 50V	
C 32	QCSB1HK-102Y	C-CAPACITOR	1000PF 10% 50V	
C 33	QEK61AM-107Z	E-CAPACITOR	100MF 20% 10V	
C 34	QCS11HJ-150	C-CAPACITOR	15PF 5% 50V	
C 35	QCB1CM-103Y	C-CAPACITOR	.010MF 30% 16V	
C 36	QEK41CM-106	E-CAPACITOR	10MF 20% 16V	
C 37	QCB1CM-103Y	C-CAPACITOR	.010MF 30% 16V	
C 38	QCC11EM-473V	C-CAPACITOR	.047MF 20% 25V	
C 39	QCC11EM-473V	C-CAPACITOR	.047MF 20% 25V	
C 40	QCB1CM-103Y	C-CAPACITOR	.010MF 30% 16V	
C 41	QEK41HM-104	E-CAPACITOR	.10MF 20% 50V	
C 42	QEK41HM-474	E-CAPACITOR	.47MF 20% 50V	
C 43	QEK61HM-335ZN	E-CAPASITOR	3.3MF 20% 50V	
C 44	QCSB1HK-221Y	C-CAPACITOR	220PF 10% 50V	
C 45	QEK41CM-106	E-CAPACITOR	10MF 20% 16V	
C 46	QCC11EM-223V	C-CAPACITOR	.022MF 20% 25V	
C 47	QCB1CM-103Y	C-CAPACITOR	.010MF 20% 16V	
C 49	QFLC1HJ-183ZM	M-CAPACITOR	.018MF 5% 50V	
C 50	QFLC1HJ-183ZM	M-CAPACITOR	.018MF 5% 50V	
C 51	QEK41HM-105	E-CAPACITOR	1.0MF 20% 50V	
C 52	QEK41HM-105	E-CAPACITOR	1.0MF 20% 50V	
C 53	QCSB1HK-102Y	C-CAPACITOR	1000PF 10% 50V	
C 54	QEK61HM-335ZN	E-CAPASITOR	3.3MF 20% 50V	
C 55	QCS11HJ-120	C-CAPACITOR	12PF 5% 50V	
C 60	QEK61AM-107Z	E-CAPACITOR	100MF 20% 10V	
C 61	QCS11HJ-120	C-CAPACITOR	12PF 5% 50V	
C 62	QCS11HJ-120	C-CAPACITOR	12PF 5% 50V	
C 63	QCC11EM-473V	C-CAPACITOR	.047MF 20% 25V	
C 65	QCSB1HK-102Y	C-CAPACITOR	1000PF 10% 50V	
C 66	QCSB1HK-151Y	C-CAPACITOR	150PF 10% 50V	
C 68	QCSB1HK-101Y	C-CAPACITOR	100PF 10% 50V	
C 69	QFV41HJ-105	TF-CAPACITOR	1.0MF 5% 50V	
C 70	QCB1CM-592Y	C-CAPACITOR	3900PF 20% 16V	
C 71	QET41CM-476	E-CAPACITOR	47MF 20% 16V	
C 72	QCSB1HK-102Y	C-CAPACITOR	1000PF 10% 50V	
C 101	QCS11HJ-330	C-CAPACITOR	33PF 5% 50V	
C 102	QCS11HJ-100	C-CAPACITOR	10PF 5% 50V	
C 103	QTE1H06-475Z	E-CAPACITOR		

BLOCK NO. 01

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
D 912	RD5-6JSAB1	ZENER DIODE		
D 913	1SS133	SI DIODE		
D 915	1SS133	SI DIODE		
D 928	MTZ2.4JB	ZENER DIODE		
EP001	E409182-001SM	GRAND TERMINAL		
IC 1	TA2057N	IC		
IC 2	LC72136N	IC		
IC301	NJM4580L	IC		
IC302	BH3854AS	IC		
IC303	NJM4580L	IC		
J 1	ENB417V-302K	ANT TERMINAL		
JA301	ENM001V-222AJ2	PIN JACK		
L 1	VQZ0098-101	COIL BLOCK		
L 4	VQP0018-221	INDUCTOR		
L 10	VGZ0069-002S	TRAP COIL		
L 11	VGP0018-2R7	INDUCTOR		
L 303	VQZ0048-009	INDUCTOR		
L 304	VGZ0048-009	INDUCTOR		
L 305	VGZ0048-009	INDUCTOR		
L 306	VGP0028-100Z	INDUCTOR		
PP301	VNZ0015-005	POST PIN		
PP302	VNZ0015-005	POST PIN		
Q 1	2SC1923	TRANSISTOR		
Q 2	DTA114YS	TRANSISTOR		
Q 3	2SC2785	TRANSISTOR		
Q 4	2SC2785	TRANSISTOR		
Q 6	DTA114YS	TRANSISTOR		
Q 16	2SC2785	TRANSISTOR		
Q 301	2SD2144S(VW)	TRANSISTOR		
Q 302	2SD2144S(VW)	TRANSISTOR		
Q 303	DTA114YS	TRANSISTOR		
Q 304	2SK246(GR,BL)	FET		
Q 305	2SK246(GR,BL)	FET		
Q 306	DTA144TSTP	TRANSISTOR		
Q 307	2SD2144S(VW)	TRANSISTOR		
Q 308	2SD2144S(VW)	TRANSISTOR		
Q 309	2SC2785	TRANSISTOR		
Q 310	2SC2785	TRANSISTOR		
Q 311	DTA114ES	TRANSISTOR		
Q 312	2SC2785	TRANSISTOR		
Q 314	DTA144ES	D-TRANSISTOR		
Q 320	DTA144TSTP	TRANSISTOR		
Q 380	2SC2785	TRANSISTOR		
Q 381	2SC2785	TRANSISTOR		
Q 907	2SA1175	TRANSISTOR		
Q 908	2SC2785	TRANSISTOR		
Q 909	2SB1375	TRANSISTOR		
Q 910	2SC2785	TRANSISTOR		
Q 913	2SB1375	TRANSISTOR		
Q 914	2SC2785	TRANSISTOR		
Q 915	2SC2785	TRANSISTOR		
Q 916	2SC2785	TRANSISTOR		
R 1	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W		
R 2	QRD161J-181	CARBON RESISTOR 180 5% 1/6W		
R 3	QRD161J-101	CARBON RESISTOR 100 5% 1/6W		

BLOCK NO. 01

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
C 364	QET41AM-108	E CAPACITOR	1000MF 20% 10V	
C 380	QCS11HJ-330	C. CAPACITOR	33PF 5% 50V	
C 381	QCXB1CM-182Y	C. CAPACITOR	1800PF 20% 16V	
C 382	QFLC1HJ-153ZM	M CAPACITOR	.015MF 5% 50V	
C 383	QCB81HK-681Y	C. CAPACITOR	680PF 10% 50V	
C 384	EETB1HM-105E	E. CAPACITOR	47MF 20% 50V	
C 385	QETC1HM-476ZM	E. CAPACITOR		
C 908	EETB1HM-475E	E. CAPACITOR		
C 909	EETB1CM-226E	E. CAPACITOR		
C 910	EETC1CM-106ZJC	E. CAPACITOR		
C 911	QFLC1HJ-103ZM	M CAPACITOR	.010MF 5% 50V	
C 912	QET41AM-107	E CAPACITOR	100MF 20% 10V	
C 920	QFLC1HJ-103ZM	M CAPACITOR	.010MF 5% 50V	
C 921	QET41AM-107	E CAPACITOR	100MF 20% 10V	
C 968	QCB81CM-103Y	C. CAPACITOR	.010MF 20% 16V	
CF 1	VCFM3B-104	CERAMIC FILTER		
CF 2	VCFM3B-102	CERAMIC FILTER		
CF 3	VCF1Z22-115Z	CERAMIC FILTER		
CF 4	CMU2-456A05	CERA LOCK		
CN302	VMCO332-010V	CONNECTOR		
CN303	VMCO163-029	CONNECTOR		
CN304	VMCO332-007V	CONNECTOR		
CN305	VMCO332-011V	CONNECTOR		
CN306	VMCO332-010V	CONNECTOR		
CN307	EMV5125-008	CONNECTOR		
CN308	EMV5125-013	CONNECTOR		
CN313	EMV7145-003Z	CONNECTOR		
D 1	1SS133	SI DIODE		
D 2	1SS133	SI DIODE		
D 3	1SS133	SI DIODE		
D 4	1SS133	SI DIODE		
D 7	1SS133	SI DIODE		
D 300	RB721Q	DIODE		
D 301	1SS133	SI DIODE		
D 302	1SS133	SI DIODE		
D 303	RB721Q	DIODE		
D 304	1SS133	SI DIODE		
D 305	MTZ5.1JAT-77	ZENER DIODE		
D 306	1SS133	SI DIODE		
D 307	1SS133	SI DIODE		
D 308	1SS133	SI DIODE		
D 310	1SS133	SI DIODE		
D 311	1SS133	SI DIODE		
D 312	1SS133	SI DIODE		
D 313	1SS133	SI DIODE		
D 314	1SS133	SI DIODE		
D 315	1SR35-100	SI DIODE		
D 318	1SS133	SI DIODE		
D 319	1SS133	SI DIODE		
D 322	1SS133	SI DIODE		
D 380	1SS133	SI DIODE		
D 904	MTZ4.3JB	ZENER DIODE		
D 905	1SS133	SI DIODE		
D 906	1SS133	SI DIODE		
D 907	MTZ3.9JB	ZENER DIODE		

BLOCK NO. 01

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
R 112	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 113	GRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 114	GRD161J-105	CARBON RESISTOR	1.0M 5% 1/6W	
R 116	GRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 117	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 118	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 119	GRD161J-822	CARBON RESISTOR	8.2K 5% 1/6W	
R 120	GRD161J-822	CARBON RESISTOR	8.2K 5% 1/6W	
R 121	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 122	GRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
R 123	GRD161J-474	CARBON RESISTOR	4.7K 5% 1/6W	
R 124	GRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
R 125	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 130	GRD161J-823	CARBON RESISTOR	82K 5% 1/6W	
R 201	GRD161J-114	CARBON RESISTOR	1.1K 5% 1/6W	
R 202	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 203	GRD161J-101	CARBON RESISTOR	100 5% 1/6W	
R 204	GRD161J-333	CARBON RESISTOR	33K 5% 1/6W	
R 207	GRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 208	GRD161J-362	CARBON RESISTOR	3.6K 5% 1/6W	
R 209	GRD161J-303Y	CARBON RESISTOR	30K 5% 1/6W	
R 210	GRD161J-184	CARBON RESISTOR	180K 5% 1/6W	
R 211	GRD161J-563	CARBON RESISTOR	56K 5% 1/6W	
R 212	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 213	GRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 214	GRD161J-105	CARBON RESISTOR	1.0M 5% 1/6W	
R 216	GRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 217	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 218	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 219	GRD161J-822	CARBON RESISTOR	8.2K 5% 1/6W	
R 220	GRD161J-822	CARBON RESISTOR	8.2K 5% 1/6W	
R 221	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 222	GRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
R 223	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 224	GRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
R 225	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 230	GRD161J-823	CARBON RESISTOR	82K 5% 1/6W	
R 300	GRD161J-334	CARBON RESISTOR	330K 5% 1/6W	
R 301	GRD161J-473	CARBON RESISTOR	47K 5% 1/6W	
R 302	GRD161J-184	CARBON RESISTOR	180K 5% 1/6W	
R 303	GRD161J-224	CARBON RESISTOR	220K 5% 1/6W	
R 304	GRD161J-124	CARBON RESISTOR	120K 5% 1/6W	
R 305	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 306	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 307	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 308	GRD161J-152	CARBON RESISTOR	1.5K 5% 1/6W	
R 309	GRD161J-101	CARBON RESISTOR	100 5% 1/6W	
R 310	GRD161J-223	CARBON RESISTOR	22K 5% 1/6W	
R 311	GRD161J-124	CARBON RESISTOR	120K 5% 1/6W	
R 313	GRD161J-302	CARBON RESISTOR	3.0K 5% 1/6W	
R 315	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 316	GRD161J-474	CARBON RESISTOR	470K 5% 1/6W	
R 318	GRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 320	GRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 327	GRD161J-223	CARBON RESISTOR	22K 5% 1/6W	

BLOCK NO. 01

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
R 10	GRD161J-152	CARBON RESISTOR	1.5K 5% 1/6W	
R 12	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 13	GRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 14	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 15	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 16	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 20	GRD161J-351	CARBON RESISTOR	350 5% 1/6W	
R 21	GRD161J-224	CARBON RESISTOR	220K 5% 1/6W	
R 22	GRD161J-331	CARBON RESISTOR	330 5% 1/6W	
R 24	GRD161J-271	CARBON RESISTOR	270 5% 1/6W	
R 25	GRD161J-473	CARBON RESISTOR	47K 5% 1/6W	
R 26	GRD161J-273	CARBON RESISTOR	27K 5% 1/6W	
R 27	GRD161J-223	CARBON RESISTOR	22K 5% 1/6W	
R 29	GRD161J-473	CARBON RESISTOR	47K 5% 1/6W	
R 30	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 31	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 34	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 35	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 36	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 37	GRD161J-562	CARBON RESISTOR	5.6K 5% 1/6W	
R 38	GRD161J-352	CARBON RESISTOR	3.5K 5% 1/6W	
R 39	GRD161J-352	CARBON RESISTOR	3.5K 5% 1/6W	
R 42	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 43	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 44	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 45	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 46	GRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 47	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 48	GRD161J-331	CARBON RESISTOR	330 5% 1/6W	
R 49	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 52	GRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
R 54	GRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
R 55	GRD161J-482	CARBON RESISTOR	4.8K 5% 1/6W	
R 56	GRD161J-332	CARBON RESISTOR	3.3K 5% 1/6W	
R 57	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 60	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 61	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 64	GRD161J-473	CARBON RESISTOR	4.7K 5% 1/6W	
R 65	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 66	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 69	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 70	GRD161J-393	CARBON RESISTOR	39K 5% 1/6W	
R 71	GRD161J-823	CARBON RESISTOR	82K 5% 1/6W	
R 72	GRD161J-122	CARBON RESISTOR	1.2K 5% 1/6W	
R 73	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 74	GRD161J-332	CARBON RESISTOR	3.3K 5% 1/6W	
R 75	GRD161J-822	CARBON RESISTOR	8.2K 5% 1/6W	
R 101	GRD161J-114	CARBON RESISTOR	110K 5% 1/6W	
R 102	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 103	GRD161J-101	CARBON RESISTOR	100 5% 1/6W	
R 104	GRD161J-393	CARBON RESISTOR	39K 5% 1/6W	
R 107	GRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 108	GRD161J-362	CARBON RESISTOR	3.6K 5% 1/6W	
R 109	GRD161J-303Y	CARBON RESISTOR	30K 5% 1/6W	
R 110	GRD161J-184	CARBON RESISTOR	180K 5% 1/6W	
R 111	GRD161J-563	CARBON RESISTOR	56K 5% 1/6W	

■ Main Amplifier Board (U/UB/UP/US/UT Version)

BLOCK NO. 0101111111		BLOCK NO. 1011111111		
A REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
BP	1	VBP4M3B-005	B.PASS FILTER	
C	1	QCS11HJ-200	C.CAPACITOR	20PF 5% 50V
C	2	QCSB1HK-102Y	C.CAPACITOR	1000PF 10% 50V
C	3	QCSB1HK-8R2Y	C.CAPACITOR	8.2PF 10% 50V
C	4	QCS11HJ-100	C.CAPACITOR	10PF 5% 50V
C	5	QCSB1HK-4R7Y	C.CAPACITOR	4.7PF 10% 50V
C	6	QCVB1CM-103Y	C.CAPACITOR	.010MF 30% 16V
C	7	QCS11HJ-200	C.CAPACITOR	20PF 5% 50V
C	8	QCVB1CM-103Y	C.CAPACITOR	.010MF 30% 16V
C	9	QCS11HJ-100	C.CAPACITOR	10PF 5% 50V
C	10	QCSB1HK-2R2Y	C.CAPACITOR	2.2PF 10% 50V
C	15	QFV41HJ-104ZM	FILM CAPACITOR	.10MF 5% 50V
C	14	QCSB1HK-102Y	C.CAPACITOR	1000PF 10% 50V
C	15	QET41CM-476	E CAPACITOR	47MF 20% 16V
C	16	QCVB1CM-103Y	C.CAPACITOR	.010MF 30% 16V
C	18	QCVB1CM-103Y	C.CAPACITOR	.010MF 30% 16V
C	19	QCSB1HK-151Y	C.CAPACITOR ZZZ	150PF 10% 50V
C	20	QCSB1HK-102Y	C.CAPACITOR	1000PF 10% 50V
C	21	QCC11EM-473V	C.CAPACITOR	.047MF 20% 25V
C	23	QCT30UJ-100Y	C.CAPACITOR	100PF 5% 50V
C	27	QCSB1HK-102Y	C.CAPACITOR	1000PF 10% 50V
C	29	QCSB1HK-151Y	C.CAPACITOR	150PF 10% 50V
C	30	QCVB1CM-103Y	C.CAPACITOR	.010MF 30% 16V
C	32	QCSB1HK-102Y	C.CAPACITOR	1000PF 10% 50V
C	33	QEK61AM-107Z	E.CAPACITOR	100MF 20% 10V
C	34	QCS11HJ-150	C.CAPACITOR	15PF 5% 50V
C	35	QCVB1CM-103Y	C.CAPACITOR	.010MF 30% 16V
C	36	QEK41CM-106	E.CAPACITOR	10MF 20% 16V
C	37	QCVB1CM-103Y	C.CAPACITOR	.010MF 30% 16V
C	38	QCC11EM-473V	C.CAPACITOR	.047MF 20% 25V
C	39	QCC11EM-473V	C.CAPACITOR	.047MF 20% 25V
C	40	QCVB1CM-103Y	C.CAPACITOR	.010MF 30% 16V
C	41	QEK41HM-104	E.CAPACITOR	.10MF 20% 50V
C	42	QEK41HM-474	E.CAPACITOR	.47MF 20% 50V
C	43	QEK61HM-335ZM	E.CAPACITOR	3.3MF 20% 50V
C	44	QCS11HJ-680	C.CAPACITOR	68PF 5% 50V
C	45	QEK41CM-106	E.CAPACITOR	10MF 20% 16V
C	46	QCC31EM-333ZV	C.CAPACITOR	.033MF 20% 25V
C	47	QCVB1CM-103Y	C.CAPACITOR	.010MF 30% 16V
C	49	QCC31EM-393ZV	C.CAPACITOR	.039MF 20% 25V
C	50	QCC31EM-393ZV	C.CAPACITOR	.039MF 20% 25V
C	51	QEK41HM-105	E.CAPACITOR	1.0MF 20% 50V
C	52	QEK41HM-105	E.CAPACITOR	1.0MF 20% 50V
C	54	QCSB1HK-102Y	C.CAPACITOR	1000PF 10% 50V
C	56	QCSB1HK-151Y	C.CAPACITOR	150PF 10% 50V
C	60	QEK61AM-107Z	E.CAPACITOR	100MF 20% 10V
C	61	QCS11HJ-120	C.CAPACITOR	12PF 5% 50V
C	62	QCS11HJ-120	C.CAPACITOR	12PF 5% 50V
C	63	QCSB1HK-151Y	C.CAPACITOR	150PF 10% 50V
C	65	QCSB1HK-102Y	C.CAPACITOR	1000PF 10% 50V
C	66	QCSB1HK-151Y	C.CAPACITOR	150PF 10% 50V
C	69	QFV41HJ-105	TF.CAPACITOR	1.0MF 5% 50V
C	70	QCSB1CM-392Y	C.CAPACITOR	3900PF 20% 16V
C	71	QET41CM-476	E.CAPACITOR	47MF 20% 16V
C	99	QCC11EM-473V	C.CAPACITOR	.047MF 20% 25V

BLOCK NO. 0101111111		BLOCK NO. 1011111111		
A REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
R	328	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W
R	347	QRD161J-153	CARBON RESISTOR	15K 5% 1/6W
R	350	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W
R	353	QRD161J-823	CARBON RESISTOR	82K 5% 1/6W
R	354	QRD161J-823	CARBON RESISTOR	82K 5% 1/6W
R	355	QRD161J-105	CARBON RESISTOR	1.0M 5% 1/6W
R	356	QRD161J-105	CARBON RESISTOR	1.0M 5% 1/6W
R	357	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
R	358	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
R	361	QRD161J-562	CARBON RESISTOR	5.6K 5% 1/6W
R	380	QRD161J-225	CARBON RESISTOR	2.2M 5% 1/6W
R	381	QRD161J-473	CARBON RESISTOR	47K 5% 1/6W
R	382	QRD161J-220	CARBON RESISTOR	22 5% 1/6W
R	383	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W
R	917	QRD161J-101	CARBON RESISTOR	100 5% 1/6W
R	918	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W
R	919	QRD161J-390	CARBON RESISTOR	39 5% 1/6W
R	920	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
R	921	QRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W
R	922	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W
R	923	QRD161J-151	CARBON RESISTOR	150 5% 1/6W
R	924	GRZ0077-220X	F.RESISTOR	22 1/0W
R	925	QRD161J-473	CARBON RESISTOR	47K 5% 1/6W
R	926	QRD161J-561	CARBON RESISTOR	560 5% 1/6W
R	927	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W
R	928	QRD161J-682	CARBON RESISTOR	6.8K 5% 1/6W
R	929	QRD161J-332	CARBON RESISTOR	3.3K 5% 1/6W
R	930	QRD161J-682	CARBON RESISTOR	6.8K 5% 1/6W
R	979	QRD161J-471	CARBON RESISTOR	470 5% 1/6W
R	980	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W
T	1	VQ17A21-111	I.F.T	
TU	1	VAF2S13-001	FRONT END	
X	1	VCS5044-001	CRYSTAL	

BLOCK NO. 10

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
C 339	QETN1HM-475Z	E-CAPACITOR	4.7MF 20% 50V	
C 340	QETN1CM-106Z	E-CAPACITOR	10MF 20% 16V	
C 342	QFV71HJ-334ZM	TF CAPACITOR	.33MF 5% 50V	
C 343	QFLC1HJ-683ZM	TF CAPACITOR	.068MF 5% 50V	
C 344	QETN1CM-106Z	E-CAPACITOR	10MF 20% 16V	
C 345	QFLC1HJ-683ZM	M-CAPACITOR	6800PF 5% 50V	
C 347	QFN1CM-226Z	E-CAPACITOR	22MF 20% 16V	
C 350	QETN1HM-105Z	E-CAPACITOR	1.0MF 20% 50V	
C 351	EETB1CM-476	E-CAPACITOR	10MF 20% 25V	
C 352	QETN1EM-106Z	E-CAPACITOR	10MF 20% 25V	
C 353	QCB1HK-471Y	C-CAPACITOR	470PF 10% 50V	
C 354	QCB1HK-471Y	C-CAPACITOR	470PF 10% 50V	
C 357	QFTC1CM-226Z	E-CAPACITOR	22MF 20% 16V	
C 361	EETB1HM-105E	E-CAPACITOR	10MF 20% 16V	
C 362	QCB1HK-151Y	C-CAPACITOR	150PF 10% 50V	
C 363	QET41AM-108	E-CAPACITOR	1000MF 20% 10V	
C 364	QET41AM-108	E-CAPACITOR	1000MF 20% 10V	
C 366	QCB1HK-151Y	C-CAPACITOR	150PF 10% 50V	
C 367	QFLC1HJ-104ZM	M-CAPACITOR	.10MF 5% 50V	
C 368	QFLC1HJ-104ZM	M-CAPACITOR	.10MF 5% 50V	
C 380	QCS1HJ-330	C-CAPACITOR	33PF 5% 50V	
C 381	QCB1CM-182Y	C-CAPACITOR	1800PF 20% 16V	
C 382	QFLC1HJ-153ZM	M-CAPACITOR	.015MF 5% 50V	
C 383	QCB1HK-681Y	E-CAPACITOR	680PF 10% 50V	
C 384	EETB1HM-105E	E-CAPACITOR	10MF 20% 16V	
C 385	QET41HM-476	E-CAPACITOR	47MF 20% 50V	
C 908	EETB1HM-475E	E-CAPACITOR	47MF 20% 50V	
C 909	EETB1CM-226E	E-CAPACITOR	22MF 20% 16V	
C 910	EETC1CM-106ZJC	E-CAPACITOR	10MF 20% 16V	
C 911	QFLC1HJ-103ZM	M-CAPACITOR	.010MF 5% 50V	
C 912	QET41AM-107	E-CAPACITOR	100MF 20% 10V	
C 920	QFLC1HJ-103ZM	M-CAPACITOR	.010MF 5% 50V	
C 921	QET41AM-107	E-CAPACITOR	100MF 20% 10V	
C 968	QCVB1CM-103Y	C-CAPACITOR	.010MF 20% 16V	
CF 1	VCF2L3B-108Z	C-FILTER		
CF 2	VCF2L3B-108Z	C-FILTER		
CF 3	VCF1Z2Z-115Z	CERAMIC FILTER		
CF 4	CMU2-456A05	CERA LOCK		
CN302	VMC0332-010V	CONNECTOR		
CN303	VMC0103-02.9	CONNECTOR		
CN304	VMC0332-007V	CONNECTOR		
CN305	VMC0332-011V	CONNECTOR		
CN306	VMC0332-010V	CONNECTOR		
CN307	ENV5125-008	CONNECTOR		
CN308	ENV5125-013	CONNECTOR		
CN310	ENV7145-005Z	SOCKET		
CN313	ENV7145-003Z	SOCKET		
D 1	SVC203SPA-AB-AL	VARI CAP		
D 2	SVC203SPA-AB-AL	VARI CAP		
D 3	1SS133	SI DIODE		
D 4	1SS133	SI DIODE		
D 6	1SS133	SI DIODE		
D 7	1SS133	SI DIODE		
D 11	1SS133	SI DIODE		
D 12	1SS133	SI DIODE		

BLOCK NO. 10

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
C 101	QCS1HJ-330	C-CAPACITOR	33PF 5% 50V	
C 102	QCS1HJ-100	C-CAPACITOR	10PF 5% 50V	
C 103	QTE1H06-475Z	E-CAPACITOR	47MF 5% 50V	
C 104	EETB1CM-226E	E-CAPACITOR	22MF 20% 16V	
C 106	QTE1H06-475Z	E-CAPACITOR	47MF 5% 50V	
C 108	QTE1V06-106Z	E-CAPACITOR	10MF 20% 16V	
C 110	QFV71HJ-124ZM	FILM CAPACITOR	.12MF 5% 50V	
C 111	QFV71HJ-124ZM	FILM CAPACITOR	.12MF 5% 50V	
C 112	QET41AM-107	E-CAPACITOR	100MF 20% 10V	
C 113	QTE1V06-106Z	E-CAPACITOR	10MF 20% 16V	
C 116	QTEC1HM-106ZN	E-CAPACITOR	10MF 20% 50V	
C 122	QETN1HM-335Z	E-CAPACITOR	3.3MF 20% 50V	
C 130	QCS1HJ-820Z	E-CAPACITOR	82PF 5% 50V	
C 201	QCS1HJ-330	C-CAPACITOR	33PF 5% 50V	
C 202	QCS1HJ-100	C-CAPACITOR	10PF 5% 50V	
C 203	QTE1H06-475Z	E-CAPACITOR	47MF 5% 50V	
C 204	QETB1CM-226E	E-CAPACITOR	22MF 20% 16V	
C 206	QTE1H06-475Z	E-CAPACITOR	47MF 5% 50V	
C 208	QTE1V06-106Z	E-CAPACITOR	10MF 20% 16V	
C 210	QFV71HJ-124ZM	FILM CAPACITOR	.12MF 5% 50V	
C 211	QFV71HJ-124ZM	FILM CAPACITOR	.12MF 5% 50V	
C 212	QET41AM-107	E-CAPACITOR	100MF 20% 10V	
C 213	QTE1V06-106Z	E-CAPACITOR	10MF 20% 16V	
C 216	QETC1HM-106ZN	E-CAPACITOR	10MF 20% 50V	
C 222	QETN1HM-335Z	E-CAPACITOR	3.3MF 20% 50V	
C 230	QCS1HJ-820Z	E-CAPACITOR	82PF 5% 50V	
C 301	QCB1HK-102Y	C-CAPACITOR	1000PF 10% 50V	
C 305	QFLC1HJ-223ZM	M-CAPACITOR	.022MF 5% 50V	
C 306	EETB1HM-475E	E-CAPACITOR	47MF 20% 50V	
C 307	EETB1HM-475E	E-CAPACITOR	47MF 20% 50V	
C 308	EETB1CM-226E	E-CAPACITOR	22MF 20% 16V	
C 309	QCS1HJ-150	C-CAPACITOR	15PF 5% 50V	
C 310	QCB1HK-471Y	C-CAPACITOR	470PF 10% 50V	
C 311	QCS1HJ-150	C-CAPACITOR	15PF 5% 50V	
C 312	QCB1HK-151Y	C-CAPACITOR	150PF 10% 50V	
C 313	QCB1HK-471Y	C-CAPACITOR	470PF 10% 50V	
C 314	QETC1HM-224Z	E-CAPACITOR	.22MF 20% 50V	
C 315	QFLC1HJ-103ZM	M-CAPACITOR	.010MF 5% 50V	
C 316	QFLC1HJ-393ZM	M-CAPACITOR	.039MF 5% 50V	
C 317	QFLC1HJ-473ZM	M-CAPACITOR	.047MF 5% 50V	
C 318	QFLC1HJ-103ZM	M-CAPACITOR	.010MF 5% 50V	
C 319	QFLC1HJ-393ZM	M-CAPACITOR	.039MF 5% 50V	
C 320	QFLC1HJ-473ZM	M-CAPACITOR	.047MF 5% 50V	
C 321	EETB1EM-106E	E-CAPACITOR	10MF 20% 16V	
C 322	EETB1AM-476E	E-CAPACITOR	47MF 20% 25V	
C 323	QET41EM-106	E-CAPACITOR	10MF 20% 25V	
C 324	EETC1CM-106ZJC	E-CAPACITOR	10MF 20% 16V	
C 325	EETB1HM-105E	E-CAPACITOR	10MF 20% 16V	
C 327	QFV41HJ-224ZM	M-M-CAPASITOR	.22MF 5% 50V	
C 329	QETB1HM-474N	E-CAPACITOR	.47MF 20% 50V	
C 332	QFLC1HJ-103ZM	M-CAPACITOR	.010MF 5% 50V	
C 334	QFLC1HJ-223ZM	M-CAPACITOR	.022MF 5% 50V	
C 335	QETN1AM-107	E-CAPACITOR	100MF 20% 10V	
C 336	QETN1CM-106Z	E-CAPACITOR	10MF 20% 16V	
C 338	QETN1CM-106Z	E-CAPACITOR	10MF 20% 16V	

BLOCK NO. 20

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
Q 307	2SD2144S(VW)	TRANSISTOR		
Q 308	2SD2144S(VW)	TRANSISTOR		
Q 309	2SC2785	TRANSISTOR		
Q 310	2SC2785	TRANSISTOR		
Q 311	DTA114ES	TRANSISTOR		
Q 312	2SC2785	TRANSISTOR		
Q 314	DTA144ES	D.TRANSISTOR		
Q 315	2SD2144S(VW)	TRANSISTOR		
Q 316	2SD2144S(VW)	TRANSISTOR		
Q 317	2SC2785	TRANSISTOR		
Q 320	DTC144TSTP	TRANSISTOR		
Q 380	2SC2785	TRANSISTOR		
Q 381	2SC2785	TRANSISTOR		
Q 907	2SA1175	TRANSISTOR		
Q 908	2SC2785	TRANSISTOR		
Q 909	2SB1375	TRANSISTOR		
Q 910	2SC2785	TRANSISTOR		
Q 913	2SB1375	TRANSISTOR		
Q 914	2SC2785	TRANSISTOR		
Q 915	2SC2785	TRANSISTOR		
Q 916	2SC2785	TRANSISTOR		
R 1	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 2	QRD161J-473	CARBON RESISTOR	47K 5% 1/6W	
R 3	QRD161J-4R7	CARBON RESISTOR	4.7 5% 1/6W	
R 7	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 8	QRD161J-821	CARBON RESISTOR	820 5% 1/6W	
R 9	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 10	QRD161J-101	CARBON RESISTOR	100 5% 1/6W	
R 11	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 12	QRD161J-560	CARBON RESISTOR	56 5% 1/6W	
R 17	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 18	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 20	QRD161J-331	CARBON RESISTOR	330 5% 1/6W	
R 21	QRD161J-474	CARBON RESISTOR	470K 5% 1/6W	
R 22	QRD161J-331	CARBON RESISTOR	330 5% 1/6W	
R 23	QRD161J-560	CARBON RESISTOR	56 5% 1/6W	
R 24	QRD161J-271	CARBON RESISTOR	270 5% 1/6W	
R 25	QRD161J-273	CARBON RESISTOR	27K 5% 1/6W	
R 26	QRD161J-273	CARBON RESISTOR	27K 5% 1/6W	
R 27	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W	
R 30	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 31	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 32	QRD161J-560	CARBON RESISTOR	56 5% 1/6W	
R 33	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 34	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 35	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 36	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 37	QRD161J-562	CARBON RESISTOR	5.6K 5% 1/6W	
R 38	QRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W	
R 39	QRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W	
R 42	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 43	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 44	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 45	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 46	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	

BLOCK NO. 20

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
D 13	1SS133	SI DIODE		
D 300	RB7210	DIODE		
D 301	1SS133	SI DIODE		
D 302	1SS133	SI DIODE		
D 303	RB7210	DIODE		
D 304	1SS133	SI DIODE		
D 305	MTZ5.1JAT-77	ZENER DIODE		
D 306	1SS133	SI DIODE		
D 307	1SS133	SI DIODE		
D 308	1SS133	SI DIODE		
D 310	1SS133	SI DIODE		
D 311	1SS133	SI DIODE		
D 312	1SS133	SI DIODE		
D 313	1SS133	SI DIODE		
D 314	1SS133	SI DIODE		
D 315	1SR35-100	SI DIODE		
D 318	1SS133	SI DIODE		
D 319	1SS133	SI DIODE		
D 322	1SS133	SI DIODE		
D 380	1SS133	SI DIODE		
D 381	1SS133	SI DIODE		
D 383	1SS133	SI DIODE		
D 904	MTZ4.3JB	ZENER DIODE		
D 905	1SS133	SI DIODE		
D 906	1SS133	SI DIODE		
D 907	MTZ3.9JB	ZENER DIODE		
D 912	RD5.6JSAB1	ZENER DIODE		
D 915	1SS133	SI DIODE		
D 915	1SS133	SI DIODE		
D 928	MTZ2.4JB	ZENER DIODE		
E001	E409T82-0015M	GRAND TERMINAL		
IC 1	TA2057N	IC		
IC 2	LC72136N	IC		
IC 4	TA7358P	IC		
IC 301	NJM4580L	IC		
IC 302	BH3854AS	IC		
IC 303	NJM4580L	IC		
IC 305	BA3837	IC(VOCALFADER)		
J 1	FMMB10YV-401K	ANT TERMINAL		
J A301	EMN00TV-222A12	PIN JACK		
L 1	VQF1820-019	OSC COIL		
L 2	VQC1505-002T	RF COIL		
L 3	VQZ0098-202	COIL BLOCK		
L 4	VQP0018-221	INDUCTOR		
L 306	VQP0028-100Z	INDUCTOR		
PP301	VMZ0015-005	POST PIN		
PP302	VMZ0015-005	POST PIN		
Q 1	2SC1923	TRANSISTOR		
Q 4	DTA114YS	TRANSISTOR		
Q 301	2SD2144S(VW)	TRANSISTOR		
Q 302	2SD2144S(VW)	TRANSISTOR		
Q 303	DTA114YS	TRANSISTOR		
Q 304	2SK246(GR,BL)	FET		
Q 305	2SK246(GR,BL)	FET		
Q 306	DTC144TSTP	TRANSISTOR		

BLOCK NO. 101

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
	R 222	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
	R 223	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	R 224	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
	R 225	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	R 230	QRD161J-823	CARBON RESISTOR	82K 5% 1/6W	
	R 231	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
	R 300	QRD161J-334	CARBON RESISTOR	330K 5% 1/6W	
	R 301	QRD161J-473	CARBON RESISTOR	47K 5% 1/6W	
	R 302	QRD161J-184	CARBON RESISTOR	180K 5% 1/6W	
	R 303	QRD161J-224	CARBON RESISTOR	220K 5% 1/6W	
	R 304	QRD161J-124	CARBON RESISTOR	120K 5% 1/6W	
	R 305	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 306	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 307	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	R 308	QRD161J-152	CARBON RESISTOR	1.5K 5% 1/6W	
	R 309	QRD161J-101	CARBON RESISTOR	100 5% 1/6W	
	R 310	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W	
	R 311	QRD161J-124	CARBON RESISTOR	120K 5% 1/6W	
	R 313	QRD161J-302	CARBON RESISTOR	3.0K 5% 1/6W	
	R 315	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	R 316	QRD161J-474	CARBON RESISTOR	470K 5% 1/6W	
	R 318	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
	R 320	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
	R 321	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 323	QRD161J-221	CARBON RESISTOR	220 5% 1/6W	
	R 327	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W	
	R 328	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W	
	R 330	QRD161J-242	CARBON RESISTOR	2.4K 5% 1/6W	
	R 331	QRD161J-242	CARBON RESISTOR	2.4K 5% 1/6W	
	R 340	QRD161J-153	CARBON RESISTOR	15K 5% 1/6W	
	R 350	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W	
	R 355	QRD161J-823	CARBON RESISTOR	82K 5% 1/6W	
	R 354	QRD161J-823	CARBON RESISTOR	82K 5% 1/6W	
	R 355	QRD161J-105	CARBON RESISTOR	1.0M 5% 1/6W	
	R 356	QRD161J-105	CARBON RESISTOR	1.0M 5% 1/6W	
	R 358	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 361	QRD161J-562	CARBON RESISTOR	5.6K 5% 1/6W	
	R 362	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	R 363	QRD161J-473	CARBON RESISTOR	47K 5% 1/6W	
	R 364	QRD161J-563	CARBON RESISTOR	56K 5% 1/6W	
	R 365	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W	
	R 380	QRD161J-225	CARBON RESISTOR	2.2M 5% 1/6W	
	R 381	QRD161J-473	CARBON RESISTOR	47K 5% 1/6W	
	R 382	QRD161J-220	CARBON RESISTOR	22 5% 1/6W	
	R 383	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
	R 399	QRD161J-101	CARBON RESISTOR	100 5% 1/6W	
	R 400	QRD161J-682	CARBON RESISTOR	6.8K 5% 1/6W	
	R 401	QRD161J-473	CARBON RESISTOR	47K 5% 1/6W	
	R 402	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	R 403	QRD161J-561	CARBON RESISTOR	560 5% 1/6W	
	R 917	QRD161J-101	CARBON RESISTOR	100 5% 1/6W	
	R 918	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
	R 919	QRD161J-390	CARBON RESISTOR	39 5% 1/6W	

BLOCK NO. 102

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
	R 47	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 50	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 52	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
	R 54	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
	R 55	QRD161J-182	CARBON RESISTOR	1.8K 5% 1/6W	
	R 56	QRD161J-332	CARBON RESISTOR	3.3K 5% 1/6W	
	R 57	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 58	QRD161J-562	CARBON RESISTOR	5.6K 5% 1/6W	
	R 59	QRD161J-562	CARBON RESISTOR	5.6K 5% 1/6W	
	R 64	QRD161J-473	CARBON RESISTOR	47K 5% 1/6W	
	R 66	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
	R 67	QRD161J-473	CARBON RESISTOR	47K 5% 1/6W	
	R 69	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	R 101	QRD161J-114	CARBON RESISTOR	110K 5% 1/6W	
	R 102	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 103	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	R 104	QRD161J-393	CARBON RESISTOR	39K 5% 1/6W	
	R 107	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
	R 108	QRD161J-362	CARBON RESISTOR	3.6K 5% 1/6W	
	R 109	QRD161J-303Y	CARBON RESISTOR	30K 5% 1/6W	
	R 110	QRD161J-184	CARBON RESISTOR	180K 5% 1/6W	
	R 111	QRD161J-563	CARBON RESISTOR	56K 5% 1/6W	
	R 112	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 113	QRD161J-104	CARBON RESISTOR	10K 5% 1/6W	
	R 114	QRD161J-105	CARBON RESISTOR	1.0M 5% 1/6W	
	R 116	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
	R 117	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	R 118	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	R 119	QRD161J-822	CARBON RESISTOR	8.2K 5% 1/6W	
	R 120	QRD161J-822	CARBON RESISTOR	8.2K 5% 1/6W	
	R 121	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 122	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
	R 123	QRD161J-474	CARBON RESISTOR	470K 5% 1/6W	
	R 124	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
	R 125	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	R 130	QRD161J-823	CARBON RESISTOR	82K 5% 1/6W	
	R 131	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
	R 201	QRD161J-114	CARBON RESISTOR	110K 5% 1/6W	
	R 202	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 203	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	R 204	QRD161J-333	CARBON RESISTOR	33K 5% 1/6W	
	R 207	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
	R 208	QRD161J-362	CARBON RESISTOR	3.6K 5% 1/6W	
	R 209	QRD161J-303Y	CARBON RESISTOR	30K 5% 1/6W	
	R 210	QRD161J-184	CARBON RESISTOR	180K 5% 1/6W	
	R 211	QRD161J-563	CARBON RESISTOR	56K 5% 1/6W	
	R 212	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 213	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
	R 214	QRD161J-105	CARBON RESISTOR	1.0M 5% 1/6W	
	R 216	QRD161J-124	CARBON RESISTOR	120K 5% 1/6W	
	R 217	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	R 218	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	R 219	QRD161J-822	CARBON RESISTOR	8.2K 5% 1/6W	
	R 220	QRD161J-822	CARBON RESISTOR	8.2K 5% 1/6W	
	R 221	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	

Power Supply & Power Amplifier Board

BLOCK NO. 02

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
C 900	QETM1HM-228	E CAPACITOR	2200MF 20% 50V	
C 901	QETM1HM-228	E CAPACITOR	2200MF 20% 50V	
C 902	QETM1EM-228	E CAPASITOR	2200PF 20% 25V	
C 904	QCBBIHK-221Y	C. CAPASITOR	220PF 10% 50V	
C 905	QET41CM-106	E CAPACITOR	10MF 20% 16V	
C 906	QETN1HM-225Z	E CAPACITOR	2.2MF 20% 50V	
C 907	QET41CM-226	E CAPACITOR	22MF 20% 16V	
C 913	QFLC1HJ-683ZM	M CAPACITOR	.068MF 5% 50V	
C 914	QFLC1HJ-683ZM	M CAPACITOR	.068MF 5% 50V	
C 915	QFLC1HJ-683ZM	M CAPACITOR	.068MF 5% 50V	
C 916	QFLC1HJ-683ZM	M CAPACITOR	.068MF 5% 50V	
C 917	QETN1JM-476Z	E CAPACITOR	47MF 20% 63V	
C 918	QET41HM-226	E CAPACITOR	22MF 20% 50V	
C 919	QETB1JM-107	E CAPACITOR	100MF 20% 63V	
C 922	QET41HM-226	E CAPACITOR	22MF 20% 50V	
C 923	QCVB1CN-103Y	C. CAPACITOR	.010MF 30% 16V	
C 924	QET41HM-475	E CAPACITOR	4.7MF 20% 50V	
C 925	QFLC1HJ-104ZM	M CAPACITOR	.10MF 5% 50V	
C 926	QFLC1HJ-104ZM	M CAPACITOR	.10MF 5% 50V	
C 927	QFLC1HJ-104ZM	M CAPACITOR	.10MF 5% 50V	
C 928	QFLC1HJ-104ZM	M CAPACITOR	.10MF 5% 50V	
C 929	QCS11HJ-100	C. CAPACITOR	10PF 5% 50V	
C 930	QCS11HJ-100	C. CAPACITOR	10PF 5% 50V	
C 931	QET41HM-476	E CAPACITOR	47MF 20% 50V	
C 932	QET41HM-476	E CAPACITOR	47MF 20% 50V	
C 933	QCBBIHK-101Y	C. CAPACITOR	100PF 10% 50V	
C 934	QCBBIHK-101Y	C. CAPACITOR	100PF 10% 50V	
C 935	QTE1V06-106Z	E. CAPACITOR		
C 936	QTE1V06-106Z	E. CAPACITOR		
C 937	QETN1HM-106Z	E CAPACITOR	10MF 20% 50V	
C 938	QETN1HM-106Z	E CAPACITOR	10MF 20% 50V	
C 939	QCBBIHK-101Y	C. CAPACITOR	100PF 10% 50V	
C 940	QCBBIHK-101Y	C. CAPACITOR	100PF 10% 50V	
C 941	QET41HM-226	E CAPACITOR	22MF 20% 50V	
C 942	QET41HM-226	E CAPACITOR	22MF 20% 50V	
C 943	QET41HM-105	E CAPACITOR	1.0MF 20% 50V	
C 944	QFLC1HJ-223ZM	M CAPACITOR	.022MF 5% 50V	
C 945	QET41CM-476	E CAPACITOR	47MF 20% 16V	
C 946	QET41CM-226	E CAPACITOR	22MF 20% 16V	
C 947	QFLC1HJ-223ZM	M CAPACITOR	.022MF 5% 50V	
C 948	QFLC1HJ-223ZM	M CAPACITOR	.022MF 5% 50V	B,E,EN,G
C 949	QFLC1HJ-223ZM	M CAPACITOR	.022MF 5% 50V	B,E,EN,G
C 950	QFLC1HJ-223ZM	M CAPACITOR	.022MF 5% 50V	B,E,EN,G
C 951	QET41HM-105	E CAPACITOR	1.0MF 20% 50V	B,E,EN,G
C 958	QF11HP-223	C. CAPACITOR	.022MF +100:-0%	
C 961	QETN1HM-106Z	E CAPACITOR	10MF 20% 50V	
C 963	QFLC1HJ-223ZM	M CAPACITOR	.022MF 5% 50V	
C 964	QFLC1HJ-223ZM	M CAPACITOR	.022MF 5% 50V	
C 967	QFLC1HJ-104ZM	M CAPACITOR	.10MF 5% 50V	
C 971	QCY31HK-272Z	C. CAPACITOR	2700PF 10% 50V	B,E,EN,G
C 972	QCY31HK-272Z	C. CAPACITOR	2700PF 10% 50V	B,E,EN,G
CN900	EMV7125-013R	CONNECTOR		
CN901	EMV7125-008R	CONNECTOR		
CN903	EMV7145-004Z	CONNECTOR		
CN904	EMV7145-005Z	CONNECTOR		

BLOCK NO. 10

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
R 920	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 921	QRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W	
R 922	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 923	QRD161J-151	CARBON RESISTOR	150 5% 1/6W	
R 924	QRZ0077-220X	FUSI. RESISTOR	22 1/6W	
R 925	QRD161J-473	CARBON RESISTOR	47K 5% 1/6W	
R 926	QRD161J-561	CARBON RESISTOR	560 5% 1/6W	
R 927	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W	
R 928	QRD167J-682	CARBON RESISTOR	6.8K 5% 1/6W	
R 929	QRD167J-332	CARBON RESISTOR	3.3K 5% 1/6W	
R 930	QRD167J-682	CARBON RESISTOR	6.8K 5% 1/6W	
R 979	QRD161J-471	CARBON RESISTOR	470 5% 1/6W	
R 980	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
T 1	VGT7F12-110	IFT		
T 2	VGT7A21-111	IFT		
X 1	VCX5044-001	CRYSTAL		

BLOCK NO. 02

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
R 901	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 902	QRD161J-1R0	CARBON RESISTOR	1.0 5% 1/6W	
R 903	QRD161J-1R0	CARBON RESISTOR	1.0 5% 1/6W	
R 904	QRD161J-1R0	CARBON RESISTOR	1.0 5% 1/6W	
R 905	QRD161J-682	CARBON RESISTOR	6.8K 5% 1/6W	
R 906	QRD161J-122	CARBON RESISTOR	1.2K 5% 1/6W	
R 907	QRD161J-821	CARBON RESISTOR	820 5% 1/6W	
R 908	QRZ0077-151X	F. RESISTOR	150 1/0W	
R 909	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
R 910	QRD161J-471	CARBON RESISTOR	470 5% 1/6W	
R 911	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 912	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 913	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
R 914	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
R 915	QRZ0077-100X	FUSE RESISTOR	10 1/0W	
R 916	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 931	QRD161J-1R0	CARBON RESISTOR	1.0 5% 1/6W	
R 933	QRD161J-1R0	CARBON RESISTOR	1.0 5% 1/6W	
R 935	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 936	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 937	QRD161J-152	CARBON RESISTOR	1.5K 5% 1/6W	
R 938	QRD161J-330	CARBON RESISTOR	330 5% 1/6W	
R 939	QRG01DJ-471X	OMF RESISTOR	470 5% 1/1W	
R 940	QRD14CJ-100SX	CARBON RESISTOR	10 5% 1/4W	
R 941	QRD14CJ-100SX	CARBON RESISTOR	10 5% 1/4W	
R 942	QRD14CJ-100SX	CARBON RESISTOR	10 5% 1/4W	
R 943	QRD14CJ-100SX	CARBON RESISTOR	10 5% 1/4W	
R 944	QRD161J-823	CARBON RESISTOR	82K 5% 1/6W	
R 945	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 946	QRX014J-R22	UNF. MF. RESISTOR	5% 1/1W	
R 947	QRX014J-R22	UNF. MF. RESISTOR	5% 1/1W	
R 948	QRD161J-122	CARBON RESISTOR	1.2K 5% 1/6W	
R 949	QRD161J-122	CARBON RESISTOR	1.2K 5% 1/6W	
R 950	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 951	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 952	QRD14J-561	UNF. C. RESISTOR	560 5% 1/4W	
R 953	QRD14J-561	UNF. C. RESISTOR	560 5% 1/4W	
R 954	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 955	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 956	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W	
R 957	QRD161J-102	CARBON RESISTOR	10K 5% 1/6W	
R 958	QRZ0077-4R7X	FUSE RESISTOR	4.7 1/0W	
R 959	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 960	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W	
R 961	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 962	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 963	QRD161J-122	CARBON RESISTOR	1.2K 5% 1/6W	
R 964	QRD161J-681.	CARBON RESISTOR	680 5% 1/6W	
R 965	QRD161J-681	CARBON RESISTOR	680 5% 1/6W	
R 966	QRD161J-821	CARBON RESISTOR	820 5% 1/6W	
R 967	QRD161J-821	CARBON RESISTOR	820 5% 1/6W	
R 968	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 969	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 971	QRD161J-563	CARBON RESISTOR	56K 5% 1/6W	
R 972	QRD161J-563	CARBON RESISTOR	56K 5% 1/6W	

BLOCK NO. 02

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
CN905	EMW7145-005Z	CONNECTOR		
D 900	1SS133	DIODE		
D 901	MT79-1JA	ZENER DIODE		
D 902	1SR35-100	SI. DIODE		
D 903	1SR35-100	SI. DIODE		
D 908	1NS401TM	SI. DIODE		
D 909	1NS401TM	SI. DIODE		
D 910	1NS401TM	SI. DIODE		
D 911	1NS401TM	SI. DIODE		
D 916	1SR139-200	DIODE		
D 917	1SR139-200	DIODE		
D 918	MT233JC	ZENER DIODE		
D 919	MT26-2JAT-77	ZENER DIODE		
D 920	MT24JC	ZENER DIODE		
D 921	1SS133	DIODE		
D 922	1SS133	DIODE		
D 923	1SS133	DIODE		
D 924	1SS133	DIODE		
D 926	1SS133	DIODE		
D 927	MZ15-IJCT-77	ZENER SIODE		
EP901	E409182-001SM	GRAND TERMINAL		
FT001	EMG7331-003Z	FUSE CLIP		U-UB,UP,US,UT
FT002	EMG7331-003Z	FUSE CLIP		U-UB,UP,US,UT
FT003	EMG7331-003Z	FUSE CLIP		
FT004	EMG7331-003Z	FUSE CLIP		
FT005	EMG7331-003Z	FUSE CLIP		
FT006	EMG7331-003Z	FUSE CLIP		
FT007	EMG7331-003Z	FUSE CLIP		
FT008	EMG7331-003Z	FUSE CLIP		
FW999	EMR39D-25LS	CORD		
IC900	TD47295	IC		
IC901	TD47295	IC		
JA901	FMJ4003-001	TERMINAL		
L 900	ESL0011-R45J1	INDUCTOR		
L 901	ESL0011-R45J1	INDUCTOR		
L 942	VZ0104-003	INDUCTOR		B,E,EN,G
L 971	VZ0104-003	INDUCTOR		B,E,EN,G
Q 901	2SA1175	TRANSISTOR		
Q 902	DTC144TSTP	TRANSISTOR		
Q 903	DTA14TSTP	TRANSISTOR		
Q 904	2SB1375	TRANSISTOR		
Q 905	2SC2785	TRANSISTOR		
Q 906	2SC2785	TRANSISTOR		
Q 911	2SA93A(Q,R)	TRANSISTOR		
Q 912	DTA144ES	TRANSISTOR		
Q 917	2SC945A	TRANSISTOR		
Q 918	2SC945A	TRANSISTOR		
Q 919	2SA935S(RS)	TRANSISTOR		
Q 920	2SC945A	TRANSISTOR		
Q 921	2SD2144S(VW)	TRANSISTOR		
Q 922	2SD2144S(VW)	TRANSISTOR		
Q 923	DTC144YSTP	TRANSISTOR		
Q 924	DTC144YSTP	TRANSISTOR		
R 900	QRD161J-471	CARBON RESISTOR	470 5% 1/6W	

System C P U & Operation Switch Board

BLOCK NO. 03

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
C 461	QEK41CM-476	E.CAPACITOR	47MF 20% 16V	
C 462	QCB11HK-102Y	C.CAPACITOR	100PF 10% 50V	
C 701	QEK51HM-226	E.CAPACITOR	22MF 20% 50V	
C 702	QEK51HM-226	E.CAPACITOR	22MF 20% 50V	
C 703	QV71HJ-124ZM	FILM CAPACITOR	.12MF 5% 50V	
C 704	QCB11HK-151Y	C.CAPACITOR	150PF 10% 50V	
C 705	QCB11HK-151Y	C.CAPACITOR	150PF 10% 50V	
C 708	QCB11HK-151Y	C.CAPACITOR	150PF 10% 50V	
C 709	QCB11HK-102Y	C.CAPACITOR	100PF 10% 50V	
C 713	QCB11HK-102Y	C.CAPACITOR	100PF 10% 50V	
C 714	QCB11HK-102Y	C.CAPACITOR	100PF 10% 50V	
C 715	QER41CM-106	E.CAPACITOR	10MF 20% 16V	
C 716	QER41CM-105VM	E.CAPACITOR	1.0MF 20% 50V	
C 717	QEK61AM-227ZM	E.CAPACITOR	220MF 20% 10V	
C 718	QEK60JM-107ZM	E.CAPACITOR	100MF 20% 6.3V	
C 719	QCB11HK-102Y	C.CAPACITOR	100PF 10% 50V	
C 720	QCS11HJ-220	C.CAPACITOR	22PF 5% 50V	
C 721	QCS11HJ-220	C.CAPACITOR	22PF 5% 50V	
C 722	QCB11HK-102Y	C.CAPACITOR	100PF 10% 50V	
C 723	QCS11HJ-390Z	C.CAPACITOR	39PF 5% 50V	
C 724	QCS11HJ-180	C.CAPACITOR	18PF 5% 50V	
C 725	QCS11HJ-220	C.CAPACITOR	22PF 5% 50V	
C 726	QCS11HJ-390Z	C.CAPACITOR	39PF 5% 50V	
C 727	QCB11HK-102Y	C.CAPACITOR	100PF 10% 50V	
C 728	QCB11HK-102Y	C.CAPACITOR	100PF 10% 50V	
C 730	QCB11HK-102Y	C.CAPACITOR	100PF 10% 50V	
C 731	QCB11HK-101Y	C.CAPACITOR	100PF 10% 50V	
C 732	QEK61AM-227ZM	E.CAPACITOR	220MF 20% 10V	
C 733	QCVB1CM-103Y	C.CAPACITOR	.010MF 30% 16V	
C 734	QCVB1CM-103Y	C.CAPACITOR	.010MF 30% 16V	
C 735	QEK41CM-476	E.CAPACITOR	47MF 20% 16V	
C 840	QCB11HK-102Y	C.CAPACITOR	100PF 10% 50V	
C 841	QCB11HK-102Y	C.CAPACITOR	100PF 10% 50V	
C 842	QCB11HK-102	C.CAPACITOR	100PF 10% 50V	
C 850	QETC1HM-224Z	E.CAPACITOR	.22MF 20% 50V	B, E, EN, G
C 851	EETB1HM-475E	E.CAPACITOR		U, UB, UP, US, UT
C 852	EETB1CM-226E	E.CAPACITOR		U, UB, UP, US, UT
C 853	QFLC1HJ-104ZM	M CAPACITOR	.10MF 5% 50V	U, UB, UP, US, UT
C 854	QETB1HM-474N	E.CAPACITOR		U, UB, UP, US, UT
C 855	QCB1CM-562Y	C.CAPACITOR	5600PF 20% 16V	U, UB, UP, US, UT
C 856	QCB1HK-821	C.CAPACITOR	820PF 10% 50V	U, UB, UP, US, UT
C 857	QFLC1HJ-183ZM	M CAPACITOR	.018MF 5% 50V	U, UB, UP, US, UT
C 858	QFLC1HJ-104ZM	M CAPACITOR	.10MF 5% 50V	U, UB, UP, US, UT
C 859	QFLC1HJ-104ZM	M CAPACITOR	.10MF 5% 50V	U, UB, UP, US, UT
C 860	QCB1CM-682Y	C.CAPACITOR	6800PF 20% 16V	U, UB, UP, US, UT
C 861	QFLC1HJ-183ZM	M CAPACITOR	.018MF 5% 50V	U, UB, UP, US, UT
C 862	QETC1HM-224Z	E.CAPACITOR	.22MF 20% 50V	U, UB, UP, US, UT
C 863	QETC1HM-224Z	E.CAPACITOR	.22MF 20% 50V	U, UB, UP, US, UT
C 864	QFLC1HJ-104ZM	M CAPACITOR	.10MF 5% 50V	U, UB, UP, US, UT
C 865	QEK41HM-474	E.CAPACITOR	.47MF 20% 50V	U, UB, UP, US, UT
C 866	QCB1CM-562Y	C.CAPACITOR	5600PF 20% 16V	U, UB, UP, US, UT
C 867	QCB1HK-821	C.CAPACITOR	820PF 10% 50V	U, UB, UP, US, UT
C 868	QCB1HK-221Y	C.CAPACITOR	220PF 10% 50V	U, UB, UP, US, UT
C 869	QCB1HK-221Y	C.CAPACITOR	220PF 10% 50V	U, UB, UP, US, UT

BLOCK NO. 02

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
R 973	QRD167J-4R7	CARBON RESISTOR	4.7 5% 1/6W	B, E, EN, G
R 974	QRD167J-4R7	CARBON RESISTOR	4.7 5% 1/6W	B, E, EN, G
R 975	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 976	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 977	QRD161J-823	CARBON RESISTOR	82K 5% 1/6W	
R 978	QRD161J-823	CARBON RESISTOR	82K 5% 1/6W	U, UB, UP, US, UT
R 997	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	U, UB, UP, US, UT
R 998	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	U, UB, UP, US, UT
R 999	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	U, UB, UP, US, UT
RY901	ESK7D24-213R	RELAY		
S 001	QSW0524-001	LEVER SWITCH		U, UB, UP, US, UT
TB001	EMZ4001-002Z	TAB		
TB002	EMZ4001-002Z	TAB		

BLOCK NO. 05

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
	Q 470	DTC114ESTP	TRANSISTOR		
	Q 471	DTC114ESTP	TRANSISTOR		
	Q 472	DTA114ES	TRANSISTOR		
	Q 473	DTA114ES	TRANSISTOR		
	Q 703	25C2785	TRANSISTOR		
	Q 704	DTC114TSTP	TRANSISTOR		
	Q 705	25A1175	TRANSISTOR		
	Q 706	25C2668(O)	TRANSISTOR		
	Q 707	25C2668(O)	TRANSISTOR		
	Q 710	DTC114ESTP	TRANSISTOR		
	Q 711	25D2144S(VW)	TRANSISTOR		
	Q 771	25C945(P,Q)	TRANSISTOR		
	Q 772	25C945(P,Q)	TRANSISTOR		
	Q 773	25C945(P,Q)	TRANSISTOR		
	Q 850	DTC144ES	D. TRANSISTOR		U,UB,UP,US,UT
	Q 851	25D2144S(VW)	TRANSISTOR		U,UB,UP,US,UT
	R 470	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 471	GRD161J-122	CARBON RESISTOR	1.2K 5% 1/6W	
	R 472	GRD161J-152	CARBON RESISTOR	1.5K 5% 1/6W	
	R 473	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	R 474	GRD161J-272	CARBON RESISTOR	2.7K 5% 1/6W	
	R 475	GRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W	
	R 476	GRD161J-562	CARBON RESISTOR	5.6K 5% 1/6W	
	R 477	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	R 478	GRD161J-183	CARBON RESISTOR	18K 5% 1/6W	
	R 479	GRD161J-473	CARBON RESISTOR	47K 5% 1/6W	B,E,EN,G
	R 480	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	R 481	GRD161J-183	CARBON RESISTOR	18K 5% 1/6W	
	R 482	GRD161J-473	CARBON RESISTOR	47K 5% 1/6W	
	R 484	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 486	GRD161J-271	CARBON RESISTOR	270 5% 1/6W	
	R 487	GRD161J-271	CARBON RESISTOR	270 5% 1/6W	
	R 488	GRD161J-271	CARBON RESISTOR	270 5% 1/6W	
	R 489	GRD161J-271	CARBON RESISTOR	270 5% 1/6W	
	R 490	GRD161J-301	CARBON RESISTOR	300 5% 1/6W	
	R 491	GRD161J-301	CARBON RESISTOR	300 5% 1/6W	
	R 491	GRD161J-301	CARBON RESISTOR	300 5% 1/6W	
	R 690	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 691	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 692	GRD161J-122	CARBON RESISTOR	1.2K 5% 1/6W	
	R 693	GRD161J-152	CARBON RESISTOR	1.5K 5% 1/6W	
	R 694	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	R 695	GRD161J-272	CARBON RESISTOR	2.7K 5% 1/6W	
	R 696	GRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W	
	R 697	GRD161J-562	CARBON RESISTOR	5.6K 5% 1/6W	
	R 698	GRD161J-753	CARBON RESISTOR	75K 5% 1/6W	B,E,EN,G
	R 700	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	R 701	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	R 702	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	R 703	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	R 704	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	R 705	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	R 707	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 708	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	R 709	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	

BLOCK NO. 06

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
	C 870	QCBB1HK-221Y	C. CAPACITOR	220PF 10% 50V	U,UB,UP,US,UT
	C 871	QFLC1HJ-103ZM	M CAPACITOR	.010MF 5% 50V	U,UB,UP,US,UT
	C 872	QETB1HM-475E	E. CAPACITOR		U,UB,UP,US,UT
	C 873	QET41AM-227	E. CAPACITOR	220MF 20% 10V	U,UB,UP,US,UT
	C 874	EETB1AM-107E	E. CAPACITOR		U,UB,UP,US,UT
	C 875	EETB1HM-475E	E. CAPACITOR		U,UB,UP,US,UT
	C 876	QCBB1HK-151Y	C. CAPACITOR	150PF 10% 50V	U,UB,UP,US,UT
	C 878	QCBB1HK-151Y	C. CAPACITOR	150PF 10% 50V	U,UB,UP,US,UT
	C 879	QCBB1HK-331Y	C. CAPACITOR	330PF 10% 50V	U,UB,UP,US,UT
	C 880	QETC1HM-225ZM	E. CAPACITOR	2.2MF 20% 50V	U,UB,UP,US,UT
	C 883	QET41CM-107	E. CAPACITOR	100MF 20% 16V	U,UB,UP,US,UT
	C 884	QET41CM-227	E. CAPACITOR	220MF 20% 16V	U,UB,UP,US,UT
	CN700	EMV7160-011	CONNECTOR		U,UB,UP,US,UT
	CN701	VMC0165-R29	CONNECTOR		U,UB,UP,US,UT
	CN840	EMV7125-004R	CONNECTOR		U,UB,UP,US,UT
	CN852	EMV5125-004	CONNECTOR		U,UB,UP,US,UT
	D 411	SLA-380LT	LED		
	D 412	SLR-342MCA47	LED		
	D 413	SLR-342MCA47	LED		
	D 414	SLR-342MCA47	LED		
	D 415	SLR-342MCA47	LED		
	D 701	1S8133	SI DIODE		
	D 702	1S8133	SI DIODE		
	D 703	1S8133	SI DIODE		
	D 704	1S8133	SI DIODE		
	D 705	MTZ5-1JAT-77	ZENER DIODE		
	D 706	1S8133	SI DIODE		
	D 850	MTZ5-1JUB	ZENER DIODE		U,UB,UP,US,UT
	D 851	1S8133	SI DIODE		U,UB,UP,US,UT
	FL701	QLF0021-001	FL TUBE		
	FW700	VWSC02-103K3K	TM FLAT		
	FW701	VWSC06-093K3K	EF FLAT WIRE		
	FW702	VWSC06-093K3K	EF FLAT WIRE		
	FW852	EMR350-30LS	FLAT WIRE		U,UB,UP,US,UT
	IC404	GP1U261X	IR DETECT UNIT		
	IC701	UPD78044FGF-055	IC		
	IC850	BA7725S	IC		U,UB,UP,US,UT
	IC851	BU9251S	IC		U,UB,UP,US,UT
	IC852	BA15218N	IC		U,UB,UP,US,UT
	J 850	VNJ4024-001	JACK	HEAD PHONE	
	J 851	ONS0007-002	6.3 JACK	MIC JACK	
	J 852	ONS0007-002	6.3 JACK	MIC JACK	
	J5701	6SW0536-001	ROTARY ENCODER		
	L 701	VGP0026-470Z	INDUCTOR		
	L 702	VGP0026-470Z	INDUCTOR		
	L 703	VGP0033-100Z	INDUCTOR		
	L 704	VGP0018-4R7	INDUCTOR		
	L 705	VGP0018-4R7	INDUCTOR		
	L 706	VGP0033-100Z	INDUCTOR		
	L 707	VGP0033-100Z	INDUCTOR		
	L 708	VGP0018-230	INDUCTOR		
	L 709	V0Z0048-009	INDUCTOR		
	L 840	EGL4007-2R2T	INDUCTOR	HP GND(D401T)	
	L 841	VGP0018-470	INDUCTOR	EMC	B,E,EN,G
	L 842	VGP0018-470	INDUCTOR	EMC	B,E,EN,G

BLOCK NO. 03

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
R 770	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W	
R 771	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W	
R 772	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 773	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 774	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
R 775	QRD161J-331	CARBON RESISTOR	330 5% 1/6W	
R 776	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 777	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 778	QRD161J-224	CARBON RESISTOR	220K 5% 1/6W	
R 779	QRD161J-105	CARBON RESISTOR	1.0M 5% 1/6W	
R 780	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
R 781	QRD161J-822	CARBON RESISTOR	8.2K 5% 1/6W	
R 782	QRD161J-822	CARBON RESISTOR	8.2K 5% 1/6W	
R 783	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
R 784	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 785	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 786	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 787	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 788	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 789	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 790	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 791	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 792	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 793	QRD161J-122	CARBON RESISTOR	1.2K 5% 1/6W	
R 794	QRD161J-152	CARBON RESISTOR	1.5K 5% 1/6W	
R 795	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 796	QRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W	
R 797	QRD161J-562	CARBON RESISTOR	5.6K 5% 1/6W	
R 800	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 801	QRD161J-473	CARBON RESISTOR	47K 5% 1/6W	
R 840	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
R 841	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
R 850	QRD161J-123	CARBON RESISTOR	12K 5% 1/6W	
R 851	QRD161J-333	CARBON RESISTOR	33K 5% 1/6W	
R 852	QRD161J-123	CARBON RESISTOR	12K 5% 1/6W	
R 853	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 854	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 855	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 856	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
R 857	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 858	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 859	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 860	QRD161J-331	CARBON RESISTOR	330 5% 1/6W	
R 861	QRD161J-682	CARBON RESISTOR	6.8K 5% 1/6W	
R 862	QRD161J-105	CARBON RESISTOR	1.0M 5% 1/6W	
R 864	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 865	QRD161J-123	CARBON RESISTOR	12K 5% 1/6W	
R 866	QRD161J-391	CARBON RESISTOR	390 5% 1/6W	
R 867	QRD161J-152	CARBON RESISTOR	1.5K 5% 1/6W	
R 868	QRD161J-475	CARBON RESISTOR	4.7M 5% 1/6W	
R 869	QRD161J-430	CARBON RESISTOR	43 5% 1/6W	
R 870	QRD161J-273	CARBON RESISTOR	27K 5% 1/6W	
R 873	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 874	QRD161J-561	CARBON RESISTOR	560 5% 1/6W	


BLOCK NO. 03

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
R 710	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 711	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 712	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 713	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 714	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 715	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 716	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 717	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 718	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 719	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 720	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 721	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 722	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 723	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 724	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 725	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 726	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 727	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 728	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 729	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 730	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 731	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 732	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 733	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 736	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 737	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 738	QRD161J-224	CARBON RESISTOR	220K 5% 1/6W	
R 739	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 740	QRD161J-224	CARBON RESISTOR	220K 5% 1/6W	
R 741	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 742	QRD161J-224	CARBON RESISTOR	220K 5% 1/6W	
R 743	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 744	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 745	QRD161J-473	CARBON RESISTOR	47K 5% 1/6W	
R 747	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 748	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 750	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 752	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 753	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 754	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
R 755	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 756	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 757	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 758	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 759	QRD161J-273	CARBON RESISTOR	27K 5% 1/6W	
R 760	QRD161J-563	CARBON RESISTOR	56K 5% 1/6W	
R 761	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
R 762	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 764	QRD161J-273	CARBON RESISTOR	27K 5% 1/6W	
R 765	QRD161J-331	CARBON RESISTOR	330 5% 1/6W	
R 766	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 767	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
R 768	QRD161J-560	CARBON RESISTOR	56 5% 1/6W	
R 768	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 769	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	

BLOCK NO. 05

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
R 875	GRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	U,UB,UP,US,UT
R 876	GRD161J-221	CARBON RESISTOR	220 5% 1/6W	U,UB,UP,US,UT
R 877	GRD161J-153	CARBON RESISTOR	15K 5% 1/6W	U,UB,UP,US,UT
R 878	GRD161J-221	CARBON RESISTOR	220 5% 1/6W	U,UB,UP,US,UT
R 879	GRD161J-152	CARBON RESISTOR	1.5K 5% 1/6W	U,UB,UP,US,UT
R 880	GRD161J-221	CARBON RESISTOR	220 5% 1/6W	U,UB,UP,US,UT
R 881	GRD161J-823	CARBON RESISTOR	82K 5% 1/6W	U,UB,UP,US,UT
R 882	GRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W	U,UB,UP,US,UT
RAY00	GRB139J-224	NET RESISTOR	220K 5% 1/3W	U,UB,UP,US,UT
RAY01	GRB149J-224	R-NETWORK	220K 5% 1/4W	
S 406	GSQ1A11-V04Z	TACT SWITCH		
S 407	GSQ1A11-V04Z	TACT SWITCH		
S 408	GSQ1A11-V04Z	TACT SWITCH		
S 409	GSQ1A11-V04Z	TACT SWITCH		
S 414	GSQ1A11-V04Z	TACT SWITCH		
S 415	GSQ1A11-V04Z	TACT SWITCH		
S 416	GSQ1A11-V04Z	TACT SWITCH		
S 417	GSQ1A11-V04Z	TACT SWITCH		
S 418	GSQ1A11-V04Z	TACT SWITCH		
S 422	GSQ1A11-V04Z	TACT SWITCH		
S 423	GSQ1A11-V04Z	TACT SWITCH		
S 424	GSQ1A11-V04Z	TACT SWITCH		
S 425	GSQ1A11-V04Z	TACT SWITCH		
S 426	GSQ1A11-V04Z	TACT SWITCH		
S 700	GSQ1A11-V04Z	TACT SWITCH		
S 701	GSQ1A11-V04Z	TACT SWITCH		
S 702	GSQ1A11-V04Z	TACT SWITCH		
S 703	GSQ1A11-V04Z	TACT SWITCH		
S 704	GSQ1A11-V04Z	TACT SWITCH		
S 705	GSQ1A11-V04Z	TACT SWITCH		
S 706	GSQ1A11-V04Z	TACT SWITCH		
S 707	GSQ1A11-V04Z	TACT SWITCH		
S 708	GSQ1A11-V04Z	TACT SWITCH		
S 709	GSQ1A11-V04Z	TACT SWITCH		
S 714	GSQ1A11-V04Z	TACT SWITCH		
S 715	GSQ1A11-V04Z	TACT SWITCH		
SP701	VYH7653-001	IC HOLDER		
VR840	QVQ0045-B54	V RESISTOR	MIC VR	U,UB,UP,US,UT
X 701	VCX5000-002	CRYSTAL		
X 702	M274.19	CERA LOCK		
X 850	ECX0000-400KS	RESONATOR		U,UB,UP,US,UT

14.Packing



■ Packing Parts List (B/E/EN/G/VX Version)

BLOCK NO. M6MM


△	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
	P 1	E309758-002	POLY BAG	FOR INSTRUCTION	1		
	P 2	FMPC9004-001	CARTON ASSY	FOR SET	1	B, E, EN, G	
		FMPC9004-002	CARTON ASSY	FOR SET	1	U, UP, UB, US, J	
	P 3	FMPH1013-001	CUSHION	FOR SET, UPPER	1		
	P 4	FMPH1014-001	CUSHION	FOR SET, BOTTOM	1		
	P 5	E309758-017	POLY BAG	FOR SET	1		
	P 6	-----	COMPUTER LABEL		1		
	P 8	QPGA010-01505	POLY BAG	FOR POWER CORD	1	B, UB	
	P 10	FMND3007-007	RATING LABEL		1	UT	
	P 11	E307733-166	CARTON ASSY	SPEAKER	1		
	P 12	E103116-001	CUSHION	SPEAKER TOP	1		
	P 13	E208754-001	CUSHION	SP BOTTOM FRONT	1		
	P 14	E208754-002	CUSHION	SP BOTTOM REAR	1		
	P 15	E309822-016	POLY BAG	SPEAKER	2		
	P 16	LE40198-007A	RATING LABEL	RIGHT SPEAKER	1		
	P 17	LE40198-008A	RATING LABEL	LEFT SPEAKER	1		
	P 18	-----	CARTON LABEL	SPEAKER	1		
	P 19	E409074-001	CARTON SHEET	SPEAKER	1		

■ Accessories Parts List (B/E/EN/G/VX Version)

BLOCK NO. M7MM

△	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
	A 1	EQB4001-015	AM LOOP ANT		1		
	A 2	FMUN9003-671M	INSTRUCTIONS		1	B	
		FMUN9003-251M	INSTRUCTIONS		1	E	
		FMUN9003-261M	INSTRUCTIONS		1	E, EN, G	
		FMUN9003-271M	INSTRUCTIONS		1	EN	
		FMUN9002-181M	INSTRUCTIONS		1	U, UB, US, UT	
		FMUN9002-151M	INSTRUCTIONS		1	UP	
	A 3	EWP503-001	ANTENNA WIRE		1	B, E, EN, G	
		EWP201-011	ANTENNA WIRE		1	U, UB, UP, US, J	
	A 5	BT-54003-1	WARRANTY CARD		1	B	
		BT-20134	WARRANTY CARD		1	G	
		BT-56004-4	WARRANTY CARD		1	UP	
	A 6	BT-20066A	SERVICE NETWORK		1	B	
	A 7	E43486-340A	SAFETY SHEET		1	B	
	A 8	RM-SED40TEU	REMOCON		1	B, E, EN, G	
		RM-SED50TXU	REMOCON		1	U, UB, UP, US, J	
	A 9	R6PPTT-2STSM	BATTERY		1		
	A 10	ENZ2202-001	AC PLUG ADAPTER		1	US	
	A 11	VMZ0139-001	CONNECT PLUG		1	U, UT	
	A 12	LET0058-001A	INSTRUCTIONS(E)	SPEAKER	1		
		LET0057-001A	INSTRUCTIONS(U)	SPEAKER	1		
	A 13	E407448-001	SPEAKER CORD		2		
	A 14	-----	SPEAKER ASS'Y	LEFT	1		
	A 15	-----	SPEAKER ASS'Y	RIGHT	1		

MX-D501T




JVC

VICTOR COMPANY OF JAPAN LIMITED

AUDIO DIVISION 10-1, 1-chome, Ohwatari-machi, Maebashi-city, Japan

(No. 10049)

 Printed in Japan
-H0907-V-