


# Service Service Service

Service Manual 1918



# Service Manual

**COMPACT**  
**disc**  
**DIGITAL AUDIO**

## TABLE OF CONTENTS

chapter	chapter
Handling chip components and safety .....	1 - 1
Technical Specification & Service Tools .....	2 - 1
Service Measurement .....	2 - 2
Connections & Controls .....	3 - 1
Instructions for use .....	3 - 2 to 3 - 5
Disassembly Diagram .....	4 - 1
CD Service Test Program .....	4 - 2 to 4 - 3
Block Diagram .....	5 - 1
Wiring Diagram .....	6 - 1
FRONT BOARD	
circuit diagram .....	7 - 1
layout diagram .....	7 - 2
TUNER BOARD	
circuit diagram .....	8 - 1
layout diagram .....	8 - 2
MAIN BOARD	
circuit diagram .....	9 - 1
layout diagram .....	9 - 2
RECORDER BOARD	
circuit diagram .....	10 - 1
layout diagram .....	10 - 2
CD MODULE	
layout diagram .....	11 - 1
circuit diagram .....	11 - 2
EXPLODED VIEWS DIAGRAM	
cabinet .....	12 - 1
tape deck .....	12 - 2
Mechanical partslist .....	12 - 2
Electrical partslist .....	13 - 1 to 13 - 4

Safety regulations require that the set be restored to its original condition and that parts which are identical with those specified be used.


©Copyright 1995 Philips Consumer Electronics B.V. Eindhoven, The Netherlands  
All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form or by any means, electronic, mechanical, photocopying, or otherwise without the prior permission of Philips.

**CLASS 1  
LASER PRODUCT**



**PHILIPS**

# HANDLING CHIP COMPONENTS



## GB WARNING

All ICs and many other semiconductors are susceptible to electrostatic discharges (ESD). Careless handling during repair can reduce life drastically.

When repairing, make sure that you are connected with the same potential as the mass of the set via a wrist wrap with resistance. Keep components and tools at this potential.

## F ATTENTION

Tous les IC et beaucoup d'autres semi-conducteurs sont sensibles aux décharges statiques (ESD). Leur longévité pourrait être considérablement écourtée par le fait qu'aucune précaution n'est prise à leur manipulation.

Lors de réparations, s'assurer de bien être relié au même potentiel que la masse de l'appareil et enfileer le bracelet serti d'une résistance de sécurité.

Veiller à ce que les composants ainsi que les outils que l'on utilise soient également à ce potentiel.



## D WARNUNG

Alle ICs und viele andere Halbleiter sind empfindlich gegenüber elektrostatischen Entladungen (ESD). Unsorgfältige Behandlung im Reparaturfall kann die Lebensdauer drastisch reduzieren.

Sorgen Sie dafür, daß Sie im Reparaturfall über ein Pulssarmband mit Widerstand mit dem Massepotential des Gerätes verbunden sind.

Halten Sie Bauteile und Hilfsmittel ebenfalls auf diesem Potential.

4822 466 10953  
4822 466 10958  
4822 395 10223  
4822 320 11307  
4822 320 11305  
4822 320 11306  
4822 320 11308  
4822 310 10671  
4822 344 13999

## GB

Safely regulations require that the set be restored to its original condition and that parts which are identical with those specified be used.

Safety components are marked by those symbol. ▲

## S Varning !

Osynlig laserstrålning när apparaten är öppnad och spärren är urkopplad. Beträkta ej strålen.

## DK Advarsel !

Usynlig laserstrålning ved åbning når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling.

## SF Varoitus !

Avatussa laitteessa ja suojaoluksien ohittamisessa olet alttiina näkymättömiin lasersäteilyihin. Älä katso sätteeseen!

## NL WAARSCHUWING

Alle IC's en vele andere halfgeleiders zijn gevoelig voor elektrostatische ontladingen (ESD).

Onzorgvuldig behandelen tijdens reparatie kan de levensduur drastisch doen verminderen. Zorg ervoor dat u tijdens reparatie via een polsband met weerstand verbonden bent met hetzelfde potentiaal als de massa van het apparaat.

Houd componenten en hulpmiddelen ook op ditzelfde potentiaal.

## I AVVERTIMENTO

Tutti IC e parechi semi-conduttori sono sensibili alle scariche statiche (ESD).

La loro longevità potrebbe essere fortemente ridotta in caso di non osservazione della più grande cautela alla loro manipolazione. Durante le riparazioni occorre quindi essere collegato allo stesso potenziale che quello della massa dell'apparecchio tramite un braccialetto a resistenza.

Assicurarsi che i componenti e anche gli utensili con quali si lavora siano anche a questo potenziale.

## GB WARNING

Safety regulations require that the set be restored to its original condition and that parts which are identical with those specified be used.

## F ATTENTION

Les normes de sécurité exigent que l'appareil soit remis à l'état d'origine et que soient utilisées les pièces de rechange identiques à celles spécifiées.

## D WARNUNG

Bei jeder Reparatur sind die geltenden Sicherheitsvorschriften zu beachten. Der Originalzustand des Gerätes darf nicht verändert werden. Für Reparaturen sind Originalersatzteile zu verwenden.

## NL WAARSCHUWING

Veiligheidsbepalingen vereisen, dat het apparaat in zijn oorspronkelijke toestand wordt teruggebracht en dat onderdelen, identiek aan de gespecificeerde, worden toegepast.

## I AVVERTIMENTO

Le norme di sicurezza estigono che l'apparecchio venga rimesso nelle condizioni originali e che siano utilizzati i pezzi di ricambio identici a quelli specificati.

## GB

After servicing and before returning the set to customer perform a leakage current measurement test from all exposed metal parts to earth ground, to assure no shock hazard exists.

The leakage current must not exceed 0.5mA.

## F

"Pour votre sécurité, ces documents doivent être utilisés par des spécialistes agréés, seuls habilités à réparer votre appareil en panne".

## TECHNICAL SPECIFICATIONS

## **GENERAL**

Mains voltage	-/00 : 230 V -/01/11 : 120/230 V -/05/10/14 : 240 V -/17 : 120 V
Mains frequency	-/00/05/10/14 : 50 Hz -/01/11 : 50 / 60 Hz -/17 : 60 Hz
Battery	mains : 9 V (R14 x 6) Remote : 3V (R03 x 2)
Power consumption	: < 35 W
Dimension (W x H x D)	: 256 x 208 x 265 mm
Weight	: 3.2 Kg

AMPLIFIER

Output power	mains : 2 x 1.6 W battery : 2 x 2 W
Speaker impedance	: 2 x 4 ohm
Frequency response	: 100 Hz - 8 kHz ( $\pm 3\text{dB}$ )

## **TUNER - FM SECTION**

Tuning range	: 87.5 - 108 MHz
IF frequency	: 10.7 MHz
Sensitivity	: < 22 dB at 26dB S/N
Selectivity	: > 20 dB at $\pm 300\text{kHz}$
IF rejection	: > 50 dB
Image rejection	: > 20 dB

## **TUNER - AM SECTION**

Tuning range	MW : 522 - 1607 kHz -17 : 520 - 1730 kHz
IF frequency	: 468 kHz ± 3 kHz
Sensitivity	MW : < 4000 µV/m at 26dB S/N
Selectivity	MW : < 16 dB
IF rejection ratio	MW : < 24 dB
Image rejection ratio	MW : < 28 dB

## **AUDIO CASSETTE RECORDER**

Number of tracks	:	1 stereo
Tape speed	:	4.76 cm/sec $\pm$ 3%
Wow & flutter	:	< 0.48 % JIS UWTD
Fast wind/rewind C60	:	< 110 sec.
Frequency response	P/B :	125 - 6300 Hz
S/N ratio	:	> 40 dB

## **COMPACT DISC**


Frequency response	:	63 Hz - 16 kHz
S/N ratio	:	> 50 dB
Channel difference	1 kHz :	< 3 dB
Channel crosstalk	1 kHz :	> 26 dB
Laser wavelength	:	$780 \pm 20$ nm
Laser light power	:	< 0.3 mW

## SERVICE TOOLS

<b>TORX T10</b> screwdriver with shaftlength 150mm.....	4822 395 50423
<b>TORX screwdriver set</b> SBC 163.....	4822 295 50145
<b>Audio signal disc</b> SBC 429.....	4822 397 30184
<b>Playability test disc</b> SBC 444.....	4822 397 30245
<b>Test disc 5</b> (disc without errors ) +	
<b>Test disc 5A</b> (disc with dropout errors, black spots and fingerprints)	
SBC 426/426A.....	4822 397 30096
<b>Burn in test disc</b> (65 min. 1kHz signal at -30 dB level without "pause")....	4822 397 30155
<b>Universal test cassette Fe</b> SBC 420 .....	4822 397 30071


## SERVICE MEASUREMENTS

### Tuner FM



Use a bandpass filter to eliminate hum (50Hz, 100Hz) and disturbance from the pilottone (19kHz, 38kHz).

### Tuner AM (MW,LW)





To avoid atmospheric interference all AM-measurements have to be carried out in a Faraday's cage.  
Use a bandpass filter (or at least a high pass filter with 250Hz) to eliminate hum (50Hz, 100Hz).

### CD


Use Audio Signal Disc SBC429 4822 397 30184  
(replaces test disc 3)

### RECORDER

Use Universal Test Cassette Fe SBC420 4822 397 30071



## CONNECTIONS AND CONTROLS



### TOP AND FRONT PANELS

- (1) **Source selector:** **OFF/TAPE, CD, BAND (FM/AM)** – to select source of sound, and also the power OFF switch
- (2) **DBB (Dynamic Bass Boost)** – to enhance bass response
- (3) **VOLUME** – to adjust the volume level
- (4) **CASSETTE RECORDER PAUSE II** – to interrupt recording or playback
- (5) **STOP•OPEN** ─ ▲ – to stop the tape and to open the cassette holder
- (6) **SEARCH** ─ ▲ or ─ ▼ – to fast wind / rewind the tape
- (7) **PLAY** ─ ▲ – to start playback
- (8) **RECORD** ─ ● – to start recording
- (9) **Remote sensor**
- (10) **CD display** – to show the CD functions
- (11) **CD PLAYER**
- (12) **STOP** ─ ■ – to stop playback
- (13) **PLAY•PAUSE** ─ ▲ – to start or interrupt CD play
- (14) **CD MODE** – to select a different play mode, to program and review programmed track numbers
- (15) **SEARCH** ─ ▲/─ ▼ – to skip or search a passage/ track backwards or forward

(8) ─ 3.5 mm headphone socket  
**Note:** Connecting headphones will mute the speakers

### Cassette compartment

- (9) **Cassette compartment**
- (10) **OPEN** – to open/ close the CD door
- (11) **Tuning dial pointer**
- (12) **TUNING** – to tune to radio stations

### BACK PANEL

- (13) **Telescopic antenna** – to improve FM reception
- (14) **Battery door** – to open the battery compartment
- (15) **AC MAINS** – inlet for power cord


### REMOTE CONTROL

- (1) ─ ▲ – to start or interrupt CD play
- (2) ─ ■ – to stop playback
- (3) ─ ▲/─ ▼ – to skip or search a passage/ track backwards or forward

### Environmental information

All unnecessary packaging material has been omitted. The packaging can be easily separated into three materials: cardboard, polystyrene and plastic.

Your set consists of materials which can be recycled if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packing materials, dead batteries and old equipment.





# INSTRUCTIONS FOR USE

3-2

Whenever convenient, use the power supply if you want to conserve battery life. Make sure you remove the plug from the set and wall outlet before inserting batteries.

## BATTERIES (OPTIONAL)

1. Open the battery compartment and insert six batteries, type **R-14, UM-2 or C-cells**, (preferably alkaline) with the correct polarity as indicated by the "+" and "-" symbols inside the compartment.
  2. Replace the compartment door, making sure the batteries are firmly and correctly in place. The set is now ready to operate.  
*Incorrect use of batteries can cause electrolyte leakage and will corrode the compartment or cause the batteries to burst. Therefore:*
- Do not mix battery types, e.g. alkaline with carbon zinc.
  - Only use batteries of the same type for the set.
  - When inserting new batteries, do not try to mix old batteries with the new ones.
  - Remove the batteries if the set is not to be used for a long time.



Connected to the mains.

The battery supply is switched off when the set is connected to the mains.

## Radio reception FM/AM

1. To select the desired waveband, set the source selector to **FM/AM**.
2. Tune to a radio station using the tuning knob.
- For **FM**, pull out the telescopic antenna. Incline and turn the antenna. Reduce its length if the signal is too strong (very close to a transmitter).
- For **AM**, the set is provided with a built-in antenna so the telescopic antenna is not needed. Direct the antenna by turning the whole set.
3. Adjust the sound using the **VOLUME** and **DBB** controls.
4. To switch off the radio, adjust the source selector to the **OFF/TAPE** position (with the cassette keys released).



## CD PLAYER

### Display indication for CD functions:


- Total track number: in stop mode
- Current track number: during CD play
- Current track number flashes when on PAUSE
- **SHUFFLE/REPEAT** modes: when the respective mode is activated
- **PROGRAM**: when active: P also appears briefly when you store a track
- n/a : no disc/error in CD operation or with the CD (see Troubleshooting)
- F : program memory full

## Playing a CD

1. Set the source selector to **CD**.
2. To open the CD door, press **OPEN** on the CD door.
3. Insert a CD with the printed side facing up and press the CD door gently close.
- The CD player scans the contents of the CD and the total number of tracks is shown.
4. Press **PLAY+PAUSE** **►■** on the set/ remote control to start playback.
5. Adjust the sound using the **VOLUME** and **DBB** controls.
6. To interrupt playback press **PLAY+PAUSE** **►■**. To resume, press **PLAY+PAUSE** **►■** again.
7. To stop CD play, press **STOP** **■** on the set/ remote control.
8. To switch off the set, adjust the source selector to the **OFF/TAPE** position (with the cassette keys released).

### Note: CD playback will also stop when:

- you press the CD door open;
- the source selector is in **OFF/TAPE or FM/AM** position;
- the CD has reached the end.



## Batteries contain chemical substances, so they should be disposed of properly.

## Using AC POWER

1. Check if the power voltage as **shown on the type plate located on the base of the set**, corresponds to your local power supply. If it does not, consult your dealer or service center.
2. Connect the power cord to the MAINS outlet and the wall outlet. The power supply is now connected and ready for use.
3. To switch off completely, withdraw the power cord from the wall outlet.
- Disconnect the power cord from the wall outlet to protect your set during heavy thunderstorms.

### The type plate is located on the bottom of the set.

# INSTRUCTIONS FOR USE

## Selecting a different track

During playback, you can use the **SEARCH** keys to select a particular track.

- If you have selected a track number in the stop or pause position, press **PLAY•PAUSE II** to start playback.
- Press **SEARCH ►►** once for the next track, or press repeatedly until the desired track number appears in the display.
- Press **SEARCH ◀◀** once to return to the beginning of a current track.
- Press **SEARCH ◀◀** more than once for a previous track.

## Finding a passage within a track

1. Press and hold down **SEARCH ◀◀** or **►►**.
2. When you recognize the passage you want, release **SEARCH**.

## CD MODE: SHUFFLE and REPEAT

The **CD MODE** button allows you to select 4 different play modes. The modes can be selected or changed during playback.

- **SHUFFLE** - all tracks are played in random order.
- **SHUFFLE REPEAT ALL**
  - repeats the entire CD in random order.
  - plays the current track continuously.
- **REPEAT**
- **REPEAT ALL**
  - repeats the entire CD

1. During playback, select your play mode by pressing **CD MODE** once or more until the desired play mode is shown.
- You can use **SEARCH ◀◀** or **►►** to skip tracks during **CD MODE** playback.

2. To return to normal playback press the **CD MODE** until the **SHUFFLE/REPEAT** mode is no longer shown in the display.
- You can also press **STOP ■** to quit the play mode.

## CD MODE: Programming track numbers

You may store up to 20 tracks in the desired sequence. If you like, store any track more than once.

1. In the **STOP** position, press **SEARCH ◀◀** or **►►** for your desired track.
2. When your chosen track number appears, press **CD MODE**.
  - The display shows 'P' briefly and 'PROGRAM' followed by your selected track number.
  - 3. Repeat steps 1. and 2. to select and store all desired tracks in this way.

## To review your set program

- In the stop position, press and hold down **CD MODE** for more than one second.
- The display shows all your stored track numbers in sequence.

- To play your program press **PLAY•PAUSE II**.

## Erasing a program

You can erase the contents of the memory by:

- pressing the CD door open;
- moving the source selector position;
- pressing **STOP ■** twice during playback/ in the stop position.
- The display shows 'P' briefly and 'PROGRAM' will disappear when the program is canceled.

## PLAYING A CASSETTE

1. Set the source selector to **TAPE**.

2. Press **STOP•OPEN ■ ▲** to open the cassette holder and insert a cassette.

3. Press the cassette holder shut.

4. Press **PLAY ▶** to start playback.






5. Adjust the sound using the **VOLUME** and **DBB** controls.

6. To interrupt playback press **PAUSE II**. To resume, press the key again.

7. By pressing **◀** or **▶** fast winding of the tape is possible in both directions. To stop fast winding, press **STOP•OPEN ■ ▲**.

8. To stop the tape, press **STOP•OPEN ■ ▲**.
  - The keys are automatically released at the end of the tape, except if **PAUSE II** has been activated.

9. With the source selector in **OFF/TAPE** position, the set is switched off when all the cassette keys are released.



## GENERAL INFORMATION ON RECORDING

- Recording is permissible insofar as copyright or other rights of third parties are not infringed.
- This deck is not suited for recording on CHROME (IEC II) or METAL (IEC IV) type cassettes. For recording, use only NORMAL type cassettes (IEC I) on which the tabs have not been broken.
- The best recording level is set automatically. Altering the **VOLUME** and **DBB** controls will not affect the recording in progress.
- At the very beginning and end of the tape, no recording will take place during the 7 seconds, when the leader tape passes the recorder heads.
- To protect a tape from accidental erasure, have the tape in front of you and break out the left tab.
- Recording on this side is no longer possible. To record over this side again, cover the tabs with a piece of adhesive tape.

### Synchro Start CD recording

- Set the source selector to **CD**.
- Insert a CD and if desired, program track numbers.
- Press **STOP•OPEN ▲** to open the cassette holder. Insert a blank tape.
- Press the cassette holder shut.
- Press **RECORD ●** to start recording.
  - Playing of the CD program starts automatically from the beginning of the program. *It is not necessary to start the CD player separately.*
- For brief interruptions press **PAUSE II**. To resume recording, press **PAUSE II** again.
- To stop recording, press both **STOP•OPEN ■ ▲**.

### To select and record a particular passage






- During CD playback, press and hold down the **SEARCH** buttons **◀◀** or **▶▶** to find your passage.
- Press **PLAY•PAUSE ▶II** to put the CD player on pause at the selected passage.
  - Recording will begin from this exact point in the track when you press **RECORD ●**.

### Recording from the radio

- Set the source selector to **FM/AM**.
- Tune to the desired radio station using (see **RADIO RECEPTION**).
- Press **STOP•OPEN ■ ▲** to open the cassette holder  
Insert a blank tape.
- Press the cassette holder shut.

## INSTRUCTIONS FOR USE

3-4



### PRECAUTIONS AND SYSTEM MAINTENANCE

- Place the set on a hard, flat surface so that the system does not tilt.
- Do not expose the set, batteries, CDs or cassettes to humidity, rain, sand or excessive heat caused by heating equipment or direct sunlight.
- Do not cover the set. Adequate ventilation with a minimum gap of 15 cm between the ventilation holes and surrounding surfaces is necessary to prevent heat build-up.
- The mechanical parts of the set contain self-lubricating bearings and must not be oiled or lubricated.
- To clean the set, use a soft, slightly dampened chamois leather. Do not use any cleaning agents containing alcohol, ammonia, benzene or abrasives as these may harm the housing.




### Tape deck maintenance

To ensure quality recording and playback of the tape deck, clean parts **A**, **B** and **C** shown in the diagram below, after approx. 50 hours of operation, or on average once a month. Use a cotton bud slightly moistened with alcohol or a special head cleaning fluid to clean both decks.

- Open the cassette holder by pressing **STOP•OPEN ■ ▲**.
- Press **PLAY ▲** and clean the rubber pressure rollers **C**.
- Press **PAUSE II** and clean the magnetic heads **A** and also the capstan **B**.
- After cleaning, press **STOP•OPEN ■ ▲**.

### CD player and CD handling

- The lens of the CD player should *never be touched!*
- Sudden changes in the surrounding temperature can cause condensation to form and the lens of your CD player to cloud over. Playing a CD is then not possible. Do not attempt to clean the lens but leave the set in a warm environment until the moisture evaporates.
- Use only Digital Audio CDs.
- To take a CD out of its box, press the center spindle while lifting the CD. Always pick up the CD by the edge and replace the CD back in its box after use to avoid scratching and dust.
- To clean the CD, wipe in a straight line from the center towards the edge using a soft, lint-free cloth. Do not use cleaning agents as they may damage the disc.
- Never write on a CD or attach any stickers to it.



## INSTRUCTIONS FOR USE

3-5


If a fault occurs, first check the points listed below before taking the set for repair.  
If you are unable to remedy a problem by following these hints, consult your dealer or service center.

**WARNING:** *Do not open the set as there is a risk of electric shock! Under no circumstances should you try to repair the set yourself, as this would invalidate the warranty.*

PROBLEM	POSSIBLE CAUSE	REMEDY
<b>No sound/power</b>	- VOLUME is not adjusted	• Adjust the VOLUME
	- Headphones connected	• Disconnect headphones
	- Power cord not securely connected	• Connect AC power cord properly
	- Batteries dead/ incorrectly inserted	• Insert (fresh) batteries correctly
<b>Display does not function properly/ No reaction to operation of any of the controls</b>	- Electrostatic discharge	• Switch off set, disconnect the power plug and reconnect after a few seconds
<b>CD playback does not work</b>	- CD is badly scratched/ dirty	• Replace/ clean CD (see MAINTENANCE)
	- Laser lens steamed up	• Wait until lens has acclimatized
<b>The CD skips tracks</b>	- CD is damaged or dirty	• Replace or clean the CD
	- SHUFFLE or a program is active	• Quit SHUFFLE/PROGRAM models
<b>Poor cassette sound quality</b>	- Dust and dirt on the heads, etc.	• Clean deck parts etc., see maintenance
	- Use of incompatible cassette types (METAL or CHROME).	• Only use NORMAL (IEC 1) for recording.
<b>Recording does not work</b>	- Cassette tab(s) may be broken	• Apply a piece of adhesive tape over the missing tab space.
<b>Remote control does not function properly</b>	- Batteries dead/ incorrectly inserted	• Insert (fresh) batteries correctly
	- Distance/ angle between the set too large	• Reduce the distance/ angle



## DISASSEMBLY DIAGRAM

4-1



4-1

## CD SERVICE TESTPROGRAM




SERVICE PRESET FREQUENCIES	
REGION	EUROPE FM/AM/WLW
PRESET	00/05/2025
1	87.5 kHz
2	108 MHz
3	531 kHz
4	1602 kHz
5	558 kHz
6	1494 kHz
7	153 kHz
8	279 kHz
9	198 kHz
10	5.9 MHz
11	17.9 MHz
12	6.2 MHz
13	17 MHz
OVERSEAS FM/AM/WLW	1/13/33
USA FM/AM	1/14/34
East EUROPE FM/AM/WLW	1/17/37
KOREA FM/MW	87.5 MHz
CHINA FM/AM/WLW	108 MHz
OVERSEAS FM/AM/WLW	530/531 kHz
OVERSEAS FM/AM/WLW	531 kHz
OVERSEAS FM/AM/WLW	1602 kHz
OVERSEAS FM/AM/WLW	558 kHz
OVERSEAS FM/AM/WLW	1494 kHz
OVERSEAS FM/AM/WLW	12.1 MHz
OVERSEAS FM/AM/WLW	4.2 MHz
OVERSEAS FM/AM/WLW	11 MHz
OVERSEAS FM/AM/WLW	17 MHz

table 1

- 1) How to set frequency grid:  
AM - 9 kHz / FM - 50 kHz : Hold **BAND** & **TUNING DOWN** buttons depressed while switching MODE-switch to RADIO.  
AM - 10 kHz / FM - 100 kHz : Hold **BAND** & **TUNING UP** buttons depressed while switching MODE-switch to RADIO.


Selected frequency grid is stored in the EEPROM.

- 2) In sets with 30kHz grid on FM band it may occur that the tuned frequency is indicated wrong on the display because of tolerances of the discriminator filter.  
For that reason the testsoftware is prepared for an automatic If-offset correction.  
Note: This test functions only with the East European tuner version used in 1/13/34 set versions.  
The test was executed on every set in the production line.  
In case the discriminator filter or the EEPROM has to be exchanged the automatic If-offset correction should also be executed after repair.  
To execute the automatic If-offset correction proceed as follows:  
• feed a strong 5MHz signal to the antenna  
• press the **PROGRAM** button  
The µP starts now several times the search mode.  
If the transmitter was found at 87.5MHz the stop-frequency sent by the radio IC is compared with the nominal frequency else the display shows "00E".  
When the same difference is found twice the value will be stored as offset.  
The actual used offset is shown on the display (-3, -2, -1, 0, 1, 2, 3).



## CD STARTUP PROCEDURE


4  
४



## Abbreviations and Pin-description of CD ICs

4-3

## BLOCK DIAGRAM




# WIRING DIAGRAM


6-1

FOR CD97/MK1-DA11 ONLY

6-1




## FRONT BOARD - CIRCUIT DIAGRAM



FRONT BOARD - LAYOUT DIAGRAM

7-2


1400 A 2	2402 A 2	3402 B 2	3414 B 2	3467 A 3	3479 B 2	3901 A 1	6403 B 2	9003 A 2	9011 B 4
1405 A 4	2403 B 2	3403 B 3	3415 B 4	3468 B 3	3480 B 2	3902 A 1	6404 B 2	9004 A 4	9012 A 2
1410 B 4	2464 B 4	3404 B 3	3460 A 4	3469 B 3	3480 A 4	3903 A 1	7401 A 3	9005 A 2	9013 A 3
1411 A 4	2465 B 2	3405 A 2	3461 A 3	3470 B 3	3484 B 4	3904 B 1	7402 B 3	9006 A 4	9014 A 3
1413 B 1	2466 B 2	3406 A 2	3462 A 3	3471 B 3	3485 B 1	5401 B 2	7403 B 4	9007 B 3	9015 A 4
1415 B 3	2901 A 1	3407 B 4	3464 B 4	3472 B 3	3486 B 2	5402 B 4	7900 A 1	9008 B 1	9016 B 1
1417 B 1	2902 A 1	3408 B 4	3465 B 2	3474 B 2	3487 A 2	5403 A 4	7901 A 1	9009 B 3	9100 B 3
2401 A 4	2903 B 1	3410 B 4	3466 A 3	3475 B 2	3488 A 2	6402 B 2	9002 B 4	9010 B 4	9158 B 1



7-2

## TUNER BOARD - CIRCUIT DIAGRAM


8.1






## MAIN BOARD - CIRCUIT DIAGRAM

一  
九




**MAIN BOARD - LAYOUT DIAGRAM**

9-2




# RECORDED BOARD - CIRCUIT DIAGRAM

10-1



RECORDER BOARD - LAYOUT DIAGRAM 10-2



10-2


71	B	3	2736	A	2	3732	B	1	9716	A	1
1702	B	3	2737	B	1	3733	B	2	9717	A	1
1703	A	1	2738	A	2	3734	B	1	9719	A	2
1707	A	2	2739	A	2	3735	A	1	8720	B	2
1709	A	3	2740	A	1	3736	B	3	8722	B	3
2700	B	3	3700	B	1	3737	B	1	8723	A	1
2701	B	3	3701	A	3	3738	B	1	9703	B	1
2703	B	2	3702	B	3	3739	B	3			
2704	B	3	3703	B	2	3740	B	3			
2706	B	3	3704	B	2	3743	A	3			
2707	B	2	3705	A	2	3744	B	3			
2708	A	3	3706	A	2	3745	B	3			
2709	B	1	3707	B	2	3746	B	1			
2710	A	1	3708	A	3	3747	B	1			
2711	B	2	3709	A	3	3748	A	2			
2712	A	2	3710	A	3	3749	A	2			
2713	B	2	3711	A	2	3750	B	1			
2714	B	2	3712	A	2	5701	A	1			
2715	B	3	3713	B	1	6704	B	2			
2716	B	2	3714	B	1	7701	A	3			
2717	A	3	3715	B	2	7702	B	1			
2718	A	2	3716	B	1	7703	A	3			
2719	A	3	3717	B	1	7704	A	3			
2720	B	2	3718	B	1	7705	B	2			
2721	B	1	3719	A	2	7706	A	3			
2722	B	2	3720	A	2	7707	B	1			
2723	B	2	3721	A	2	9701	B	3			
2724	B	1	3722	A	2	9702	B	3			
2725	A	2	3723	A	2	9704	A	2			
2726	A	2	3724	B	3	9705	B	1			
2727	A	2	3725	A	3	9706	A	2			
2728	A	3	3726	A	3	9707	A	2			
2729	B	3	3727	B	3	9708	B	2			
2730	A	1	3728	B	3	9711	A	1			
2731	A	1	3729	A	3	9712	A	2			
2732	B	1	3730	A	1	9713	B	1			
2733	B	1	3731	B	1	9714	A	1			

10-2


CASSETTE ADJUSTMENT


Adjustment	Cassette	SK ....	Deck 1	Measure on	Read on	Adjust with	Adjust to
Azimuth	10kHz SBC420*	TAPE	Play	H/P Jack	mV meter	Left hand Screw R/P Head	max.
Motor Speed	3150kHz SBC420*	TAPE	Play	H/P Jack	Wow and flutter meter	Preset motor	**a

\* SBC420 : 4822 397 30071  
\*\*a The maximum permissible speed deviation is  $\pm 3\%$ . Moreover, the wow and flutter value can be read.



## CD PART







ATTENTION:  
Take care of ESD

## SCREW LIST

1. T2 x 8
2. T2.5 x 8
3. T3 x 8
4. T3 x 10
5. T3 x 12
6. T3 x 16
7. T3 x 25
8. C P/W 2.5 x 10
9. T P/W 3 x 12
10. T P/W 3 x 16






## MECHANICAL PARTSLIST - CABINET

12-2

401	4822 443 11258	Door Cassette	438	4822 532 12798	Ring Pressure
402	4822 492 11776	Spring Cass Door	439	4822 492 11777	Spring CD
403	4822 458 10689	Speaker Cloth Assy (L)	441	4822 443 11259	Door CD
404	4822 458 10688	Speaker Cloth Assy (R)	442	4822 492 11778	Spring Handle
406	4822 529 10322	Damper Assy	443	4822 498 10738	Handle Assy
407	4822 380 10278	Light Guide	444	4822 290 80313	Contact Plate
408	4822 410 12502	Button Play	446	4822 492 11779	Spring Compression
409	4822 410 12501	Button Mode	447	4822 492 11781	Spring Compression
411	4822 402 11356	Bracket LCD	448	4822 303 14065	Telescopic Aerial
412	4822 691 10612	Tape Deck CDS-83-VBF-77	449	4822 442 01889	Door Battery
413	4822 492 11061	Spring Recording	451	4822 321 10249	Mains Cord (For -00/01/11/14)
414	4822 410 12507	Knob Cassette	451	4822 321 10886	Mains Cord (For -05)
416	4822 402 10126	Lever Recording	451	4822 321 10954	Mains Cord (For -10)
417	4822 529 10387	Damper Rubber (40 DEG)	451	4822 321 11466	Mains Cord (For -17)
418	4822 529 10386	Damper Rubber (30 DEG)	452	4822 219 10749	Remote Control
419	4822 691 10747	CD Drive Assy CD97 DA11	4822 256 90463	Ferrite Bar Holder	
421	4822 442 01096	CD Lens Cover	4822 736 17084	Instructions Manual (For -00/05)	
422	4822 492 33422	Spring Tension	4822 736 17077	Instructions Manual (For -01/01/11)	
423	4822 528 11345	Dial Drum	4822 736 17078	Instructions Manual (For -14)	
424	4822 528 80907	Pulley Pom	4822 736 17079	Instructions Manual (For -17)	
426	4822 402 11358	Bracket Tuning			
427	4822 535 10648	Shaft Tuning			
428	4822 450 10685	Pointer			
429	4822 410 12505	Knob DBB			
431	4822 410 12506	Knob Mode			
432	4822 529 10322	Damper Assy			
433	4822 410 12503	Knob Tuning			
434	4822 410 12504	Knob Volume			
436	4822 535 60096	Disc			
437	4822 532 13153	Ring (CD Lid)			

## MECHANICAL PARTSLIST - TAPE DECK

Note : Only those parts mentioned in the are  
normal service parts.



## EXPLODED VIEW DIAGRAM - TAPE DECK (CDS-83-VBF-77)

12-2

10	4822 528 70849	Pinch Roller Arm (B)	110	4822 278 90721	Leaf Switch
11	4822 528 70695	Pinch Roller Assy	111	4822 249 30218	MS18R-AKKONI
74	4822 403 70968	Eject Hook (A)	112	4822 249 40306	E. Head
106	4822 358 31325	Main Belt 45.2 x 1.2	115	4822 361 21565	Motor EG-530AD-9B
107	4822 358 31124	Sub Belt 44.7 x 1.2	116	4822 528 81497	Motor Pulley

Note : Only those parts mentioned in the are  
normal service parts.

CD 97 (DA11 MK I)

13-1

CD 97 (DA11 MK I)

	3847	4822 116 52298	680K	5%	0,5W
	3848	4822 116 52251	18K	5%	0,5W
	3849	4822 052 10478	4R7	5%	0,33W
	3850	4822 116 52251	18K	5%	0,5W
	3851	4822 116 52244	15K	5%	0,5W
	3852	4822 116 83883	470R	5%	0,5W
	3853	4822 116 52251	18K	5%	0,5W
	3854	4822 116 52243	1K5	5%	0,5W
	3855	4822 116 52264	27K	5%	0,5W
	3856	4822 116 52303	8K2	5%	0,5W
	3857	4822 116 52269	3K3	5%	0,5W
	3858	4822 116 80176	1R	5%	0,5W
	3859	4822 116 83864	10K	5%	0,5W
	3860	4822 116 52207	1K2	5%	0,5W
	3870	4822 052 10478	4R7	5%	0,33W
	3871	4822 116 52175	100R	5%	0,5W
	3880	4822 050 11002	1K	1%	0,4W
	3881	4822 050 11002	1K	1%	0,4W
	3882	4822 050 11002	1K	1%	0,4W
	3883	4822 050 11002	1K	1%	0,4W
	3884	4822 116 83882	39K	5%	0,5W
	3886	4822 116 52235	1M	5%	0,5W
	3889	4822 050 11002	1K	1%	0,4W
	3891	4822 050 11002	1K	1%	0,4W
	3892	4822 050 11002	1K	1%	0,4W
	3893	4822 050 11002	1K	1%	0,4W
	3894	4822 050 11002	1K	1%	0,4W
	3895	4822 050 11002	1K	1%	0,4W
	3896	4822 116 52256	2K2	5%	0,5W
	3897	4822 116 52256	2K2	5%	0,5W
	3898	4822 116 52256	2K2	5%	0,5W
	3899	4822 050 11002	1K00	1%	0,4W
	5000	4822 526 10494	Ferrite Bead		
	5010	4822 526 10494	Ferrite Bead		
	5020	4822 526 10494	Ferrite Bead		
	5030	4822 526 10494	Ferrite Bead		
	5040	4822 526 10494	Ferrite Bead		
	5050	4822 526 10494	Ferrite Bead		
	5060	4822 157 50964	Coil 100µH		
	5803	4822 242 73557	Filter CST8,46MTW-TF01		

	6001	4822 130 30621	Diode 1N4148	
				
7801	4822 209 13703	IC M65821FP		
7802	4822 209 32421	IC TDA1311A/N2		
7803	4822 209 90496	IC M62475FP		
7804	4822 130 42231	Trans BC557C		
7805	4822 209 32852	IC TDA7073A/N2		
7806	4822 209 32852	IC TDA7073A/N2		
<b>- MISCELLANEOUS -</b>				
1802	4822 265 10925	Connector 15P		
8000	4822 320 12178	Flexible Foil 15P 65mm		

**Note :** Only those parts mentioned in the list are normal service parts.

**MAIN BOARD****MAIN BOARD**

	2305 4822 124 41407 0,47µF 20% 63V	3271 4822 116 83876 270R 5% 0,5W
	2306 4822 124 41407 0,47µF 20% 63V	3272 4822 116 83868 150R 5% 0,5W
	2308 4822 124 40769 4,7µF 20% 100V	3273 4822 116 83868 150R 5% 0,5W
	2309 4822 122 10466 220pF 10% 50V	3305 4822 116 83883 470R 5% 0,5W
	2310 4822 122 10466 220pF 10% 50V	3306 4822 116 83883 470R 5% 0,5W
	2311 4822 124 40433 47µF 20% 25V	3307 4822 116 52219 330R 5% 0,5W
	2312 4822 124 40433 47µF 20% 25V	3308 4822 116 52219 330R 5% 0,5W
	2313 4822 124 41407 0,47µF 20% 63V	3309 4822 116 52244 15K 5% 0,5W
	2314 4822 124 41407 0,47µF 20% 63V	3310 4822 116 52175 100R 5% 0,5W
	2315 4822 124 11878 4700µF 16V	3311 4822 116 52175 100R 5% 0,5W
	2317 4822 124 81029 100µF 20% 25V	3500 4822 102 10447 VR 50K
	2319 4822 124 80195 470µF 20% 10V	3501 4822 116 52256 2K2 5% 0,5W
	2320 4822 124 80195 470µF 20% 10V	3502 4822 116 52256 2K2 5% 0,5W
	2321 4822 124 40746 0,22µF 20% 63V	3503 4822 116 52256 2K2 5% 0,5W
	2322 4822 124 40746 0,22µF 20% 63V	3504 4822 116 52256 2K2 5% 0,5W
	2323 4822 126 11585 22nF +80-20% Y5V 25V	3505 4822 116 83864 10K 5% 0,5W
	2325 4822 124 23052 100µF 20% 16V	3506 4822 116 83864 10K 5% 0,5W
	2326 4822 124 40433 47µF 20% 25V	3507 4822 050 11002 1K 1% 0,4W
	2327 4822 124 40433 47µF 20% 25V	3630 4822 116 52269 3K3 5% 0,5W
	2328 4822 122 33197 1nF 10% 50V	3631 4822 116 52269 3K3 5% 0,5W
	2329 4822 121 51387 10nF 20% 16V	3632 4822 116 83961 6K8 5%
	2330 4822 121 51387 10nF 20% 16V	3633 4822 116 83961 6K8 5%
	2501 4822 121 51387 10nF 20% 16V	3634 4822 116 52264 27K 5% 0,5W
	2502 4822 121 51387 10nF 20% 16V	3635 4822 116 52264 27K 5% 0,5W
	2503 4822 121 42408 220nF 5% 63V	3800 4822 116 52256 2K2 5% 0,5W
	2504 4822 121 42408 220nF 5% 63V	3801 4822 116 52256 2K2 5% 0,5W
	3110 4822 116 52234 100K 5% 0,5W	3802 4822 050 11002 1K 1% 0,4W
	3116 4822 116 83961 6K8 5%	3803 4822 050 11002 1K 1% 0,4W
	3117 4822 050 11002 1K 1% 0,4W	
	3118 4822 050 11002 1K 1% 0,4W	
	3119 4822 116 83961 6K8 5%	

	6311 4822 130 31878 Diode 1N4003G
	7300 4822 209 31544 IC TA8227P
	7301 4822 130 40959 Trans BC547B
	7302 4822 130 40959 Trans BC547B
	7303 4822 130 41246 Trans BC327-25
	7304 4822 130 41246 Trans BC327-25
	7305 4822 130 42231 Trans BC557C
	7306 4822 130 44503 Trans BC547C
	7308 4822 130 40959 Trans BC547B
	7309 4822 130 40959 Trans BC547B
	7310 4822 130 40959 Trans BC547B

<b>- MISCELLANEOUS -</b>		
	1007 4822 240 10391 Loudspeaker 4 Ohm	
	1008 4822 265 20318 Socket Main (Not for -'17)	
	1008 4822 265 20706 Socket Main gFor -'17)	
	1009  4822 146 11179 Transf (For -00/05/10/14)	
	1009  4822 146 11175 Transf (For -01/11)	
	1009  4822 146 11176 Transf (For -17)	
	1010 4822 276 13963 CD Door Switch	
	1011  4822 277 21794 Volt Sel (For -0/1/11)	
	1255 4822 265 11317 Connector 1p	
	1300  4822 070 31602 Fuse 1.6A (Not for -17)	
	1300  5322 253 30116 Fuse 2A (For -17)	
	1500 4822 276 12648 Push Switch 2P2T	
	1560 4822 277 11739 Slide Switch	

Note : Only those parts mentioned in the list are normal service parts.

FRONT BOARD

133

TUNER BOARD

2401	4822 124 41584	100µF 20%	10V	
2402	4822 124 22651	1µF 20%	50V	
2403	4822 126 12882	100nF +80-20%	50V	
2464	4822 122 10466	220pF 10%	50V	
2465	4822 122 10466	220pF 10%	50V	
2466	4822 122 33197	1nF 10%	50V	
2901	4822 122 33519	470pF 10%	50V	
2902	4822 122 33519	470pF 10%	50V	
2903	4822 124 23432	100µF 20%	10V	
3402	4822 116 52234	100K 5%	0,5W	
3403	4822 116 52244	15K 5%	0,5W	
3404	4822 116 83876	270R 5%	0,5W	
3405	4822 116 52238	12K 5%	0,5W	
3406	4822 116 52276	3K9 5%	0,5W	
3407	4822 116 52243	1K5 5%	0,5W	
3408	4822 116 52226	560R 5%	0,5W	
3410	4822 116 52238	12K 5%	0,5W	
3414	4822 116 83961	6K8 5%		
3415	4822 116 83961	6K8 5%		
3460	4822 116 52283	4K7 5%	0,5W	
3461	4822 116 52269	3K3 5%	0,5W	
3462	4822 116 52243	1K5 5%	0,5W	
3464	4822 116 52283	4K7 5%	0,5W	
3465	4822 116 52283	4K7 5%	0,5W	
3466	4822 116 52243	1K5 5%	0,5W	
3467	4822 116 52243	1K5 5%	0,5W	
3468	4822 116 52283	4K7 5%	0,5W	
3469	4822 116 52231	820R 5%	0,5W	
3470	4822 116 52231	820R 5%	0,5W	
3471	4822 116 52283	4K7 5%	0,5W	
3472	4822 116 52231	820R 5%	0,5W	
3474	4822 116 52283	4K7 5%	0,5W	
3475	4822 116 52234	100K 5%	0,5W	
3479	4822 050 11002	1K 1%	0,4W	
3480	4822 116 52234	100K 5%	0,5W	
3481	4822 116 52257	22K 5%	0,5W	
3484	4822 116 52264	27K 5%	0,5W	
3485	4822 116 52264	27K 5%	0,5W	
3486	4822 116 52269	3K3 5%	0,5W	

	3487	4822 116 52283	4K7	5%	0,5W
	3488	4822 116 52257	22K	5%	0,5W
	3901	4822 116 52257	22K	5%	0,5W
	3902	4822 116 52234	100K	5%	0,5W
	3903	4822 116 52234	100K	5%	0,5W
	3904	4822 116 52175	100R	5%	0,5W
	5401	4822 242 73769	Filter CST4,19MGW		
	5402	4822 157 11228	Coil LAN02TB101J		
	5403	4822 157 11231	Coil LAN02TB1R0J		
	6402	4822 130 30621	Diode 1N4148		
	6403	4822 130 30621	Diode 1N4148		
	6404	5322 130 31504	Diode BZX79-B3V3		
	6405	4822 130 11657	LED (Blue)		
	6406	4822 130 11657	LED (Blue)		
	7401	4822 209 17523	IC TMP47PC422F-50560		
	7402	4822 130 44503	Trans BC547C		
	7403	4822 130 40959	Trans BC547B		
	7900	4822 218 11745	Receiver TSOP1736		
	7901	5322 209 11147	IC HEF4093BT		
	<b>- MISCELLANEOUS -</b>				
	1401	4822 265 10981	Connector 15FE-BT-VK-N		
	1405	4822 265 10979	Connector 15FE-BT-VK-N		
	1400	4822 135 00291	LCD Display		
	1410	4822 276 13114	Tact Switch		
	1411	4822 276 13114	Tact Switch		
	1413	4822 276 13114	Tact Switch		
	1415	4822 276 13114	Tact Switch		
	1417	4822 276 13114	Tact Switch		
	8404	4822 320 11974	Flexible Foil 15p 190mm		

	2101	4822 122 33195	100pF	10%	50V	
	2102	4822 122 33848	47pF	5%SL	50V	
	2103	4822 124 41579	10µF	20%	50V	
	2104	4822 124 41579	10µF	20%	50V	
	2105	4822 122 33191	22pF	5%	50V	
	2106	4822 125 50681	Variable Capacitor			
	2108	4822 126 13508	3,3pF	10% NPO	50V	
	2109	4822 126 14482	27pF	5% 50V	N470	
	2110	4822 126 12229	8,2pF	N750	50V	
	2112	4822 124 40433	47µF	20%	25V	
	2113	4822 124 40746	0,22µF	20%	63V	
	2114	4822 126 12787	330pF	10%	Y5V 50V	
	2115	4822 124 40769	4,7µF	20%	100V	
	2116	4822 121 70619	22nF	10%	50V	
	2116	4822 121 43145	33nF	10%	50V	
	2117	4822 124 40242	1µF	20%	63V	
	2118	4822 124 40242	1µF	20%	63V	
	2119	4822 121 70619	22nF	10%	50V	
	2119	4822 121 43145	33nF	10%	50V	
	2120	4822 124 40242	1µF	20%	63V	
	2121	4822 124 41407	0,47µF	20%	63V	
	2122	4822 124 41407	0,47µF	20%	63V	
	3101	4822 100 20167	50K	30%	LIN 0,1W	
	3102	4822 116 52297	68K	5%	0,5W	
	3104	4822 116 52256	2K2	5%	0,5W	
	3106	4822 116 52231	820R	5%	0,5W	
	3107	4822 116 52182	15R	5%	0,5W	
	3108	4822 116 52182	15R	5%	0,5W	
	3109	4822 116 52176	10R	5%	0,5W	
	3113	4822 116 52234	100K	5%	0,5W	
	3114	4822 116 52234	100K	5%	0,5W	
	3115	4822 116 52226	560R	5%	0,5W	
	5101	4822 157 70513	Coil FM			
	5102	4822 157 70731	Coil MW/ANT			
	5104	4822 157 11843	Coil MD7B-01F			
	5105	4822 157 71145	Coil 270µH			
	5106	4822 157 70499	Coil IFT AM			

	5107 5108	4822 242 81154 4822 156 11146	Filter KMFC5058-Z Coil IFT AM
	6101 6102	4822 130 30621 4822 130 30621	Diode 1N4148 Diode 1N4148
	7101 7102	4822 209 32746 4822 130 44503	IC TEA5711T/N2 Trans BC547C
<b>- MISCELLANEOUS -</b>			
	1003 1003	4822 256 90463 4822 526 10176	Ferrite Bar Holder Ferrite Bar 5x13x55mm

**Note :** Only those parts mentioned in the list are normal service parts.

## RECORDER BOARD

13-4

## RECORDER BOARD

13-4



2703	4822 124 81151	22µF 50V	3705	4822 116 838672	220R 5% 0,5W
2704	4822 124 81151	22µF 50V	3706	4822 116 52245	150K 5% 0,5W
2706	4822 124 40433	47µF 20% 25V	3707	4822 116 52245	150K 5% 0,5W
2707	4822 124 80144	220µF 20% 25V	3708	4822 116 83961	6K8 5%
2708	4822 124 42446	100µF 20% 10V	3709	4822 116 83961	6K8 5%
2709	4822 124 42446	100µF 20% 10V	3710	4822 116 83864	10K 5% 0,5W
2710	4822 124 22726	4,7µF 35V	3711	4822 116 52207	1K2 5% 0,5W
2711	4822 124 81151	22µF 50V	3712	4822 116 52303	8K2 5% 0,5W
2712	4822 126 12339	2,2nF 10% Y5R	3713	4822 116 52195	47R 5% 0,5W
2713	5322 122 32311	470pF 10% 100V	3714	4822 116 83883	470R 5% 0,5W
2714	4822 126 12339	2,2nF 10% Y5R	3715	4822 116 83872	220R 5% 0,5W
2715	4822 126 13174	33nF +80-20% 16V	3716	4822 116 52245	150K 5% 0,5W
2716	4822 126 11585	22nF +80-20% Y5V 25V	3717	4822 116 83961	6K8 5%
2717	4822 121 10686	4,7nF 10% 50V	3718	4822 116 83961	6K8 5%
2718	4822 122 10466	220pF 10% 50V	3719	4822 116 83864	10K 5% 0,5W
2719	4822 121 51305	15nF 10% 50V	3720	4822 116 52303	8K2 5% 0,5W
2720	5322 122 32311	470pF 10% 100V	3721	4822 116 52207	1K2 5% 0,5W
2721	4822 126 12339	2,2nF 10% Y5R	3722	4822 116 52257	22K 5% 0,5W
2722	4822 126 13174	33nF +80-20% 16V	3723	4822 116 52257	22K 5% 0,5W
2723	4822 126 11585	22nF +80-20% Y5V 25V	3725	4822 116 52256	2K2 5% 0,5W
2724	4822 121 10686	4,7nF 10% 50V	3726	4822 116 52256	2K2 5% 0,5W
2725	4822 122 10466	220pF 10% 50V	3727	4822 116 52256	2K2 5% 0,5W
2726	4822 121 51305	15nF 10% 50V	3729	4822 116 52256	2K2 5% 0,5W
2727	4822 126 12339	2,2nF 10% Y5R	3730	4822 116 52186	22R 5% 0,5W
2728	4822 126 11714	4,7nF 20%	3731	4822 116 52297	68K 5% 0,5W
2729	4822 126 11714	4,7nF 20%	3732	4822 116 52176	10R 5% 0,5W
2730	4822 126 14316	680pF 10% 50V Y5P	3733	4822 116 30893	4M7 5% 0,2W
2731	4822 121 41857	10nF 5% 250V	3734	4822 116 83864	10K 5% 0,5W
2732	4822 126 11714	4,7nF 20%	3735	4822 050 21002	1K 1% 0,6W
2733	4822 121 70619	22nF 10% 50V	3743	4822 116 52269	3K3 5% 0,5W
2736	4822 126 14316	680pF 10% 50V Y5P	3744	4822 116 52269	3K3 5% 0,5W
2737	4822 126 14316	680pF 10% 50V Y5P	3745	4822 116 83864	10K 5% 0,5W
2738	4822 122 33519	470pF 10% 50V	3746	4822 116 83864	10K 5% 0,5W
2739	4822 122 33519	470pF 10% 50V	3747	4822 116 52191	33R 5% 0,5W
2740	4822 124 42446	100µF 20% 10V	3748	4822 116 52283	4K7 5% 0,5W
3700	4822 116 83883	470R 5% 0,5W	3749	4822 116 52283	4K7 5% 0,5W
3701	4822 116 83883	470R 5% 0,5W	3750	4822 116 52176	10R 5% 0,5W
3702	4822 116 52175	100R 5% 0,5W			
3703	4822 116 52195	47R 5% 0,5W			
3704	4822 116 83883	470R 5% 0,5W			



3705	4822 116 83872	220R 5% 0,5W
3706	4822 116 52245	150K 5% 0,5W
3707	4822 116 52245	150K 5% 0,5W
3708	4822 116 83961	6K8 5%
3709	4822 116 83961	6K8 5%
3710	4822 116 83864	10K 5% 0,5W
3711	4822 116 52207	1K2 5% 0,5W
3712	4822 116 52303	8K2 5% 0,5W
3713	4822 116 52195	47R 5% 0,5W
3714	4822 116 83883	470R 5% 0,5W
3715	4822 116 83872	220R 5% 0,5W
3716	4822 116 52245	150K 5% 0,5W
3717	4822 116 83961	6K8 5%
3718	4822 116 83961	6K8 5%
3719	4822 116 83864	10K 5% 0,5W
3720	4822 116 52303	8K2 5% 0,5W
3721	4822 116 52207	1K2 5% 0,5W
3722	4822 116 52257	22K 5% 0,5W
3723	4822 116 52257	22K 5% 0,5W
3725	4822 116 52256	2K2 5% 0,5W
3726	4822 116 52256	2K2 5% 0,5W
3727	4822 116 52256	2K2 5% 0,5W
3729	4822 116 52256	2K2 5% 0,5W
3730	4822 116 52186	22R 5% 0,5W
3731	4822 116 52297	68K 5% 0,5W
3732	4822 116 52176	10R 5% 0,5W
3733	4822 116 30893	4M7 5% 0,2W
3734	4822 116 83864	10K 5% 0,5W
3735	4822 050 21002	1K 1% 0,6W
3743	4822 116 52269	3K3 5% 0,5W
3744	4822 116 52269	3K3 5% 0,5W
3745	4822 116 83864	10K 5% 0,5W
3746	4822 116 83864	10K 5% 0,5W
3747	4822 116 52191	33R 5% 0,5W
3748	4822 116 52283	4K7 5% 0,5W
3749	4822 116 52283	4K7 5% 0,5W
3750	4822 116 52176	10R 5% 0,5W

Note : Only those parts mentioned in the list are normal service parts.

1707      4822 277 11504      Push Switch

### - MISCELLANEOUS -

6704	4822 130 30621	Diode 1N4148
7702	4822 130 40981	Trans BC337-25
7705	4822 209 32918	IC AN7318S
7706	4822 130 44503	Trans BC547C
7707	4822 130 44503	Trans BC547C