

Service
Service
Service



Service Manual



TABLE OF CONTENTS

	Page
Location of pc boards & Version variations	1-2
Technical Specifications	1-3
Measurement setup	1-4
Service Aids, Safety Instruction, etc.	1-5
Instruction for use: European version excerpt	2-1
Disassembly Instructions & Service positions	3-1
Service Test Programs	3-4
Set Block diagram	4
Set Wiring diagram	5
Front Board	6
Tuner Board: ECO5 Sys	7B
Tuner 95	7D
ETF7 Tape Module	9
3CDC-LC-MB Module	10A
Combi Board	11
Set Mechanical Exploded view & parts list	12



© Copyright 2000 Philips Consumer Electronics B.V. Eindhoven, The Netherlands
All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form or by any means, electronic, mechanical, photocopying, or otherwise without the prior permission of Philips.

Published by KC 0050 Service Audio Printed in The Netherlands Subject to modification




3139 785 22610



PHILIPS

LOCATION OF PC BOARDS



VERSION VARIATIONS:

Type /Versions:	FW-C280							
	/22	/34						
Features & Board in used:								
Incredible Surround	x	x						
Karaoke								
News	x	x						
RDS	x	x						
Rotary Encoder (volume control)	x	x						
Jog Shuttle	x	x						
Voltage Selector								
Aux Input	x	x						
Digital Output								
Headphone Socket	x	x						
Line Output								
Subwoofer Output								
Surround Output								
Matrix Surround Loudspeakers								
Standby - Clock Display	x	x						
Standby - Dark								
Tuner board - ECO5 Sys		x						
Tuner board - Tuner 95	x							
Combi board 12W version								
Combi board 18W version								
Combi board 25W version	x	x						

SPECIFICATIONS**GENERAL:**

Mains voltage : 220-230V for /22/34
Mains frequency : 50Hz
Power consumption : < 25W at Standby
 < 75W Active
Clock accuracy : < 4 seconds per day
Dimension centre unit : 265 x 310 x 340mm

TUNER:**FM**

Tuning range : 87.5-108MHz
 65.81-74MHz for /34 ¹⁾
Grid : 50kHz (& 30kHz for /34)
IF frequency : 10.7MHz \pm 25kHz
Aerial input : 75 Ω coaxial
Sensitivity at 26dB S/N : < 7 μ V
Selectivity at 600kHz bandwidth : > 30dB
Image rejection : > 25dB [> 60 dB]
Distortion at RF=1mV, dev. 75kHz : < 3%
-3dB Limiting point : < 8 μ V
Crosstalk at RF=1mV, dev. 40kHz : > 18dB

MW

Tuning range : 531-1602kHz
 530-1700kHz for /21/21M/37
Grid : 9kHz
IF frequency : 450kHz \pm 1kHz
Aerial input : Frame aerial
Sensitivity at 26dB S/N : < 4.0mV/M
Selectivity at 18kHz bandwidth : > 18dB
IF rejection : > 24dB [40dB]
Image rejection : > 28dB
Distortion at RF=50mV, m=80% : < 5%

LW

Tuning range : 153-279kHz for /22
Grid : 3kHz
IF frequency : 450kHz \pm 1kHz
Aerial input : Frame aerial
Sensitivity at 26dB S/N : [< 7.0 mV/M]
Selectivity at 18kHz bandwidth : [> 30 dB]
IF rejection : [> 25 dB]
Image rejection : [> 35 dB]
Distortion at RF=50mV, m=80% : [< 5 %]

AMPLIFIER:

Output power (6 Ω , 1 kHz, 10% THD) : 2 x 35W \pm 1dB
Frequency response within -3dB : 50Hz-15kHz
Dynamic Bass Boost : DBB ON, DBB Off ²⁾
Digital Sound Control : Jazz, Techno, Optimal, Rock ²⁾
Incredible Surround : IS, IS Off ²⁾
VEC Control : Hall, Cinema, Concert ²⁾
Headphone output at 32 Ω : 16mW
Input sensitivity
 Aux/Line-in : 700mV \pm 2dB at 600 Ω

CASSETTE RECORDER:

Number of track : 2 x 2 stereo
Tape speed : 4.76 cm/sec \pm 2%
Wow and flutter : < 0.4% DIN
Fast-wind/rewind time C60 : 130 sec
Bias system : 75kHz \pm 10kHz
Rec/Pb frequency response within 8dB : 80Hz - 12.5kHz
Signal to noise ratio : > 48dBA

COMPACT DISC:

Measurement done at output conn. of the CDC module.
Frequency response within ± 1.5 dB: 20Hz - 20kHz
Output level (in Vrms) : 550mV, $Z_{out} = 100\Omega$
Signal/Noise ratio (A-weighted) : > 80dBA
Distortion at 1kHz : < 0.003%
Channel unbalance at 1kHz : ± 1 dB
Channel separation at 1kHz : > 60dB
De-emphasis : 0 or 15/50 mS (Switched by subcode
 on the disc)


[...] Values indicated are for "Tuner 95 Board" only

¹⁾ Default setting is OFF, to switch on please refer page 3-4.

²⁾ Frequency response in each setting is software controlled.


MEASUREMENT SETUP

Tuner FM



Use a bandpass filter to eliminate hum (50Hz, 100Hz) and disturbance from the pilotone (19kHz, 38kHz).


Tuner AM (MW,LW)



To avoid atmospheric interference all AM-measurements have to be carried out in a Faraday's cage.
Use a bandpass filter (or at least a high pass filter with 250Hz) to eliminate hum (50Hz, 100Hz).


CD

Use Audio Signal Disc SBC429 4822 397 30184
(replaces test disc 3)



Recorder

Use Universal Test Cassette **CrO2** SBC419 4822 397 30069
or Universal Test Cassette **Fe** SBC420 4822 397 30071



SERVICE AIDS

Service Tools:

Universal Torx driver holder	4822 395 91019
Torx bit T10 150mm	4822 395 50456
Torx driver set T6 - T20	4822 395 50145
Torx driver T10 extended	4822 395 50423

Cassette:

SBC419 Test cassette CrO2	4822 397 30069
SBC420 Test cassette Fe	4822 397 30071
MTT150 Dolby level 200nWb/M	4822 397 30271






Compact Disc:

SBC426/426A Test disc 5 + 5A	4822 397 30096
SBC442 Audio Burn-in Test disc 1kHz	4822 397 30155
SBC429 Audio Signals disc	4822 397 30184
Dolby Pro-logic Test Disc	4822 395 10216

ESD Equipment:

Anti-static table mat - large 1200x650x1.25mm ...	4822 466 10953
Anti-static table mat - small 600x650x1.25mm	4822 466 10958
Anti-static wristband	4822 395 10223
Connector box (1MΩ)	4822 320 11307
Extension cable (to connect wristband to conn. box)	4822 320 11305
Connecting cable (to connect table mat to conn. box)	4822 320 11306
Earth cable (to connect product to mat or box)	4822 320 11308
Complete kit ESD3 (combining all above products)	4822 320 10671
Wristband tester	4822 344 13999

HANDLING CHIP COMPONENTS



(GB) WARNING

All ICs and many other semi-conductors are susceptible to electrostatic discharges (ESD). Careless handling during repair can reduce life drastically.

When repairing, make sure that you are connected with the same potential as the mass of the set via a wrist wrap with resistance. Keep components and tools also at this potential.

(F) ATTENTION

Tous les IC et beaucoup d'autres semi-conducteurs sont sensibles aux décharges statiques (ESD).

Leur longévité pourrait être considérablement écourtée par le fait qu'aucune précaution n'est prise à leur manipulation.

Lors de réparations, s'assurer de bien être relié au même potentiel que la masse de l'appareil et enfiler le bracelet serti d'une résistance de sécurité.

Veiller à ce que les composants ainsi que les outils que l'on utilise soient également à ce potentiel.

(D) WARNUNG

Alle ICs und viele andere Halbleiter sind empfindlich gegenüber elektrostatistischen Entladungen (ESD).

Unvorsichtige Behandlung im Reparaturfall kann die Lebensdauer drastisch reduzieren.

Veranlassen Sie, dass Sie im Reparaturfall über ein Pulsarmband mit Widerstand verbunden sind mit dem gleichen Potential wie die Masse des Gerätes.

Bauteile und Hilfsmittel auch auf dieses gleiche Potential halten.

(NL) WAARSCHUWING

Alle IC's en vele andere halfgeleiders zijn gevoelig voor electrostatistische ontladingen (ESD).

Onzorgvuldig behandelen tijdens reparatie kan de levensduur drastisch doen verminderen. Zorg ervoor dat u tijdens reparatie via een polsband met weerstand verbonden bent met hetzelfde potentiaal als de massa van het apparaat.

Houd componenten en hulpmiddelen ook op ditzelfde potentiaal.

(I) AVVERTIMENTO

Tutti IC e parecchi semi-conduttori sono sensibili alle scariche statiche (ESD).

La loro longevità potrebbe essere fortemente ridatta in caso di non osservazione della più grande cauzione alla loro manipolazione.

Durante le riparazioni occorre quindi essere collegato allo stesso potenziale che quello della massa dell'apparecchio tramite un braccialetto a resistenza.

Assicurarsi che i componenti e anche gli utensili con quali si lavora siano anche a questo potenziale.

(GB)

Safety regulations require that the set be restored to its original condition and that parts which are identical with those specified, be used.

"Pour votre sécurité, ces documents doivent être utilisés par des spécialistes agréés, seuls habilités à réparer votre appareil en panne".

(NL)

Veiligheidsbepalingen vereisen, dat het apparaat bij reparatie in zijn oorspronkelijke toestand wordt teruggebracht en dat onderdelen, identiek aan de gespecificeerde, worden toegepast.

(F)

Les normes de sécurité exigent que l'appareil soit remis à l'état d'origine et que soient utilisées les pièces de rechange identiques à celles spécifiées.

(D)

Bei jeder Reparatur sind die geltenden Sicherheitsvorschriften zu beachten. Der Originalzustand des Geräts darf nicht verändert werden; für Reparaturen sind Original-Ersatzteile zu verwenden.

(I)

Le norme di sicurezza esigono che l'apparecchio venga rimesso nelle condizioni originali e che siano utilizzati i pezzi di ricambio identici a quelli specificati.

"After servicing and before returning set to customer perform a leakage current measurement test from all exposed metal parts to earth ground to assure no shock hazard exist. The leakage current must not exceed 0.5mA."

ESD**(GB) Warning !**

Invisible laser radiation when open.
Avoid direct exposure to beam.

(S) Varning !

Osynlig laserstrålning när apparaten är öppnad och spärren är urkopplad. Betrakta ej strålen.

(SF) Varoitus !


Avatussa laitteessa ja suojaletyksen ohitettaessa olet alltiina näkymättömälle laserisäteilylle. Älä katso säteeseen!

(DK) Advarse !

Usynlig laserstrålning ved åbning når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling.

Index

English	6
Français	29
Español	53
Deutsch	77
Nederlands	101
Italiano	125
Svenska	149
Dansk	173
Suomi	197
Português	221
Ελληνικά	245



General Information	
Environmental Information	7
Supplied Accessories	7
Safety Information	7
Preparation	
Rear Connections	8-9
Inserting batteries into the Remote Control ...	9
Controls	
Controls on the player and remote control	9-10
Operating the System	
Plug and Play	11
Demonstration Mode	11-12
Switching On	12
Switching the system to standby mode	12
Selecting the source	12
DIM mode	12
Sound Control	13
Compact Disc	
Discs for playback	14
Loading the CD Changer	14
CD Direct Play	14
Playing a Disc	15
Disc Change	15
Selecting a desired track	15
Searching for a particular passage during playback	15
Programming Tracks	15
Reviewing the programme	15
Erasing the programme	16
Shuffle	16
Repeat	16

Tuner	
Tuning to radio stations	17
Storing Preset Stations	17-18
Tuning to Preset Radio Stations	18
Receiving RDS Radio Station	20-21
News	21
Tape	
Loading a tape	19
Auto Replay	19
Tape Playback	20
Rewind/Fast Forward	20
Aux	
Selecting External Equipment	21
Recording	
One Touch Recording	22
CD Synchro Start Recording	23
Dubbing tapes	23
Recording from other sources	23
Clock/Timer	
View Clock	24
Clock Setting	24
Timer Setting	24-25
Sleep Timer	25
Specifications	
.....	26
Maintenance	
.....	27
TroubleShooting	
.....	27-28

- **The type plate (which contains the serial number) is located at the rear of the player.**
 - **Recording is permissible if copyright or other rights of third parties are not infringed.**
 - **This product complies with the radio interference requirements of the European Community.**
- Environmental Information**
All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet).
Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.

Supplied Accessories


- Remote control
- AM loop antenna
- FM wire antenna
- AC power cord

General Information

Safety Information

- Before operating the player, check that the operating voltage indicated on the typeplate (or the voltage indication beside the voltage selector) of your player is identical with the voltage of your local power supply. If not, please consult your dealer. The typeplate is located at the rear of your player.
- When the player is switched on, do not move it around.
- Place the player on a solid base (e.g. a cabinet).
- Place the player in a location with adequate ventilation to prevent internal heat build-up in your player. Allow at least 10 cm (4 inches) clearance from the rear and the top of the unit and 5 cm (2 inches) from the each side.
- Do not expose the player to excessive moisture, rain, sand or heat sources.
- Under no circumstances should you repair the player yourself, as this will invalidate the warranty!
- If the player is brought directly from a cold to a warm location, or is placed in a very damp room, moisture may condense on the lens of the disc unit inside the player. Should this occur, the CD player will not operate normally. Leave the power on for about one hour with no disc in the player until normal playback is possible.
- Electrostatic discharge may cause unexpected problems. See whether these problems disappear if you unplug the AC power cord and plug it in again after a few seconds.
- **To disconnect the player from the power supply completely, remove the AC power plug from the wall socket.**

Preparations



Rear Connections

- Clip the stripped portion of the speaker wire as shown.

(A) AM Loop Antenna Connection


Connect the supplied loop antenna to the AM ANTENNA terminal. Place the AM loop antenna far away from the system and adjust its position for the best reception.

(B) FM Wire Antenna Connection

Connect the supplied FM wire antenna to the FM AERIAL (FM ANTENNA) 75 Ω terminal. Adjust the position of the FM antenna for the best reception.

Outdoor Antenna

For better FM stereo reception, connect an outdoor FM antenna to the FM AERIAL (FM ANTENNA) 75 Ω terminal using a 75 Ω coaxial wire.



(C) Speakers Connection

- Connect the right speaker to Front terminal R, with the colored wire to + and the black wire to -.
- Connect the left speaker to Front terminal L, with the colored wire to + and the black wire to -.


Preparation

CAUTION

- Remove batteries if they are exhausted or not to be used for a long time.
- Do not use old and new or different types of batteries in combination.
- Batteries contain chemical substances, so they should be disposed off properly.

Inserting batteries into the Remote Control

- Insert the batteries (not supplied) into the remote control as shown in the battery compartment (Type R06 or AA).



Controls (illustrations on page 3)

Controls on the player and remote control

- STANDBY-ON**
 - switches the system to standby/on.
- DIGITAL SOUND CONTROL PANEL**
 - to view the desired DSC display
- DBB (DYNAMIC BASS BOOST)**
 - to switch on bass boost to enhance bass response or to switch off bass boost
- VEC**
 - to select the desired Virtual Environment Control effect : HALL, CINEMA or CONCERT.
- DSC (DIGITAL SOUND CONTROL)**
 - to select the desired sound effect : OPTIMAL, JAZZ, ROCK or TECHNO.
- JOG CONTROL**
 - to select the desired DSC setting. You must select the DSC feature first.
 - to select the desired VEC setting. You must select the VEC feature first.
- PROGRAM**
 - for CD to programme disc tracks.
 - for TUNER to programme preset radio stations.
 - for CLOCK to select 12 or 24 hour in clock setting mode.
- RECORD**
 - to start recording on tape deck 2.
- DUBBING**
 - to dub a tape in normal speed.

(10) AUTO REPLAY

- to select playback mode either in continuous AUTO PLAY or ONCE only.

(11) DISPLAY SCREEN

- to view the current setting of the system.

(12) CD CHANGER TRAY

(13) DISC CHANGE

- to change disc(s).

(14) OPEN-CLOSE

- to open or close the CD changer tray.

(15) DISC 1 / DISC 2 / DISC 3 (DISC DIRECT PLAY)

- to select a disc tray for playback.

(16) SOURCE – to select the following:

CD / (CD 1-2-3)

- to select CD mode. When disc playback is stopped, press to select disc tray 1, 2, or 3.

TUNER / (BAND)

- to select Tuner mode. When in tuner mode, press to select the waveband: FM, MW or LW.

TAPE / (TAPE 1-2)

- to select Tape mode. When tape playback is stopped, press to select either tape deck 1 or 2.

AUX (CDR/VIDEO)

- to select sound from an external source (e.g. TV, VCR, Laser Disc player, DVD player or CD Recorder).


- 17 MODE SELECTION**
- SEARCH ◀◀ ▶▶ (TUNING ◀◀▶▶)**
 - for CD to search backward/forward.
 - for TUNER to tune to a lower or higher radio frequency.
- for TAPE to rewind or fast forward a tape.
- for CLOCK to set the hour (on the system only).
- STOP•CLEAR ■**
- for CD to stop disc playback or to clear a programme.
- for TUNER to stop programming (on the system only).
- for TAPE to stop playback or recording.
- for DEMO to start or stop demonstration mode (on the system only).
- for CLOCK to exit clock setting or cancel timer (on the system only).
- for PLUG & PLAY to exit plug & play mode and return to standby mode (on the system only).

- PLAY ▶ / PAUSE ■**
- for CD to start or interrupt playback.
- for TAPE to start playback.
- for PLUG & PLAY to initiate and start plug & play from standby/demo mode (on the system only).

- PREV ◀ / NEXT ▶ (PRESET ▼▲)**
- for CD to skip to the beginning of the current, previous, or next track
- for TUNER to select a preset station in memory
- for CLOCK to set the minute (on the system only).


- 18 VOLUME**
 - to increase or decrease the volume.
- 19 INCREDIBLE SURROUND**
 - to switch on or off the surround sound effect.
- 20 ⤴**
 - to connect headphones.
- 21 CLOCK•TIMER**
 - to view the clock, set the clock or set the timer.

- 22 RDS**
 - to select RDS data in the following order: station name, programme type, radio text and frequency.
- NEWS**
 - to hear news automatically



- 23 DIM**
 - to select different brightness for the display screen : DIM 1, DIM 2, DIM 3 or DIM OFF.
- 24 TAPE DECK 2**
- 25 TAPE DECK 1**
- 26 REPEAT**
 - to repeat a disc track, a disc, or all available discs.
- 27 SHUFFLE**
 - to play all the available discs and their tracks in random order.
- 28 SLEEP**
 - to switch the system to standby mode at a selected time.
- 29 ⏻**
 - to switch the system to standby mode.

- Notes for remote control:**
- First select the source you wish to control by pressing one of the source select keys on the remote control (e.g. CD, TUNER, etc.).
 - Then select the desired function (▶, ◀, ⏻, etc.).



- 3** The system will proceed to set the RDS time automatically with the stored RDS preset station.
- If no RDS station is available in the first preset station, the programme will exit automatically.
 - After the RDS radio station is found, "INSTALL" will be displayed and followed by "TIME".
- When searching RDS time;
 - "SEARCH RDS TIME" will be displayed.
 - When RDS time is read, "RDS TIME" will be displayed. The current time will be displayed for 2 seconds and stored automatically.

- Note:**
- If RDS station does not transmit RDS time within 90 seconds, the programme will exit automatically and the display will show "RDS TIME".

- To reinstall the PLUG & PLAY**
- 1** In Standby or Demonstration mode, press and hold **PLAY** for 5 seconds (on the system only) "PLUG INSTALL - PRESET PLUG" will be displayed.
- 2** Press **PLAY** (on the system only) again to start installation.
 - To exit without storing the PLUG and PLAY; press **■** button (on the system only).

- Important:**
- Before you operate the system, complete the preparation procedures.**
- Plug and Play**
- The system provides PLUG and PLAY feature that allows you to store all available radio stations and RDS stations automatically upon power up.
- If the PLUG and PLAY has not been installed**
- Upon power up, "PLUG INSTALL - PRESET PLUG" will be displayed.
- Press **PLAY** (on the system only) to start installation.
 - "INSTALL" will be displayed and followed by "TUNER" and then "PLUG".
 - The **PROGRAM** starts flashing.
 - PLUG and PLAY will start searching for all RDS radio stations with sufficient signal strength and then followed by radio stations on FM, MW and LW band respectively. Weak RDS radio stations may be stored in later presets.
 - All available RDS and radio stations with sufficient signal strength will be stored. Up to 40 presets may be stored.
 - The last preset radio station or the first available RDS station will appear on the display when PLUG and PLAY is completed.

Operating the System

English

Notes:

- **PLUG** and **PLAY** will be reinitiated again during the next power up if:
 - i) **PLUG** and **PLAY** installation was not completed.
 - ii) No stereo frequency being detected during **PLUG** and **PLAY** "CHECK ANTENNA" will be displayed.
- You can store any radio stations manually or automatically after **PLUG** and **PLAY**.
 - When **PLUG** and **PLAY** is used, all previously stored radio stations will be replaced.
 - During **PLUG** and **PLAY**, if no button is pressed within 15 seconds, the system will go to demonstration mode (if demonstration mode is enable)

Demonstration mode

The system has a demonstration mode that shows the various features offered by the system.

To disable the demonstration mode

- Press and hold **■** (on the system only) for **5 seconds** when the system is in demonstration mode.
 - "DEMO OFF" is displayed.
 - The system will switch to standby mode.
- To enable the demonstration mode**
 - Press and hold **■** (on the system only) for **5 seconds** when the system is in standby mode.
 - The demonstration will begin.

Notes:

- If the demonstration mode has not been disabled, it will resume 5 seconds later after the system switches to standby mode.
- When the system is switched on from the main power outlet, the CD changer tray may open and close again to initialize the set.
- Even though the AC power cord is removed from and reconnected to the wall socket, the demonstration will remain off until it is switched on again.

Switching the system ON

- Press **CD**, **TUNER**, **TAPE** or **AUX**.
- Press **STANDBY-ON** in demo.

You can also switch on the system by pressing any one of the CD **DIRECT PLAY** buttons (on system only).

Switching the system to standby mode

- Press **STANDBY-ON** or **⏻** on the remote control.
 - The system will switch to standby mode.

Selecting the Source

Press the respective source selection button: **CD**, **TUNER**, **TAPE** or **AUX**.

- The display indicates the selected source.

Note:

- For an external source, make sure you have connected the audio left and right **OUT** terminals of the external equipment (TV, VCR, Laser Disc player, DVD player or CD Recorder) to the **AUX IN** terminals.

DIM mode

You can select the desired brightness for the display.

- Press **DIM** to select DIM 1, DIM 2, DIM 3 or DIM OFF display mode.
 - The **DIM** display lights up.
 - "DIM 1", "DIM 2", "DIM 3" or "DIM OFF" will be displayed depending on the mode selected.

DIM OFF - normal brightness with Spectrum Analyzer On



DIM 1 - normal brightness with Spectrum Analyzer Off



DIM 2 - half brightness with Spectrum Analyzer On



Operating the System

English

DIM 3 - half brightness with Spectrum Analyzer Off and all LEDs on the system will be switched off.



VIRTUAL ENVIRONMENT CONTROL (VEC)

The VEC feature enables you to adjust the system to select a type of environment.

- Press to select the **VEC** feature.
- Adjust the **JOG CONTROL** to select the desired Virtual Environment Control setting: **HALL**, **CINEMA** or **CONCERT**.
 - "HALL", "CINEMA" or "CONCERT" and the respective flag will be displayed.

VEC Selection	DBB	IS
HALL	On	On
CONCERT	Off	On
CINEMA	Off	On

Sound Control

VOLUME ADJUSTMENT
Adjust **VOLUME** to increase or decrease the sound level.

For Personal Listening

Connect the headphones plug to the **Ⓜ** socket at the front of the system. The speakers will be muted.

DIGITAL SOUND CONTROL (DSC)

The DSC feature enables you to enjoy special sound effects that have preset equalizer settings, providing the best music reproduction.

- Press to select the **DSC** feature.
- Adjust **JOG CONTROL** to select **OPTIMAL**, **JAZZ**, **ROCK** or **TECHNO**.
 - The Digital Sound Control display panel will light up respectively.
 - "OPTIMAL", "JAZZ", "ROCK" or "TECHNO" and the respective flag will be displayed.

Note:

- When "OPTIMAL" sound is selected, **DBB** will be switched on automatically.

DYNAMIC BASS BOOST (DBB)

The DBB mode enhances the bass response.

- Press **DBB** to switch on bass response.
 - The **DBB** button lights up.
 - "DBB ON" and the **DBB** flag will be displayed.

To switch off DBB

- Press **DBB** again.
 - The **DBB** button light is switched off.
 - "DBB OFF" will be displayed.
 - The **DBB** flag disappear from the display.

Note:

- Some CDs or tapes might be recorded in high modulation, which causes a distortion at high volume. If this occurs, switch off **DBB** or reduce the volume.


INCREDIBLE SURROUND

Normal stereo sound is determined by the distance between the front speakers. When Incredible Surround is switched on, it magnifies the virtual distance between the front speakers for an incredibly wide, enveloping, stereo effect.

- Press **INCREDIBLE SURROUND** to switch on.
 - The **INCREDIBLE SURROUND** button lights up.
 - "INCREDIBLE SURROUND" and the **IS** flag will be displayed.

To switch off Incredible Surround

- Press **INCREDIBLE SURROUND** again.
 - The **INCREDIBLE SURROUND** button light is switched off.
 - "IS OFF" will be displayed.
 - The **IS** flag disappear from the display.

**Warning!**

- 1) This system is designed for conventional discs. Do not use any accessories such as disc stabilizer rings or disc treatment sheets, etc., which may damage the disc mechanism.
 - 2) Do not load more than one disc into each tray.
 - 3) When the CD changer is loaded with discs, do not turn over or shake the system. This may jam the changer.
- You may load three discs in the CD changer for continuous playback without interruption.

Discs for playback

This system can play all digital audio disc, finalized digital audio CD-Recordable and finalized digital audio CD-Rewritable format discs.

**Disc Direct Play**

- You can play a disc directly by pressing the **DISC 1**, **DISC 2** or **DISC 3** button. The CD player will stop at the end of playback of the selected disc.
 - A lit button indicates that a disc is loaded in the disc tray
 - A flashing button indicates that a disc is playing.

Loading the CD Changer

- 1 Press **CD** to select CD mode.
- 2 Press **OPEN-CLOSE**.
 - The CD changer tray slides out.
- 3 Load a disc with the printed side up in the right tray.
 - You can load another disc in the left tray.
 - To load the third disc, press the **DISC CHANGE** button.
 - The CD changer tray will rotate until the empty tray is ready for loading.
- 4 Press **OPEN-CLOSE** to close the CD changer tray.
 - The total number of tracks and the playing time of the selected disc appear on the display.

Note:

- To ensure good system performance, wait until the CD changer completely reads the disc(s) before proceeding.

Playing a Disc

- 1 Press **▶** to start playback.
 - The disc tray, track number and elapsed playing time of the current track appear on the display.
- To interrupt playback, press **||**.
- To resume playback, press **▶** again.
- To stop playback, press **■**.

Note:

- All the available discs will play once, then stop.

Disc Change

You can change the outer two discs while the third inner disc is stopped or is playing.

- 1 Press **DISC CHANGE**.
 - The CD changer tray slides out.
- 2 Replace the discs in the left and right disc trays.
- If you wish to change the inner disc during playback, press **DISC CHANGE** again.
 - "DISC CHANGE" will be displayed.
 - The disc will stop playing.
 - The CD changer tray will close to retrieve the inner disc and then open again with the inner disc accessible.
- 3 Press **OPEN-CLOSE** to close the CD changer tray.

Selecting a desired track**Selecting a desired track when playback is stopped**

- 1 Press **◀** or **▶** until the desired track appears on the display.
- 2 Press **▶** to start playback.
 - The selected track number and elapsed playing time appear on the display.

Selecting a desired track during playback

- 1 Press **◀** or **▶** until the desired track appears on the display.
 - The selected track number and elapsed playing time appear on the display.
- If you press **◀** once it will skip to the beginning of the current track and play the track again.

Note:

- Pressing **◀** during shuffling can only skip to the beginning of the current track.

Searching for a particular passage during playback

- Press and hold **◀** or **▶** until the desired passage is located.
 - The volume will be reduced.
- Play returns to normal when **◀** or **▶** is released.

Programming Tracks

Programming tracks of a loaded disc is possible when playback is stopped. The display will indicate the total tracks stored in the programme. Up to 40 tracks can be stored in the memory in any order. When 40 tracks are stored and you attempt to store another track, the display will show "FULL".

- 1 Load the desired discs in the disc trays.
- 2 Press **PROGRAM** to start programming.
 - The **PROG** flag starts flashing.
- 3 Press the **CD (1-2-3)** or **DISC 1/2/3** button to select the disc.
- 4 Press **◀** or **▶** to select the desired track.
- 5 Press **PROGRAM** to store the track.
- Repeat steps 3 to 5 to store other discs and tracks.
- 6 Press **■** once to end programming.
 - The total number of tracks programmed and total playing time appear on the display.

Notes:

- If the total playing time is more than "99:59" or if one of the programmed tracks has a number greater than 30, then "...:..." appears on the display instead of the total playing time.
- If the system is reading the discs, programming is not possible. "READING" will be displayed and followed by "DISC 1", "2" or "3" is the current read disc number.
- During programming, if no button is pressed within 20 seconds, the system will exit programme mode automatically.
- "SELECT A DISC" will be displayed when programming an empty disc slot.

Reviewing the programme

- Reviewing of the programme is possible only when playback is stopped.
- Press **◀** or **▶** repeatedly to review the programmed tracks.
 - Press **■** to exit review mode.

Compact Disc

Playing the programme

- Press **▶** to start programme playback.
 - "PLAY PROGRAM" will be displayed.
 - The track number and elapsed playing time of the current track will appear on the display.
- If you press **REPEAT** during programme playback, the current track or all programmed tracks will be played repeatedly.
 - "TRACK" or "PROGRAM" will be displayed.
 - The **REP** and **PROG** flags appear on the display.
- Press **■** to stop programme playback.

Notes:

- If you press any of the **DISC DIRECT PLAY** buttons, the system will play the selected disc and the stored programme will be ignored temporarily. The **PROG** display also will disappear temporarily from the display. It will reappear when playback of the selected disc ends.
- **REPEAT DISC** mode will be cancelled when programme playback begins.

Erasing the programme (when playback is stopped)

- Press **■**.
- "PROGRAM CLEAR" will be displayed.

Note:

- The programme will be erased when the system is disconnected from the power supply or when the CD changer tray is opened.

Shuffle (only on remote control)

In shuffle mode, the system plays all the available discs and their tracks in random order. Shuffle may be used also when tracks are programmed.

To shuffle all the discs and tracks

- Press **SHUFFLE**.
 - "SHUFFLE" will be displayed.
 - The **SHUF** flag, the disc and the track selected at random appear on the display.
 - The discs and the tracks will be played in random order until you press **■**.
- If you press **REPEAT** during shuffling, the current track or all available discs will be played repeatedly.
 - "TRACK" or "ALL DISC" will be displayed.
 - The **REP** and **SHUF** flags appear on the display.
- Press **SHUFFLE** again to resume normal playback.
 - The **SHUF** flag disappears from the display.

Note:

- **REPEAT DISC** mode will be cancelled when shuffle is selected.


Repeat (only on remote control)

- You can play the current track, a disc or all available discs repeatedly.
- Press **REPEAT** on the remote control to select the various repeat modes.
 - "TRACK", "DISC", "ALL DISC" or "OFF" will be displayed.
 - The **REP** flag appears on the display.
 - The selected track, selected disc or all available discs will now be played repeatedly until you press **■**.
 - Press **REPEAT** until the "OFF" mode is displayed to resume normal playback.
 - The **REP** flag disappears from the display.

Notes:

- **REPEAT DISC** mode is not available during programme play or shuffle mode.
- You can also repeat shuffling a programme.
 - "TRACK" or "PROGRAM" will be displayed.
 - The **REP**, **PROG**, and **SHUF** flags appear on the display.

Tuner



Note:

- For "PLUG & PLAY" feature, please refer to page 11.

Automatic programming

- Press **TUNER (BAND)**.
- Press **PROGRAM** for more than one second.
 - The **PROG** flag starts flashing and "PLUG" will be displayed.
 - The system will start searching for all radio stations with RDS and then followed by radio stations on FM, MW and LW band respectively.
 - All available stations will be stored automatically. The frequency and preset number will be displayed briefly.
 - The system will stop searching when all the available radio stations are stored or when the memory for 40 preset radio stations is used.
 - The system will remain tuned to the last stored preset radio station.

Notes:

- You can cancel the automatic programming by pressing **PROGRAM** or **■** (on the system only).
- If you want to reserve a section of preset numbers, for example preset numbers 1 to 9, select preset 10 before starting automatic programming, only the preset numbers 10 to 40 will be programmed.

Tuning to radio stations

- Press **TUNER (BAND)** to select **TUNER** mode.
 - "TUNER" will be displayed.
 - A few seconds later, the current radio frequency will be displayed.
- Press **TUNER (BAND)** again to select the desired waveband: FM, MW or LW.
- Press **◀** or **▶** for more than one second, then release.
 - The display will show "SEARCH" until a radio station with sufficient signal strength is found.
 - Repeat this procedure until the desired station is reached.
 - To tune to a weak station, briefly press **◀** or **▶** repeatedly until the display shows the desired frequency and/or when the best reception has been obtained.

Storing Preset Stations

You can store up to 40 radio stations in the memory. When a preset radio station is selected, the preset number appears next to the frequency on the display.

Manual programming

- 1 Press **TUNER** (BAND).
- 2 Press **TUNER** (BAND) again to select the desired waveband: FM, MW or LW.
- 3 Press **PROGRAM** for less than one second. → The **PROG** flag starts flashing. → The next available preset number will be displayed for selection.
- 4 Press **◀** or **▶** to tune to the desired frequency. If you wish to store the radio station to another preset number, press **▼** or **▲** to select the desired preset number.
- 5 Press **PROGRAM** again. → The **PROG** flag disappears and the radio station will be stored.
- Repeat **steps 3 – 5** to store other preset radio stations.

Notes:

- When **40** radio stations are stored and you attempt to store another radio station, the display will show "FULL". If you want to change an existing preset number, repeat steps 3 – 5.
- You can cancel manual programming by pressing **■** (on the system only).
- During programming, if no button is pressed within 20 seconds, the system will exit programme mode automatically.

Tuning to Preset Radio Stations

- Press **▼** or **▲** to select the desired preset number. → The preset number, radio frequency, and waveband appear on the display.

Receiving RDS Radio Station

RDS (Radio Data System) is a broadcasting service that allows FM stations to send additional information along with the regular FM radio signal. This additional information can contain:

- **STATION NAME:** The radio station name is displayed.
- **PROGRAMTYPE:** The following programme types exist and can be received by your tuner: News, Affairs, Info, Sport, Educate, Drama, Culture, Science, Varied, Pop M, Rock M, MOR, (middle of the road music), Light M, Classics, Other M, No type.
- **RADIO TEXT (RT):** text messages appear in the display.

When you have tuned to a RDS station, the RDS logo  and the radio station name will appear on the display.

- The display normally shows the radio station name if available. By repeatedly pressing **RDS** button you can change the type of display information:

→ The display shows in turn:
 STATION NAME → PROGRAM TYPE →
 RADIO TEXT → TUNED FREQUENCY →
 STATION NAME ...

Note:

- When you press the **RDS** button and the display shows "NO RDS", it indicates that either the tuned station is not transmitting RDS signal or it is a non RDS station.

RDS Clock

Some RDS station may be transmitting a real clock time at an interval of every minute.

Setting the time with RDS clock

- 1 Press **CLOCK-TIMER**. → "12:00" or current time appears on the display.
- 2 Press **CLOCK-TIMER** once more to enter clock setting mode. → "00:00" or "01:00" or current time starts flashing.
- 3 Press **RDS**. → The message "SEARCH RDS TIME" will be displayed. → If the current station is not receiving any RDS information, "NO RDS TIME" will be displayed. → When the RDS clock is read, "RDS TIME" will be displayed. The current clock time is displayed for 2 seconds and will be stored automatically. → If within 90 seconds, the RDS time is not detected, "NO RDS TIME" will be displayed.

Note:

- Some RDS station may be transmitting a real time clock at a minute interval. The accuracy of the transmitted time depends on the transmitting RDS station.

News (only available in Radio Station with RDS)

You can activate NEWS function in Standby or any source mode except Tuner mode. Once the News PTY (programme type) is detected in a RDS station, it will switch to TUNER mode automatically.

To start NEWS function

- 1 Press **NEWS**.
 - The **NEWS** and "NEWS" will be displayed.
 - It will scan stations stored in the first 5 preset and wait for the News Program Type data to be available in any of these RDS stations. During the search :
 - The current source activity will remain uninterrupted.
 - If no RDS station is found in the first 5 presets, the NEWS function will be switched off. The display will show "NO RDS NEWS" and **NEWS** will disappear from the display.
 - When NEWS transmission is detected, the system will switch to Tuner mode.
 - The **NEWS** starts flashing.

To cancel NEWS function

- Press **NEWS** again.
 - The **NEWS** disappears and "NEWS OFF" will be displayed.


Notes:

- If you are listening to a non RDS TUNER radio station and should you decide to hear NEWS, first select other source (e.g. CD, TAPE or AUX), then press NEWS.

- Before using the NEWS feature, ensure that the first 5 presets are RDS stations.
- The NEWS works only once for each activation.
- During News bulletin, you can press any available source or Tuner function keys to cancel NEWS function and execute the relevant source mode.

- If set is switched to Tuner source, the NEWS function will be cancelled. "NEWS OFF" will be displayed immediately after the "TUNER" message.

Tape



Tape

Rewind/Fast Forward

- 1 **When playback is stopped**
You can rewind or fast forward the tape by pressing ◀ or ▶▶ respectively.
→ If rewinding, "T 1" or "T 2" with "<" scrolling left will be displayed.
→ If fast forwarding, "T 1" or "T 2" with ">" scrolling right will be displayed.
→ The tape will stop automatically at the end of rewinding or fast forwarding.
- 2 Press ■ to stop rewinding or fast forwarding.


- **During playback**
Press and hold ◀◀ or ▶▶ until the desired passage is located.
→ "T 1" or "T 2" with "<<" or ">>" scrolling left or right will be displayed depending on which button is pressed.
→ During searching, the sound is reduced to a low volume.
→ When you release ◀◀ or ▶▶, the tape continues playing.

Notes:

- During rewinding or fast forwarding of a tape, it is also possible to select another source (e.g. CD, TUNER, or AUX).
- Before playing a tape, check and tighten slack tape with a pencil. Slack tape may get jammed or may burst in the mechanism.
- C-120 tape is extremely thin and is easily deformed or damaged. It is not recommended for use in this system.
- Store the tapes at room temperature and do not put them too close to a magnetic field (for example, a transformer, TV, or speaker).

Loading a tape

- 1 Press **OPEN**.
- 2 The tape deck door opens.
- 3 Load the tape with the open side downward and the full spool to the left.



- 4 Close the tape deck door.

Auto Replay

- Press **A. REPLAY** to select either continuous **AUTO REPLAY** or **ONCE** during tape playback.
→ "AUTO REPLAY" (♻️) or "ONCE" (↺) will be displayed.


Notes:

- This feature is available during tape playback only.
- When "AUTO REPLAY" is selected, the tape will rewind automatically at the end of playback for the selected side. Then it will start playing again. It will replay up to a maximum of 20 times until you press ■.
- When "ONCE" is selected, the tape will play the selected side once and then stop.

Tape Playback

- 1 Press **TAPE** (TAPE 1/2) to select TAPE mode.
→ "TAPE 1" or "TAPE 2" will be displayed and followed by "T 1" or "T 2" with ">>>" or "<<<" displayed.
- 2 Load the tape into the selected tape deck.
- 3 Press ▶ to start playback.
→ "T 1" or "T 2" with ">" scrolling right will be displayed.
- Press **A. REPLAY** to select the different type of playback mode (see Auto Replay).
- 4 Press ■ to end playback.
→ "T 1" or "T 2" with ">>>>" will be displayed.

Aux




Selecting External Equipment

If you have connected the audio out terminals of the external equipment (TV/VCR, Laser Disc player, DVD player or CD Recorder) to the AUX IN terminals, you can hear the enhanced sound from the system.

- Press **AUX (CDR/VIDEO)** to select the external equipment.
→ "AUX: 1 CDR" will be displayed.

Note:

- All the sound control features (e.g. DSC, DBB, etc.) are available for selection.



CD Synchro Start Recording

- 1 Load a blank tape into tape deck 2, and a disc into a disc tray.
- 2 Press **CD** to select CD mode.
- 3 You can programme the tracks in the order you want them to be recorded (see Programming Tracks). If not, select the disc by pressing **CD** (CD 1•2•3) and the tracks are recorded according to the order on the selected disc.
- 3 Press **RECORD** to start recording.
 - The REC starts flashing.
 - Disc will start playback automatically.
- 4 Press **■** to stop recording.

Recording from other sources

- (only on tape deck 2)
- 1 Load a blank tape into tape deck 2 with the open side downward.
 - 2 Press **CD, TUNER** or **AUX**.
 - 3 Start playback of the selected source.
 - 3 Press **RECORD** to start recording.
 - The REC starts flashing.
 - 4 Press **■** to stop recording.
- Notes:
- During recording, it is not possible to listen to another source.

Dubbing tapes (from tape deck 1 to tape deck 2)

- 1 Press **TAPE** (TAPE 1•2) to select tape deck 2.
- 2 Load the prerecorded tape into tape deck 1 and a blank tape into tape deck 2 with full spool to the left.
- 3 Press **DUBBING**.
- 4 → "DUB" with ">" scrolling right will be displayed. Dubbing will start immediately.
- 4 → The REC starts flashing.
- 4 Press **■** to stop dubbing.

Notes:

- At the end of side A, flip the tapes to side B and repeat the procedure.
- Dubbing of tapes is only possible from tape deck 1 to tape deck 2.
- To ensure good dubbing, use tapes of the same length.
- You can switch to other source while dubbing.

Notes:

- If you do not intend to record via the microphone, unplug the microphone to avoid accidental mixing with other recording source.
- For recording, use only tape of IEC type I (normal tape).
- The tape is secured at both ends with leader tape. At the beginning and end of tape, nothing will be recorded for six to seven seconds.
- The recording level is set automatically, regardless of the position of VOLUME, DBB, Incredible Surround, DSC or VEC.
- To prevent accidental recording, break out the tab on the left shoulder of the tape side that you want to protect.
 - If "CHECK TAPE" is displayed, the protection tab has been broken. Put a piece of clear adhesive tape over the opening.

Recording the mixed sound / One Touch Recording

For One Touch Recording, as soon as you press

- **RECORD**, the current source (CD, TUNER or AUX) will be recorded on tape deck 2.

- 1 Load a blank tape in tape deck 2.
- 2 Press **RECORD** to start recording.
 - The REC starts flashing.
- 3 Press **■** to stop recording.

Note:

- When you press **RECORD** while in TAPE mode, "SELECT SOURCE" will be displayed. One Touch Recording is not possible in TAPE mode.

Troubleshooting

English

English


Maintenance

Cleaning the Cabinet

- Use a soft cloth slightly moistened with a mild detergent solution. Do not use a solution containing alcohol, spirits, ammonia or abrasives.

Cleaning Discs

- When a disc becomes dirty, clean it with a cleaning cloth. Wipe the disc from the center out.



- Do not use solvents such as benzene, thinner, commercially available cleaners, or antistatic spray intended for analog records.

Cleaning the DISC lens

- After prolonged use, dirt or dust may accumulate at the disc lens. To ensure good playback quality, clean the disc lens with Philips CD Lens Cleaner or any commercially available cleaner. Follow the instructions supplied with cleaner.

Cleaning the Heads and the Tape Paths

- To ensure good recording and playback quality, clean the heads, the capstan(s), and pressure roller(s) after every 50 hours of tape operation. Use a cotton swab slightly moistened with cleaning fluid or alcohol.
- You can also clean the heads by playing a cleaning tape once.

Demagnetizing the heads

- Use a demagnetizing tape available at your dealer.

Troubleshooting

WARNING

Do not open the player as there is a risk of electric shock! Under no circumstances should you try to repair the player yourself, as this will invalidate the warranty

If a fault occurs, first check the points listed below before taking the player for repair. If you are unable to remedy a problem by following these hints, consult your dealer or service centre.

Symptom

"NO DISC" is displayed.

- If the disc is inserted upside down.
- Moisture condensation at the lens.
- There is no disc in the CD tray.
- The disc is dirty, badly scratched or warped.
- The disc lens is dirty or dusty, refer to section under: Maintenance.

"DISC NOT FINALIZED" is displayed.

- The CD-RW or CD-R disc is not properly recorded for use with a standard CD player.
- The disc is badly scratched or dirty.

Poor radio reception.

- The signal is too weak, adjust the antenna or connect an external antenna for better reception.
- The TV or VCR is too close to the stereo system.

27

28

Recording or playback cannot be made or there is a decrease in audio level.

- Dirty tape heads, capstans or pressure rollers, refer to section under Maintenance.
- Magnetic build-up in the record/playback head, use demagnetizing tape.

Tape deck door cannot open.

- Reconnect the AC power plug and switch on the system again.

System does not react when any button is pressed.

- Press **STANDBY/ON** to switch the system off. Remove the AC power plug from the wall outlet, then reconnect the power plug and switch on the system again.

No or poor sound.

- Adjust the volume.
- Disconnect the headphones.
- Check that the speakers are connected correctly.
- Check if the stripped speaker wire is clamped.

Reversed left and right sound.

- Check the speaker connections and location.

Lack of bass sound or apparently imprecise physical location of musical instruments.

- Check the speaker connection for proper phasing, colored/black wires to colored/black terminals.

Remote control has no effect on the system.

- Select the source (CD, TUNER, etc.) before pressing the function button (▶, ◀, ⏪, ⏩, etc.).
- Reduce the distance to the system.
- Insert the batteries with their polarities (+/- signs) as indicated.
- Replace the batteries.

Timer is not working.

- Set the clock.
- Press **CLOCK** • **TIMER** to switch on the timer.
- If recording is in progress, stop recording.

Clock setting is erased.

- Reset the clock.

System displays features automatically, button flash continuously.



- Press and hold **■** (on the system) for five seconds to switch off the demonstration.

All lighted buttons are not lit.

- Press **DIM** until **DIM OFF** display mode is shown.

DISMANTLING INSTRUCTIONS



Dismantling of the Cassette Cover



Cassette door

Opening the CDC Tray manually



- 1) Take a paper clip or any stiff wire diameter of 1 mm -1.5mm and make a marking about 17mm from the tip.
- 2) Place the set in an upright position and insert the paper clip into the slot on the right side of the Cabinet Rear.
- 3) With the marking just outside the Cabinet Rear, you should be able to engage the gear on the side of the 3CDC-LC Module. Because of the distance between the gear and the Cabinet Rear the chance of the paper clip slipping above or below the gear is high, therefore you have to feel and adjust slightly to engage the gear correctly.
- 4) Push the gear slowly towards the front as shown until the Tray CDC starts to move out of the Front Cabinet. The Tray CDC is now disengage and can be pulled out completely



Note: If the Cabinet Rear has to be replaced, it has to be replaced by one that has a similar slot on the right side of the Cabinet otherwise there is no possibility to disassemble the same set in the future.

Dismantling of the Front Panel


- 1) With the CDC tray opened remove the Cover Tray CDC (pos 107) as indicated.
- 2) Loosen the 8 screws to separate the Front Panel from the rear portion.
 - 2 screws B on the front
 - 2 screws each on the left & right side
 - 2 screws at the bottom



Dismantling of the Cover Control on the Front (see Notes)


- 1) Insert a strong string into the slot between the Volume knob (pos 146) and Cover Ring Volume (pos 144), looped it 1,5 turns securely around the Volume knob and pulled it out as shown.
- 2) Do likewise for the Jog Rotary knob (pos 145).
- 3) Remove the 2 hidden screws A to take out the Cover Control assembly (pos 153 + 143 + 144).

Note: Only the Lightguide DSC (pos 127) is sandwiched between the Front Cabinet (pos 101) & Cover Control (pos 153).





Dismantling of Assemblies on the Front Panel


- 1) Remove the Volume and Jog Rotary knobs (pos 145 & 146) as per step 1 and 2 of **Dismantling of the Cover Control on the Front**.
- 2) Remove 3 screw C to loosen the Headphone board (1x) and the Karaoke board (2x).
Note: Karaoke board is for some version only.
- 2) Remove 12 screws D as indicated to loosen the Front board.
- 3) Remove 6 screws E to loosen the ETF7 Module.

**Dismantling of Rear Portion**


- 1) Remove 1 screw H & uncatch C1 to loosen the Mains socket board.
- 2) Remove 2 screws F, 2 screws G and uncatch C2 to loosen the Tuner board assembly.
- 3) Remove 5 screws J (3x on the rear and 2x on the heatsink) to loosen the Combi board (Main part).
- 4) Remove 2 screws K to loosen the Mains Transformer.




Service pos A




Service pos C



Service pos B



Service pos D

**Note:**

1. During repair it is possible to disconnect the following assemblies or modules while working on other areas:
 - Tuner Board
 - 3CDC Module
2. Flex cables are very fragile, care should be taken not to damage them during repair. After repair, be very sure that the flex cables are inserted properly into the flex sockets before encasing, otherwise faults may occur.

SERVICE TEST PROGRAM

To start service test program hold **▶▶** & **AUX** depressed while plugging in the mains cord

Display shows the ROM version "S-Vyy" (Main menu)

S refers to Service Mode.
V refers to Version.
yy refers to Software version number of Processor. (Counting up from 01 to 99)





Figure 1




Figure 2

Error code	Error Description
E1000	Focus Error Triggered when the focus could not be found within a certain time when starting up the CD or when the focus is lost for a certain time during play.
E1001	Radial Error Triggered when the radial servo is off-track for a certain time during play.
E1002	Sledge In Error The sledge did not reach its inner position (inner-switch is still close) before approximately 6 Sec. have passed by. Inner-switch or sledge motor problem.
E1003	Sledge Out Error The sledge did not come out of its inner position (inner-switch is still open) before approximately 250 mSec. have passed by. Inner-switch or sledge motor problem.
E1005	Jump-offtrack error Triggered in normal play when the jump destination could not be found within a certain time. When this error occurred, software will try to recover by initiating the jump command again. If it is recoverable, the disc will continue to play.
E1006	Subcode Error Triggered when a new subcode was missing for a certain time during play.
E1007	PLL Error The Phase Lock Loop could not lock within a certain time.
E1008	Turntable Motor Error Generated when the CD could not reached 75% of speed during startup within a certain time. Discmotor problem.
E1020	Focus Search Error The focus point has not been found within a certain time.
E1070	The carousel switch is not open within certain time. This can happen when either the switch is defective and closed all the time, or when the carousel is blocked when located exactly at a disc position.
E1071	The carousel position switch did not close within a certain time. This can happen when the switch is defective and never closes electrically, or when the carousel is blocked in between two disc positions. The time-out is approximately 5 Sec.
E1079	The drawer could not enter the inside position and is opening again. This happen when the drawer is blocked and cannot go fully inside or when the drawer switch is defective and does not close.

Table 2


PRESET	Europe "EUR"	East Eur. "EAS"	East Eur. Extended-band "EAS"	USA "USA"	Oversea "OSE"
1	87.5MHz	87.5MHz	65.81MHz	87.5MHz	87.5MHz
2	108MHz	108MHz	108MHz	108MHz	108MHz
3	531kHz	531kHz	74MHz	530kHz	531/530kHz*
4	1602kHz	1602kHz	87.5MHz	1700kHz	1602/1700kHz*
5	558kHz	558kHz	531kHz	560kHz	558/560kHz*
6	1494kHz	1494kHz	1602kHz	1500kHz	1494/1500kHz*
7	153kHz	87.5MHz	558kHz	98MHz	87.5/98MHz*
8	279kHz	87.5MHz	1494kHz	87.5MHz	87.5MHz
9	198kHz	87.5MHz	98MHz	87.5MHz	87.5MHz
10	98MHz	87.5MHz	70.01MHz	87.5MHz	87.5MHz
11	87.5MHz	98MHz	65.81MHz	87.5MHz	98/87.5MHz*

Table 1

Note: * Depending on the selected grid frequency (9 or 10kHz)
By holding the TUNER and **▶▶** buttons depressed while switching on the Mains supply, one of the undermentioned features will be activated:
- the tuning grid frequency is toggled between 9kHz and 10kHz for the Oversea (/21) version.
- the extended FM1 (65.81MHz - 74MHz) is toggled on and off for East Eur. (/34) version.

TEST	Activated with	ACTION
EEPROM TEST	▶▶	A test pattern will be sent to the EEPROM. "PASS" is displayed if the uProcessor read back the test pattern correctly, otherwise "ERROR" will be displayed.
EEPROM FORMAT	◀◀	Load default data. Display shows "NEW" for 1 second. Caution! All presets from the customer will be lost!!
ENCODER TEST	Volume Knob or Jog Shuttle knob	Display shows value for 2 seconds. Values increases or decreases in steps of 1 until 0 (Min.) or 40 (Max.) is reached.
LEAVE SERVICE TESTPROGRAM	Disconnect mains cord	

SET BLOCK DIAGRAM



NOTE :

- ➔ MAIN SIGNAL PATH
- MEASUREMENTS ARE IN AUX MODE
- XX mV LEVELS AT MAX VOL
- YY dBA S/N AT 500mW
- ZZ dB HEADROOM (1% thd) WRT TO LEVEL AT MAX VOL.
- ** For version with small FTD, only SA3 is use.
- # Provision for VCD



Updated on 10-06-99

FRONT BOARD

TABLE OF CONTENTS

FTD Display pin connection	6-1
Variation Table	6-2
Circuit diagram	6-3
Component Layout	6-4
Chip layout	6-5
Electrical parts list	6-6

FTD DISPLAY PIN CONNECTIONS



	1G	2G	3G	4G	5G	6G	7G	8G	9G	10G	11G	12G		
P1	a	a	a	a	a	a	a	a	CINEMA	B1	B1	OPTI		
P2	h	h	h	h	h	h	h	h	HALL	B2	B2	JAZZ		
P3	j, p	j, p	j, p	j, p	j, p	j, p	j, p	j, p	REC	B3	B3	ROCK		
P4	k	k	k	k	k	k	k	k	CONCERT	B4	B4	TECHNO		
P5	b	b	b	b	b	b	b	b	O((B5	B5	SLEEP		
P6	f	f	f	f	f	f	f	f	REP	B6	B6	TIMER		
P7	m	m	m	m	m	m	m	m	SHUF	B7	B7	CDC		
P8	g	g	g	g	g	g	g	g	PROG	B8	B8	1		
P9	c	c	c	c	c	c	c	c	IS	B9	B9	2		
P10	e	e	e	e	e	e	e	e	DBB	B10	B10	3		
P11	r	r	r	r	r	r	r	r	S1	B11	B11	↶		
P12	n	n	n	n	n	n	n	n	S2	B12	B12	➤		
P13	d	d	d	d	d	d	d	d	-	B13	B13	S3		
P14	MUTE	DIM	1	ALB	(((•)))	R•D•S	NEWS	TITLE	-	B14	B14	S4		
P15	-	-	2	-	-	Col	-	-	-	LW	FM	-		
P16	-	-	3	-	-	Dp	-	-	-	AM	MW	-		

Front Board application

A53920	FW-C200/21/21M, FW-C220/21K
A53930	FW-C220/22/34
A53940	FW-C200/33
A53950	FW-C100/21/21M/22/30/33/34/37, FW-C105/21
A53970	FW-C250/37
A53980	FW-C250/21
A53990	FW-C280/22/34
A54000	FW-C290/21
A54340	FW-C200/30
A54450	FW-C150/37

FEATURES:	A53920	A53930	A53940	A53950	A53970	A53980	A53990	A54000	A54340	A54450
RDS	-	x	-	-	-	-	x	-	-	-
Rotary Encoder	x	x	x	-	x	x	x	x	x	-
Jog Encoder	-	-	-	-	x	x	x	x	-	-
Spectrum Analyzer	-	-	-	-	-	-	x	x	-	-
Biplaner LED	-	-	-	-	-	-	x	x	-	-
Small FTD	x	x	x	x	x	x	-	-	x	x
Large FTD	-	-	-	-	-	-	x	x	-	-
NTC	-	-	-	-	-	x	-	x	-	-
LED Control	x	x	x	-	x	x	x	x	x	-


Variations table for Front Board

ITEM NO.	A53920	A53930	A53940	A53950	A53970	A53980	A53990	A54000	A54340	A54450
DM21	-	-	-	x	x	x	-	-	-	x
DM23	-	-	-	-	-	-	-	-	-	-
DM26	x	-	x	x	x	x	-	x	x	x
DM27	-	x	-	-	-	-	x	-	-	-
DM29	-	-	-	-	-	x	-	x	-	-
1402	-	-	-	-	-	-	x	x	-	-
1403	x	x	x	x	x	x	-	-	x	x
1404	x	x	x	x	x	x	x	x	x	x
1405	x	x	x	-	-	-	x	x	x	-
1418	-	-	-	-	-	-	x	x	-	-
1419	-	-	-	-	-	-	x	x	-	-
1420	-	-	-	-	-	-	x	x	-	-
1421	x	x	x	-	-	-	x	x	x	-
1423	x	x	x	-	-	-	x	x	x	-
1425	-	x	-	-	-	-	x	-	-	-
1426	x	x	x	-	-	-	x	x	x	-
1427	-	x	-	-	-	-	x	-	-	-
1428	-	-	-	x	-	-	-	-	-	x
1429	-	-	-	x	-	-	-	-	-	x
1430	x	x	x	x	-	-	-	-	x	x
2417	220μF	220μF	220μF	-	220μF	220μF	220μF	220μF	220μF	-
2421	22μF	22μF	22μF	2.2μF	22μF	22μF	22μF	22μF	22μF	2.2μF
2432	-	100pF	-	-	-	-	100pF	-	-	-
2433	-	47pF	-	-	-	-	47pF	-	-	-
2462	220nF	220nF	220nF	-	220nF	220nF	220nF	220nF	220nF	-
3407	-	-	-	-	-	-	1k	1k	-	-
3417	820R	820R	820R	-	820R	820R	820R	820R	820R	-
3419	820R	820R	820R	-	820R	820R	820R	820R	820R	-
3433	820R	820R	820R	-	820R	820R	820R	820R	820R	-

ITEM NO.	A53920	A53930	A53940	A53950	A53970	A53980	A53990	A54000	A54340	A54450
3448	820R	820R	820R	-	820R	820R	820R	820R	820R	-
3449	820R	820R	820R	-	820R	820R	820R	820R	820R	-
3451	820R	820R	820R	-	820R	820R	820R	820R	820R	-
3452	820R	820R	820R	-	820R	820R	820R	820R	820R	-
3457	820R	820R	820R	-	820R	820R	820R	820R	820R	-
3458	-	-	-	-	-	-	1k	1k	-	-
3460	-	-	-	-	-	-	1k	1k	-	-
3465	1k	1k	1k	-	1k	1k	1k	1k	1k	-
3471	4R7	4R7	4R7	4R7	4R7	4R7	1R	4R7	4R7	4R7
3475	820R	820R	820R	-	820R	820R	820R	820R	820R	-
3479	1k	1k	1k	-	1k	1k	1k	1k	1k	-
3483	4R7	4R7	4R7	4R7	4R7	4R7	1R	4R7	4R7	4R7
3516	-	-	-	330R	-	-	-	-	-	330R
3518	-	-	-	-	-	-	330R	330R	-	-
3524	1k	1k	1k	-	-	-	1k	1k	1k	-
3539	10k	-	10k	10k	10k	10k	-	10k	10k	10k
3541	-	1k	-	-	-	-	1k	-	-	-
3546	10k	-	10k	10k	10k	10k	-	10k	10k	10k
3555	10k	10k	10k	10k	10k	10k	-	-	10k	10k
3575	10k	10k	10k	10k	10k	10k	-	-	10k	10k
3576	10k	10k	10k	10k	10k	10k	-	-	10k	10k
3577	-	-	-	-	-	-	12k	12k	-	-
3578	-	-	-	-	-	-	5k6	5k6	-	-
3586	-	-	-	-	-	-	1k	1k	-	-
3588	-	-	-	10k	-	-	-	-	-	10k
3600	5k6	5k6	5k6	5k6	5k6	5k6	-	-	5k6	5k6
3602	-	-	-	10k	10k	10k	-	-	-	10k
3603	10k	10k	10k	6k8	10k	10k	10k	10k	10k	10k
3613	12k	12k	12k	47k	12k	12k	12k	12k	12k	12k
3614	-	-	-	-	-	-	820R	820R	-	-
3615	-	-	-	-	-	-	820R	820R	-	-
3616	-	-	-	-	-	1k	-	1k	-	-
3617	10k	10k	10k	10k	10k	-	10k	-	10k	10k
4400	x	x	x	x	-	-	-	-	x	x
4407	x	x	x	-	x	x	-	-	x	-
4410	x	x	x	x	x	-	x	-	x	x
4412	-	-	-	-	-	-	x	x	-	-
4413	-	-	-	x	-	-	-	-	-	x
4417	x	x	x	-	-	-	-	-	x	-
4436	x	x	x	-	-	-	-	-	x	-
4588	-	-	-	x	-	-	-	-	-	x
6401	-	-	-	-	-	x	x	x	x	-
6402	-	-	-	-	-	-	x	x	-	-
6404	-	-	-	-	-	x	x	x	-	-
6405	-	-	-	-	-	-	x	x	-	-
6420	-	-	-	-	-	-	x	x	-	-
6422	-	-	-	x	-	-	-	-	-	x
6423	x	-	x	-	-	-	x	-	x	-
6424	-	-	-	-	-	x	x	-	-	-
6428	x	x	x	-	-	x	x	x	x	-
6433	-	-	-	-	-	x	x	-	-	-
6445	x	x	x	-	-	-	-	-	x	-
6446	x	x	x	-	-	-	-	-	x	-
6447	x	x	x	-	-	x	x	-	-	-
9475	x	x	x	x	x	x	-	-	x	x
9488	-	-	-	-	-	x	x	x	x	-
9520	-	-	-	-	-	x	x	x	x	-
9523	x	x	x	x	x	x	-	-	x	x

x = Item in use.

CIRCUIT DIAGRAM



21 H6	3446 D10	4417 E16
23 H8	3447 D10	4436 C16
26 M2	3448 D16	4446 D4
27 K2	3449 D16	4588 E18
28 I3	3451 D16	4589 B2
29 H2	3452 E16	4590 B3
1400 B5	3453 D6	5400 B8
1401 D1	3454 E13	5401 G9
1402 C3	3455 D6	5402 E5
1403 C2	3456 E10	5403 H10
1404 J18	3457 E16	5404 E3
1405 H16	3458 D6	5405 E3
1406 E13	3459 E11	5406 D10
1407 E13	3460 D6	5407 H10
1408 E14	3461 H11	6400 C16
1409 E13	3462 E13	6401 C16
1410 E13	3463 E5	6402 D15
1411 E13	3464 E11	6403 D15
1412 F13	3465 F6	6404 E15
1413 F14	3466 H11	6405 G16
1414 F13	3467 F13	6406 F16
1415 F13	3468 F5	6407 G16
1416 F14	3471 E3	6408 G16
1417 F13	3472 F6	6409 F16
1418 F13	3474 F13	6410 D13
1419 F14	3475 F16	6411 D14
1420 G13	3476 F6	6412 E12
1421 G13	3477 F11	6413 E12
1422 G14	3478 F6	6414 F12
1423 G13	3479 F11	6415 F12
1424 G13	3480 F13	6416 F12
1425 G14	3481 F6	6417 G12
1426 G13	3482 H15	6418 G12
1427 G13	3483 D3	6419 G12
1428 H13	3484 G6	6420 H12
1429 H14	3485 H15	6421 H12
1430 G14	3486 G6	6422 H12
1431 H2	3488 G13	6423 E14
1432 H13	3489 G6	6424 E14
1433 F7	3490 H11	6425 D4
1434 B2	3493 G13	6426 E4
1436 I12	3494 L13	6428 F5
1437 J12	3495 L13	6433 F14
1438 A9	3496 L14	6445 E15
2406 H6	3497 G7	6446 E15
2407 H8	3498 G7	6447 D15
2408 B8	3500 G8	7401 G6
2410 H8	3501 G9	7402 J2
2411 B9	3502 J15	7403 D14
2412 C17	3503 G10	7404 F17
2414 J2	3504 H10	7405 D17
2415 D11	3505 G13	7406 J13
2416 E5	3506 H7	7409 M14
2417 J14	3507 H7	7410 A13
2418 D3	3508 H7	7411 A15
2419 D5	3509 H7	7412 B13
2420 D3	3510 H9	7413 B15
2421 G11	3511 J16	7414 B8
2422 J13	3512 H10	7415 B8
2423 H8	3513 H10	9418 D11
2424 H9	3515 K14	9458 H10
2425 K13	3516 H13	9479 E3
2426 L13	3517 F15	9469 B8
2427 L14	3518 H13	9475 H12
2428 K13	3519 H13	9479 E3
2430 J6	3520 H8	9488 E16
2431 J16	3521 H8	9517 M5
2432 L4	3522 F15	9520 D16
2433 K4	3523 H10	9521 D3
2434 L4	3525 H15	9522 D3
2435 M5	3527 H15	9523 C4
2436 M5	3528 C14	
2437 M5	3529 C14	
2439 K9	3530 D19	
2440 K6	3531 C13	
2441 K11	3532 B9	
2442 K11	3533 L5	
2443 H9	3534 L5	
2444 J6	3535 L5	
2446 H11	3536 H3	
2447 H11	3537 H4	
2448 L16	3539 J10	
2449 K17	3541 L4	
2450 E17	3543 L4	
2451 G18	3544 J10	
2452 L17	3545 L4	
2453 L17	3546 K10	
2454 K17	3547 L4	
2455 K16	3548 L4	
2456 G3	3549 K15	
2457 G3	3551 D18	
2458 G3	3550 G11	
2459 J16	3553 J11	
2460 H15	3554 J11	
2462 H4	3555 E11	
2464 I4	3556 G11	
2468 I4	3558 C17	
2469 A13	3559 H10	
2470 B13	3561 A13	
2471 A15	3562 A13	
2472 B15	3563 A15	
2473 D11	3564 A15	
2474 D12	3565 B13	
2475 F18	3566 B13	
2476 D3	3567 B15	
2477 D3	3568 B15	
2478 D4	3569 F4	
2479 D4	3570 G4	
2480 H13	3571 H18	
2481 H6	3572 G18	
2482 M5	3573 F4	
2483 H5	3574 G4	
2484 H5	3575 E6	
2485 H6	3576 D5	
2486 H6	3577 F16	
2487 F18	3578 H15	
2488 E5	3581 B14	
2489 J15	3582 H10	
2490 C5	3583 H11	
2491 D2	3584 F10	
2492 D2	3585 F10	
2493 E2	3586 F11	
3400 I8	3587 E10	
3401 I9	3588 B5	
3402 J10	3600 B5	
3406 J2	3601 G5	
3407 G17	3602 G6	
3410 J3	3600 F16	
3412 J1	3604 K15	
3414 J3	3605 L15	
3415 J1	3606 L16	
3417 G16	3607 J16	
3419 G16	3608 J16	
3420 D7	3609 J16	
3421 D7	3610 J16	
3422 D7	3611 H4	
3423 D8	3612 J13	
3424 D8	3613 G15	
3425 D8	3614 C13	
3426 D8	3615 C14	
3427 D8	3616 F11	
3428 D9	3617 H11	
3429 D9	3618 E11	
3430 D18	3618 L16	
3431 D10	4400 G14	
3433 F16	4401 K1	
3434 D6	4402 J3	
3435 D7	4403 B16	
3436 D7	4404 C8	
3437 D7	4405 C9	
3438 D7	4406 L15	
3439 D8	4406 H6	
3440 D8	4407 D16	
3441 D8	4408 J15	
3442 D9	4409 J16	
3443 D9	4410 E11	
3444 D9	4411 C4	
3445 D9	4412 F6	

ELECTRICAL PARTS LIST - FRONT BOARD

MISCELLANEOUS

1401	2422 025 14546	Flex Socket 16pin Hort.	2427	4822 122 33127	2,2nF 10% 63V
1404	4822 265 11531	Flex Socket 9pin Hort.	2428	4822 122 33177	10nF 20% 50V
1405	4822 267 10953	Flex Socket 7pin Vert.	2430	5322 116 80853	560pF 5% 63V
1406	4822 276 13775	Tact Switch	2431	4822 126 14585	100nF 10% 50V
1407	4822 276 13775	Tact Switch	2432	5322 122 32531	100pF 5% 50V
1408	4822 276 13775	Tact Switch	2433	4822 126 13692	47pF 1% 63V
1409	4822 276 13775	Tact Switch	2434	4822 126 13692	47pF 1% 63V
1410	4822 276 13775	Tact Switch	2435	4822 126 13692	47pF 1% 63V
1411	4822 276 13775	Tact Switch	2436	4822 126 13692	47pF 1% 63V
1412	4822 276 13775	Tact Switch	2437	4822 126 13692	47pF 1% 63V
1413	4822 276 13775	Tact Switch	2439	4822 126 14585	100nF 10% 50V
1414	4822 276 13775	Tact Switch	2440	4822 124 22652	2,2µF 20% 50V
1415	4822 276 13775	Tact Switch	2441	4822 122 33177	10nF 20% 50V
1416	4822 276 13775	Tact Switch	2442	4822 122 33177	10nF 20% 50V
1417	4822 276 13775	Tact Switch	2443	4822 122 33177	10nF 20% 50V
1418	4822 276 13775	Tact Switch	2445	5322 116 80853	560pF 5% 63V
1419	4822 276 13775	Tact Switch	2446	4822 122 33177	10nF 20% 50V
1420	4822 276 13775	Tact Switch	2447	4822 122 33177	10nF 20% 50V
1421	4822 276 13775	Tact Switch	2462	4822 126 14076	220nF +80/-20% 25V
1422	4822 276 13775	Tact Switch	2464	4822 126 14076	220nF +80/-20% 25V
1423	4822 276 13775	Tact Switch	2468	4822 126 14076	220nF +80/-20% 25V
1424	4822 276 13775	Tact Switch	2475	4822 126 14585	100nF 10% 50V
1425	4822 276 13775	Tact Switch	2476	4822 124 12032	4,7µF 20% 50V
1426	4822 276 13775	Tact Switch	2477	4822 126 14043	1µF +80/-20% 16V
1427	4822 276 13775	Tact Switch	2479	4822 126 14585	100nF 10% 50V
1432	4822 276 13775	Tact Switch	2481	5322 122 32268	470pF 5% 63V
1433	4822 242 72195	Quartz 4,332MHz	2482	4822 126 12882	100nF +80/-20% 50V
1436	4822 273 10366	Rotary Encoder 24pin	2483	5322 122 32268	470pF 5% 63V
1437	4822 273 10365	Rotary Encoder 24pin	2484	5322 122 32268	470pF 5% 63V
1438	3139 110 52640	FTD Display BJ796GNK	2485	5322 122 32268	470pF 5% 63V
			2486	5322 122 32268	470pF 5% 63V
			2488	4822 126 14585	100nF 10% 50V
			2489	4822 122 33891	3,3nF 10% 63V
			2493	4822 126 14585	100nF 10% 50V

CAPACITORS

2406	5322 122 32659	33pF 5% 50V
2407	5322 122 32659	33pF 5% 50V
2408	5322 122 32531	100pF 5% 50V
2409	5322 122 32531	100pF 5% 50V
2410	4822 126 13692	47pF 1% 63V
2411	4822 126 13692	47pF 1% 63V
2412	4822 126 14585	100nF 10% 50V
2414	4822 126 13838	100nF +80/-20% 50V
2415	4822 126 14585	100nF 10% 50V
2416	4822 124 23432	100µF 20% 10V
2417	4822 124 12245	220µF 20% 16V
2418	4822 126 14043	1µF +80/-20% 16V
2419	4822 124 41584	100µF 20% 10V
2420	4822 124 12032	4,7µF 20% 50V
2421	4822 124 81151	22µF 20% 50V
2422	4822 126 14585	100nF 10% 50V
2423	4822 126 13486	15pF 2% 63V
2424	4822 126 13486	15pF 2% 63V
2425	4822 126 13838	100nF +80/-20% 50V
2426	4822 126 13751	47nF 10% 63V

RESISTORS

3400	4822 117 13579	220k 1% 0,1W
3401	4822 117 11449	2k2 5% 0,1W
3402	4822 117 10833	10k 1% 0,1W
3406	4822 051 20479	47R 5% 0,1W
3407	4822 051 10102	1k 2% 0,25W
3410	4822 051 20392	3k9 5% 0,1W
3412	4822 051 20392	3k9 5% 0,1W
3417	4822 117 11454	820R 1% 0,1W
3419	4822 116 52231	820R 5% 0,5W
3420	4822 051 10102	1k 2% 0,25W
3421	4822 051 10102	1k 2% 0,25W
3422	4822 051 10102	1k 2% 0,25W
3423	4822 051 10102	1k 2% 0,25W
3424	4822 051 10102	1k 2% 0,25W
3425	4822 051 10102	1k 2% 0,25W
3426	4822 051 10102	1k 2% 0,25W

ELECTRICAL PARTS LIST - FRONT BOARD

3427	4822 051 10102	1k 2% 0,25W	3484	4822 051 10102	1k 2% 0,25W
3428	4822 051 10102	1k 2% 0,25W	3485	4822 051 10102	1k 2% 0,25W
3429	4822 051 10102	1k 2% 0,25W	3486	4822 051 10102	1k 2% 0,25W
3430	4822 051 10102	1k 2% 0,25W	3488	4822 117 13577	330R 1% 0,1W
3431	4822 051 10102	1k 2% 0,25W	3489	4822 051 10102	1k 2% 0,25W
3433	4822 117 11454	820R 1% 0,1W	3490	4822 051 10102	1k 2% 0,25W
3434	4822 051 10102	1k 2% 0,25W	3493	4822 117 13577	330R 1% 0,1W
3435	4822 051 10102	1k 2% 0,25W	3494	4822 117 13577	330R 1% 0,1W
3436	4822 051 10102	1k 2% 0,25W	3495	4822 117 10833	10k 1% 0,1W
3437	4822 051 10102	1k 2% 0,25W	3496	4822 051 10102	1k 2% 0,25W
3438	4822 051 10102	1k 2% 0,25W	3497	4822 050 11002	1k 1% 0,4W
3439	4822 051 10102	1k 2% 0,25W	3498	4822 051 10102	1k 2% 0,25W
3440	4822 051 10102	1k 2% 0,25W	3499	4822 117 10833	10k 1% 0,1W
3441	4822 051 10102	1k 2% 0,25W	3500	4822 051 10102	1k 2% 0,25W
3442	4822 051 10102	1k 2% 0,25W	3501	4822 116 52226	560R 5% 0,5W
3443	4822 051 10102	1k 2% 0,25W	3502	4822 051 20182	1k8 5% 0,1W
3444	4822 051 10102	1k 2% 0,25W	3503	4822 050 11002	1k 1% 0,4W
3445	4822 051 10102	1k 2% 0,25W	3504	4822 051 10102	1k 2% 0,25W
3446	4822 051 10102	1k 2% 0,25W	3505	4822 117 13577	330R 1% 0,1W
3447	4822 051 10102	1k 2% 0,25W	3506	4822 051 10102	1k 2% 0,25W
3448	4822 117 11454	820R 1% 0,1W	3507	4822 050 11002	1k 1% 0,4W
3449	4822 116 52231	820R 5% 0,5W	3508	4822 051 10102	1k 2% 0,25W
3451	4822 116 52231	820R 5% 0,5W	3509	4822 051 10102	1k 2% 0,25W
3452	4822 117 11454	820R 1% 0,1W	3510	4822 050 11002	1k 1% 0,4W
3453	4822 051 10102	1k 2% 0,25W	3511	4822 051 20182	1k8 5% 0,1W
3454	4822 117 13577	330R 1% 0,1W	3512	4822 050 21003	10k 1% 0,6W
3455	4822 051 10102	1k 2% 0,25W	3513	4822 050 21003	10k 1% 0,6W
3456	4822 117 10833	10k 1% 0,1W	3515	4822 117 10837	100k 1% 0,1W
3457	4822 117 11454	820R 1% 0,1W	3517	4822 117 11507	6k8 1% 0,1W
3458	4822 051 10102	1k 2% 0,25W	3518	4822 117 13577	330R 1% 0,1W
3459	4822 050 21003	10k 1% 0,6W	3519	4822 117 13577	330R 1% 0,1W
3460	4822 051 10102	1k 2% 0,25W	3520	4822 050 21003	10k 1% 0,6W
3461	4822 117 10833	10k 1% 0,1W	3521	4822 051 10102	1k 2% 0,25W
3462	4822 117 13577	330R 1% 0,1W	3522	4822 117 12955	2k7 1% 0,1W
3463	4822 117 10833	10k 1% 0,1W	3524	4822 050 11002	1k 1% 0,4W
3464	4822 117 10833	10k 1% 0,1W	3525	4822 050 11002	1k 1% 0,4W
3465	4822 051 10102	1k 2% 0,25W	3527	4822 050 11002	1k 1% 0,4W
3466	4822 117 10833	10k 1% 0,1W	3528	4822 051 10102	1k 2% 0,25W
3467	4822 117 13577	330R 1% 0,1W	3529	4822 051 10102	1k 2% 0,25W
3469	4822 051 10102	1k 2% 0,25W	3530	4822 117 10833	10k 1% 0,1W
3471	4822 050 24708	4R7 1% 0,6W	3531	4822 117 10837	100k 1% 0,1W
3472	4822 051 10102	1k 2% 0,25W	3532	4822 117 10837	100k 1% 0,1W
3474	4822 117 13577	330R 1% 0,1W	3533	4822 117 10833	10k 1% 0,1W
3475	4822 116 52231	820R 5% 0,5W	3534	4822 117 10833	10k 1% 0,1W
3476	4822 051 10102	1k 2% 0,25W	3535	4822 117 10833	10k 1% 0,1W
3477	4822 051 10102	1k 2% 0,25W	3536	4822 051 20474	470k 5% 0,1W
3478	4822 117 11373	100R 1% 0,1W	3537	4822 051 20474	470k 5% 0,1W
3479	4822 051 10102	1k 2% 0,25W	3541	4822 050 11002	1k 1% 0,4W
3480	4822 117 13577	330R 1% 0,1W	3543	4822 051 10102	1k 2% 0,25W
3481	4822 051 10102	1k 2% 0,25W	3544	4822 117 10833	10k 1% 0,1W
3482	4822 051 10102	1k 2% 0,25W	3545	4822 051 10102	1k 2% 0,25W
3483	4822 050 24708	4R7 1% 0,6W	3547	4822 051 10102	1k 2% 0,25W

ELECTRICAL PARTS LIST - FRONT BOARD

RESISTORS

3548	4822 051 10102	1k 2% 0,25W
3549	4822 117 10833	10k 1% 0,1W
3551	4822 117 13577	330R 1% 0,1W
3552	4822 117 13577	330R 1% 0,1W
3553	4822 117 10833	10k 1% 0,1W
3554	4822 117 10833	10k 1% 0,1W
3556	4822 051 10102	1k 2% 0,25W
3558	4822 117 10833	10k 1% 0,1W
3559	4822 051 20105	1M 5% 0,1W
3561	4822 051 20472	4k7 5% 0,1W
3562	4822 117 10833	10k 1% 0,1W
3563	4822 117 10833	10k 1% 0,1W
3564	4822 117 10833	10k 1% 0,1W
3565	4822 051 20472	4k7 5% 0,1W
3566	4822 117 10833	10k 1% 0,1W
3567	4822 117 10833	10k 1% 0,1W
3568	4822 117 10834	47k 1% 0,1W
3569	4822 051 20223	22k 5% 0,1W
3570	4822 051 20223	22k 5% 0,1W
3571	4822 117 11383	12k 1% 0,1W
3572	4822 117 10833	10k 1% 0,1W
3573	4822 051 20223	22k 5% 0,1W
3574	4822 051 20223	22k 5% 0,1W
3577	4822 117 11383	12k 1% 0,1W
3578	4822 051 20562	5k6 5% 0,1W
3581	4822 117 10833	10k 1% 0,1W
3584	4822 051 10102	1k 2% 0,25W
3585	4822 051 10102	1k 2% 0,25W
3586	4822 050 11002	1k 1% 0,4W
3587	4822 050 21003	10k 1% 0,6W
3601	4822 117 10833	10k 1% 0,1W
3603	4822 117 10833	10k 1% 0,1W
3607	4822 051 20182	1k8 5% 0,1W
3608	4822 051 20182	1k8 5% 0,1W
3609	4822 051 20182	1k8 5% 0,1W
3610	4822 051 20182	1k8 5% 0,1W
3611	4822 051 20474	470k 5% 0,1W
3612	4822 117 10833	10k 1% 0,1W
3613	4822 117 11383	12k 1% 0,1W
3614	4822 117 11454	820R 1% 0,1W
3615	4822 117 11454	820R 1% 0,1W
3617	4822 050 21003	10k 1% 0,6W
4401	4822 051 20008	0R Jumper 0805
4402	4822 051 20008	0R Jumper 0805
4410	4822 051 20008	0R Jumper 0805
4411	4822 051 20008	0R Jumper 0805
4412	4822 051 20008	0R Jumper 0805
4414	4822 051 20008	0R Jumper 0805
4416	4822 051 20008	0R Jumper 0805
4418	4822 051 20008	0R Jumper 0805
4419	4822 051 20008	0R Jumper 0805
4420	4822 051 20008	0R Jumper 0805

4421	4822 051 20008	0R Jumper 0805
4422	4822 051 20008	0R Jumper 0805
4423	4822 051 20008	0R Jumper 0805
4424	4822 051 20008	0R Jumper 0805
4425	4822 051 20008	0R Jumper 0805
4426	4822 051 20008	0R Jumper 0805
4427	4822 051 20008	0R Jumper 0805
4428	4822 051 20008	0R Jumper 0805
4429	4822 051 20008	0R Jumper 0805
4430	4822 051 20008	0R Jumper 0805
4431	4822 051 20008	0R Jumper 0805
4432	4822 051 20008	0R Jumper 0805
4433	4822 051 20008	0R Jumper 0805
4434	4822 051 20008	0R Jumper 0805
4435	4822 051 20008	0R Jumper 0805
4437	4822 051 20008	0R Jumper 0805
4438	4822 051 20008	0R Jumper 0805
4439	4822 051 20008	0R Jumper 0805
4440	4822 051 20008	0R Jumper 0805
4441	4822 051 20008	0R Jumper 0805
4442	4822 051 20008	0R Jumper 0805
4443	4822 051 20008	0R Jumper 0805
4444	4822 051 20008	0R Jumper 0805
4445	4822 051 20008	0R Jumper 0805
4446	4822 051 20008	0R Jumper 0805
4447	4822 051 20008	0R Jumper 0805
4448	4822 051 20008	0R Jumper 0805
4449	4822 051 20008	0R Jumper 0805
4450	4822 051 20008	0R Jumper 0805
4451	4822 051 20008	0R Jumper 0805
4452	4822 051 20008	0R Jumper 0805
4453	4822 051 20008	0R Jumper 0805
4454	4822 051 20008	0R Jumper 0805
4455	4822 051 20008	0R Jumper 0805
4456	4822 051 20008	0R Jumper 0805
4457	4822 051 20008	0R Jumper 0805
4458	4822 051 20008	0R Jumper 0805
4459	4822 051 20008	0R Jumper 0805
4460	4822 051 20008	0R Jumper 0805
4461	4822 051 20008	0R Jumper 0805
4462	4822 051 20008	0R Jumper 0805
4463	4822 051 20008	0R Jumper 0805
4464	4822 051 20008	0R Jumper 0805
4465	4822 051 20008	0R Jumper 0805
4466	4822 051 20008	0R Jumper 0805
4467	4822 051 20008	0R Jumper 0805
4468	4822 051 20008	0R Jumper 0805
4469	4822 051 20008	0R Jumper 0805
4470	4822 051 20008	0R Jumper 0805
4471	4822 051 20008	0R Jumper 0805
4472	4822 051 20008	0R Jumper 0805
4473	4822 051 20008	0R Jumper 0805

ELECTRICAL PARTS LIST - FRONT BOARD

4474	4822 051 20008	0R Jumper 0805
4475	4822 051 20008	0R Jumper 0805
4476	4822 051 20008	0R Jumper 0805
4477	4822 051 20008	0R Jumper 0805
4478	4822 051 20008	0R Jumper 0805
4479	4822 051 20008	0R Jumper 0805
4480	4822 051 20008	0R Jumper 0805
4481	4822 051 20008	0R Jumper 0805
4482	4822 051 20008	0R Jumper 0805
4483	4822 051 20008	0R Jumper 0805
4484	4822 051 20008	0R Jumper 0805
4485	4822 051 20008	0R Jumper 0805
4486	4822 051 20008	0R Jumper 0805
4487	4822 051 20008	0R Jumper 0805
4488	4822 051 20008	0R Jumper 0805
4489	4822 051 20008	0R Jumper 0805
4490	4822 051 20008	0R Jumper 0805
4491	4822 051 20008	0R Jumper 0805
4492	4822 051 20008	0R Jumper 0805
4493	4822 051 20008	0R Jumper 0805
4494	4822 051 20008	0R Jumper 0805
4495	4822 051 20008	0R Jumper 0805
4496	4822 051 20008	0R Jumper 0805
4497	4822 051 20008	0R Jumper 0805
4498	4822 051 20008	0R Jumper 0805
4499	4822 051 20008	0R Jumper 0805
4500	4822 051 20008	0R Jumper 0805
4501	4822 051 20008	0R Jumper 0805
4502	4822 051 20008	0R Jumper 0805
4503	4822 051 20008	0R Jumper 0805
4504	4822 051 20008	0R Jumper 0805
4505	4822 051 20008	0R Jumper 0805
4506	4822 051 20008	0R Jumper 0805
4508	4822 051 20008	0R Jumper 0805
4509	4822 051 20008	0R Jumper 0805
4510	4822 051 20008	0R Jumper 0805
4511	4822 051 20008	0R Jumper 0805
4512	4822 051 20008	0R Jumper 0805
4513	4822 051 20008	0R Jumper 0805
4514	4822 051 20008	0R Jumper 0805
4515	4822 051 20008	0R Jumper 0805
4516	4822 051 20008	0R Jumper 0805
4517	4822 051 20008	0R Jumper 0805
4518	4822 051 20008	0R Jumper 0805
4519	4822 051 20008	0R Jumper 0805
4520	4822 051 20008	0R Jumper 0805
4521	4822 051 20008	0R Jumper 0805
4522	4822 051 20008	0R Jumper 0805
4523	4822 051 20008	0R Jumper 0805
4524	4822 051 20008	0R Jumper 0805
4525	4822 051 20008	0R Jumper 0805
4526	4822 051 20008	0R Jumper 0805

4527	4822 051 20008	0R Jumper 0805
4528	4822 051 20008	0R Jumper 0805
4529	4822 051 20008	0R Jumper 0805
4530	4822 051 20008	0R Jumper 0805
4531	4822 051 20008	0R Jumper 0805
4532	4822 051 20008	0R Jumper 0805
4533	4822 051 20008	0R Jumper 0805
4534	4822 051 20008	0R Jumper 0805
4535	4822 051 20008	0R Jumper 0805
4536	4822 051 20008	0R Jumper 0805
4537	4822 051 20008	0R Jumper 0805
4538	4822 051 20008	0R Jumper 0805
4539	4822 051 20008	0R Jumper 0805
4540	4822 051 20008	0R Jumper 0805
4541	4822 051 20008	0R Jumper 0805
4542	4822 051 20008	0R Jumper 0805
4543	4822 051 20008	0R Jumper 0805
4544	4822 051 20008	0R Jumper 0805
4545	4822 051 20008	0R Jumper 0805
4546	4822 051 20008	0R Jumper 0805
4547	4822 051 20008	0R Jumper 0805
4549	4822 051 20008	0R Jumper 0805

COILS & FILTERS

5400	4822 242 72066	Ceram Resonator 8MHz
5401	2422 543 01069	X'tal Resonator 32,768kHz
5402	4822 157 62552	Coil 2,2µH 5%
5403	4822 157 62552	Coil 2,2µH 5%
5404	4822 157 62552	Coil 2,2µH 5%
5405	4822 157 62552	Coil 2,2µH 5%

DIODES

6400	4822 130 11589	LTL-1CHAE
6401	4822 130 11589	LTL-1CHAE
6402	4822 130 11589	LTL-1CHAE
6403	4822 130 11589	LTL-1CHAE
6404	4822 130 11589	LTL-1CHAE
6405	4822 130 10791	LTL-1CHGE
6406	4822 130 11589	LTL-1CHAE
6407	4822 130 11589	LTL-1CHAE
6408	4822 130 11589	LTL-1CHAE
6409	4822 130 11589	LTL-1CHAE
6410	9322 161 99676	LTL-2R3VYKNT
6411	9322 161 99676	LTL-2R3VYKNT
6412	4822 130 30621	1N4148
6413	4822 130 30621	1N4148
6414	4822 130 30621	1N4148
6415	4822 130 30621	1N4148
6416	4822 130 30621	1N4148
6417	4822 130 30621	1N4148
6418	4822 130 30621	1N4148
6419	4822 130 30621	1N4148

ELECTRICAL PARTS LIST - FRONT BOARD

DIODES


6420	4822 130 30621	1N4148
6421	4822 130 30621	1N4148
6425	4822 130 31878	1N4003G
6426	4822 130 31878	1N4003G
6428	4822 130 30621	1N4148

TRANSISTORS & INTEGRATED CIRCUITS

7400	4822 209 31981	SAA6579T
7401	3139 110 52521	TMP87CS71F "290S52521"
7402	9965 000 04931	M24C01-WMN6
7403	5322 130 60159	BC847B
7404	5322 209 11306	HEF4094BT
7405	5322 209 11306	HEF4094BT
7408	5322 130 60159	BC847B
7409	4822 130 10165	GP1U28XP
7410	5322 130 60159	BC847B
7411	5322 130 60159	BC847B
7412	5322 130 60159	BC847B
7413	5322 130 60159	BC847B
7414	5322 130 60159	BC847B
7415	5322 130 60159	BC847B

Note: Only the parts mentioned in this list are normal service spare parts.


BLOCKDIAGRAM



TUNER BOARD ECO5

TABLE OF CONTENTS

Blockdiagram7B-1
 Adjustmant table7B-2
 Component layout7B-2
 Circuit diagram7B-3
 Partslist7B-4



1101 A1	2106 C2	2137 C5	3149 C5	3173 A5	5114 C4	5130 A3	7104 C2	9117 B2	9129 B3
1102 A1	2107 C2	2138 A5	3152 A5	5102 C2	5115 A4	5131 A3	7105 C3	9118 B4	9130 C3
1103 C1	2110 C2	2144 B5	3154 C5	5103 C2	5116 A4	6101 A2	7107 B3	9119 C4	9131 A5
1104 B1	2115 C1	2148 B4	3157 B5	5104 C2	5119 B5	6102 A1	7119 C4	9120 B4	9133 C3
1105 A1	2123 A2	2155 A3	3158 A5	5105 B2	5120 B4	6103 A1	9100 A2	9121 A2	9134 B3
1119 C5	2125 A2	2162 A2	3159 A5	5106 B2	5121 B4	6104 A2	9101 B3	9122 C3	9136 A5
1120 A5	2128 C3	3105 B3	3160 A5	5109 B4	5122 B3	6106 B3	9105 B2	9123 B1	9137 A5
1130 B5	2129 C4	3110 A2	3161 A5	5110 B4	5123 B2	6107 C5	9111 C2	9124 C4	
1131 B5	2130 A4	3132 B3	3170 C5	5111 C3	5124 B2	6109 C2	9113 B2	9125 A3	
2104 A2	2133 A4	3142 A4	3171 C5	5112 C4	5126 B3	6120 C4	9114 B2	9126 B5	
2105 A1	2135 B5	3147 B5	3172 C5	5113 B3	5127 B4	7102 A3	9115 B3	9128 A2	

2101 C4	2118 B4	2139 B2	2153 C3	2166 B2	3112 A3	3123 A3	3143 C2	3175 A2	4105 B3	4153 B4	6105 A4	7120 B4
2102 C4	2119 B4	2141 B1	2154 C3	2167 B2	3113 A2	3125 A3	3144 C2	3176 C2	4106 B4	4154 C3	6110 A4	7121 B3
2103 C3	2120 B4	2142 B1	2156 C4	2168 B1	3114 A3	3126 B3	3145 C2	3177 A1	4107 C4	4155 A4	6111 B4	7122 B4
2108 A4	2122 B3	2143 A1	2157 B4	3101 C3	3115 A3	3127 B3	3146 A1	3178 A1	4108 B4	4156 A2	6130 C2	7123 B4
2109 A4	2124 A5	2145 C1	2158 B4	3102 C3	3116 A3	3128 B3	3148 A1	3179 A1	4109 A3	4157 B3	6131 C3	7124 C4
2111 A2	2126 C2	2146 C1	2159 C2	3103 C3	3117 B4	3133 B4	3153 C2	3180 A4	4110 A3	4158 C2	7101 B2	7125 A1
2112 B5	2127 C2	2147 C1	2160 C4	3104 B3	3118 B3	3134 B4	3155 A2	3181 C3	4111 C1	4159 A2	7103 C2	
2113 A4	2131 C2	2149 B2	2161 A3	3106 C4	3119 A3	3136 B4	3156 A1	4101 A4	4120 C2	4160 A1	7106 A3	
2114 A4	2132 C1	2150 B2	2163 A2	3108 A4	3120 B4	3137 B4	3167 C2	4102 A4	4150 B2	4161 A1	7108 A3	
2116 B3	2134 C1	2151 C2	2164 B1	3109 A4	3121 A3	3140 B2	3168 B3	4103 C2	4151 B3	4162 C1	7109 A3	
2117 A3	2136 B1	2152 C3	2165 B3	3111 A3	3122 B3	3141 C2	3169 B2	4104 A2	4152 B3	4163 C1	7111 A1	

TUNER ADJUSTMENT TABLE (ECO5 FM/MW- and FM/MW/LW - versions with AM-frame aerial)

Waverange	Input frequency	Input	Tuned to	Adjust	Output	Scope/Voltmeter
VARICAP ALIGNMENT						
FM 87.5 - 108MHz (65.81 - 74, 87.5 - 108MHz)			108MHz	5130		8V ±0.2V
			87.5MHz (65.81MHz)	check		4.3V ±0.5V (1.2V ±0.5V)
MW FM/AM-version, 10kHz grid 530 - 1700kHz			1700kHz	5123		8V ±0.2V
			530kHz	check		1.1V ±0.4V
FM/MW-version, 9kHz grid 531 - 1602kHz			1602kHz	5123	1	6.9V ±0.2V
			531kHz	check		1.1V ±0.4V
LW	153 - 279kHz		279kHz	5122		8V ±0.2V
			153kHz	check		1.1V ±0.4V
MW FM/MW/LW-version, 9kHz grid 531 - 1602kHz			1602kHz	5123		8V ±0.2V
			531kHz	check		1.1V ±0.4V
FM IF						
FM	10.7MHz, 50mV continuous wave	F	IC 7101 21 shortcircuit to block AFC	5119	2	0 ± 3 mV DC
FM RF						
FM 87.5 - 108MHz (65.81 - 74, 87.5 - 108MHz)	108MHz	A		2155	4	MAX
	87.5MHz (65.81MHz)	mod=1kHz Δf=±22.5kHz		5131		
VCO						
FM	98MHz, 1mV continuous wave	A		98MHz	3	152kHz ±1kHz ¹⁾
AM IF						
MW	450kHz	C	IC 7101 36 100nF	5111	4	symmetric
				IC 7101 40 100nF see remark 2)		
AM AFC	connect pin 6 of IC 7101 (AM Osc.) with short wire to ground (pin 4)	C		5114	2	0 ± 2 mV DC
AM RF³⁾						
MW⁴⁾ FM/MW/LW- and FM/MW-version (9kHz grid) 531 - 1602kHz	1494kHz	B		2106	4	symmetric
	558kHz			5102		
LW	198kHz			5103		
MW FM/AM-version, 10kHz grid 530 - 1700kHz	1500kHz	Δf = ±30kHz V _{RF} as low as possible		2106		
	560kHz			5102		

Use service test program. By selecting the TUNER TEST test frequencies will be stored as preset frequencies automatically.



1) If sensitivity of frequency counter is too low adjust to max. channel separation (input signal: stereo left 90% + 9%, adjust output on right channel to minimum)

2) RC network serves for damping the IF-filter while adjusting the other one.


3) For AM RF adjustments the original frame antenna has to be used!

4) MW has to be aligned before LW.

Repeat







TUNER BOARD ECO5 / Systems



VERSION PROGRAMMING COMPONENTS					
	6120	3156	3157	3170	remark
/00 FMMW/LW	x	-	-	-	7111 not mounted
/00 FMMW/LW/SW-Eu	-	-	-	-	
/01 FMMW-Stereo	-	-	x	-	SW
/01 FMMW	-	x	-	x	
/01 FMMW/SW-Ov	-	x	-	-	
/06 FM-Japan/MW-stereo	-	-	-	x	
/13 FMMW-Stereo	-	-	x	-	SW
/14 FM-ORT/MW/LW	x	-	x	x	
/14 FM-ORT/MW	x	-	x	-	
/17 FM/AM-Stereo	-	-	x	-	SW
/17 FM/AM	x	-	-	x	
/.. FMMW/2xSW	-	-	x	x	
/15 FMMW/SW-Eu	-	x	x	x	

x = component mounted
SW = Software initialisation



Signal path

- FM (solid line)
- AM (dashed line)
- MPX (Audio Frequency) (dotted line)
- AF - left/right (blue arrow)

r....for RDS version only
 s....for East European version (/14/34) only
 t....for Japanese version (/06/26) only
 u....for 2-band (FM/AM) version only
 v....for SW-version 3.9-12.1MHz only
 w....for LW only
 x....not for all versions
 y....for USA version (/17/37) only
 z....for AM-STEREO (/06/13/26/33) versions only

Vdc FM mode stereo
 Vdc MW mode
 Vdc LW mode

Voltages measured while set is tuned to a strong transmitter

1101 A 1
1102 B 2
1103 D 2
1121 E 20
1124 C 20
1126 E 20
1130 I 20
1131 I 20
2101 C 6
2102 G 7
2103 D 9
2104 S 6
2106 F 5
2107 G 6
2108 G 3
2109 G 3
2111 C 13
2120 L 11
2122 M 11
2123 M 11
2125 M 11
2128 G 9
2127 G 10
2128 C 11
2129 C 9
2130 H 13
2131 I 10
2132 I 10
2133 H 11
2134 H 17
2135 J 18
2136 J 17
2137 F 16
2138 H 12
2139 H 13
2140 H 14
2141 H 14
2142 H 14
2143 H 7
2144 H 7
2145 G 16
2146 F 15
2147 F 16
2148 F 16
2149 C 15
2150 B 13
2152 F 8
2153 D 8
2154 E 7
2155 D 8
2156 F 8
2159 F 8
2160 M 12
2161 D 16
2162 C 13
2164 H 14
2165 C 9
2166 H 16
2167 F 16
2168 I 13
3101 E 7
3102 C 6
3103 C 6
3104 B 11
3105 C 7
3108 S 5
3109 F 2
3110 F 6
3113 C 13
3118 B 13
3119 B 13
3120 C 6
3123 M 7
3125 S 6
3128 M 8
3132 J 9
3134 M 12
3142 G 9
3143 I 10
3144 I 10
3145 H 10
3146 I 7
3147 I 5
3152 H 8
3153 H 9
3154 H 8
3155 H 7
3156 G 17
3157 F 17
3158 F 16
3159 F 16
3160 H 8
3161 H 8
3167 G 18
3169 G 15
3170 F 17
3171 H 5
3175 B 16
3176 J 9
3177 H 8
3178 H 5
3179 H 6
3180 M 7
4100 G 5
4102 F 5
4103 G 9
4104 B 13
4105 B 11
4106 K 12
4108 L 9
5102 E 4
5103 F 4
5109 B 13
5110 B 14
5111 A 13
5112 A 15
5113 B 12
5114 C 16
5119 I 12
5120 H 13
5121 F 15
5122 M 11
5123 L 11
5130 E 8
5131 D 8
6103 C 2
6104 C 3
6105 K 12
6106 S 6
6106 C 6
6107 H 7
6120 G 16
6130 E 7
6130 E 7
6131 D 7
7101 G 11
7102 D 8
7103 I 9
7104 E 3
7105 F 2
7108 M 7
7111 F 18
7119 B 13
7122 M 9
7124 M 13
7125 H 6
9100 B 4
9101 C 6
9117 L 10
9128 A 4

ELECTRICAL PARTS LIST - ECO5 TUNER BOARD

MISCELLANEOUS

1101	4822 267 31505	Antenna Socket 300R
1102	4822 267 10283	Antenna Socket Coax IEC 75R

CAPACITORS

2101	5322 122 32531	100pF 5% 50V
2101	4822 126 13692	47pF 1% 63V for USA
2102	4822 122 33177	10nF 20% 50V
2103	5322 122 34123	1nF 10% 50V
2104	4822 122 33195	100pF 10% 50V
2106	4822 125 50355	Trimmer 4-20pF for LW version
2106	4822 125 60101	Trimmer 3-11pF 100V
2107	4822 121 51319	1μF 10% 63V
2108	5322 122 32531	100pF 5% 50V for LW version
2109	5322 122 32448	10pF 5% 50V for LW version
2120	4822 126 13691	27pF 1% 63V for LW version
2120	5322 122 32658	22pF 5% 50V
2122	4822 122 33891	3,3nF 10% 63V for LW version
2125	4822 121 51381	560pF 5% 400V
2126	5322 122 31863	330pF 5% 50V
2127	4822 126 13473	220nF +80/-20% 50V
2128	4822 124 41579	10μF 20% 50V
2129	4822 124 41584	100μF 20% 10V
2130	4822 126 11585	22nF+80/- 20% 25V
2131	4822 122 33325	470nF 16V
2132	4822 122 33325	470nF 16V
2131	4822 126 13482	470nF +80/- 20% 16V
2132	4822 126 13482	470nF +80/- 20% 16V
2133	4822 124 40242	1μF 20% 63V
2134	4822 126 13188	15nF 5% 63V
2134	5322 122 32654	22nF 10% 63V for USA
2135	4822 124 40746	0,22μF 20% 63V
2136	4822 126 13188	15nF 5% 63V
2136	5322 122 32654	22nF 10% 63V for USA
2137	4822 124 40746	0,22μF 20% 63V
2138	4822 124 41576	2,2μF 20% 50V
2139	4822 126 14236	50V 15pF 5%
2140	4822 121 51252	470nF 5% 63V
2141	4822 126 10002	100nF 20% 25V
2142	4822 126 10002	100nF 20% 25V
2143	4822 126 13473	220nF +80/-20% 50V
2144	4822 124 40242	1μF 20% 63V
2145	4822 122 33575	220pF 5% 50V
2146	4822 122 33575	220pF 5% 50V
2147	4822 122 33575	220pF 5% 50V
2148	4822 126 11585	22nF+80/- 20% 25V
2149	5322 122 32654	22nF 10% 63V
2150	4822 122 31947	100nF 20% 63V
2152	5322 116 80853	560pF 5% 63V for East. Europe
2152	4822 126 12105	33nF 5% 63V
2153	4822 122 32139	12pF 2% 63V for East. Europe
2153	4822 122 32504	15pF 2% 63V
2155	4822 125 60101	Trimmer 3-11pF 100V

2158	5322 122 32448	10pF 5% 50V for LW version
2159	5322 122 32659	33pF 5% 50V
2160	5322 122 32654	22nF 10% 63V
2161	4822 126 10002	100nF 20% 25V
2163	4822 126 10002	100nF 20% 25V
2164	4822 126 13482	470nF +80/- 20% 16V
2165	4822 126 10002	100nF 20% 25V
2166	5322 122 34123	1nF 10% 50V
2167	4822 122 32139	12pF 2% 63V
2168	4822 126 13695	82pF 1% 63V

RESISTORS

3101	4822 051 20562	5k6 5% 0,1W for East. Europe
3101	4822 051 20333	33k 5% 0,1W
3102	4822 051 20104	100k 5% 0,1W
3103	4822 117 10965	18k 1% 0,1W
3104	4822 117 11448	180R 1% 0,1W
3105	4822 116 83872	220R 5% 0,5W
3108	4822 117 11449	2k2 1% 0,1W for LW version
3109	4822 051 20472	4k7 5% 0,1W for LW version
3110	4822 116 52195	47R 5% 0,5W
3120	4822 051 20008	0R Jumper 0805
3123	4822 051 20472	4k7 5% 0,1W for LW version
3125	4822 117 10833	10k 1% 0,1W for LW version
3128	4822 117 11449	2k2 1% 0,1W for LW version
3132	4822 116 52195	47R 5% 0,5W
3134	4822 051 20223	22k 5% 0,1W
3137	4822 051 20223	22k 5% 0,1W for LW version
3140	4822 051 20008	0R Jumper 0805
3140	4822 117 10353	150R 1% 0,1W 5120=CDA10.7MG40K
3141	4822 051 20563	56k 5% 0,1W 5120=CDA10.7MG61KA
3142	4822 100 11163	Trimmer 100k 30% 0,1W
3143	4822 051 20223	22k 5% 0,1W for RDS version
3144	4822 051 10102	1k 2% 0,25W for RDS version
3145	4822 117 11449	2k2 1% 0,1W
3146	4822 051 20229	22R 5% 0,1W
3152	4822 116 83883	470R 5% 0,5W
3153	4822 051 20471	470R 5% 0,1W
3154	4822 116 83868	150R 5% 0,5W
3155	4822 051 20471	470R 5% 0,1W
3156	4822 051 20104	100k 5% 0,1W for /21/30/33 only
3157	4822 116 52234	100k 5% 0,5W for East. Europe
3158	4822 116 83883	470R 5% 0,5W
3159	4822 116 83883	470R 5% 0,5W
3160	4822 116 83883	470R 5% 0,5W
3161	4822 116 83883	470R 5% 0,5W
3167	4822 117 11503	220R 1% 0,1W
3169	4822 051 20154	150k 5% 0,1W
3170	4822 116 52234	100k 5% 0,5W
3171	4822 116 52219	330R 5% 0,5W

ELECTRICAL PARTS LIST - ECO5 TUNER BOARD

3176	4822 051 10102	1k 2% 0,25W for RDS version
3180	4822 051 20223	22k 5% 0,1W for LW version
4101	4822 051 20008	0R Jumper 0805 for 2-Band only
4102	4822 051 20008	0R Jumper 0805 for 2-Band only
4103	4822 051 20008	0R Jumper 0805
4104	4822 051 20008	0R Jumper 0805
4105	4822 051 20008	0R Jumper 0805
4106	4822 051 20008	0R Jumper 0805
4108	4822 051 20008	0R Jumper 0805
4111	4822 051 20008	0R Jumper 0805
4120	4822 051 20008	0R Jumper 0805
4150	4822 051 10008	0R Jumper 1206
4151	4822 051 20008	0R Jumper 0805
4152	4822 051 10008	0R Jumper 1206
4153	4822 051 10008	0R Jumper 1206
4154	4822 051 10008	0R Jumper 1206
4155	4822 051 10008	0R Jumper 1206
4156	4822 051 20008	0R Jumper 0805
4157	4822 051 10008	0R Jumper 1206
4158	4822 051 10008	0R Jumper 1206
4159	4822 051 10008	0R Jumper 1206
4162	4822 051 10008	0R Jumper 1206

COILS & FILTERS

5102	4822 157 71634	MW RF Coil
5103	4822 157 71635	LW RF Coil for LW version
5109	4822 242 70665	Ceram Filter 10,7MHz
5110	4822 242 70665	Ceram Filter 10,7MHz
5111	4822 158 60511	AM-IF Filter 450kHz
5112	4822 157 70302	AM-IF Filter 450kHz
5114	4822 157 70302	AM-IF Filter 450kHz
5119	4822 157 11443	Discriminator 10,7MHz
5120	4822 242 82065	Cer. Disc. 10,7MG40K
5120	4822 242 10251	Cer. Disc.10,7MG61KA-TF21
5121	4822 242 10261	Quartz 75kHz
5122	4822 157 60517	Osc. Coil LW for LW version
5123	4822 157 60517	Osc. Coil MW
5130	4822 156 30947	RF-Coil 1.5T
5131	4822 156 30947	RF-Coil 1.5T

DIODES


6103	4822 130 30621	1N4148
6104	4822 130 30621	1N4148
6105	4822 130 83075	HN1V02H-B
6106	4822 130 30621	1N4148
6107	4822 130 34488	BZX79-B11
6120	4822 130 30621	1N4148 not for /21/30/33
6130	4822 130 82833	1SV228
6131	4822 130 82833	1SV228

TRANSISTORS & INTEGRATED CIRCUITS

7101	4822 209 90924	TEA5757H/V1
------	----------------	-------------

7102	4822 130 60093	2SA838B
7103	4822 130 42513	BC858C for RDS version
7104	5322 130 44779	BC338-40 for LW version
7105	5322 130 44779	BC338-40 for LW version
7109	5322 130 41983	BC858B for LW version
7111	5322 130 42136	BC848C
7122	5322 130 42136	BC848C for LW version
7124	5322 130 42136	BC848C for LW version

Note: Only the parts mentioned in this list are normal service spare parts.



TUNER 95 BOARD

BLOCKDIAGRAM





TABLE OF CONTENTS

- Blockdiagram7D-1
- Adjustmant table7D-2
- Component layout.....7D-2
- Circuit diagram7D-3
- Partslist7D-4

1102	F4	2107	C4	2128	C7	2136	G10	2144	E10	2160	E9	3120	D6	3132	E5	3143	G8	3153	G9	3163	F8	3176	D9	3188	G11	5111	C8	6106	E7	7110	D11	9108	G11	9121	D9
1103	C4	2108	C6	2129	C8	2137	E11	2145	G11	2161	E9	3123	E4	3134	E5	3144	H9	3154	C10	3164	C11	3177	F7	3192	D8	5112	C9	6107	B10	7122	F7	9111	C4	9123	D9
1110	G7	2109	C5	2130	F8	2138	E10	2147	G11	2162	C11	3124	E5	3137	G5	3145	F9	3155	C10	3165	D8	3178	B8	3197	C7	5114	D8	6120	D10	7124	G6	9114	E5	9125	D8
1121	H11	2120	F5	2131	F9	2139	E8	2148	E9	3103	H6	3125	C7	3138	D9	3146	B10	3158	G11	3167	F8	3181	D8	5102	C4	5115	G9	7101	E9	9100	F4	9115	C8	9126	C8
1124	H9	2122	E6	2132	F9	2140	F10	2150	F8	3104	G6	3128	F6	3139	F8	3147	H9	3159	G11	3169	D5	3183	E7	5103	C5	5121	E9	7103	G9	9101	E7	9116	G8		
1126	G10	2123	F6	2133	F10	2141	E10	2151	F9	3107	G7	3129	E6	3140	H8	3150	C11	3160	G11	3171	D11	3184	E7	5107	F10	5122	E7	7104	D5	9102	D10	9118	G10		
2102	G7	2125	G6	2134	G10	2142	E9	2152	F9	3108	C6	3130	E6	3141	G9	3151	C10	3161	G11	3172	F7	3185	E7	5109	D7	5123	E5	7105	B6	9104	E6	9119	G7		
2106	C5	2127	F9	2135	G11	2143	C10	2158	D10	3109	B7	3131	C6	3142	G10	3152	G9	3162	D9	3173	F7	3186	G8	5110	E9	6105	D4	7109	C6	9107	F11	9120	D10		

TUNER 95 bis Adjustment Table (FM, MW, LW with Frame antenna)


Waverange	Input frequency	Input	Set tuned to	Adjust	Output	Scope / Voltmeter
VARICAP ALIGNMENT						
FM (50)	87.5 - 108 MHz		108 MHz	check		7 ... 9V
			87.5 MHz	check		1.3 ... 2V
MW (9)	531 - 1602 kHz		1602 kHz	5123	◇ 6	8.3V ± 0.2V
			531 kHz	check		1V ± 0.4V
LW (3)	153 - 279 kHz		279 kHz	5122		8.3V ± 0.2V
			153 kHz	check		1V ± 0.4V
FM - DETECTION						
FM	98 MHz 1mV continuous wave <i>short pin 21 (IC7101) to ground</i>	◇ A	98 MHz	5107	◇ 1 ◇ 2	0mV ± 3mV
FM - VCO						
FM	98 MHz 1 mV continuous wave	◇ A	98 MHz	3142	◇ 3	152kHz ± 1 kHz
DISTORTION						
FM	98 MHz 1 mV 90 % L + 9 % pilot mod = 1kHz	◇ A	98MHz	mixcoil inside Tuner 1110	◇ 4	Distortion minimum
AM - IF						
MW	450kHz Δf = 10kHz Low as possible Swept signal	◇ C	MW	5111	◇ 7	symmetrical and max. height
	450kHz continuous wave			5112		
				5114	◇ 1 ◇ 2	0mV ± 2mV
AM - RF						
MW	558kHz Mod = 1kHz 30 % AM 1494 kHz	◇ B	558kHz	5102	◇ 7	MAX
			1494kHz	2106		
LW	198kHz mod = 1kHz 30 % AM	*	198kHz	5103		MAX



* Signal send via a frame antenna
(..) = tuning grid in kHz
↑ repeat

adjtable for 3104 217 04121/04341

1102	D1	1124	F21	2107	J6	2122	M7	2128	I13	2132	I17	2136	H19	2140	C14	2144	K20	2150	C6	2160	I15	3104	G4	3120	H5	3128	L9	3132	J7	3141	I16	3145	I17	3151	I20	3155	J20	3161	D19	3167	I20	3177	M10	3184	I8	3192	C12	5107	J12	5112	C12	5122	L7	6106	H5	7103	K17	7110	I19
1103	G2	1126	E20	2108	L2	2123	L7	2129	I8	2133	G18	2137	G19	2141	H15	2145	E19	2151	H12	2161	I15	3107	C6	3123	I6	3129	K8	3134	L6	3142	I16	3146	L20	3152	F20	3158	E19	3162	I15	3169	L5	3178	N20	3185	I13	3197	L11	5109	B6	5114	C13	5123	K7	6107	K20	7104	J2	7122	L9
1110	D4	2102	C2	2109	L3	2125	L7	2130	J20	2134	G19	2138	H18	2142	K19	2147	E19	2152	I11	2162	H20	3108	J1	3124	K7	3130	K8	3137	L5	3143	K17	3150	H19	3154	J20	3160	D19	3164	I20	3173	B6	3183	I13	3188	M20	5103	L4	5111	C11	5121	I15	6105a	I5	6120	E17	7105	K2	7124	L6
1121	C21	2106	J4	2120	K7	2127	H16	2131	I17	2135	F19	2139	I7	2143	K20	2148	E19	2158	L18	3103	G3	3109	K1	3125	L11	3131	M10	3140	F7	3144	K17	3150	H19	3154	J20	3160	D19	3164	I20	3173	B6	3183	I13	3188	M20	5103	L4	5111	C11	5121	I15	6105b	I6	7101	C15	7109	L10		



ELECTRICAL PARTS LIST - TUNER 95 BOARD**MISCELLANEOUS**

1102	4822 267 10283	Socket Coaxial IEC 75R
1103	4822 265 31184	JST Connector 2 pin
1110	4822 210 10739	Frontend Assembly FE415-G23

CAPACITORS

2102	4822 124 40433	47μF 20% 25V
2106	4822 125 60102	Trimmer 5,2-30pF 100V
2107	4822 121 51252	470nF 5% 63V
2108	4822 126 13695	82pF 1% 63V
2109	4822 126 13691	27pF 1% 63V
2120	5322 122 32659	33pF 5% 50V
2122	5322 126 10465	3,9nF 10% 50V
2123	4822 121 10766	390pF 1% 630V
2125	4822 121 10578	560pF 1% 630V
2127	4822 122 32927	220nF +80/-20% 50V
2128	4822 124 41579	10μF 20% 50V
2129	4822 124 40242	1μF 20% 63V
2130	4822 126 11585	22nF +80/-20% 25V
2131	4822 122 33325	470nF 16V
2132	4822 122 33325	470nF 16V
2133	4822 124 40242	1μF 20% 63V
2134	4822 126 13188	15nF 5% 63V
2135	4822 122 32927	220nF +80/-20% 50V
2136	4822 126 13188	15nF 5% 63V
2137	4822 122 32927	220nF +80/-20% 50V
2138	4822 124 41576	2,2μF 20% 50V
2139	4822 126 10002	100nF 20% 25V
2140	4822 121 51252	470nF 5% 63V
2141	4822 122 31947	100nF 20% 63V
2142	4822 122 31947	100nF 20% 63V
2143	4822 122 32927	220nF +80/-20% 50V
2144	4822 124 40242	1μF 20% 63V
2145	4822 122 33575	220pF 5% 50V
2147	4822 122 33575	220pF 5% 50V
2148	4822 122 33809	22nF 20% 50V
2150	4822 122 31947	100nF 20% 63V
2151	4822 126 14236	15pF 5% 50V
2152	4822 126 13695	82pF 1% 63V
2158	4822 122 31947	100nF 20% 63V
2160	4822 122 32139	12pF 2% 63V
2161	5322 122 34123	1nF 10% 50V
2162	4822 124 81151	22μF 50V

RESISTORS

3103	4822 051 20008	0R Jumper 0805
3104	4822 051 10102	1k 2% 0,25W
3107	4822 051 20829	82R 5% 0,1W
3108	4822 117 11449	2k2 1% 0,1W
3109	4822 117 11449	2k2 1% 0,1W
3120	4822 051 20008	0R Jumper 0805
3123	4822 051 10008	0R Jumper 1206
3124	4822 051 10008	0R Jumper 1206

3125	4822 116 83864	10k 5% 0,5W
3128	4822 116 52256	2k2 5% 0,5W
3129	4822 051 20008	0R Jumper 0805
3130	4822 051 10008	0R Jumper 1206
3131	4822 051 10008	0R Jumper 1206
3132	4822 051 20008	0R Jumper 0805
3134	4822 051 20223	22k 5% 0,1W
3137	4822 117 10833	10k 1% 0,1W
3138	4822 051 20008	0R Jumper 0805
3139	4822 051 10008	0R Jumper 1206
3140	4822 051 20331	330R 5% 0,1W
3141	4822 117 11148	56k 1% 0,1W
3142	4822 100 11163	Trimmer 100k 30% 0,1W
3143	4822 051 20223	22k 5% 0,1W
3144	4822 051 10102	1k 2% 0,25W
3145	4822 117 11449	2k2 1% 0,1W
3146	4822 051 20479	47R 5% 0,1W
3147	4822 051 10008	0R Jumper 1206
3150	4822 051 20472	4k7 5% 0,1W
3151	4822 051 20683	68k 5% 0,1W
3152	4822 051 20471	470R 5% 0,1W
3153	4822 051 20471	470R 5% 0,1W
3154	4822 116 83872	220R 5% 0,5W
3155	4822 116 52219	330R 5% 0,5W
3158	4822 116 83883	470R 5% 0,5W
3159	4822 116 83883	470R 5% 0,5W
3160	4822 116 83883	470R 5% 0,5W
3161	4822 116 83883	470R 5% 0,5W
3162	4822 117 13579	220k 1% 0,1W
3163	4822 051 10008	0R Jumper 1206
3164	4822 052 10478	Δ 4R7 5% 0,33W
3165	4822 051 10008	0R Jumper 1206
3167	4822 116 83872	220R 5% 0,5W
3169	4822 051 20008	0R Jumper 0805
3171	4822 051 20008	0R Jumper 0805
3172	4822 051 10008	0R Jumper 1206
3173	4822 051 20008	0R Jumper 0805
3176	4822 051 20008	0R Jumper 0805
3177	4822 051 20223	22k 5% 0,1W
3178	4822 051 10008	0R Jumper 1206
3181	4822 051 10008	0R Jumper 1206
3183	4822 051 10008	0R Jumper 1206
3184	4822 051 10008	0R Jumper 1206
3185	4822 051 10008	0R Jumper 1206
3186	4822 051 10102	1k 2% 0,25W
3188	4822 051 10008	0R Jumper 1206
3192	4822 051 20008	0R Jumper 0805
3197	4822 051 20472	4k7 5% 0,1W

COILS & FILTERS

5102	4822 157 71634	MW Aerial
5103	4822 157 71635	LW Aerial

ELECTRICAL PARTS LIST - TUNER 95 BOARD

5107	4822 157 11443	FM Discriminator 10,7MHz
5109	4822 157 71639	Ceram Filter 10,7MHz
5110	4822 242 70665	Ceram Filter 10,7MHz
5111	4822 158 60511	AM-IF Filter 450kHz
5112	4822 157 70302	AM-IF Filter 450kHz
5114	4822 157 70302	AM_IF Filter 450kHz
5115	4822 157 71636	Anti-Birdy Filter
5121	4822 242 10261	X'tal Resonator 75kHz
5122	4822 157 60517	RF Coil AM
5123	4822 157 60517	RF Coil AM

DIODES

6105	4822 130 83075	HN1V02H-B
6106	4822 130 30621	1N4148
6107	4822 130 34488	BZX79-C11
6120	4822 130 30621	1N4148

TRANSISTORS & INTEGRATED CIRCUITS

7101	4822 209 90315	TEA5762H/V1
7103	4822 130 42513	BC858C
7104	5322 130 44779	BC338-40
7105	5322 130 44779	BC338-40
7109	5322 130 41983	BC858B
7110	5322 130 41983	BC858B
7122	5322 130 42136	BC848C
7124	5322 130 42136	BC848C

Note : Only the parts mentioned in this list are normal service spare parts.


ETF7 TAPE MODULE

(Non-Dolby Version)

TABLE OF CONTENTS

Tape Module Wiring & variation table 9-1
 Block diagram 9-2
 Brief Introduction 9-3
 Connector assignment 9-4
 Tape deck electronics & Tape adjustments 9-5
 ETF7 Non-Dolby board layouts 9-6
 Analog Circuit diagram 9-7
 Servo Circuit diagram 9-8
 Exploded views & parts list 9-9
 Electrical parts list 9-13

Tapedeck wiring (Double deck)





Variations table for Analog Circuit

	Autoreverse	Non-autoreverse	
	ND/DD/FR	ND/DD/FF	FF
	Chrome/Ferro	Chrome/Ferro	Ferro
2624	-	-	100nF
2701 , 2702	150pF	270pF	270pF
2703 , 2704	100pF	220pF	220pF
2717 , 2718	10nF	15nF	15nF
2721 , 2722	6,8nF	6,8nF	-
2727 , 2728	470pF	1nF	1nF
3616	10k	1k	1k
3618	6k8	-	-
3620	10k trimmer	-	-
3622	-	10k trimmer	10k trimmer
3672	4k7	-	-
3676	47k	-	-
3687	220R	220R	-
3688	680R	-	-
3723 , 3724	15k	18k	18k
3725 , 3726	10R	10R	-
3727 , 3728	5k6	6k8	6k8
3729 , 3730	3k3	4k7	4k7
3743 , 3744	1k5	2k2	2k2
3745 , 3746	3k3	5k6	5k6
3754 , 3755	1M	47R	47R


	Autoreverse	Non-autoreverse	
	ND/DD/FR	ND/DD/FF	FF
	Chrome/Ferro	Chrome/Ferro	Ferro
3769	12k	8k2	8k2
3772	6k8	5k6	5k6
4785	-	-	0R jumper
3774	15k	8k2	8k2
6614	1N4148	-	-
7616	BC857B	-	-
7622	BC847B	-	-

BLOCK DIAGRAM



NOTE: # For Non-dolby version only
Only 1 channel is presented.

- □ □ MicroProcessor Control / Communication lines
- Direct / Indirect Control lines from Shift Registers



Brief introduction

General

1. Playback Mode
Signal from the playback head Deck A or Deck B is selected and fed through by the Mode Selector IC7710 (HEF4952BT). The signal is amplified by amplifier IC7720 (AN7323S) before feeding to the IC7740 (HEF4952BT) and out to the AF Board via connector 1701.
2. Recording Mode
Recording Signal is selected and fed through by the Mode Selector IC7710 (HEF4952BT) which is then amplified by the amplifier IC7720 (AN7323S). The amplified output signal will pass through IC7730 (HEF4952BT) for record equalization and back to IC7710 (HEF4952BT) before registered into the Rec/PB Head of Deck B.
3. Dubbing Mode
In Dubbing mode, signal from the playback head Deck A is selected and fed through by the Mode Selector IC7710 (HEF4952BT) which is then equalised for playback mode by the amplifier IC7720 (AN7323S) so that a flat response is obtained after the pre-amp. The equalised signal will then follow the same path as in the Recording mode.
4. Mode Selector
The Mode Selector IC7710 (HEF4952BT) caters for 4 inputs signal, namely Playback Signal from Deck A, Playback Signal from Deck B, Recording Signal and Dubbing Signal.
5. Amplifier PB/REC
Amplifier IC7720 (AN7323S) is for the purpose of amplifying the Playback and Recording signal from the Mode Selector.
6. Automatic Level Control (ALC)
ALC circuit consists of resistors (3760, 3765, 3766, 3767), capacitors (2762, 2763) and control by transistor 7787 (BC847B). ALC limits the amplifier output to a constant value when input signal becomes too large, thus limiting recording current to below saturation level, to prevent recording distortion.
7. Muting Circuit (For Non-Dolby version only)
Switch S4 of the IC7740 (HEF4952BT) is for the purpose of muting the output during Recording mode. During Recording mode, S4 is closed and shorted to the ground.
8. IC7740 (HEF4952BT)
The function of the IC7740 (HEF4952BT) is to change time constant between 120us Ferro (IEC I) and 70us Chrome (IEC II) during playback mode. It will automatically determined whether the tape type is 120us Ferro (IEC I) or 70us Chrome (IEC II). This IC will switch to Flat Gain during the Recording mode.
9. IC7730 (HEF4952BT)
The function of the IC7730 (HEF4952BT) is to change gain and time constant according to tape type and recording speed to boost recording current at higher frequency during recording to compensate for head loss. It will automatically determined whether the tape type is 120us Ferro (IEC I) or 70us Chrome (IEC II).
10. Bias Level
Bias Level making use of the Variable resistor (3773) for adjusting the optimal level of the bias current for Ferro or Chrome.
11. Bias Symm (For Dolby B NR version only)
Bias Symm making use of the Variable resistor (3785) to adjust the bias current for the left and the right channel to be equal.
12. PB Switch
Playback Switch which consists of the FETs 7785 (For Dolby B NR version only) & 7786 (J111) is for the purpose of providing a virtual ground for the Rec/PB Head (Deck B) during Playback mode. During the Playback mode, the FETs are turn on and shorted pin 2 and 4 of connector 1720 to the ground. During Recording mode, the FETs are turn off to allow the oscillator signal to be superposition onto the Recording signal for recording.

13. Motor Speed (For FR versions only)
During High speed dubbing, a feedback signal from the uP through pin 03 of the IC7610 (HEF4094BT) will trigger the transistors 7622 (BC847B) and 7616 (BC857B) to cause a change in the voltage level between High and Low, thus changing the speed of the motor.
14. IC7610 (HEF4094BT)
IC7610 (HEF4094BT) is a Shift Register use for issues the logic for cmos switch ICs (HEF4952BT) via 1A0, 2A1 and 2A2. It also issues logic to On/Off SOL_A, SOL_B and MOT. Recording speed is controlled via NS/HS.

Dolby Circuit (For sets with Dolby B NR version only)

15. IC7630 (CXA1551M)
IC7630 (CXA1551M) in the Dolby circuit is a Dolby Noise Reduction Type B IC for the Playback and Recording signal. Noise Reduction ON/OFF are controlled by $\overline{\text{DOLBY}}$, which is from CLK, direct from uP. After clocking in DATA, CLK is set to HIGH/LOW for NR OFF/ON.
16. 19kHz Filter
The 19kHz filters 5631 & 5632 (LXD-210) in the Dolby circuit is for the purpose of filtering the 19kHz Pilot Tone (for Tuner signal only) of the Recording signal.
17. Level Adjust
The Variable resistor 3635, 3636, 3641 and 3642 in the Dolby circuit is for adjusting the playback level of the Dolby reference (400Hz, 200nWb/m). Transistor 7631, 7632 are ON to enable adjustment of 3641, 3642 during Playback Deck A. Transistor 7633, 7634 and 3635, 3636 are active for Playback Deck B.
18. Amplifier IC7640 (NJM4560M)
The Amplifiers 7640A & 7640B (NJM4560M) in the Dolby circuit is for the purpose of amplified the Recording signal.
19. Muting Circuit
The muting circuit which consists of transistors 7788, 7789 and 7790 (BC847B) is for the purpose of muting the output during Recording mode.

NOTATIONS & ABBREVIATIONS USED IN THIS DOCUMENT

CR	Chrome (IEC type II)
DB	Dolby NR type B
DD	Double Deck
DM	Double Motor
FE	Ferro (IEC type I)
FF	Non-Autoreverse
FR	Autoreverse Deck B
Gnd x	Ground x
HSD	High speed dubbing
ND	Non Dolby
NR	Noise Reduction
NSD	Normal speed dubbing
PB	Playback
REC	Record
S/A	Sub-assy
SD	Single Deck
SM	Single Motor

CONNECTORS ASSIGNMENTS:**CONNECTOR 1701****INTERCONNECTION TO AF BOARD**

○ 1	REC-L	Record input left
○ 2	REC-R	Record input right
○ 3	GND A	AF Ground
○ 4	TAPE-L	Playback output left
○ 5	+12V	D.C. supply (+12V) for AF electronics
○ 6	TAPE-R	Playback output right
○ 7	-CMOS	Negative d.c. supply (-9V) for CMOS ICs

CONNECTOR 1703**INTERCONNECTION TO AF BOARD**

○ 1	GND M	Motor Ground
○ 2	+MOTOR	D.C. supply (+12V) for tape deck motor & solenoid

CONNECTOR 1706**INTERCONNECTION TO FRONT BOARD**

○ 1	AD2	Deck sensing switches output voltage / Deck A EOT
○ 2	AD1	Deck sensing switches output voltage / Deck B EOT
○ 3	+5V	DC supply +5V for ADC network
○ 4	GND P	Control & Oscillator Ground
○ 5	CLK	HEF4094BT shift register Clock line
○ 6	DATA	HEF4094BT shift register Data line
○ 7	STROBE	HEF4094BT shift register Strobe line

CONNECTOR 1710**DECK B HEADS CONNECTOR (For Non-Dolby version only)**

○ 1	B R/P HD L+	R/P Head left channel positive
○ 2	GND A	R/P Head return ground
○ 3	B R/P HD R+	R/P Head right channel positive
○ 4	ERASE HEAD	Erase Head
○ 5	GND A	Erase Head ground

CONNECTOR 1720**DECK B HEADS CONNECTOR (For Dolby B NR version only)**

○ 1	B R/P HD L+	R/P Head left channel positive
○ 2	B R/P HD L-	R/P Head left channel negative
○ 3	B R/P HD R+	R/P Head right channel positive
○ 4	B R/P HD R-	R/P Head right channel negative
○ 5	ERASE HEAD	Erase Head
○ 6	GND A	Erase Head ground

CONNECTOR 1730**DECK A HEAD CONNECTIONS (For Double Deck versions only)**

○ 1	A PB HD L+	Pb Head left channel positive
○ 2	GND A	Pb Head return ground shield
○ 3	A PB HD R+	Pb Head right channel positive


CONNECTOR 1740**DECK A & B CONTROL INTERFACE (For Dolby B NR version only)**

○ 1	REC REW	Record tab protection status switch (reverse)	[open=on: close=off]
○ 2	CrO2 B	Chrome tape detection switch deck B	[open=Cr: close=Fe]
○ 3	REC FWD	Record tab protection status switch (forward)	[open=on: close=off]
○ 4	PHOTO B	Photo sensor output (tape movement indication)	
○ 5	SOL B	Solenoid supply for deck B	
○ 6	Vcc	Deck / Motor supply	
○ 7	MODE B	Mode switch (head engagement)	[open=off: close=engaged]
○ 8	GND M	Deck / Motor ground	
○ 9	SOL A	Solenoid supply for deck A	
○ 10	PHOTO A	Photo sensor output (tape movement indication)	
○ 11	MODE A	Mode switch (head engagement)	[open=off: close=engaged]
○ 12	L	L pin for motor	
○ 13	CrO2 A	Chrome tape detection switch deck A	[open=Cr: close=Fe]
○ 14	H	H pin for motor	


CONNECTOR 1770**DECK A & B CONTROL INTERFACE (For Non-Dolby version only)**

○ 1	REC REW	Record tab protection status switch (reverse)	[open=on: close=off]
○ 2	CrO2 B	Chrome tape detection switch deck B	[open=Cr: close=Fe]
○ 3	REC FWD	Record tab protection status switch (forward)	[open=on: close=off]
○ 4	PHOTO B	Photo sensor output (tape movement indication)	
○ 5	SOL B	Solenoid supply for deck B	
○ 6	Vcc	Deck / Motor supply	
○ 7	MODE B	Mode switch (head engagement)	[open=off: close=engaged]
○ 8	GND M	Deck / Motor ground	
○ 9	SOL A	Solenoid supply for deck A	
○ 10	PHOTO A	Photo sensor output (tape movement indication)	
○ 11	MODE A	Mode switch (head engagement)	[open=off: close=engaged]
○ 12	L	L pin for motor	
○ 13	CrO2 A	Chrome tape detection switch deck A	[open=Cr: close=Fe]
○ 14	H	H pin for motor	


TAPE MECHANISM ELECTRONICS




* No Leaf switch & copper pattern shorted together for Ferro version



Mechanism B Head Wires Soldering (Non-Dolby version)



Mechanism B Head Wires Soldering (Dolby B NR version)



TAPE ADJUSTMENT & CHECK TABLE

	TEST CASSETTE	RECORDER MODE	MEASURE ON	READ ON	ADJUST	
					with	to
ADJUST MOTOR SPEED						
NORMAL SPEED	SBC420 3150Hz	PLAY B	1 or 2	frequency counter	3620	3150Hz - 0.5%
		PLAY A	LEFT RIGHT		check	3150Hz -0.8/+1.8%
CHECK WOW & FLUTTER						
DECK A & B	SBC420 3150Hz	PLAY	1 or 2 LEFT RIGHT	W&F-meter	check	†0.4 % DIN
ADJUST AZIMUTH						
DECK A & B	SBC420 10kHz	PLAY FWD	1 or 2	mV-meter	left hand screw	max. output level & left=right
		PLAY REV #	LEFT RIGHT		right hand screw	
CHECK PLAYBACK FREQUENCY RESPONSE						
DECK A & B	SBC420	PLAY	1 or 2 LEFT RIGHT	mV-meter	check	limits see fig.1
ADJUST BIAS CURRENT						
DECK B	SBC419A^	RECORD	5 or 6	mV-meter	3773	995mV
	SBC420		LEFT RIGHT		check	750mV - 1.5dB
CHECK OVERALL FREQUENCY RESPONSE AND DISTORTION						
Inject 3mV signals 100Hz, 250Hz, 1kHz, 10kHz, 12.5kHz via 3 or 4	SBC419A^ or SBC420	RECORD B				
	RECORDED CASSETTE	PLAY B	1 or 2 LEFT RIGHT	mV-meter	check	limits see fig. 2 *
Inject 1kHz 8.85mV via 3 or 4	SBC419A^ or SBC420	RECORD B				
	RECORDED CASSETTE	PLAY B	1 or 2 LEFT RIGHT	THD-meter	check	†3% *

SBC419A^ : 4822 397 30069
SBC420 : 4822 397 30071

For Auto-reverse version only
* If high frequencies are not within limits, decrease bias and re-measure. If distortion is too high, increase bias and re-measure
^ Not applicable for Ferro version




figure. 1





figure. 2


COMPONENT LAYOUT

1701 B2	2714 B2	2784 B1	3761 A1	6770 A1	6782 A2	9706 A1	9715 A1	9724 B2
1702 A2	2715 B2	2785 B1	3764 B2	6771 A1	6785 B2	9707 A2	9716 A2	9725 A2
1703 A2	2716 B2	3607 A1	3773 A1	6772 B1	6786 B2	9708 A2	9717 A2	9726 A2
1706 A1	2741 B1	3609 A1	3778 B1	6773 B1	7782 B1	9709 A2	9718 B2	9727 A2
1710 B1	2761 B2	3611 A1	5701 B1	6774 B1	7786 B2	9710 A1	9719 B1	9728 A2
1730 B2	2762 B2	3620 A1	5703 B1	6775 A1	9702 A1	9711 A1	9720 B1	9729 B1
1760 A2	2763 B2	3622 A1	6611 A2	6776 A1	9703 A1	9712 A1	9721 B1	9791 A1
1770 A2	2765 B2	3674 A2	6612 A2	6777 A1	9704 A2	9713 A1	9722 B1	9792 A2
2713 B2	2780 A1	3685 A1	6614 A1	6778 A1	9705 A2	9714 A1	9723 B2	9793 A1




CHIP LAYOUT


2621 A2	2724 B2	3602 A1	3688 A2	3725 A2	3757 A1	4701 A1	4727 B1	7612 A1
2622 A2	2725 A2	3603 A1	3689 A1	3726 B2	3758 A2	4702 A1	4728 B1	7613 A1
2623 A2	2726 B2	3604 A1	3701 B2	3727 A1	3759 A1	4703 A1	4729 B1	7614 A1
2624 A1	2727 B2	3605 A1	3702 B2	3728 B1	3760 B1	4704 A1	4730 B1	7616 A2
2625 A2	2728 B2	3606 A1	3703 B1	3729 A1	3762 A2	4705 A1	4731 B1	7618 A1
2626 A1	2729 A1	3608 A2	3704 B1	3730 B1	3763 B1	4706 A1	4732 B2	7619 A1
2627 A1	2730 B1	3610 A2	3705 B1	3731 A1	3765 B1	4707 A2	4733 B2	7620 A1
2701 B2	2733 B1	3612 A2	3706 B1	3732 B1	3766 B1	4708 A2	4734 B1	7622 A1
2702 B2	2734 B1	3613 A1	3707 B1	3733 B1	3767 B1	4709 A2	4735 B1	7623 A1
2703 B1	2735 B1	3614 A2	3708 B1	3734 B1	3768 B1	4710 A2	4736 B1	7624 A1
2704 B1	2737 B1	3616 A2	3709 B1	3735 B1	3769 A2	4711 A2	4737 B1	7710 B2
2705 B1	2738 B1	3618 A2	3710 B1	3736 B1	3770 B2	4712 A2	4738 B1	7720 B1
2706 B1	2742 A2	3619 A2	3711 B1	3737 B1	3771 B2	4713 A1	4739 B1	7730 A2
2707 B1	2743 B1	3623 A1	3712 B1	3742 B1	3772 A2	4714 A1	4740 B1	7740 A1
2708 B1	2744 B1	3624 A1	3713 B1	3743 B1	3774 A2	4715 A1	4741 B2	7780 A2
2709 B1	2745 B2	3625 A1	3714 B1	3744 B1	3775 B2	4716 A1	4742 B2	7781 B2
2710 B1	2746 B1	3626 A1	3715 B1	3745 B1	3776 B2	4717 A1	4744 A2	7783 A2
2711 B1	2747 B1	3628 A1	3716 B1	3746 B1	3777 B2	4718 A1	4745 A1	7784 B2
2712 B1	2760 A2	3630 A1	3717 A1	3748 B1	3779 B2	4719 A2	4746 A1	7787 B1
2717 A2	2769 B1	3672 A2	3718 B2	3749 A1	3780 B2	4720 A2	4747 A1	7791 A1
2718 B2	2770 B1	3676 A2	3719 A2	3751 A1	3781 B1	4721 A2	4748 B1	7792 A2
2719 A2	2771 B2	3678 A1	3720 B2	3752 A1	3784 B2	4722 A2	4785 A2	
2720 B2	2782 B2	3679 A1	3721 A2	3753 A1	3786 A2	4723 B1	4790 B2	
2721 A2	2786 B2	3680 A1	3722 A2	3754 A1	3787 A2	4724 B1	4794 B1	
2722 B2	2787 B2	3686 A2	3723 B2	3755 A1	3788 B2	4725 A1	4795 A1	
2723 A2	3601 A1	3687 A2	3724 B2	3756 A1	3789 A2	4726 B1	7610 A2	



ANALOG CIRCUIT

1701 F9	2705 A2	2712 B6	2719 C5	2726 D4	2735 B3	2745 F5	2765 B4	2785 F1	3705 A4	3712 B4	3719 C6	3726 D5	3733 A2	3744 F8	3753 F5	3760 A7	3767 A7	3774 E3	3781 D2	4794 C6	6774 D3	6786 B7	7782 E1	9791 A8
1710 C1	2706 A2	2713 A6	2720 D5	2727 A3	2737 A6	2746 F8	2769 F7	2786 D1	3706 B4	3713 A7	3720 E6	3727 A7	3734 B2	3745 F8	3754 E8	3761 E3	3768 E8	3775 F3	3784 D1	5701 D2	6775 C3	7710 A3	7783 E2	9792 B8
1730 A1	2707 A4	2714 B6	2721 C5	2728 E5	2738 B6	2747 E8	2770 F8	2787 D3	3707 A5	3714 B7	3721 C6	3728 B7	3735 A2	3746 E8	3755 E7	3762 E2	3769 E4	3776 F2	3786 F4	5703 F1	6776 F3	7720 A5	7784 D2	9793 A6
2701 B2	2708 B4	2715 A4	2722 D5	2729 A8	2741 D6	2760 E3	2780 F3	3701 B1	3708 B4	3715 A6	3722 C6	3729 A7	3736 B1	3748 C8	3756 D8	3763 A5	3770 F2	3777 F2	3787 C3	6770 E2	6777 E2	7730 D6	7786 C2	
2702 B2	2709 A5	2716 C4	2723 C5	2730 B8	2742 C3	2761 B5	2781 F2	3702 C2	3709 A4	3716 B6	3723 A3	3730 B7	3741 A6	3749 C7	3757 D8	3764 A5	3771 F2	3778 E1	3788 C3	6771 E2	6778 E4	7740 A8	7787 C8	
2703 A2	2710 B5	2717 C6	2724 D5	2733 A5	2743 F1	2762 B6	2782 F2	3703 A2	3710 C4	3717 C6	3724 D5	3731 A7	3742 C7	3751 E5	3758 D8	3765 B6	3772 F3	3779 D3	3789 F4	6772 D1	6782 C7	7780 F4	7791 F5	
2704 B2	2711 A6	2718 D6	2725 D4	2734 C4	2744 A4	2763 B6	2784 F1	3704 B1	3711 A5	3718 E6	3725 C5	3732 B7	3743 F8	3752 F4	3759 D7	3766 B7	3773 E3	3780 D2	4790 C3	6773 D1	6785 A7	7781 F3	7792 D8	






3139 118 77070 (Incl. ...77080) dd wk926

TAPE MODULE EXPLODED VIEW

- 1 3139 118 77130 Autoreverse Mech. CWE44FR01
- 1 3139 118 77140 Non-Autoreverse Mech. CWE44FF02 Chrome/Ferro
- 1 3139 118 77950 Non-Autoreverse Mech. CWE44FF05 Ferro
- 3 - Screw D3 x 10
- 6 - Screw M2 x 16
- 7 3139 110 34080 Flex Cable 14 pin 7,5 cm

Note: Only the parts mentioned in this list are normal service spare parts.



TAPE MECHANISM - MOTOR EXPLODED VIEW

- 31 4822 361 11055 Motor Assembly
- 91 - Screw M2,6 x 5
- 92 - Screw M2 x 5


Note: Only the parts mentioned in this list are normal service spare parts.

TAPE MECHANISM A - PLAY

MECHANICAL PARTS - PLAY MECHANISM

1	9965 000 02313	Play Head (Non-Autoreverse deck)
1	9965 000 02321	Play Head (Autoreverse deck)
12	4822 402 10972	Pinch Arm Assembly R
23	9965 000 02314	Coil Assembly
25	9965 000 06443	Cam Gear
32	4822 528 11209	Flywheel Assembly RV
42	9965 000 02315	Belt AF (Autoreverse deck)
42	9965 000 02718	Belt AF (Non-autoreverse deck)
69	4822 492 11761	Spring
102	4822 532 12931	Washer
103	4822 532 12932	Washer
104	4822 532 12933	Washer

Note: Only the parts mentioned in the list are normal service spare parts.




TAPE MECHANISM B - RECORD/PLAYBACK (Non-Autoreverse version)

MECHANICAL PARTS - REC/PB MECHANISM

1	9965 000 02313	Play Head
3	9965 000 02600	Head, Erase
12	4822 402 10972	Pinch Arm Assembly R
23	9965 000 02314	Coil Assembly
25	9965 000 06443	Cam Gear
32	4822 528 11209	Flywheel Assembly RV
44-2	9965 000 02317	Flex Socket 14 Pin
44-3	9965 000 02320	Photo Interrupter
44-4	4822 050 16801	680R 1% 0,4W
44-6	9965 000 02318	Leaf Switch
44-7	9965 000 02319	Mode Switch
59	9965 000 02719	Belt BF (Large)
69	4822 492 11761	Spring
102	4822 532 12931	Washer
103	4822 532 12932	Washer
104	4822 532 12933	Washer

Note: Only the parts mentioned in the list are normal service spare parts.



TAPE MECHANISM B - RECORD/PLAYBACK (Autoreverse version)

MECHANICAL PARTS - REC/PB MECHANISM

12	4822 402 10972	Pinch Arm Assembly R
23	9965 000 02314	Coil Assembly
25	9965 000 06443	Cam Gear
32	4822 528 11209	Flywheel Assembly RV
39	9965 000 02322	Belt AF
44-2	9965 000 02317	Flex Socket 14 Pin
44-3	9965 000 02320	Photo Interrupter
44-4	4822 050 16801	680R 1% 0,4W
44-6	9965 000 02318	Leaf Switch
44-7	9965 000 02319	Mode Switch
45	9965 000 02323	Rec/Pb Head Assembly
50	4822 402 10973	Pinch Arm Assembly L
54	9965 000 02324	Flywheel Assembly L
69	4822 492 11761	Spring
73	4822 492 11762	Spring
101	9965 000 02325	Washer
102	4822 532 12931	Washer
103	4822 532 12932	Washer
104	4822 532 12933	Washer
107	9965 000 02326	Washer
109	9965 000 02327	Washer

Note: Only the parts mentioned in the list are normal service spare parts.

