

Service
Service
Service



Service Manual

TABLE OF CONTENTS

	Page
Location of pc boards & Version variations	1-2
Technical Specifications	1-3
Measurement setup	1-4
Service Aids, Safety Instruction, etc.	1-5 to 1-6
Lead-free Information & Service Instruction	1-7
Preparations & Controls & Troubleshooting ..	1-8 to 1-14
Disassembly Instructions & Service positions	2
Service Test Programs	3-1
Set Block diagram	4-1
Set Wiring diagram	5-1
Display Board	6
Tuner Board (ECO Non Cenelec)	7A
Tuner Board (ECO Cenelec)	7B
Main Board	8
Cassette Board	9
Output & Microphone Board	10
Power Board	11
Set Mechanical Exploded view & parts list	12
Revision List	13



© Copyright 2005 Philips Consumer Electronics B.V. Eindhoven, The Netherlands
All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form or by any means, electronic, mechanical, photocopying, or otherwise without the prior permission of Philips.

Published by SL 0540 Service Audio Printed in The Netherlands Subject to modification




3141 785 30611

Version 1.1



PHILIPS

LOCATION OF PCBS



VERSION VARIATIONS:

Type /Versions:	MCD510									
	/22	/21M	/14	/21						
Features & Board in used:										
Aux in / CDR in	x	x	x	x						
Line Out	x	x	x	x						
Video Out										
Surround Out										
Subwoofer Out	x	x	x	x						
Power Booster Out										
Digital Out	x	x	x	x						
Digital in										
Matrix Surround										
RDS	x									
News	x									
Dolby Pro Logic (DPL)										
Incredible Surround	x	x	x	x						
Karaoke Features										
Voltage Selector		x		x						
ECO Power Standby (LCD Display Off)	x	x	x	x						
ECO6 Tuner Board - Systems Non-Cenelec		x		x						
ECO6 Tuner Board - Systems Cenelec	x		x							

SPECIFICATIONS

GENERAL:

Mains voltage : 230V \pm 10% for /22/14
 110-127V/220-240V Switchable for /21M/21
 Mains frequency : 50/60Hz
 Clock accuracy : < 4 seconds per day
 Dimension centre unit : 180(W) x 265(H) x 325(D) (mm)

Power consumption
 Active : 60W
 Standby : < 15W (DEMO mode off)
 ECO Power Standby : < 1W

Input sensitivity
 Aux in (at 1kHz) : 500mV at 600 Ω
 Microphone in (at 1kHz) : 1mV rms at 600 Ω /21
 /21M

Output sensitivity
 Headphone output at 32 k Ω : 12mW \pm 1dB (Max. vol.)
 Line output at 10 k Ω : 2Vrms
 Subwoofer output at 10 k Ω : 3Vrms (100Hz, Dist: 1%)
 Digital output (Coaxial SPDIF): 0.5Vpp at 75 Ω

TUNER:

FM

Tuning range : 87.5-108MHz
 Grid : 50kHz
 100kHz for /21
 IF frequency : 10.7MHz \pm 20kHz
 Aerial input : 75 Ω coaxial
 Sensitivity at 26dB S/N : < 22dBf
 Selectivity at 300kHz bandwidth : > 33dB
 Image rejection : > 20dB
 Distortion at RF=1mV, dev. 75kHz : < 3%
 -3dB Limiting point : < 23.5dB
 Crosstalk at RF=1mV, dev. 40kHz : > 26dB

AM

Tuning range : 531-1602kHz
 530-1700kHz for /21/21M
 Grid : 9kHz
 10kHz for /21/21M
 IF frequency : 450kHz \pm 1kHz
 Aerial input : Frame aerial 18.1 μ H
 Sensitivity at 26dB S/N : > 1.3mV/M
 Selectivity at 300kHz bandwidth : > 20dB
 IF rejection : > 24dB
 Image rejection : > 28dB
 Distortion at RF=50mV, M=80% : < 5%

COMPACT DISC:

Frequency response within \pm 3dB : 20Hz - 20kHz
 Output level (in Vrms) : 500mV, $Z_{out} = 100\Omega$
 Signal/Noise ratio (A-weighted): > 65dBA
 Distortion at 1kHz : < 0.02%
 Channel unbalance at 1kHz : < \pm 2dB
 Channel separation at 1kHz : > 30dB
 Emphasis : 15/50 μ S (switched
 automatically by CD10)

THD Noise(1kHz) : < 0.5%
 Outband Attenuation : 35dB
 MP3-CD Bit Rate : 32-320 kbps
 Sampling Rate : 32, 44.1, 48 kHz
 Forma : ISO9660, Joliet

VIDEO PART

Video Bandwidth : 6MHz(-5dB)
 S/N luminance : > 48dB
 S/N chroma : AM: >58dB/PM: >51dB
 Chrome/Luminance delay : < 80ns
 Burst/Chroma ratio : \pm 5%

CASSETTE RECORDER:


Number of track : 2 stereo
 Tape speed : 4.76 cm/sec \pm 2%
 Wow and flutter : < 0.4% DIN
 Fast-wind/Rewind time C60 : 130 sec
 Bias system : 75kHz \pm 10kHz
 Rec/Pb frequency response within 8dB: 100Hz - 10kHz
 Signal to Noise Ratio (Type I) : > 38dB

AMPLIFIER:

Output power
 L & R : 2 x 25W (6 Ω , 1kHz, 10% THD)
 Frequency response within +0.5/-1.0dB
 : 20Hz-20kHz
 Digital Sound Control (DSC) : Jazz / Rock / Pop / Optimal
 Dynamic Bass Boost (DBB) : On / Off
 Incredible Surround : On / Off


MEASUREMENT SETUP

Tuner FM



Use a bandpass filter to eliminate hum (50Hz, 100Hz) and disturbance from the pilotone (19kHz, 38kHz).

Tuner AM (MW,LW)





To avoid atmospheric interference all AM-measurements have to be carried out in a Faraday's cage. Use a bandpass filter (or at least a high pass filter with 250Hz) to eliminate hum (50Hz, 100Hz).

CD

Use Audio Signal Disc SBC429 4822 397 30184 (replaces test disc 3)

RECORDER

Use Universal Test Cassette **CrO₂** SBC419 4822 397 30069 or Universal Test Cassette **Fe** SBC420 4822 397 30071



SERVICE AIDS

Service Tools:

Universal Torx driver holder	4822 395 91019
Torx bit T10 150mm	4822 395 50456
Torx driver set T6-T20	4822 395 50145
Torx driver T10 extended	4822 395 50423






Compact Disc:

SBC426/426A Test disc 5 + 5A	4822 397 30096
SBC442 Audio Burn-in test disc 1kHz	4822 397 30155
SBC429 Audio Signals disc	4822 397 30184
Dolby Pro-logic Test Disc	4822 395 10216

ESD Equipment:

Anti-static table mat - large 1200x650x1.25mm ...	4822 466 10953
anti-static table mat - small 600x650x1.25mm	4822 466 10958
Anti-static wristband	4822 395 10223
Connectorbox (1M Ω)	4822 395 11307
Extension cable (to connect wristband to conn.box)	4822 320 11305
Connecting cable (to connect table mat to conn.box)	4822 320 11306
Earth cable (to Connect product to mat or box) --	4822 320 11308
Complete kit ESD3 (combining all above products)	4822 320 10671
Wristband tester	4822 344 13999

HANDLING CHIP COMPONENTS



(GB) WARNING

All ICs and many other semi-conductors are susceptible to electrostatic discharges (ESD). Careless handling during repair can reduce life drastically.

When repairing, make sure that you are connected with the same potential as the mass of the set via a wrist wrap with resistance. Keep components and tools also at this potential.

(F) ATTENTION

Tous les IC et beaucoup d'autres semi-conducteurs sont sensibles aux décharges statiques (ESD).

Leur longévité pourrait être considérablement écourtée par le fait qu'aucune précaution n'est prise à leur manipulation.

Lors de réparations, s'assurer de bien être relié au même potentiel que la masse de l'appareil et enfiler le bracelet serti d'une résistance de sécurité.

Veiller à ce que les composants ainsi que les outils que l'on utilise soient également à ce potentiel.

(GB)

Safety regulations require that the set be restored to its original condition and that parts which are identical with those specified, be used.

(NL)

Veiligheidsbepalingen vereisen, dat het apparaat bij reparatie in zijn oorspronkelijke toestand wordt teruggebracht en dat onderdelen, identiek aan de gespecificeerde, worden toegepast.

(F)

Les normes de sécurité exigent que l'appareil soit remis à l'état d'origine et que soient utilisés les pièces de rechange identiques à celles spécifiées.

(D)

Bei jeder Reparatur sind die geltenden Sicherheitsvorschriften zu beachten. Der Originalzustand des Geräts darf nicht verändert werden; für Reparaturen sind Original-Ersatzteile zu verwenden.

(I)

Le norme di sicurezza esigono che l'apparecchio venga rimesso nelle condizioni originali e che siano utilizzati i pezzi di ricambio identici a quelli specificati.

"After servicing and before returning set to customer perform a leakage current measurement test from all exposed metal parts to earth ground to assure no shock hazard exist. The leakage current must not exceed 0.5mA."

ESD**(D) WARNUNG**

Alle ICs und viele andere Halbleiter sind empfindlich gegenüber elektrostatischen Entladungen (ESD).

Unvorsichtige Behandlung im Reparaturfall kann die Lebensdauer drastisch reduzieren. Veranlassen Sie, dass Sie im Reparaturfall über ein Pulsarmband mit Widerstand verbunden sind mit dem gleichen Potential wie die Masse des Gerätes.

Bauteile und Hilfsmittel auch auf dieses gleiche Potential halten.

(NL) WAARSCHUWING

Alle IC's en vele andere halfgeleiders zijn gevoelig voor electrostatische ontladingen (ESD).

Onzorgvuldig behandelen tijdens reparatie kan de levensduur drastisch doen verminderen. Zorg ervoor dat u tijdens reparatie via een polsband met weerstand verbonden bent met hetzelfde potentiaal als de massa van het apparaat.

Houd componenten en hulpmiddelen ook op ditzelfde potentiaal.

(I) AVVERTIMENTO

Tutti IC e parecchi semi-conduttori sono sensibili alle scariche statiche (ESD).

La loro longevità potrebbe essere fortemente ridotta in caso di non osservazione della più grande cauzione alla loro manipolazione. Durante le riparazioni occorre quindi essere collegato allo stesso potenziale che quello della massa dell'apparecchio tramite un braccialetto a resistenza.

Assicurarsi che i componenti e anche gli utensili con quali si lavora siano anche a questo potenziale.

"Pour votre sécurité, ces documents doivent être utilisés par des spécialistes agréés, seuls habilités à réparer votre appareil en panne".

**(GB) Warning !**

Invisible laser radiation when open. Avoid direct exposure to beam.

(S) Varning !

Osynlig laserstrålning när apparaten är öppnad och spårren är urkopplad. Betrakta ej strålen.

(SF) Varoitus !

Avatussa laitteessa ja suojalukituksen ohitettaessa olet alttiina näkymättömälle laserisäteilylle. Älä katso säteeseen!

(DK) Advarse !

Usynlig laserstråling ved åbning når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling.

INFORMATION ABOUT LEAD-FREE SOLDERING


Philips CE is producing lead-free sets from 1.1.2005 onwards.

IDENTIFICATION:

Regardless of special logo (not always indicated) one must treat all sets from 1 Jan 2005 onwards, according next rules:



Example S/N:



Bottom line of typeplate gives a 14-digit S/N. Digit 5&6 is the year, digit 7&8 is the week number, so in this case 2005 wk12

So from 0501 onwards = from 1 Jan 2005 onwards

Important note: In fact also products of year 2004 must be treated in this way as long as you avoid mixing solder-alloys (leaded/ lead-free). So best to always use SAC305 and the higher temperatures belong to this.

Due to lead-free technology some rules have to be respected by the workshop during a repair:

- Use only lead-free solder alloy Philips SAC305 with order code 0622 149 00106. If lead-free solder-paste is required, please contact the manufacturer of your solder-equipment. In general use of solder-paste within workshops should be avoided because paste is not easy to store and to handle.
- Use only adequate solder tools applicable for lead-free solder alloy. The solder tool must be able
 - To reach at least a solder-temperature of 400°C,
 - To stabilize the adjusted temperature at the solder-tip
 - To exchange solder-tips for different applications.
- Adjust your solder tool so that a temperature around 360°C – 380°C is reached and stabilized at the solder joint. Heating-time of the solder-joint should not exceed ~ 4 sec. Avoid temperatures above 400°C otherwise wear-out of tips will rise drastically and flux-fluid will be destroyed. To avoid wear-out of tips switch off un-used equipment, or reduce heat.
- Mix of lead-free solder alloy / parts with leaded solder alloy / parts is possible but PHILIPS recommends strongly to avoid mixed solder alloy types (leaded and lead-free).
If one cannot avoid or does not know whether product is lead-free, clean carefully the solder-joint from old solder alloy and re-solder with new solder alloy (SAC305).
- Use only original spare-parts listed in the Service-Manuals. Not listed standard-material (commodities) has to be purchased at external companies.
- Special information for BGA-ICs:
 - always use the 12nc-recognizable soldering temperature profile of the specific BGA (for de-soldering always use the lead-free temperature profile, in case of doubt)
 - lead free BGA-ICs will be delivered in so-called 'dry-packaging' (sealed pack including a silica gel pack) to protect the IC against moisture. After opening, dependent of MSL-level seen on indicator-label in the bag, the BGA-IC possibly still has to be baked dry. (MSL=Moisture Sensitivity Level). This will be communicated via AYS-website.
 - Do not re-use BGAs at all.
- For sets produced before 1.1.2005 (except products of 2004), containing leaded solder-alloy and components, all needed spare-parts will be available till the end of the service-period. For repair of such sets nothing changes.
- On our website www.atyourservice.ce.Philips.com you find more information to:
 - * BGA-de-/soldering (+ baking instructions)
 - * Heating-profiles of BGAs and other ICs used in Philips-sets

You will find this and more technical information within the "magazine", chapter "workshop news".

For additional questions please contact your local repair-helpdesk.


SERVICE INSTRUCTION

Safety regulations require that after a repair, the set must be returned in its original condition. Pay in particular attention to the following points:

- Route the wire trees correctly and fix them with the mounted cable clamps.
- Check the insulation of the AC Power lead for external damage.
- Check the strain relief of the AC Power cord for proper function.
- Check the electrical DC resistance between the AC Power Plug and the secondary side (only for sets which have a AC Power isolated power supply):
 1. Unplug the AC Power cord and connect a wire between the two pins of the AC Power plug.
 2. Set the AC Power switch to the "on" position (keep the AC Power cord unplugged!).
 3. Measure the resistance value between the pins of the AC Power plug and the metal shielding of the tuner or the aerial connection on the set. The reading should be larger than 4.5 Mohm (For U.S. it should be between 4.2 Mohm and 12 Mohm).
 4. Switch "off" the set, and remove the wire between the two pins of the AC Power plug.
- Check the cabinet for defects, to avoid touching of any inner parts by the customer.

CONNECTIONS AND CONTROLS

Connections




IMPORTANT!

- The type plate is located at the rear of the system.
- Before connecting the AC power cord to the wall outlet, ensure that all other connections have been made.
- Never make or change any connections with the power switched on.

To avoid overheating of the system, a safety circuit has been built in. Therefore, your system may switch to Standby mode automatically under extreme conditions. If this happens, let the system cool down before reusing it (not available for all versions).

Step 1: Placing speakers




Place the front left and right speakers at equal distances from the TV set and at an angle of approximately 45 degrees from the listening position.

Notes:

- To avoid magnetic interference, do not position the front speakers too close to your TV set.
- Allow adequate ventilation around the DVD System.

Connections

Step 2: Connecting speakers



Connect the speaker wires to the **SPEAKERS** terminals, right speaker to "R" and left speaker to "L", coloured (marked) wire to "+" and black (unmarked) wire to "-". Fully insert the stripped portion of the speaker wire into the terminal as shown.


Notes:

- Ensure that the speaker cables are correctly connected. Improper connections may damage the system due to short-circuit.
- For optimal sound performance, use the supplied speakers.
- Do not connect more than one speaker to any one pair of +/- speaker terminals.
- Do not connect speakers with an impedance lower than the speakers supplied. Please refer to the SPECIFICATIONS section of this manual.

Step 3: Antennas Connection

Connect the supplied MW loop antenna and FM antenna to the respective terminals. Adjust the position of the antenna for optimal reception.

MW Antenna



Position the antenna as far as possible from a TV, VCR or other radiation source.

FM Antenna



For better FM stereo reception, connect an outdoor FM antenna to the FM AERIAL (FM ANTENNA) terminal.

CONNECTIONS AND CONTROLS


Connections

Step 4: Connecting TV

IMPORTANT!

- You only need to make one video connection from the following options, depending on the capabilities of your TV system.
- Connect the DVD system directly to the TV.
- A SCART connection will let you use features both Audio and Video on the DVD Player.

Using SCART jack




Use the SCART cable (black) to connect the DVD Player's SCART jack (**SCART OUT**) to the corresponding Scart input jacks on the TV (cable not supplied).

Note:

- Ensure that the "TV" indication on SCART cable is connected to the TV set and "DVD" indication on SCART cable is connected to the DVD Player.

Using Composite Video jacks (CVBS)




1 Use the composite video cable (yellow) to connect the DVD Player's CVBS (VIDEO OUT) jack to the video input jack (or labeled as AV In, Video In, Composite or Baseband) on the TV.

2 To hear the sound of this DVD Player through your TV, use the audio cables (white/red) to connect LINE OUT (L/R) jacks of the DVD Player to the corresponding AUDIO IN jacks on the TV.

Using S-Video In jack

IMPORTANT!

- If the picture is distorted, check the Video Output setting. Make sure it is set to 'S-Video'. (See Setting video preference).




1 Use the S-Video cable (not supplied) to connect the system's **S-VIDEO OUT** jack to the S-Video input jack (or labeled as Y/C or S-VHS) on the TV set.

2 To hear the sound of this DVD Player through your TV, use the audio cables (white/red) to connect LINE OUT (L/R) jacks of the DVD Player to the corresponding AUDIO IN jacks on the TV.

Using an accessory RF modulator

IMPORTANT!


- If your TV set only has a single Antenna In jack (or labeled as 75 ohm or RF In), you will need a RF modulator in order to view the DVD playback via TV. See your electronics retailer or contact Philips for details on RF modulator availability and operations.



Use the composite cable (yellow) to connect the system's **CVBS** jack to the video input jack on the RF modulator.

Use the RF coaxial cable (not supplied) to connect the RF modulator to your TV's RF jack.

CONNECTIONS AND CONTROLS




Connections

Viewing and listening to the playback of other equipment (A)

Connect the system's **AUX/CDR IN (R/L)** jacks to the **AUDIO OUT** jacks on the other audio/visual device (such as a TV/VCR, Laser Disc player or cassette deck).
Before starting operation, press **SOURCE** on the front panel to select **AUX** or press **AUX** on the remote in order to activate the input source.

Connecting an active subwoofer (B)

Connect the DVD micro system's **SUBWOOFER OUT** jack to the **AUDIO INPUT** jack on an active subwoofer (not supplied).



Using the VCR for recording DVDs (C)

Connect one of the system's **VIDEO OUT** jacks to the corresponding **VIDEO IN** jack and **LINE OUT (R/L)** jacks to the **AUDIO IN** jacks on the VCR. This will allow you to make analogue stereo (two channel, right and left) recordings.

Recording (digital) (D)

Connect the system's **DIGITAL OUT** jack to the **DIGITAL IN** jack on a digital recording device (such as DTS-Digital Theatre compatible, with Dolby Digital decoder).
Before starting operation, set the **DIGITAL OUT** according to the audio connection. (See page 28)

Step 5: Connecting the power cord

IMPORTANT!

- Never make or change any connection with the power switched on.


"AUTO INSTALL - PRESS PLAY TO START" may appear on the display panel when the AC power cord is plugged into the power outlet for the first time.

Press **▶||** on the main unit to store all available radio stations or press **■** to exit (refer to 'Tuner Reception').
After everything is connected properly, plug in the AC power cord to the power outlet.

Optional: Connecting additional equipment

IMPORTANT!

- Some discs are copy-protected. You cannot record the disc through a VCR or digital recording device.
- When making connections, make sure the colour of cables matches the colour of jacks.
- Always refer to the owner's manual of the other equipment for complete connection and usage details.




CONNECTIONS AND CONTROLS

Controls

Controls on the system

- 1 **ECO POWER/STANDBY-ON**
 - to switch the system on or to Eco power/normal standby mode.
- 2 **Display screen**
 - to view the current status of the system.
- 3 **SOURCE**
 - to select the respective sound source : DISC, TUNER, TAPE or AUX.
- 4 **BAND / DISPLAY**
 - for Tuner to select waveband : FM or MW.
 - for DVD/VCD/CD/MP3-CD displays disc information on the TV screen and system display panel during playback.
- 5 **PROGRAM**
 - for VCD/CD/MP3-CD ... to program disc tracks.
 - for Tuner to program preset radio stations.
- 6 **▲▼ ALBUM/PRESET/TIMER SET**
 - for MP3-CD to select previous/next album.
 - for Tuner to select a preset radio station.
 - *for Timer (▲)...to set the timer function
- 7 **TUNING**
 - *for DVD/VCD/CD.....to fast reverse/forward the disc. (It is impossible to fast reverse / forward for MP3-CD)
 - for DVD/VCD/CD/MP3 CD ... to select a desired track.
 - for Tuner to tune to a lower or higher radio frequency.
 - for Tape to rewind or fast forward.
 - for clock/timer setting to adjust the hours and minutes for the clock/timer functions.
- 8 **Tape deck**
- 9 **OPEN/CLOSE**
 - to open the tape compartment.
- 10 **▶||**
 - to start or interrupt playback.
- 11 **■**
 - for DVD/VCD/CD/MP3-CD ...to stop playback or to clear a program.
 - for Tapeto stop playback or recording.

Controls



12 VOLUME

- to increase or decrease the volume.

13 RECORD

- to start recording.

14 CLOCK SET/RDS

- *for Clock.....(on the system only) to set the clock function.
- for tunerdisplays RDS information.

15 IR sensor

- infrared sensor for remote control.

16 OPEN•CLOSE ▲

- to open or close the disc tray.

17 DSC

- selects different types of preset sound equalizer settings (JAZZ, ROCK, POP or OPTIMAL).

18 DBB/INCREDIBLE SURROUND

- to create a super-enhanced stereo effect.
- to enhance the bass.

19

- to connect headphones.

Controls on the remote control

- 1
 - to switch the system on or to Eco power/normal standby mode.
- 2 **SOURCE**
 - to select the respective sound source : DISC, TUNER, TAPE or AUX.
- 3 **Numeric Keypad (0-9)**
 - to enter a track/title number of the disc.
- 4 **VOL +/-**
 - to increase or decrease the volume.
- 5 **ALBUM/+ <<</>>>**
 - to select a fast playback speed forward and backward.
 - in the tuner mode, to tune to a higher or lower radio frequency.
 - to select a movement direction in the disc menu or system menu bar.
 - for MP3, to select an album up or down.
 - for VCD/DVD, to move an enlarged picture left or right.

* = Press and hold the button for more than two seconds.

PREPARATIONS AND CONTROLS

Controls

- (6) GOTO**
- to start playback at any chosen time on the disc (for VCD operation with PBC off).
- (7) ANGLE/PROG**
- for VCD/CD/MP3-CD... to program disc tracks.
 - for Tuner to program preset radio stations.
 - for DVD to view the same scene from different angles if the DVD is recorded with multi-angles.
- (8) SHUFFLE**
- to play tracks in a random order
- (9) ECHO (not for this version)**
- (10) KEY (not for this version)**
- (11) DISPLAY (OSD)**
- displays disc information on the TV screen and system display panel during playback to show the status of the system.
- (12) ZOOM**
- to zoom in picture.
- (13) MUTE**
- to interrupt or resume sound reproduction.
- (14) DBB (Dynamic Bass Boost)**
- Enhances the bass
- (15) DSC**
- to select various sound effect: JAZZ, ROCK, POP or OPTIMAL.
- (16) IS**
- to switch incredible surround on or off.
- (17) TIMER**
- * to set the timer.
 - to select TIMER ON or TIMER OFF.
- (18) SLEEP**
- to set the sleep (auto-off) timer function.
- (19) AUDIO**
- For VCD... sets Stereo, Mono-Left or Mono-Right sound mode.
 - For DVD... selects an audio language.
- (20) SUBTITLE**
- to select the preferred language for subtitle.
- (21) REPEAT A-B**
- for CD: to repeat a specific section within the same track.
 - for DVD/VCD: to repeat a specific section in a disc.
- (22) REPEAT**
- to repeat a track/disc.
- (23) PLAY/PAUSE ►II**
- to start or interrupt disc playback.
- (24) STOP ■**
- for CD/DVD/VCD (with PBC off) press it once to stop playback and press ►II to resume.
 - press it twice to stop playback completely.
- (25) ◀, ▶**
- In disc mode, to select the previous or next chapter or track.
- (26) OK**
- to exit or confirm the selection.
- (27) ▲, ▼**
- to select a movement direction in the disc menu or system menu bar.
 - (for DVD/VCD only) to select a desired slow playback speed forward or backward.
- (28) SYSTEM MENU (disc mode only)**
- to enter or exit the system menu bar.
- (29) DISC MENU (disc mode only)**
- to enter or exit the disc contents menu.
- Notes for remote control:**
- First, select the source you wish to control by pressing one of the source select keys on the remote control (DISC or TUNER, for example).
 - Then select the desired function (►II, ►I, ◀ for example).


* = Press and hold the button for more than two seconds.

Preparations

IMPORTANT!

- Make sure to complete the preparation procedures before operating the system.


Step 1: Inserting batteries into the remote control



- Open the battery compartment.
- Place two batteries (Type R06 or AA) in the compartment with the correct polarity as indicated by "+" and "-" symbols.
- Close the cover.

Using the remote control to operate the system

- Point the remote control directly at the remote sensor (IR) on the front panel.
- Select the source you wish to control by pressing one of the source select buttons on the remote control (for example TAPE, TUNER).
- Then select the desired function (for example ►II, ◀, ▶).



CAUTION!

- Remove batteries if they are exhausted or will not be used for a long time.
- Do not use old and new or different types of batteries in combination.
- Batteries contain chemical substances, so they should be disposed of properly.

Step 2: Setting the clock

- In standby mode, press and hold **CLOCK SET/RDS** on the system. "SET CLOCK" appears. Then, the clock digits for the hours flash. Press **TUNING ◀◀◀▶▶▶** on the system to set the hours. Press **CLOCK SET/RDS** again. The clock digits for the minutes flash. Press **TUNING ◀◀◀▶▶▶** on the system to set the minutes. Press **CLOCK SET/RDS** to confirm your setting. The system will store the setting automatically. The time setting becomes effective.

Note:

- The clock will be cancelled when the power cord is disconnected or if a power failure occurs.
- During setting, if no button is pressed within 30 seconds, the system will exit clock setting mode automatically.

PREPARATIONS

Preparations

- TV Shape

Selects the aspect ratio of the TV to be connected.

4:3 PS (Pan and Scan mode)

- If you have a conventional TV set and your DVD is not formatted for widescreen viewing, use this setting. A wide picture is displayed on the whole TV screen with a portion automatically cut off.



4:3 LB (Letterbox mode)

- If you have a conventional TV set and your DVD is formatted for widescreen viewing, use this setting. A wide picture with bands displayed on the upper and lower portions of the TV screen.



16:9 (Wide screen mode)

- If you have a widescreen TV set, use this setting (you must also set your widescreen TV to "full size") available on a disc, then the disc's own preference will be used.



Note:

The format you select must be available on the disc. If it is not, the setting for TV Shape will not affect the picture during playback.

To remove the menu

Press **SYSTEM MENU**.

IMPORTANT!

- **Make sure you have completed all the necessary connections. (See Connections - Connecting TV)**

Step 4: Setting video preference

Turn on the TV set and set it to the correct Video-In channel.

You may go to channel 1 on your TV set, then press the channel button repeatedly until you see the Video In channel.

Or, you can use the TV remote control to select different video modes.

Or, set TV to channel 3 or 4 if you are using an RF modulator.

Language	Video	Audio	Rating
TV Shape	4:3 LB	4:3 PS	4:3 LB
TV System	Auto	S-VIDEO	16:9

1 In the disc mode, stop playback and press **SYSTEM MENU**.

2 Press **◀/▶/▲/▼** on the remote control to toggle through the functions and select your preferential option.

Move to **Video** and press **OK** or **▼**.
Move to one of the following and press **OK** or **▶▶**.

Step 3: Setting language preference

You can select your preferred language settings so that this DVD Micro System will automatically switch to the language for you whenever you load a disc. If the language selected is not available on the disc, the language set by default will be used instead. But the menu language of the DVD Micro System cannot be changed once selected.

Language	Video	Audio	Rating
OSD Menu	English	English	English
Subtitle	English	French	French
Audio	English	Spanish	Spanish
Menu	English	Portuguese	Portuguese
		Deutsch	Deutsch

1 In stop mode, press **SYSTEM MENU**.

2 Press **◀/▶/▲/▼** on the remote control to select your preferred option.

Move to **Language** and press **OK** or **▼**.
Move to one of the following and press **OK** or **▶▶**.

OSD Menu (On-Screen Display)

Switches the display language on the TV screen. Select the language from the displayed list.

Subtitle (DVD only)

Switches the display language of the subtitle. Select the language from the displayed list.

Audio (DVD only)

Switches the display language of the sound track. Select the language from the displayed list.

Menu (DVD only)

Select the language for the DVD menu.

When the selected language is not recorded in the DVD, one of the recorded languages will be selected automatically (except for OSD).

You can reset all the DVD settings except for Rating.

If the language selected is not available on the disc, the original language designated by each disc will be selected.

3 Press **▲/▼** to select a language and press **OK**.

4 Repeat **steps 2~3** for other settings.

- TV System

Allows you to select the color system matching the connected TV set.

NTSC

- If the connected TV is NTSC system, select this mode. It will change the video signal of a PAL disc and output in NTSC format.

PAL

- If the connected TV is PAL system, select this mode. It will change the video signal of an NTSC disc and output in PAL format.

AUTO

- If the connected TV is multi system, select this mode. The output format will be in accordance with the video signal of the disc.

- Video Out

- Video out selection enables you to choose the type of video output suitable for your DVD system.

S-VIDEO

- Select **S-VIDEO** if you have connected the S-VIDEO output to your TV using S-VIDEO jack.

SCART

- Select **SCART** if you have connected the video output to your TV using SCART OUT jack.

To remove the menu

Press **SYSTEM MENU**.

To resume playback

Press **▶▶ (PLAY/PAUSE ▶▶)** on the remote).

Troubleshooting

Troubleshooting

WARNING

Under no circumstances should you try to repair the system yourself, as this will invalidate the warranty. Do not open the system as there is a risk of electric shock.

If a fault occurs, first check the points listed below before taking the system for repair. If you are unable to remedy a problem by following these hints, consult your dealer or Philips for help.

Problem	Solution
No power.	<ul style="list-style-type: none"> Check if the AC power cord is properly connected. Check if the disc is inserted upside down. Wait until the moisture condensed at the lens has cleared. Replace or clean the disc, see "Maintenance". Use a readable disc or correctly recorded format MP3-CD.
No picture.	<ul style="list-style-type: none"> Select the appropriate video input mode on the TV set. Check if the TV set is switched on. Check the video connection. Check if the system is securely connected.
Distorted or poor picture.	<ul style="list-style-type: none"> Sometimes a slight picture distortion may appear. This is not a malfunction. Clean the disc. Connect the system to the S-video input of your TV set.
The aspect ratio of the screen cannot be changed even though you have set the TV shape.	<ul style="list-style-type: none"> The aspect ratio is fixed on the DVD disc. The aspect ratio may not be changed for some TV systems.
The DVD player does not start playback.	<ul style="list-style-type: none"> Insert a readable disc. Check the disc type, color system and region code. Clean the disc. Place the disc with the playback side down. Press SYSTEM MENU to turn off the setup menu. Cancel the parental control rating function or change the rating level. Moisture has condensed inside the system. Remove the disc and leave the system turned on for about an hour. Disconnect the power plug from the jack, and insert again.
The DVD player does not respond when buttons are pressed.	
The language for the sound or subtitle cannot be changed when playing a DVD.	<ul style="list-style-type: none"> Multi-language sound or subtitle is not recorded on the DVD. Changing the language for the sound or subtitle is prohibited on the DVD.
No image is output when a function is selected.	<ul style="list-style-type: none"> Make sure the component is connected correctly. Press the correct function button for the input source.
Sound cannot be heard or is of poor quality	<ul style="list-style-type: none"> Adjust the volume. Disconnect the headphones. Check that the speakers are connected correctly. Check if the stripped speaker wire is clamped. If the system is in pause, slow motion or fast forward/reverse mode, press ▶ to resume the normal play mode. Make sure the MP3-CD was recorded within 32-256 kbps bit rate with sampling frequencies at 48 kHz, 44.1 kHz or 32 kHz. If the signal is too weak, adjust the antenna or connect an external antenna for better reception. Increase the distance between the System and your TV set or VCR.
Poor radio reception.	<ul style="list-style-type: none"> Clean deck parts, see "Maintenance". Use only NORMAL tape. Apply a piece of adhesive tape over the missing tab space. Remove and reconnect the AC power plug and switch on the system again. Check the speaker connections and location.
Recording or playback cannot be made	<ul style="list-style-type: none"> Point the remote control at the remote control sensor of the unit. Reduce the distance to the player. Remove any possible obstacles. Replace the batteries with new ones. Check that the batteries are loaded correctly. Set the clock correctly. If recording is in progress, stop it. Power has been interrupted or the power cord has been disconnected. Reset the clock/timer.
The tape deck door cannot open	
Left and right sound outputs are reversed.	
The remote control does not function.	
The timer is not working	
The Clock/Timer setting is erased	

DISMANTLING INSTRUCTIONS

Dismantling of the Cover Cassette and Universal Loader

- 1) Push 1 catch each on the left & right side then remove the Cover Cassette in the direction as shown in Figure 1 and Figure 1A.
- 2) Loosen 8 screws to remove the Cover Top by sliding it out towards the rear before lifting up.
 - 6 screws on the rear
 - 1 screw each on the left & right side
- 3) Loosen 2 screws each to remove the Panel Left and Panel Right. The Panels are removed by sliding it towards the rear and outwards.
 - 1 screw on the rear
 - 1 screw on the side
 - see Service position A
- 6) Loosen 2 screws A (see Figure 2) to remove the Bracket Module Mounting and CD Module.
 - 1 screw each on the left & right side




Figure 1




Figure 1A




Figure 2

Detaching the Front Panel assembly from the Bottom/Rear assembly

- 1) Remove 2 screws B (see Figure 3) from the bottom of the Cabinet Front.




Figure 3

- 2) Release the fixation of the Combi Board (pos1102-1003) to Bracket Combi (pos 155) by releasing the 2 catches C1 (see Figure 7) and pulling the Combi Board outwards as shown in Figure 7A.
- 3) Uncatch 2 catches C2 (see Figure 7) on the left & right sides of the Cabinet Front (pos 101) and slides the Front Panel assembly out towards the front.
 - see Service position C

Detaching the Front Panel assembly from the Bottom/Rear assembly




Figure 4A

Figure 4

Dismantling of the Front Panel assembly

- 1) The Knob Volume can be removed by pulling it out in the direction as shown in Figure 5.
- 2) Loosen 3 screws C (see Figure 6) to remove the Bracket Front Cabinet Display.
- 3) Loosen 3 screws D (see Figure 6) to remove Front Display Board.
- 4) Loosen 2 screws E (see Figure 6) to remove the Headphone Board.
- 5) Loosen 4 screws F (see Figure 7) to remove the Module Tape Deck.




Figure 5

DISMANTLING INSTRUCTIONS


Dismantling of the Front Panel assembly

Figure 6




Figure 7

Dismantling of the Rear Panel assembly

- 1) Loosen 3 screws K and 2 catches C5 (see Figure 8) to remove the Tuner Board assembly.
- 2) Loosen 5 screws L (see Figure 8) to free the Main Board.
- 3) Loosen 1 screw M (see Figure 8) to free the Mains Socket Bracket.

- 4) Loosen 1 screw N and 2 catches C6 (see Figure 8) to free the Panel Rear by sliding it out towards the rear.

Note : Tuner Board assembly and Mains Socket Bracket can also be removed together with the Panel Rear.




Figure 8


DISMANTLING INSTRUCTIONS

Repair Hints & Service Positions


- 1) During repair it is possible to disconnect the Tuner Board and/or CD Module completely unless the fault is suspected to be in that area. This will not affect the performance of the rest of the set.

Note: The flex cables are very fragile, care should be taken not to damage them during repair. After repair, be very sure that the flex cables are inserted properly into the flex sockets before encasing, otherwise faults may occur.


Service position A



Service position B



Service position C



SERVICE TEST PROGRAM






Figure 1


SET BLOCK DIAGRAM



- CASS BOARD
- MPEG BOARD
- MAIN BOARD
- RECITIFIER BOARD
- MICROPHONE BOARD
- FRONT PANEL BOARD
- COMPONENT VIDEO BOARD
- POWER BOARD
- VFD BOARD
- SCART BOARD

" * " MARK PARTS FOR EMC

SET WIRING DIAGRAM




**IC BLOCK DIAGRAM - VFD DRIVER
PT6315**

DISPLAY BOARD

TABLE OF CONTENTS

IC Internal Block Diagram 6-1 to 6-3
 Display Board Layout Top View 6-4
 Display Board Layout Bottom View 6-5
 Circuit Diagram 6-6
 Headphone Board Layout 6-7
 Electrical Parts List 6-7

BLOCK DIAGRAM




**IC PIN DESCRIPTION - VFD DRIVER
PT6315**


PIN DESCRIPTION

Pin Name	I/O	Description	Pin No.
LED1 to LED4	O	LED Output Pin	1 to 4
OSC	I	Oscillator Input Pin A resistor is connected to this pin to determine the oscillation frequency	5
DOUT	O	Data Output Pin (N-Channel, Open-Drain) This pin outputs serial data at the falling edge of the shift clock (starting from the lower bit).	6
DIN (Schmitt Trigger)	I	Data Input Pin This pin inputs serial data at the rising edge of the shift clock (starting from the lower bit)	7
CLK (Schmitt Trigger)	I	Clock Input Pin This pin reads serial data at the rising edge and outputs data at the falling edge.	8
STB (Schmitt Trigger)	I	Serial Interface Strobe Pin The data input after the STB has fallen is processed as a command. When this pin is "HIGH", CLK is ignored.	9
K1 to K2	I	Key Data Input Pins The data inputted to these pins are latched at the end of the display cycle.	10 ,11
VSS	-	Logic Ground Pin	12,44
VDD	-	Logic Power Supply	13,43
SG1/KS1 to SG16/KS16	O	High-Voltage Segment Output Pins Also acts as the Key Source	14 to 29
VEE	-	Pull-Down Level	30
SG17/GR12 to SG24/GR5	O	High Voltage Segment/Grid Output Pins	31 to 38
GR4 to GR1	O	High-Voltage Grid Output Pins	39 to 42

**IC BLOCK DIAGRAM - MICROCONTROLLER
uPD780078**




**IC PIN CONFIGURATION - MICROCONTROLLER
uPD780078**



A8 to A15:	Address bus	PCL:	Programmable clock
AD0 to AD7:	Address/data bus	RD:	Read strobe
ADTRG:	AD trigger input	RESET:	Reset
ANI0 to ANI7:	Analog input	RxD0, RxD2:	Receive data
ASCK0, ASCK2:	Asynchronous serial clock	SCK1, SCK3:	Serial clock
ASTB:	Address strobe	SI1, SI3:	Serial input
AVREF:	Analog reference voltage	SO1, SO3:	Serial output
AVSS:	Analog ground	SS1:	Serial interface chip select input
BUZ:	Buzzer clock	TI000, TI010, TI001,	
IC:	Internally connected	TI011, TI50, TI51:	Timer input
INTP0 to INTP3:	External interrupt input	TO00, TO01, TO50,	
P00 to P03:	Port 0	TO51:	Timer output
P10 to P17:	Port 1	TxD0, TxD2:	Transmit data
P20 to P25:	Port 2	VDD0, VDD1:	Power supply
P30 to P36:	Port 3	VPP:	Programming power supply
P40 to P47:	Port 4	VSS0, VSS1:	Ground
P50 to P57:	Port 5	WAIT:	Wait
P64 to P67:	Port 6	WR:	Write strobe
P70 to P75:	Port 7	X1, X2:	Crystal (main system clock)
P80:	Port 8	XT1, XT2:	Crystal (subsystem clock)


**IC BLOCK DIAGRAM - RDS/RBDS DEMODULATOR
SAA6581T**



**IC PIN DESCRIPTION - RDS/RBDS DEMODULATOR
SAA6581T**


PINNING

SYMBOL	PIN	DESCRIPTION
QUAL	1	signal quality indication output
RDDA	2	RDS data output
Vref	3	reference voltage output (1/2 VDDA)
VDDA	5	analog supply voltage (5 V)
VSSA	6	analog ground (0 V)
CIN	7	comparator input
SCOUT	8	switched capacitor filter output
MODE	9	oscillator frequency select input
SYNC	10	ARI clamping control input
VSSD	11	digital ground (0 V)
VDDD	12	digital supply voltage (5 V)
OSCI	13	oscillator input
OSCO	14	oscillator output
TCON	15	test control input
RDCL	16	RDS clock output




Pin configuration.


LAYOUT DIAGRAM - DISPLAY BOARD
TOP SIDE




LAYOUT DIAGRAM - DISPLAY BOARD
BOTTOM SIDE




CIRCUIT DIAGRAM - DISPLAY BOARD



LAYOUT DIAGRAM - HEADPHONE BOARD TOP SIDE




LAYOUT DIAGRAM - HEADPHONE BOARD BOTTOM SIDE




ELECTRICAL PARTSLIST - DISPLAY BOARD

D3	9940 000 03291	ZENER DIODE 5.6V 1/2W
IR201	9940 000 03347	IR SENSOR 5V 38.0KHZ
JW15	9940 000 03603	RADIAL INDUCTOR 10μH /21/21M
LED1	9940 000 02115	LED 3MM 3R4HD-7(RE D)
Q4	9940 000 02646	TRANSISTOR SS8050
Q5	9940 000 02642	TRANSISTOR 3CA8550
Q6	9940 000 03299	TRANSISTOR 8550
QD6	9940 000 03299	TRANSISTOR 8550
SW1	9940 000 03349	SWITCH TACT TSA-064301-250
SW10	9940 000 03349	SWITCH TACT TSA-064301-250
SW11	9940 000 03349	SWITCH TACT TSA-064301-250
SW12	9940 000 03349	SWITCH TACT TSA-064301-250
SW13	9940 000 03349	SWITCH TACT TSA-064301-250
SW14	9940 000 03349	SWITCH TACT TSA-064301-250
SW2	9940 000 03349	SWITCH TACT TSA-064301-250
SW3	9940 000 03349	SWITCH TACT TSA-064301-250
SW4	9940 000 03349	SWITCH TACT TSA-064301-250
SW5	9940 000 03349	SWITCH TACT TSA-064301-250
SW6	9940 000 03349	SWITCH TACT TSA-064301-250
SW7	9940 000 03349	SWITCH TACT TSA-064301-250
SW8	9940 000 03349	SWITCH TACT TSA-064301-250
SW9	9940 000 03349	SWITCH TACT TSA-064301-250
U1	9940 000 03607	IC RESET BD4844G /21/21M
U2	9940 000 03351	IC UPD780078
U3	9940 000 02671	IC BR24L02F-WE2
U4	9940 000 03346	IC SAA6581T RDS /14/22
U5	9940 000 03353	IC VFD DRIVER PT6315
VFD1	9940 000 03348	FTD HNA-13SM42T
VOL1	9940 000 03354	ENCODER F-12EN5H24B
Y1	9940 000 03343	CRYSTAL 8.38MHZ +/-20PPM
Y2	9940 000 03344	CRYSTAL 32.768KHZ +/-20PPM
Y4	9940 000 03345	CRYSTAL 4.332MHZ +/-20PPM

Note: Only these parts mentioned in the list are normal service parts.



BLOCK DIAGRAM




ECO6 Tuner Board
version: *SYSTEMS non-CENELEC*

TABLE OF CONTENTS

Blockdiagram7A-1
 Schematic Diagram7A-2
 Component Layout.....7A-3
 Adjustment table7A-3
 Electrical Partslist.....7A-4


TUNER BOARD ECO6 / SYSTEMS NON CENELEC



VERSION PROGRAMMING COMPONENTS

VERSION	6120	3156	3157	3170	7111
/00 /02 FM/MW/LW					
/00 /02 FM/MW					
/01 FM/MW					
/14 FM-OIRT/MW					
/17 FM/AM					
/06 FM-Japan/AM					

component mounted



- 1101 A1
- 1102 B1
- 1103 F2
- 1120 E14
- 1130 A2
- 1131 B2
- 1132 G13
- 2101 B3
- 2102 B1
- 2103 C7
- 2104 B3
- 2105 A2
- 2106 F3
- 2107 F4
- 2119 H6
- 2120 G6
- 2124 H6
- 2125 H6
- 2126 F7
- 2127 E7
- 2128 C8
- 2129 C7
- 2130 F11
- 2131 G8
- 2132 G8
- 2133 G8
- 2134 H8
- 2135 H9
- 2136 G14
- 2137 G13
- 2138 F9
- 2139 G9
- 2140 G9
- 2141 F10
- 2143 G12
- 2144 G11
- 2145 F12
- 2146 E12
- 2147 E12
- 2148 E12
- 2149 H7
- 2150 A10
- 2152 E4
- 2153 E5
- 2154 D5
- 2155 D5
- 2159 F6
- 2161 C11
- 2163 D11
- 2164 F10
- 2165 C7
- 2166 E11
- 2167 E11
- 2169 H8
- 3101 E4
- 3102 D4
- 3103 C6
- 3104 A7
- 3105 B6
- 3132 G5
- 3134 H6
- 3141 E7
- 3142 E7
- 3143 G7
- 3144 H7
- 3145 F8
- 3146 G13
- 3152 G14
- 3153 G13
- 3154 G13
- 3155 G11
- 3156 C12
- 3157 C12
- 3158 E13
- 3159 D13
- 3160 D12
- 3161 D13
- 3167 F12
- 3168 F11
- 3169 E11
- 3170 C12
- 3172 G12
- 3176 G7
- 3181 E6
- 5102 F2
- 5109 B9
- 5110 B10
- 5111 A8
- 5112 A11
- 5114 B11
- 5119 G9
- 5121 E11
- 5123 G5
- 5130 E5
- 5131 C6
- 5132 E2
- 6105-2 F3
- 6105-2 G5
- 6106 C3
- 6107 G13
- 6120 G13
- 6130 E5
- 6131 D5
- 7101 C8
- 7102 C6
- 7103 H7
- 7111 C13
- 7112 G12
- T102 B2
- T103 B2
- T105 F2
- T106 F2
- T109 B6
- T110 F5
- T111 F4
- T112 F7
- T113 A8
- T114 B10
- T115 A8
- T116 B10
- T117 G13
- T118 G13
- T119 F13
- T122 F13
- T123 F13
- T124 G14
- T125 F14
- T126 F13
- T127 F13
- T128 D7
- T140 F11
- T141 F10
- T142 F10


LEGEND
 (P)...for provision only
 USA ... for USA version only
 E-EU ... for East European version only
 J ... for Japanese version only

...V FM mode stereo
 ...V MW mode
 ...V LW mode
 voltages measured while set is tuned to a strong transmitter


Signal path
 — FM
 - - - AM
 - - - MPX (Audio Frequency)
 ⇨ AF - left/right

ECO6 Sys-non Cenelec, 000911

1101 A6 1120 A4 1132 A5 2128 C4 2138 C2 3142 D2 5110 B3 5114 A2 5123 D5 7112 C1 9104 B5 9107 D4
 1102 B6 1130 B5 2106 C5 2129 B4 2144 B2 5102 D6 5111 B4 5119 C2 5130 D3 9101 A2 9105 B1 9108 C4
 1103 D6 1131 D5 2107 B5 2133 D2 2155 C4 5109 A3 5112 A3 5121 B2 5131 D4 9103 B2 9106 B3 9109 D2



2101 B4 2119 D3 2130 D5 2137 A4 2146 B7 2153 C5 2165 C4 3103 C4 3134 D3 3152 A4 3158 A4 3169 B6 4106 C4 6107 C7 7103 D7
 2102 B1 2120 D3 2131 C5 2139 C6 2147 A5 2154 C4 2166 B6 3104 B4 3141 C5 3153 A4 3159 A5 3170 A6 4107 C5 6120 A6 7111 A5
 2103 D4 2124 D3 2132 D6 2140 C6 2148 B6 2159 C5 2167 B6 3105 C4 3143 D6 3154 C7 3160 A5 3172 C7 4108 C5 6130 D4 7119 B5
 2104 B4 2125 D3 2134 D7 2141 C6 2149 D6 2161 A6 2169 A4 3113 B5 3144 B7 3155 C7 3161 A5 3176 D6 6103 B3 6131 C4
 2105 C1 2126 D6 2135 D7 2143 C7 2150 B5 2163 B6 3101 D5 3119 B5 3145 C5 3156 A6 3167 B7 3181 D4 6105 C3 7101 C5
 2112 B5 2127 C5 2136 A4 2145 A5 2152 C5 3102 C3 3132 D5 3146 C7 3157 A6 3168 C7 4103 B5 6106 C3 7102 D4



These assembly drawings show a summary of all possible versions.
 For components used in a specific version see schematic diagram respectively partlist.

TUNER ADJUSTMENT TABLE (ECO6 FM/MW- and FM/MW/LW - versions with AM-frame aerial)

Waverange	Input frequency	Input	Tuned to	Adjust	Output	Scope/Voltmeter
VARICAP ALIGNMENT						
FM 87.5 - 108MHz (65.81 - 74, 87.5 - 108MHz)			108MHz	5130		8V ±0.2V
			87.5MHz (65.81MHz)	check		4.3V ±0.5V (1.2V ±0.5V)
MW FM/AM-version, 10kHz grid 530 - 1700kHz			1700kHz	5123		8V ±0.2V
			530kHz	check		1.1V ±0.4V
FM/MW-version, 9kHz grid 531 - 1602kHz			1602kHz	5123	1	6.9V ±0.2V
			531kHz	check		1.1V ±0.4V
LW 153 - 279kHz			279kHz	5122		8V ±0.2V
			153kHz	check		1.1V ±0.4V
MW FM/MW/LW- version, 9kHz grid 531 - 1602kHz			1602kHz	5123		8V ±0.2V
			531kHz	check		1.1V ±0.4V
FM IF						
FM	10.7MHz, 45mV continuous wave	D		5119	2	0 ± 3 mV DC
FM RF						
FM 87.5 - 108MHz (65.81 - 74, 87.5 - 108MHz)	108MHz	A	108MHz	2155	4	MAX
	87.5MHz (65.81MHz)	mod=1kHz Δf=±22.5kHz	87.5MHz (65.81MHz)	5131		
VCO						
FM	98MHz, 1mV continuous wave	A	98MHz	3142	3	152kHz ±1kHz ¹⁾
AM IF						
MW	450kHz connect pin 6 of IC 7101 (AM Osc.) with 3.3kΩ to Vcc	C		5111	5	
		C		5112		
AM AFC MW		C		5114	2	0 ± 2 mV DC
AM RF³⁾						
MW⁴⁾ FM/MW/LW- and FM/MW-version (9kHz grid)	1494kHz	B	1494kHz	2106	5	
	531 - 1602kHz		558kHz	5102		
LW	198kHz		198kHz	5103		
MW FM/AM-version, 10kHz grid 530 - 1700kHz	1500kHz	B	1500kHz	2106	5	
	560kHz		560kHz	5102		

Use Service Testprogram. By selecting the TUNER TEST test frequencies will be stored as preset frequencies automatically.

- 1) If sensitivity of frequency counter is too low adjust to max. channel separation (input signal: stereo left 90% + 9%, adjust output on right channel to minimum)
- 2) RC network serves for damping the IF-filter while adjusting the other one.
- 3) For AM RF adjustments the original frame antenna has to be used!
- 4) MW has to be aligned before LW.

↑ Repeat

MISCELLANEOUS

1101	2422 015 19376	SOCKET 2P CLICKFIT	USA only
1102	4822 267 10283	SOCKET COAX, IEC 75Ω	not USA
1103	4822 265 31184	JST CONNECTOR 2 POLE	
1120	4822 265 11515	FFC SOCKET, 8P	

CAPACITORS

2101	4822 126 13692	47pF	1%	63V	
2102	4822 126 13838	100nF	10%	50V	not USA
2103	5322 122 31647	1nF	10%	63V	
2104	5322 122 32531	100pF	5%	50V	
2105	4822 126 13838	100nF	10%	50V	USA only

2106	2020 800 00191	3-11pF TRIMCAP.,N450		
2107	4822 121 51319	1μF	20%	50V
2120	4822 126 13689	18pF	1%	63V
2124	5322 122 32654	22nF	10%	63V
2125	2020 552 96199	560pF	1%	50V

2126	5322 122 31863	330pF	5%	50V
2127	4822 126 14076	220nF	20%	25V
2128	4822 124 40248	10μF	20%	63V
2129	4822 124 41584	100μF	20%	10V
2130	5322 122 32654	22nF	10%	63V

2131	4822 126 13482	470nF	20%	16V	
2132	4822 126 13482	470nF	20%	16V	
2133	4822 124 21913	1μF	20%	63V	
2134	4822 126 13188	15nF	5%	63V	not USA
2134	5322 122 32654	22nF	10%	63V	USA only

2135	4822 126 13188	15nF	5%	63V	not USA
2135	5322 122 32654	22nF	10%	63V	USA only
2136	4822 126 14076	220nF	20%	25V	
2137	4822 126 14076	220nF	20%	25V	
2138	4822 124 22652	2,2μF	20%	50V	

2139	4822 126 14236	15pF	5%	50V
2140	4822 126 13695	82pF	1%	63V
2141	4822 126 13838	100nF	10%	50V
2143	4822 126 14076	220nF	20%	25V
2144	4822 124 21913	1μF	20%	63V

2145	4822 122 33575	220pF	5%	50V	
2146	4822 122 33575	220pF	5%	50V	
2147	4822 122 33575	220pF	5%	50V	
2148	4822 122 33127	2,2nF	10%	63V	
2149	5322 122 32659	33pF	5%	50V	RDS only

2150	4822 126 13838	100nF	10%	50V	
2152	4822 126 12105	33nF	5%	63V	not for East Europe
2152	5322 116 80853	560pF	5%	63V	for East Europe only
2153	4822 126 13486	15pF	2%	63V	not for East Europe
2153	4822 122 33926	12pF	2%	50V	for East Europe only

2155	2020 800 00191	3-11pF TRIMCAP.,N450		
2159	5322 122 32659	33pF	5%	50V
2164	4822 126 13482	470nF	20%	16V
2165	4822 126 13838	100nF	10%	50V
2166	5322 122 31647	1nF	10%	63V

2167	4822 122 33926	12pF	5%	50V	
2169	4822 122 33127	2,2nF	10%	63V	RDS only

RESISTORS

3101	4822 051 20333	33kΩ	5%	0,1W
3102	4822 117 10837	100kΩ	1%	0,1W
3103	4822 051 20822	8,2kΩ	5%	0,1W
3104	4822 117 13577	330Ω	1%	0,1W
3105	4822 117 11503	220Ω	5%	0,1W

3132	4822 051 20479	47Ω	5%	0,1W
3134	4822 051 20223	22kΩ	5%	0,1W
3141	4822 117 11148	56kΩ	1%	0,1W
3142	4822 100 12159	TRIMPOT. 100kΩ		

RESISTORS

3143	4822 051 20223	22kΩ	5%	0,1W	RDS only
3144	4822 051 10102	1kΩ	2%	0,25W	RDS only
3145	4822 117 11449	2,2kΩ	1%	0,1W	
3146	4822 051 20229	22Ω	5%	0,1W	
3152	4822 051 20471	470Ω	5%	0,1W	

3153	4822 051 20471	470Ω	5%	0,1W
3154	4822 117 13577	330Ω	1%	0,1W
3155	4822 117 11503	220Ω	5%	0,1W
3156	4822 117 10837	100kΩ	1%	0,1W
3157	4822 117 10837	100kΩ	1%	0,1W

3158	4822 051 20471	470Ω	5%	0,1W
3159	4822 051 20471	470Ω	5%	0,1W
3160	4822 051 20471	470Ω	5%	0,1W
3161	4822 051 20223	22kΩ	5%	0,1W
3167	4822 051 20121	120Ω	5%	0,1W

3168	4822 051 20121	120Ω	5%	0,1W	
3169	4822 051 20154	150kΩ	5%	0,1W	
3170	4822 117 10837	100kΩ	1%	0,1W	
3172	4822 051 20562	5,6kΩ	5%	0,1W	
3176	4822 051 20333	33kΩ	5%	0,1W	RDS only

3181	4822 051 10102	1kΩ	2%	0,25W
4103	4822 051 20008	CHIP JUMPER 0805		
4106	4822 051 20008	CHIP JUMPER 0805		
4107	4822 051 20008	CHIP JUMPER 0805		
4108	4822 051 20008	CHIP JUMPER 0805		

COILS

5102	4822 157 71634	RF-COIL MW
5109	4822 242 70665	FM-IF FILTER 10,7MHz
5110	4822 242 70665	FM-IF FILTER 10,7MHz
5111	2422 549 44023	AM-IF FILTER 450kHz
5112	4822 157 70302	AM-IF FILTER 450kHz

5114	4822 157 70302	AM-IF FILTER 450kHz
5119	4822 157 11443	DISCRIMINATOR COIL
5121	4822 242 10261	QUARTZ 75kHz
5123	2422 549 44108	RF-COIL, AM-OSCILLATOR
5130	4822 157 11843	RF COIL 1,5 TURNS

5131	4822 157 11843	RF COIL 1,5 TURNS
------	----------------	-------------------

DIODES

6103	5322 130 34337	BAV99
6105	4822 130 83075	HN1V02H
6106	4822 130 83757	BAS216
6107	9340 386 90115	BZX284-C11
6120	4822 130 83757	BAS216


6130	4822 130 82833	1SV228
6131	4822 130 82833	1SV228

TRANSISTORS

7102	4822 130 42131	BF550	
7103	5322 130 42756	BC857C	RDS only
7111	5322 130 42755	BC847C	
7112	4822 130 44503	BC547C	

INTEGRATED CIRCUITS

7101	9351 740 80557	TEA5757H/V1, RADIO IC
------	----------------	-----------------------




ECO6 Tuner Board

version: **SYSTEMS CENELEC**

TABLE OF CONTENTS

- Blockdiagram.....7B-1
- Schematic Diagram.....7B-2
- Component Layout.....7B-3
- Adjustment table7B-3
- Electrical Partslist.....7B-4

BLOCK DIAGRAM





TUNER BOARD ECO6 / SYSTEMS-CENELEC

VERSION PROGRAMMING COMPONENTS

VERSION	6120	3156	3157	3170	7111
/00 /02 FM/MW/LW					
/00 /02 FM/MW					
/01 FM/MW					
/14 FM-OIRT/MW					
/17 FM/AM					

☒ component mounted

VERSION DETECTION



- 1101 A2
- 1102 B1
- 1103 E2
- 1110 B4
- 1120 E14
- 1130 A2
- 1131 C2
- 1132 F13
- 1132 B1
- 2105 A2
- 2106 E3
- 2107 E4
- 2108 G3
- 2109 G3
- 2118 H6
- 2119 H6
- 2120 H6
- 2122 I6
- 2123 H6
- 2124 H6
- 2125 H6
- 2127 E7
- 2128 B8
- 2129 C7
- 2130 F11
- 2131 F8
- 2132 F8
- 2133 F8
- 2134 I8
- 2135 I9
- 2136 H14
- 2137 H13
- 2138 F9
- 2139 G9
- 2140 G9
- 2141 F10
- 2143 G12
- 2144 G11
- 2145 E11
- 2146 E12
- 2147 E12
- 2148 E12
- 2149 H7
- 2150 A10
- 2159 D5
- 2161 C11
- 2162 H12
- 2163 D11
- 2164 G10
- 2165 C7
- 2166 E11
- 2167 E11
- 2169 G8
- 2180 C4
- 2190 C3
- 2191 C3
- 3105 D5
- 3108 D2
- 3109 G4
- 3123 H3
- 3125 H2
- 3128 H3
- 3130 I9
- 3131 I9
- 3132 G4
- 3134 H6
- 3135 E7
- 3137 H7
- 3141 E7
- 3142 E6
- 3143 G7
- 3144 G8
- 3145 F8
- 3146 G13
- 3150 H12
- 3151 H12
- 3152 G14
- 3153 G13
- 3154 F13
- 3155 G12
- 3156 C12
- 3157 D12
- 3158 E13
- 3159 D13
- 3160 D13
- 3161 D13
- 3167 F12
- 3168 F11
- 3169 E11
- 3170 D12
- 3171 G12
- 3172 G12
- 3176 H7
- 3180 I3
- 3190 B6
- 3191 B7
- 3192 B6
- 3193 B4
- 3194 C4
- 3195 C3
- 4101 E2
- 4102 F3
- 4104 H5
- 5102 E3
- 5103 F2
- 5109 B9
- 5110 B10
- 5111 A9
- 5112 A11
- 5114 B11
- 5115 E7
- 5118 G9
- 5119 G9
- 5121 E11
- 5122 H5
- 5123 G5
- 6105-1 E4
- 6105-2 G6
- 6106 D4
- 6107 G13
- 6120 C13
- 7101 C8
- 7103 H8
- 7104 D2
- 7105 F4
- 7109 H3
- 7110 H12
- 7111 C13
- 7112 H4
- 7124 H7
- T102 B2
- T103 B2
- T104 B6
- T105 B2
- T106 B2
- T107 B2
- T109 B2
- T110 B2
- T111 B2
- T112 B2
- T113 B2
- T114 B2
- T115 B2
- T120 B2
- T121 B2
- T122 B2
- T123 B2
- T124 B2
- T125 B2
- T126 B2
- T127 B2
- T128 B2
- T129 B2
- T130 B2
- T131 B2
- T132 B2
- T133 B2
- T134 B2
- T135 B2
- T136 B2
- T137 B2
- T138 B2
- T139 B2
- T140 B2
- T141 B2
- T142 B2
- T143 B2
- T144 B2
- T145 B2
- T146 B2
- T147 B2
- T148 B2
- T149 B2
- T150 B2

LEGEND

*... only assembled in FM/AM-version
 Ⓞ... for provision only
 USA ... for USA version only
 LW ... for LW version only


SMD jumper
 41xx
 OR

...V FM mode stereo
 ...V MW mode
 ...V LW mode
 voltages measured while set is tuned to a strong transmitter


Signal path

— FM
 - - - AM
 - - - MPX (Audio Frequency)
 ⇨ AF - left/right

1101 B5 1110 B4 1131 C5 2107 B3 2133 C1 2162 A4 5102 C4 5110 A2 5114 A2 5121 B2 7104 C4 9101 A2 9104 B1 9107 B4 9110 A4
 1102 B5 1120 A4 1132 A4 2128 A3 2138 B1 2191 B4 5103 C4 5111 A3 5115 C2 5122 C3 7105 C5 9102 B2 9105 B1 9108 B3 9111 A3
 1103 C5 1130 A5 2106 B4 2129 B3 2144 B1 3142 C2 5109 B3 5112 A2 5119 B2 5123 C3 7112 B1 9103 A1 9106 B1 9109 C2



2102 B1 2120 C3 2130 B3 2137 A3 2146 B5 2161 A4 2169 A3 3123 A5 3134 C3 3145 C4 3154 B5 3160 A3 3171 B5 3192 A2 4104 C3 6106 B2 7110 B2
 2105 B1 2122 C3 2131 C4 2139 B4 2147 A5 2163 A4 2180 B2 3125 A5 3135 C4 3146 B5 3155 B5 3161 A4 3172 B5 3193 B2 4105 B2 6107 B5 7111 A4
 2108 C1 2123 C3 2132 C4 2140 B4 2148 B4 2164 B4 2190 B2 3128 C2 3137 C4 3150 B3 3156 A4 3167 A5 3176 C4 3194 B2 4106 B3 6120 A4 7122 C3
 2109 C1 2124 C3 2134 C5 2141 B5 2149 C4 2165 B3 3105 B3 3130 C4 3141 B3 3151 A2 3157 A4 3168 C5 3180 A5 3195 B2 4107 C4 7101 B4 7124 C3
 2118 C3 2125 C3 2135 C5 2143 B5 2150 B3 2166 B5 3108 C2 3131 C4 3143 C5 3152 A3 3158 A3 3169 B4 3190 B2 4101 C2 5118 C4 7103 C5
 2119 C3 2127 C4 2136 A3 2145 B5 2159 B3 2167 B4 3109 C1 3132 B3 3144 A5 3153 A3 3159 A3 3170 A4 3191 A3 4102 C2 6105 B2 7109 A5



These assembly drawings show a summary of all possible versions.
 For components used in a specific version see schematic diagram respectively partslist.

TUNER ADJUSTMENT TABLE (ECO6 Cenelec FM/MW - and FM/MW/LW - versions with AM-frame aerial)

Waverange	Input frequency	Input	Tuned to	Adjust	Output	Scope/Voltmeter
VARICAP ALIGNMENT						
FM 87.5 - 108MHz (50kHz grid)			108MHz	check		8V ±1.2V
			87.5MHz	check		1.6V ±0.5V
MW 531 - 1602kHz (9kHz grid)			1602kHz	5123	1	8V ±0.2V 3-band 6.9V ±0.2V 2-band
			531kHz	check		1.1V ±0.4V
LW 153 - 279kHz (3kHz grid)			279kHz	5122		8V ±0.2V
			153kHz	check		1.1V ±0.4V
FM - IF						
FM	10.7MHz, 45mV continuous wave	D		5119	2	0mV ±3mV
FM - VCO						
FM	98MHz, 1mV continuous wave	A	98MHz	3142	3	152kHz ±1kHz ¹⁾
FM RF (channel separation) Note: The FM-frontend unit has already been adjusted by the factory and needs therefore no further adjustments for service purposes.						
FM	98MHz, 1mV 90% Left + 9% pilot mod=1kHz	A	98MHz	IF coil inside FM frontend 1110	4	right channel min.
AM IF						
MW	450kHz connect pin 6 of IC 7101 (AM Osc.) with 3.3kΩ to Vcc	C		5111	5	
				5112		
AM AFC MW	continuous wave V _{RF} = 2mV	C		5114	2	0mV ±2mV
AM RF³⁾						
MW	1494kHz	B	1494kHz	2106	5	
	558kHz					
LW	198kHz	C	198kHz	5103		

Use Service Testprogram. By selecting the TUNER TEST test frequencies will be stored as preset frequencies automatically.

- ¹⁾ If sensitivity of frequency counter is too low adjust to max. channel separation (input signal: stereo left 90% + 9%, adjust output on right channel to minimum)
- ²⁾ RC network serves for damping the IF-filter while adjusting the other one.
- ³⁾ For AM RF adjustments the original frame antenna has to be used!
 MW has to be aligned before LW.

↑ Repeat

MISCELLANEOUS

1101	2422 015 19376	SOCKET CLICKFIT 2P	USA only
1102	4822 267 10283	SOCKET COAX, IEC 75Ω	not USA
1103	4822 265 31184	JST CONNECTOR, 2 POLE	
1110	2422 542 90071	FM FRONTEND	
1120	4822 265 11515	FFC SOCKET, 8P	

CAPACITORS

2102	4822 126 13838	100nF 10% 50V	not USA
2105	4822 126 13838	100nF 10% 50V	USA only
2106	2020 800 00204	TRIMCAP. 4.2 - 20pF, N750	LW only
2106	2020 800 00191	TRIMCAP. 3 - 11pF, N450	FM/AM only
2107	4822 121 51319	1μF 20% 50V	
2108	5322 122 32531	100pF 5% 50V	LW only
2109	5322 122 32448	10pF 5% 50V	LW only
2120	4822 126 13689	18pF 1% 63V	FM/AM only
2120	5322 122 32658	22pF 5% 50V	LW only
2122	4822 122 33891	3,3nF 10% 63V	LW only
2123	2020 552 93494	390pF 1% 50V	LW only
2124	4822 122 33177	10nF 20% 50V	FM/AM only
2125	2020 552 96199	560pF 1% 50V	
2127	4822 126 14076	220nF 20% 25V	
2128	4822 124 40248	10μF 20% 63V	
2129	4822 124 41584	100μF 20% 10V	
2130	5322 122 32654	22nF 10% 63V	
2131	4822 126 13482	470nF 20% 16V	
2132	4822 126 13482	470nF 20% 16V	
2133	4822 124 21913	1μF 20% 63V	
2134	3198 017 31530	15nF 10% 50V	not USA
2134	5322 122 32654	22nF 10% 63V	USA only
2135	3198 017 31530	15nF 10% 50V	not USA
2135	3198 017 32230	22nF 10% 25V	USA only
2136	4822 126 14076	220nF 20% 25V	
2137	4822 126 14076	220nF 20% 25V	
2138	4822 124 22652	2,2μF 20% 50V	
2139	4822 126 14236	15pF 5% 50V	
2140	4822 126 13695	82pF 1% 63V	
2141	4822 126 13838	100nF 10% 50V	
2143	4822 126 14076	220nF 20% 25V	
2144	4822 124 21913	1μF 20% 63V	
2145	4822 122 33575	220pF 5% 50V	
2146	4822 122 33575	220pF 5% 50V	
2147	4822 122 33575	220pF 5% 50V	
2148	4822 122 33127	2,2nF 10% 63V	
2149	5322 122 32659	33pF 5% 50V	RDS only
2150	4822 126 13838	100nF 10% 50V	
2159	5322 122 31151	22μF 20% 50V	
2163	4822 126 13838	100nF 10% 50V	LW only
2164	4822 126 13482	470nF 20% 16V	
2165	4822 126 13838	100nF 10% 50V	
2166	5322 122 31647	1nF 10% 63V	
2167	4822 122 33926	12pF 5% 50V	
2169	4822 122 33127	2,2nF 10% 63V	RDS only
2180	3198 017 31030	10nF 10% 50V	
2190	4822 126 13838	100nF 10% 50V	
2191	4822 124 40178	100μF 20% 10V	

RESISTORS

3105	4822 117 11503	220Ω 5% 0,1W	
3108	4822 117 11449	2,2kΩ 1% 0,1W	LW only
3109	4822 051 20472	4,7kΩ 5% 0,1W	LW only
3123	4822 051 20472	4,7kΩ 5% 0,1W	LW only
3125	4822 117 10833	10kΩ 1% 0,1W	LW only

RESISTORS

3128	4822 117 11449	2,2kΩ 1% 0,1W	LW only
3130	3198 021 38210	820Ω 5% 0,06W	
3131	3198 021 38210	820Ω 5% 0,06W	
3132	4822 051 20479	47Ω 5% 0,1W	
3134	4822 051 20223	22kΩ 5% 0,1W	
3135	3198 021 31020	1kΩ 5% 0,06W	
3137	4822 051 20223	22kΩ 5% 0,1W	LW only
3141	4822 117 11148	56kΩ 1% 0,1W	
3142	4822 100 12159	TRIMPOT. 100kΩ	
3143	4822 051 20223	22kΩ 5% 0,1W	RDS only
3144	4822 051 10102	1kΩ 2% 0,25W	RDS only
3145	4822 117 11449	2,2kΩ 1% 0,1W	
3146	4822 051 20229	22Ω 5% 0,1W	
3150	4822 117 10833	10kΩ 1% 0,1W	
3151	4822 051 20683	68kΩ 5% 0,1W	
3152	4822 051 20471	470Ω 5% 0,1W	
3153	4822 051 20471	470Ω 5% 0,1W	
3154	4822 117 13577	330Ω 1% 0,1W	
3155	4822 117 10353	150Ω 5% 0,1W	
3156	4822 117 10837	100kΩ 1% 0,1W	
3157	4822 117 10837	100kΩ 1% 0,1W	
3158	4822 051 20471	470Ω 5% 0,1W	
3159	4822 051 20471	470Ω 5% 0,1W	
3160	4822 051 20471	470Ω 5% 0,1W	
3161	4822 051 20223	22kΩ 5% 0,1W	
3167	4822 051 20121	120Ω 5% 0,1W	
3168	4822 051 20121	120Ω 5% 0,1W	
3169	4822 051 20154	150kΩ 5% 0,1W	
3170	4822 117 10837	100kΩ 1% 0,1W	
3171	4822 117 10834	47kΩ 1% 0,1W	
3172	4822 051 20562	5,6kΩ 5% 0,1W	
3176	4822 051 20333	33kΩ 5% 0,1W	RDS only
3180	4822 117 10833	10kΩ 1% 0,1W	LW only
3190	4822 051 20121	120Ω 5% 0,1W	
3191	4822 051 20121	120Ω 5% 0,1W	
3192	4822 117 13577	330Ω 1% 0,1W	
3193	4822 117 13577	330Ω 1% 0,1W	
3194	4822 117 11449	2,2kΩ 1% 0,1W	
3195	4822 051 20101	100Ω 5% 0,1W	
4101	4822 051 20008	CHIP JUMPER 0805	FM/AM only
4102	4822 051 20008	CHIP JUMPER 0805	FM/AM only
4104	4822 051 20008	CHIP JUMPER 0805	FM/AM only
4105	4822 051 20008	CHIP JUMPER 0805	
4106	4822 051 20008	CHIP JUMPER 0805	
4107	4822 051 20008	CHIP JUMPER 0805	

COILS

5102	4822 157 71634	RF-COIL MW	
5103	2422 549 44107	RF-COIL LW	LW only
5109	4822 157 71639	FM-IF FILTER 10,7MHz	
5110	4822 242 70665	FM-IF FILTER 10,7MHz	
5111	2422 549 44023	AM-IF FILTER 450kHz	
5112	4822 157 70302	AM-IF FILTER 450kHz	
5114	4822 157 70302	AM-IF FILTER 450kHz	
5115	4822 157 71636	ANTI BIRDY FILTER	
5118	2422 535 95881	100nH	
5119	4822 157 11443	DISCRIMINATOR COIL	
5121	4822 242 10261	QUARTZ 75kHz	
5122	2422 549 44108	RF-COIL, LW-OSCILLATOR	LW only
5123	2422 549 44108	RF-COIL, MW-OSCILLATOR	

DIODES

6105	4822 130 83075	HN1V02H	
6106	4822 130 83757	BAS216	
6107	9340 386 90115	BZX284-C11	
6120	4822 130 83757	BAS216	

TRANSISTORS

7103	5322 130 42756	BC857C	RDS only
7104	9322 003 64676	TBC337-40	LW only
7105	9322 003 64676	TBC337-40	LW only
7109	4822 130 60373	BC856B	LW only
7110	4822 130 60373	BC856B	
7111	5322 130 42755	BC847C	
7112	4822 130 44503	BC547C	
7122	5322 130 42755	BC847C	LW only
7124	5322 130 42755	BC847C	LW only

INTEGRATED CIRCUITS


7101	4822 209 90315	TEA5762H/V1, RADIO IC	
------	----------------	-----------------------	--

MAIN BOARD


TABLE OF CONTENTS

Internal IC Diagram	8-1
Main Board Layout Top View	8-2
Main Board Layout Bottom View	8-3
Circuit Diagram	8-4
Electrical Parts List	8-5


**BLOCK DIAGRAM - 4-CHANNEL AUDIO AMPLIFIER
TDA8947J**




TDA7468 INTERNAL BLOCK DIAGRAM




LAYOUT DIAGRAM - MAIN BOARD TOP SIDE



LAYOUT DIAGRAM - MAIN BOARD BOTTOM SIDE



CIRCUIT DIAGRAM - MAIN BOARD



ELECTRICAL PARTSLIST - MAIN BOARD

CA3	9940 000 03285	CAP ELE 3900 μ F 35V +/-20%	QS301	9940 000 03301	TRANSISTOR 2SA1037AK
CS103	9940 000 03286	CAP ELE 4700 μ F 25V +/-20% /14/21/21M	QS302	9940 000 03297	TRANSISTOR DTC114YKA
CS103	9940 000 02644	CAP ELE 6800 μ F 35V +/-20% /21/21/21M	RS101 Δ	9940 000 03287	FUSE RES 33 Ω 1/4W +/-5%
CS4	9940 000 02644	CAP ELE 6800 μ F 35V +/-20%	TS301	9940 000 03311	28 μ H CORE 6TURNS 715 Ω 1.2A
DA1	9940 000 03586	ZENER DIODE 24V /21/21M	U3	9940 000 03587	MOSFET BUK9507-30B /21/21M
DA2	9940 000 03294	ZENER DIODE 12V /21/21M	UA1	9940 000 02639	IC TDA8947J AMPLIFIER
DA104	9940 000 03293	ZENER DIODE 10V	UA101	9940 000 03304	IC TDA7468D SOUND
DS1	9940 000 03289	RECTIFIER BRIDGE RS502	UA102	9940 000 00374	IC BA4558F OPERATIONAL
DS101	9940 000 00679	RECTIFIER BRIDGE RS402	UA201	9940 000 00374	IC BA4558F OPERATIONAL
DS103	9940 000 03294	ZENER DIODE 12V	UA301	9940 000 00374	IC BA4558F OPERATIONAL
DS104	9940 000 03294	ZENER DIODE 12V	UH1	9940 000 03307	IC BH4453F
DS2	9940 000 03295	DIODE MC2838	US301	9940 000 03306	IC AP1501-50T5L 5V 3A 150KHZ
DS201	9940 000 03291	ZENER DIODE 5.6V 1/2W	ZDH1	9940 000 03291	ZENER DIODE 5.6V 1/2W
DS301	9940 000 02645	DIODE SCHOTTKY SS14			
DS4	9940 000 03292	ZENER DIODE 9.1V			
JK601	9940 000 02174	SPK TERMINAL TC08-043-01			
JK603	9940 000 03315	JACK RCA-405A-04 W/R			
JK604	9940 000 03313	JACK RCA 1P D8.4MM(BLACK)			
JK605	9940 000 03314	JACK RCA 1P D8.4MM(ORANGE)			
LA1	9940 000 03589	IND. 3A1868N 8 μ H +/-20% 0.06 Ω			
LA2	9940 000 03589	IND. 3A1868N 8 μ H +/-20% 0.06 Ω			
LA3	9940 000 03589	IND. 3A1868N 8 μ H +/-20% 0.06 Ω			
LA4	9940 000 03589	IND. 3A1868N 8 μ H +/-20% 0.06 Ω			
LS301	9940 000 03308	POWER INDUCTOR 33 μ H			
QA104	9940 000 03296	TRANSISTOR DTA114YKA			
QA105	9940 000 03297	TRANSISTOR DTC114YKA			
QA106	9940 000 03302	TRANSISTOR PBSS4140T			
QA203	9940 000 03296	TRANSISTOR DTA114YKA			
QA401	9940 000 03588	TRANSISTOR MPS8050S /21/21M			
QF1	9940 000 02636	TRANSISTOR PBSS4140S			
QF3	9940 000 03299	TRANSISTOR 8550			
QF4	9940 000 03299	TRANSISTOR 8550			
QH204	9940 000 03296	TRANSISTOR DTA114YKA			
QL1	9940 000 03303	TRANSISTOR 2SC2412			
QS1	9940 000 03303	TRANSISTOR 2SC2412			
QS101	9940 000 02636	TRANSISTOR PBSS4140S			
QS102	9940 000 03301	TRANSISTOR 2SA1037AK			
QS103	9940 000 03296	TRANSISTOR DTA114YKA			
QS104	9940 000 03297	TRANSISTOR DTC114YKA			
QS105	9940 000 02647	TRANSISTOR 2SB1370			
QS106	9940 000 02649	TRANSISTOR 2SC5343			
QS2	9940 000 03303	TRANSISTOR 2SC2412			
QS201	9940 000 03298	TRANSISTOR 2SB1260R			
QS202	9940 000 03303	TRANSISTOR 2SC2412 SMT3			
QS203	9940 000 03303	TRANSISTOR 2SC2412 SMT3			
QS3	9940 000 03303	TRANSISTOR 2SC2412 SMT3			

Note: Only these parts mentioned in the list are normal service parts.

CASSETTE BOARD

This module is not intend to be repaired on componen level.


**Circuit Diagram and Printed Circuit Board drawings
are published for orientation only.**

In case of defects please replace the entire board and mechanic.


The Cassette Board can be ordered with codenumber "9940 000 03339".

The Cassette Deck can be ordered with codenumber "9940 000 03317".


LAYOUT DIAGRAM - CASS BOARD TOP SIDE




LAYOUT DIAGRAM - CASS BOARD BOTTOM SIDE



CIRCUIT DIAGRAM - CASS BOARD



LAYOUT DIAGRAM - OUTPUT BOARD
TOP SIDE




OUTPUT & MICROPHONE BOARD


TABLE OF CONTENTS

Output Board Layout Top View 10-1
 Output Board Layout Bottom View 10-1
 Output Board Circuit Diagram 10-2
 Microphone Board Circuit Diagram 10-3
 Electrical Parts List 10-4

LAYOUT DIAGRAM - OUTPUT BOARD
BOTTOM SIDE




CIRCUIT DIAGRAM - OUTPUT BOARD



	RGB	CVBS
RGB_ON/OFF(131) H		L
mode	8~12V(4:3)	5~8V(16:9)
pin		0V(TV)
TV/DVD(134)	H	H
16:9_EN/P-SCAN(130) L	H	X

CIRCUIT DIAGRAM - MICROPHONE BOARD (ONLY FOR /21M)



ELECTRICAL PARTSLIST - OUTPUT BOARD

JR1	9940 000 03336	JACK RCA 1P D8.4MM
JR2	9940 000 03337	JACK DSW-12 S-VIDEO 6PIN
JR3	994000003595	JACK RCA D8.4MM(R) /21/21M
JR4	994000003596	JACK RCA D8.4MM(B) /21/21M
JR5	994000003597	JACK RCA D8.4MM(G) /21/21M
Q2	9940 000 03333	TRANSISTOR BT3904 /14/22
Q5	9940 000 03333	TRANSISTOR BT3904 /14/22
SC1	9940 000 03338	JACK SCART CS-109 /14/22
ZD1	9940 000 03334	SW DIODE BAV99
ZD2	9940 000 03334	SW DIODE BAV99
ZD3	9940 000 03334	SW DIODE BAV99
ZD4	9940 000 03334	SW DIODE BAV99
ZD5	9940 000 03334	SW DIODE BAV99
ZD6	9940 000 03334	SW DIODE BAV99 /14/22
ZD7	9940 000 03334	SW DIODE BAV99 /14/22
ZD9	9940 000 03335	ZENER DIODE BZX79-C3V3

Note: Only these parts mentioned in the list are normal service parts.

ELECTRICAL PARTSLIST - MICROPHONE BOARD (ONLY FOR /21/21M)

D701	9940 000 03599	DIODE RLS4148 LL-34
FB701	9940 000 03604	FILTER BEAD RH3.5X6X0.8
JK701	9940 000 03605	MICRO PHONE JACK
L701	9940 000 03603	RADIAL AXIAL INDUCTOR 10 μ H
Q701	9940 000 03602	TRANSISTOR 2SD2144
Q703	9940 000 03303	TRANSISTOR 2SC2412
U701	9940 000 00374	IC BA4558F OPERATIONAL AMP.CD
U702	9940 000 03606	KARAOKE ECHO IC BU9253FS
VR701	9940 000 03598	SEMI FIX RESISTOR 50K +/-20%
ZD701	9940 000 03601	ZENER DIODE BZX79-C5V1


Note: Only these parts mentioned in the list are normal service parts.

POWER BOARD


TABLE OF CONTENTS

Power Board Layout Diagram	11-2
Power Board Circuit Diagram	11-3
AC Socket Board Layout Diagram	11-4
Electrical Parts List	11-4


LAYOUT DIAGRAM - POWER BOARD



CIRCUIT DIAGRAM - POWER BOARD




LAYOUT DIAGRAM - AC SOCKET BOARD

**ELECTRICAL PARTSLIST - POWER BOARD**

FS301	△ 9940 000 03324	FUSE 2A 250V VDE
FS302	△ 9940 000 03324	FUSE 2A 250V VDE /21/21M
FS304	△ 9940 000 03591	FUSE 0.5A 250V /21/21M
FS305	△ 9940 000 03326	FUSE 2.5A 250V /22/14
FS305	△ 9940 000 03592	FUSE 2.5A 250V /21/21M
L301	9940 000 03319	LINE FILTER 330UH 32MR 3A
RL301	△ 9940 000 03321	RELAY ME-7-009 9V 10A
T301	△ 9940 000 03323	TRASFO EI76X50 230V /22/14
T301	△ 9940 000 03594	TRASFO EI-76x40 AC120/230V /21/21M
T302	△ 9940 000 03322	TRANSFORMER EI28 230V /22/14
T302	△ 9940 000 03593	TRASFO EI28 AC120/230V /21/21M
	△ 9940 000 03327	AC POWER SOCKET 2P 2.5A/250V

Note: Only these parts mentioned in the list are normal service parts.

SET MECHANICAL EXPLODED VIEW



MECHANICAL & ACCESSORIES PARTSLIST

01	9940 000 03367	COVER-CASS-DOOR	9940 000 02595	AM LOOP ANT
02	9940 000 03368	DOOR-CASSETTE	9940 000 02597	RCA CABLE VIDEO (Y)
03	9940 000 03383	SPRING-CASS DOOR EJECT	9940 000 02598	RCA CABLE AUDIO (R/W)
04	9940 000 03372	KNOB-VOLUME	9940 000 03385	REMOTE CONTROL
06	9940 000 03364	PANEL-CONTROL	△ 9940 000 03386	POWER CORD 230V /22/14
07	9940 000 03366	LENS-DISPLAY /22/14	△ 9940 000 03616	AC CORD 120/230V /21M/21
07	9940 000 03613	LENS-DISPLAY /21M/21	9940 000 03387	SPEAKER BOX ASSY /22/14
08	9940 000 03365	FRONT COSMETIC RING	9940 000 03617	SPEAKER BOX ASSY /21M/21
09	9940 000 03363	CABINET-FRONT /22/14	9940 000 03388	FM ANT WIRE 75OHM 1.0M
09	9940 000 03612	CABINET-FRONT /21M/21	9940 000 03618	MAINS PLUG ADAPTOR /21M/21
11	3140 114 60321	BRACKET-PUSH LOCK		
12	4822 492 11344	SPRING COMPRESSION		
13	9940 000 01412	PUSH LOCK FOR CASS DOOR		
14	9940 000 03317	CASS DECK W991S-390BCR		
15	9940 000 03374	COVER SOURCE SELEC BUTT		
16	9940 000 03373	COVER-VCD CONTROL BUTT		
17	9940 000 03377	POWER KNOB		
18	9940 000 03376	TOP BUTTON COVER		
19	9940 000 03614	BRACKET TOP BUTTON		
21	9940 000 01422	CD DOOR SWITCH		
22	9940 000 03358	DOOR-CD		
23	9940 000 03615	SPRING CD DOOR EJECT		
24	9940 000 03359	TRAY-CD		
26	9940 000 03356	PANEL-LEFT		
27	9940 000 03331	DVD MECHANISM KHM-310AHC		
28	9940 000 03361	PANEL-TOP /22/14		
28	9940 000 03608	PANEL-TOP /21M/21		
29	9940 000 03611	MIC KNOB /21M/21		
31	9940 000 03362	CABINET-REAR /22/14		
31	9940 000 03609	CABINET-REAR /21M/21		
32	9940 000 03357	PANEL-RIGHT		
33	9940 000 00168	CD DAMPER 38DEG		
34	9940 000 03378	HOLDER-DAMPER GEAR		
35	9940 000 03371	HOOK-CASSETTE DOOR		
36	9940 000 03369	DAMPER GEAR		
37	9940 000 03381	HOLDER DAMPER GEAR(A)		
38	9940 000 03379	DAMPER GEAR(A)		
39	9940 000 03375	BRACKET-VCD CNTR BUTT		

Note: Only these parts mentioned in the list are normal normal service parts.

ELECTRICAL PARTSLIST - MISCELLANEOUS

JK602	9940 000 03318	HP JACK D3.6MM
	9940 000 03316	FAN 12VDC 0.07A
	9940 000 03312	FFC 7P P1.25MM L160MM
	9940 000 03328	FFC 13P P1.25MM L120MM
	9940 000 03329	FFC 24P P0.5MM L130MM
	9940 000 03332	CD DOOR SW DLS-02-W-1
	9940 000 03339	CASSETTE BOARD ASSY
	9940 000 03341	SERVO & MPEG BOARD ASSY
	9940 000 03342	TUNER BOARD ASSY
	9940 000 03355	FFC 21P L125MM

Note: Only these parts mentioned in the list are normal normal service parts.

REVISION LIST

1.0 Manual 3141 785 30610

Initial Service Manual released.

1.1 Manual 3141 785 30611

Add new version MCD510/14 and MCD510/21.

The following have been updated.

- 1) P1-2 Version Variations,
- 2) P1-3 Specifications,
- 3) P6-7 Electrical Partslist, P8-5 Electrical Partslist, P10-4 Electrical Partslist, P11-4 Electrical Partslist, P12-2 Mechanical & Accessories Partslist.