


Operating Instructions

COMPACT DISC PLAYER

PD-7050

COMPACT
disc
DIGITAL AUDIO



Thank you for buying this Pioneer product. Please read through these operating instructions so you will know how to operate your model properly. After you have finished reading the instructions, put them away in a safe place for future reference.

In some countries or regions, the shape of the power plug and power outlet may sometimes differ from that shown in the explanatory drawings. However, the method of connecting and operating the unit is the same.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

IMPORTANT NOTICE

[For U.S. and Canadian models]

The serial number for this equipment is located on the rear panel. Please write this serial number on your enclosed warranty card and keep in a secure area. This is for your security.

[For Canadian model]

CAUTION: TO PREVENT ELECTRIC SHOCK DO NOT USE THIS (POLARIZED) PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE.

ATTENTION: POUR PREVENIR LES CHOCS ELECTRIQUES NE PAS UTILISER CETTE FICHE POLARISEE AVEC UN PROLONGATEUR UNE PRISE DE COURANT OU UNE AUTRE SORTIE DE COURANT, SAUF SI LES LAMES PEUVENT ETRE INSEREES A FOND SANS EN LAISSER AUCUNE PARTIE A DECOUVERT.

LINE VOLTAGE SELECTOR SWITCH

Only multi-voltage models are provided with this switch. U.S., Canadian, European, U.K., and Australian models are not provided with this switch.

Mains voltages in Saudi Arabia are 127V and 220V only. Never use this model with 110V setting in Saudi Arabia.

The line voltage selector switch is located on the rear panel of this player. Before your player is shipped from the factory, the switch is set to the power requirements of the player's destination. Check that it is set properly before plugging the power cord into the outlet. If the voltage is not properly set or if you move to an area where the voltage requirements differ, adjust the selector switch as follows:

- Use a medium-sized (flat-blade) screwdriver. Insert the tip of the screwdriver into the groove of the selector switch and turn it so that the power voltage marking of your area points to the arrow.



VOLTAGE SELECTOR
SELECTEUR DE TENSION

"This product is manufactured to comply with the radio interference requirements of EEC Directive 76/889/EEC and 82/499/EEC."

 **PIONEER**
The future of sound and vision.

SAFETY INSTRUCTIONS

READ INSTRUCTIONS — All the safety and operating instructions should be read before the appliance is operated.

RETAIN INSTRUCTIONS — The operating instructions should be retained for future reference.

HEED WARNING — All warnings on the appliance and in the operating instructions should be adhered to.

FOLLOW INSTRUCTIONS — All operating and use instructions should be followed.

WATER AND MOISTURE — The appliance should not be used near water — for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool, etc.

LOCATION — The appliance should be installed in a stable location.

WALL OR CEILING MOUNTING — The appliance should not be mounted to a wall or ceiling.

VENTILATION — The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings; or, placed in a built-in installation, such as a bookcase or cabinet that may impede the flow of air through the ventilation openings.

HEAT — The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.

POWER SOURCES — The appliance should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.

POWER-CORD PROTECTION — Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.

POLARIZATION — If your purchased product is provided with a polarized power plug, please read the following instructions. This product is equipped with a polarized alternating current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

CLEANING — The appliance should be cleaned only with a polishing cloth or a soft dry cloth. Never clean with furniture wax, benzene, insecticides or other volatile liquids since they may corrode the cabinet.

POWER LINES — An outdoor antenna should be located away from power lines.

NONUSE PERIODS — The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time.

OBJECT AND LIQUID ENTRY — Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.

DAMAGE REQUIRING SERVICE — The appliance should be serviced by a Pioneer authorized service center or qualified service personnel when:

- The power-supply cord or the plug has been damaged; or
- Objects have fallen, or liquid has been spilled into the appliance; or
- The appliance has been exposed to rain; or
- The appliance does not appear to operate normally or exhibits a marked change in performance; or
- The appliance has been dropped; or the enclosure damaged.

SERVICING — The user should not attempt to service the appliance beyond that described in the operating instructions. For all other servicing, contact the nearest Pioneer authorized service center.

OUTDOOR ANTENNA GROUNDING — If an outside antenna is connected to the antenna terminal, be sure the antenna system is grounded so as to provide some protection against voltage surges and built up static charges.

In the U.S.A. section 810 of the National Electrical Code, ANSI/NFPA No. 70-1984, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode. See Fig. A.

- a) Use No. 10 AWG (5.3 mm²) copper, No. 8 AWG (8.4 mm²) aluminum, No. 17 AWG (1.0 mm²) copperclad steel, bronze wire, or larger as ground wire.
- b) Secure antenna lead-in and ground wires to house with stand-off insulators spaced from 4 feet (1.22 meters) to 6 feet (1.83 meters) apart.
- c) Mount antenna discharge unit as closely as possible to where lead-in enters house.
- d) Use jumper wire not smaller than No. 6 AWG (13.3 mm²) copper, or the equivalent, when a separate antenna-grounding electrode is used. See NEC Section 810-21 (j).




FIG. A

IMPORTANT 1



The lightning flash with arrowhead, within an equilateral triangle, is intended to alert the user of the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



CAUTION:
TO PREVENT THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The exclamation point within an equilateral triangle is intended to alert the user of the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

IMPORTANT 2

If the apparatus is fitted with AC mains power outlet(s), see REAR PANEL FACILITIES for convenient connection of additional Hi-Fi component(s). Make all connections to the AC outlet(s) and the signal terminals first. Connect the plug to the wall socket last, make sure that the power switch is off.

FOR USE IN THE UNITED KINGDOM

The wires in this mains lead are coloured in accordance with the following code:

Blue: Neutral
Brown: Live

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured marking identifying the terminals in your plug proceed as follows:

The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.

The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

Equipment sold in the U.K. is not supplied with a power plug.

CONTENTS

FEATURES.....	4	NAMES AND USE OF PARTS	8
CAUTIONS REGARDING HANDLING	4	OPERATION	13
BEFORE OPERATING PLAYER	6	TROUBLESHOOTING	31
CONNECTIONS	7	SPECIFICATIONS	32

[FOR EUROPEAN AND U.K. MODELS]

CAUTION

This product contains a laser diode of higher class than 1. To ensure continued safety, do not remove any covers or attempt to gain access to the inside of the product.

Refer all servicing to qualified personnel.

The following caution label appear on your player.

Location: rear of the player



[FOR U.S. MODEL]

CAUTION

- Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.
- The use of optical instruments with this product will increase eye hazard.

INFORMATION TO USER [FOR U.S. MODEL]

This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for a Class B computing device in accordance with the specifications in Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- reorient the receiving antenna
- relocate this component with respect to the receiver
- move this component away from the receiver
- plug this component into a different outlet so that component and receiver are on different branch circuits.

If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions. The user may find the following booklet prepared by the Federal Communications Commission helpful:

"How to Identify and Resolve Radio-TV Interference Problems".

This booklet is available from the US Government Printing Office, Washington, D.C., 20402, Stock No. 004-000-00345-4.

The above instructions apply only to units which will be operated in the United States.

FEATURES

A CD player with a 4fs digital filter and a glitchless twin D/A converter for quality sound and functionality.

- Honeycomb chassis for high rigidity and suppression of resonance.
- Disc stabilizer and ballast base optical mechanism with low center of gravity for stable playback.
- Rigid feet, and excellent audio insulation for reduced vibration.
- High-performance, 4 times over sampling digital filter and independent left and right D/A converters.
- Equipped with digital output.
- Equipped with a digital level controller.

Besides auto-program editing, the digital level controller allows more convenient tape-editing features.

- Time Fade Editing
After specifying the desired time period, playback will last for only that time period, with automatic fade-out at the end of playback. The player will then go into pause mode.
- Auto Program Editing
After specifying the desired time period, tracks will be automatically programmed to playback in order from track 1 within the specified time period.
- Music Window Program
Desired sections of tracks can be retrieved and played back together consecutively. The last section fades out while the next section fades in.
- Pause Program
A pause can be incorporated into a program.
- Program Time Display

- Advance Programming
During normal playback, a program may be incorporated or added.
- Auto Fade In and Auto Fade Out

Numeric keys are featured on the player and the remote control unit for quick track selecting.

Large, multi-display for displaying the track number, output level or index number, elapsed time, and program step number at the same time.

- The total playback time and the remaining playback time can also be displayed.

Multi-function remote control unit is supplied.

- The output volume can be controlled by sending a signal from the remote control unit to the digital level controller.
- Except for turning the power on, the remote control unit can operate most of the player's functions.

Thin pick-up for a slim design.

The power supply circuit is independent for the D/A converter, digital section, analog section, and FL display. This reduces mutual interference.

Timer start


If a disc is set on the disc tray beforehand, then, when power is turned ON, the player will automatically start playing from track 1.

CAUTIONS REGARDING HANDLING

LOCATION

Install the player in a well ventilated location where it will not be exposed to high temperature or humidity.

Do not install the player in a location which is exposed to the direct rays of the sun, or near to stoves or radiators. Excessive heat can adversely affect the cabinet and internal components. Also, installation of the player in a damp or dusty environment, may result in malfunction or accident. (Also avoid installation near cookers etc., where the player may be exposed to smoke from oil, steam or heat.)




PRECAUTIONS REGARDING INSTALLATION

Install this compact disc player as far as possible from tuners and TV sets. A compact disc player installed in close proximity to such equipment, may cause noise or degradation of the picture. Such noise may be particularly noticeable when an indoor antenna is used. In such a case, make use of an outdoor antenna, or turn off power to the compact disc player.

CONDENSATION

When the player is brought into a warm room from previously cold surroundings or when the room temperature is suddenly increased, condensation may form inside and the player may not be able to attain its full performance. In cases like this, allow the unit to stand for about an hour or raise the room temperature gradually.




CARE OF DISCS


■ With this player, use discs which display the mark shown below. (Optical audio digital discs.)




■ When holding discs, do not touch their signal surfaces. Hold by the edges, or by one edge and the center hole.



■ Do not affix gummed labels or tape to the label surfaces. Also, do not scratch or damage the label.




■ Discs rotate at high speed inside the player. Do not use damaged (cracked or warped) discs.



CLEANING DISCS


■ The presence of fingerprints or smudges on the surface of the disc, will not directly affect the recorded signals, but depending on the degree of contamination, the brightness of the light reflected from the signal surfaces may be reduced, causing degradation of sound quality.

Always keep your discs clean by wiping them gently with a soft cloth from the inner edge toward the outer periphery.



■ If a disc becomes very dirty, dip a soft cloth in water and after wringing it out well, wipe the dirt away gently, and then remove any water drops with another soft dry cloth.


■ Do not use record cleaning sprays of anti-static agents on discs. Also, never clean discs with benzene, thinner, or other volatile solvents, since damage to the disc surface may result.



STORING DISCS

■ Discs are made of the same kinds of plastic used for conventional analog audio records. Be careful not to allow discs to warp; always store discs in their cases vertically, avoiding locations with high heat or humidity, or extremely low temperatures. Avoid leaving discs in cars, since the seat of a car in direct sunlight can become very hot.

■ Always read and abide by the precautionary notes provided with each disc.






BEFORE OPERATING PLAYER

1. CONFIRM SUPPLIED ACCESSORIES


Remote control unit

Size AAA/R03 dry cell batteries x 2

Output cable



2. PUT BATTERIES INTO REMOTE CONTROL UNIT



- [1] Remove the cover of the battery compartment on the reverse side of the remote control unit. This can easily be done by pressing down on the cover with your thumb and pulling it in the direction of the arrow.
- [2] Take out the two size "AAA" [IEC R03 (UM-4)] dry cell batteries supplied and load them into the battery compartment, taking care to follow the markings on the compartment.
- [3] Replace the cover of the battery compartment.


NOTE:

- If the remote control unit will not be used for a long time (1 month or more), please remove the batteries to avoid battery leakage. If fluid should ever leak from batteries, please wipe away the fluid and then install new batteries.
- Please do not put books etc. on top of the remote control unit. If keys are continuously depressed, the batteries will run down.
- If the operating range decreases, the batteries have probably run down. Please replace with new batteries.

Incorrect use of batteries may result in leakage of fluid, explosion of batteries and other dangers. Please pay particular attention to the following points.

- Please correctly install batteries so that the (+) and (-) battery polarity matches with the (+) and (-) markings inside the battery case.
- Do not use new batteries together with batteries which have already been used.
- The voltages of dry batteries may differ even though they are of the same size and shape. Please do not use different types of dry batteries together.
- Batteries may be either rechargeable or non-rechargeable. Before using batteries please read the cautions and notes printed on them.


CONNECTIONS



Connecting the output cable

Connect the plugs of the cable to the input terminals of the amplifier (terminals marked CD or AUX), and to the output terminals of the compact disc player.


- Connect the white plugs to the left (L) terminals and the red plugs to the right (R) terminals.
- Make sure plugs are pushed fully into the terminals.



Connect the power cord

Insert the power cord plug into the auxiliary AC outlet of your amplifier unit, or into a household wall outlet.

Using the DIGITAL OUT Jack



NOTE:

- The player can be connected to a digital audio interface format type D/A converter.
 - Connect the DIGITAL OUT jack to the D/A converter. Do not connect the player to an audio jack such as CD INPUT.
- If digital connection is unnecessary, do not connect the cord to the DIGITAL OUT jack.

NAMES AND USE OF PARTS

FRONT PANEL

Indicators

REPEAT : Lights during repeat play.
PROGRAM : Lights after programming (after program has been memorized).

TIME/REMAIN/TOTAL


: Changes each time the TIME key is pressed.

● **TIME** : Displays the track number of the track being played, the index number *1, and the playback time (minutes and seconds).

● **REMAIN** : Indicates the time remaining on the track being played. When the TIME key is pressed again, the time remaining on the disc will be displayed.

● **TOTAL** : Displays the total number of tracks on one disc (TRACK) and the overall playback time (MIN, SEC).

During programmed playback operation, displays the remaining playback time of the programmed tracks (REMAIN), and the total playback time (TOTAL).

TRACK : Indicates current track number, and track numbers within program. The lower figures light up in accordance with the number of tracks recorded on the disc, and the numbers of the tracks which have been played extinguish in order. (During programmed playback only the programmed tracks light.) Above number 16 the  mark lights.

 — 
and 

MIN : Displays the playback time or remaining time in minutes.

SEC : Displays the playback time or remaining time in seconds.

MUSIC WINDOW IN : Lights when a Music Window has been programmed.

IN : Lights when the Music Window program starts or during fade in.

OUT : Lights when the Music Window program ends or during fade out.

LEVEL : Displays the volume level during fade in and fade out, and when the volume control is adjusted.


ATT : Displays the volume level decrease during fade in and fade out and volume control adjustment.

INDEX*1 : Displays index numbers which divide the music and tunes within one track. During programmed playback displays the step number.

AUTO PGM EDITING : Displayed when Auto Program Editing is set or operated.

TIME FADE EDITING : Displayed when Time Fade Editing is set or operated.

*1The INDEX is a signal which is recorded within a track, to indicate division of the track into separate tunes and items of music.



POWER switch

Press to turn power to the unit ON and OFF. If there is a disc in the unit when power is turned ON, playback will begin automatically. (Timer start function)

REMOTE SENSOR

PHONES (headphones) jack

When you wish to use headphones, insert the plug for the headphones into the headphone jack.

PHONES LEVEL control knob

Use to adjust the level of sound when using headphones. Turning the knob to the right increases the sound level.

OPEN/CLOSE key

Press when you wish to eject or load a disc. Each time the key is pressed, the tray is alternately pushed out or pulled in.

Disc Tray

This is where the disc is set. When power is switched ON and the OPEN/CLOSE key is pressed, the tray is ejected forward.

To insert the tray, press the OPEN/CLOSE key, or lightly push the tray in with your finger. During play operation, pressing the PLAY key causes the tray to be inserted automatically.

STOP key


Press to stop playback. When pressed, the player goes into stop mode and all operations stop.

PAUSE key/Indicator

Press to temporarily interrupt playback. When pressed again, the pause mode is cancelled and playback resumes.

PLAY key/Indicator

Press to begin playback, and to cancel the pause mode.

**MANUAL SEARCH Keys**

When the player is in play or pause modes, these keys are pressed to perform fast forward or fast backward operations, to allow manual searching. These operations are only carried out during the time either key is pressed.

[▶▶] : Fast forward operation (If fast forward operation is performed to the end of the disc, "End" will be displayed and the player will enter pause mode.)

[◀◀] : Fast backward operation (If fast backward operation is performed to the beginning of the disc, the player will enter play mode.)

- For programmed playback, when the forward search reaches the next track, it will enter the pause mode. When it reaches the beginning of the track in backward search, the player will enter the playback mode.

- For Music Window playback, when the forward search reaches the starting point of window fade out, the player will enter the pause mode. When it reaches the starting point of the window in backward search, the player will enter the playback mode.

TRACK SEARCH keys

When the player is in the normal play, (or during programmed or Music Window playback) or pause modes, these keys are pressed to search for a desired track. Pressing either key causes the player to advance to the next track, or return to the previous track. The keys can also be used to check the contents of a program during program entry (but only when the player is stopped).

[▶▶] : When pressed once, the disc playback advances to the beginning of the next track on the disc; when pressed continuously, the disc playback moves to the beginning of succeeding tracks on the disc. (During programmed playback, it moves to the beginning of the next programmed track.) During Music Window playback, the player advances to the beginning of the next programmed window.

[◀◀] : When pressed once, the disc playback returns to the beginning of the currently playing track; when pressed continuously, the disc playback moves further in reverse to the beginning of previous tracks on the disc. (During programmed playback it returns to the beginning of the previously programmed track.)

During Music Window playback, it returns to the beginning of the previously programmed window.

TIME key

- Use to select the method for displaying the playing time on the indicator panel. Each time the key is pressed, the indication changes from TIME, REMAIN, to TOTAL in that order. (For details concerning the display contents, refer to the explanation about the indicators.)
- If pressed after pressing the TRACK NO. key, the playback time of the selected track only is displayed.

REPEAT key

Press to perform repeat playback

- If pressed during normal playback mode, all tracks on the disc will be repeatedly played back.
- If pressed during programmed playback, the programmed tracks will be repeatedly played back in the programmed order.

AUTO PGM EDITING key

Press to program a tune which may be played back within a specified time.

TIME FADE EDITING key

Press this key when ending play at a desired time with fade out.*1

DIGITAL FADE IN key (AUTO FADE IN)


When this key is pressed while in pause mode (during normal or programmed playback), the pause mode will be cancelled and playback will start with fade in sound*1.

DIGITAL FADE OUT key (AUTO FADE OUT)

When this key is pressed during normal or programmed playback, playback will PAUSE with sound fade out*1.

MUSIC WINDOW key (MUSIC WINDOW)

One Music Window step is designated by a starting point and end point stored in memory. Up to 8 Music Window steps can be programmed. During normal playback, each time this key is pressed, the start and end of the window can be designated alternately.



TRACK NO. keys (1 to 0)

- Use to specify track numbers (track 1 - track 99) for selection of tracks, program entry, or to confirm playback time.
- For Auto Program Edit or Time Fade Edit operation, the track number keys are used to specify the time period (in minutes).

PROGRAM key

Used to program a sequence of tracks.

- Press this key after selecting a desired track with the TRACK NO. keys. Tracks will be added to the program in the order in which a track is selected.


CLEAR key (CLEAR)

Press this key to clear the program or Music Window.

NOTE:

*1 The output level of the digital out output (digital data) cannot be controlled. (It will not fade in or fade out.)

REMOTE CONTROL UNIT




Digital Level Controller

By pressing the LEVEL -/+ key, the volume level can be controlled from 0 dB to -25 dB in 1 dB steps via digital circuit processing.

- To increase the volume — Press the LEVEL [+] key.
(If the level is 0 dB, there will be no change.)
 - To decrease the volume — Press the LEVEL [-] key.
(If the key is held down, the level will stop at -25 dB.)
- The level will be displayed on the digital level controller indicator.

(Indicator)

- In play mode, it will display "2 seconds."
 - In stop mode, it will display "Normal."
- Example: For -12 dB:



When the power is turned on, the level will be set at 0 dB. Use this setting for normal use. The digital level controller changes the output from the rear panel output jack and the output from the headphone jack at the front panel at the same time.


NOTE:

However, if the DIGITAL OUT jack is used during playback, the volume level cannot be controlled.

REAR PANEL


DIGITAL OUTPUT terminals (DIGITAL OUT)

The digital output terminals output the disc's audio data and sub-code data (certain data that can be recorded onto compact discs together with audio data) in their original digital form.



OPERATION

OPERATION PROCEDURES BEFORE PLAYBACK (Inserting a disc)




1. Push in the POWER switch and switch ON power.
2. Press the OPEN/CLOSE key. The disc tray will be ejected forward.
3. Place a disc on the disc tray.


NOTE:

- Make sure to place the disc on the tray with the label side upward.
- Hold the disc so that you do not touch the playing side (the iridescent side) with your hands or fingers.

PROCEDURES AFTER PLAYBACK (Removal of disc)




1. Press the OPEN/CLOSE key and eject the disc tray.
2. Remove the disc and put it into its case. Be careful not to touch the playing side.
3. Press the OPEN/CLOSE key, or gently push the disc tray in with your fingers.




4. Push the disc tray into the player. Press the OPEN/CLOSE key, or gently push the disc tray in with your fingers. After insertion of the disc, the total number of tracks on the disc and the total playing time will be displayed for 5 seconds.

Disc Setting



5. Set your stereo amplifier controls for compact disc playback. (For details refer to the operating instructions of your stereo amplifier.)




4. Press the POWER switch so as to turn OFF power.

- The key operations explained here, may be carried out using either the keys on player or on the remote control unit.

- The indicators are shown for a case in which the TIME setting is used.

OPERATIONS FOR NORMAL PLAYBACK


Playback of all tracks, from the first track to the last track.



1. Carry out "PROCEDURES BEFORE PLAYBACK", and set a disc.
2. Press the PLAY key.
The PLAY indicator will light, and playback will begin.

Shows the elapse time of current playback, and the track number.

Normal Playback



3. Adjust sound volume and tone with the stereo amplifier controls.


When the last track finishes playing, the player enters stop mode. All operations stop and the player stops at the position of the first track number and displays "01".

4. After finishing playback, carry out the "PROCEDURES AFTER PLAYBACK".

Operation example

- To start playback
POWER - OPEN / CLOSE - Set disc - PLAY
- To stop playback
OPEN / CLOSE - Remove disc - OPEN / CLOSE
POWER


TO STOP PLAYBACK





1. Press the STOP key or the OPEN/CLOSE key.

- When the STOP key is pressed, the player enters stop mode. All operations stop, and the player is set to the position of the first track.


- When the OPEN/CLOSE key is pressed, the disc tray is ejected.



Playback Stop




PAUSE OPERATION



1. **Press the PAUSE key**
The PAUSE indicator will light, and the player will pause at the position at which it was playing.
2. **To resume playback, press the PAUSE key again, or the PLAY key.**

- To temporarily stop playback
PAUSE
- To resume playback
PAUSE or PLAY

TO PAUSE AT THE START OF A TRACK




1. **Press the PAUSE key.**
2. **Select a track with the TRACK NO. keys.**
3. **Press the PLAY key.**
4. **To start playback press the PAUSE key or the PLAY key.**

Operation example

- To pause at the start of the 3rd track:

PAUSE → 3 → PLAY


Pause at the Desired Track



- To start playback
PAUSE or PLAY

TO START PLAYING BACK FROM A DESIRED TRACK (DIRECT TRACK SEARCH OPERATION)

Playback will begin from the track selected by specifying the track number, and will continue to the last track on the disc.



1. When playback is not in progress, select the desired track number with the TRACK NO. keys.
2. Press the PLAY key to begin playback.
In playback mode the selected number is cancelled after about 4 seconds, so press the PLAY key within 4 seconds.

Operation example


- To play back the 3rd track:
[3] - [PLAY]
- To play back the 12th track:
[1] [2] - [PLAY]

NOTE:

- When a track number of a track not on the disc is selected, playback starts from the first track.
- Performing these operations during programmed playback, causes the program to be cleared.
- Playback from a selected track is not possible when memorizing a program.

OPERATIONS FOR REPEAT PLAYBACK

- During normal playback, all tracks on the disc will be played back repeatedly (all track repeat).
- During programmed playback, the tracks programmed will be played back repeatedly in the order programmed (programmed repeat).



1. With the player in the play or stop mode, press the REPEAT key.

The REPEAT indicator will light

2. When the last track has been played back, playback will begin again from the first track.

Playback will be repeated until repeat playback is cancelled.

REPEAT → PLAY or PLAY → REPEAT


TO CANCEL THE REPEAT MODE

- Press the REPEAT key once again. The REPEAT indicator will go out, and the player will revert to the normal (or programmed) playback mode.
- Press the STOP key or OPEN/CLOSE key. Playback will stop and the repeat mode will be cancelled simultaneously.

REPEAT or STOP or OPEN / CLOSE

TO LOOK FOR A DESIRED TRACK (TRACK SEARCH OPERATIONS)

During playback (programmed or Music Window playback) or pause, the beginning of the desired track can be quickly searched for. Tracks can be skipped while searching.




- When the [▶▶] key is pressed once, the playback advances to the beginning of the next track. When pressed continuously, playback is advanced to further tracks. (During programmed play, playback advances to the beginning of the next programmed track.)
- Press this key [▶▶] once to advance to the next track. It can also be pressed and held down to advance to successive tracks continuously. (In the case of programmed playback, it will advance to the next programmed track, and for Music Window playback, it will advance to the next window.)

- When the [◀◀] key is pressed once, playback returns to the beginning of the currently playing track; when pressed continuously, playback returns to earlier tracks on the disc. (During programmed playback, playback returns to earlier programmed tracks.)
- Press this key [◀◀] once to return to the beginning of the currently playing track. Press and hold down this key to return to previous tracks continuously. (In the case of programmed playback, it will go back to the previous programmed track, and for Music Window playback, it will go back to the previous window.)


During search operation, the number of the track being searched for will be displayed on the indicator. This allows you to monitor the progress of the search operation.

Search for the Desired Track



FAST FORWARD AND FAST BACKWARD (MANUAL SEARCH OPERATIONS)


During playback or pause modes, this function allows you to quickly advance or reverse through the disc to find a desired track. Listen to the sound from your speakers or headphones connected to your amplifier while performing the search (during playback mode only). When the key is released the player returns to its original mode (playback or pause).



- When the [▶▶] key is pressed, the player will advance quickly through the disc. If the end of the disc is reached, the player will enter the pause mode. (The indicator will display "End".)
- When the [◀◀] key is pressed, the player will reverse quickly through the disc. If the beginning of the disc is reached, the player will enter the play mode.

During search operation the elapsed time will be displayed. Watch this display during search operation.

Manual Search



Fast forward and fast backward speeds compared with normal playback speed.

- During playback:
 - 20 x playback speed (Sound produced)
- During pause mode
 - 60 x playback speed (No sound produced)


NOTE:

- During programmed (or Music Window) playback, fast forward and fast backward can be done only for the currently playing track (or window). Therefore, if the ▶▶ key is pressed and held down until the end of the currently-playing track (or the starting point of window fade out) is reached, the player will enter pause mode. Also, if the ◀◀ key is pressed and held down until the start of the currently-playing track (or the starting point of window fade in) is reached, the player will enter the play mode.

HOW TO FIND TRACK INDEXES (INDEX SEARCH OPERATION)

- The supplied remote control unit can be used for index search.

During playback mode or pause mode, these operations allow divisions between items of music and tunes in a track (indexes) to be searched for.




- When the [▶▶] key is pressed once, the player will advance to the next index number. When held depressed, the player will advance to following index numbers.

- When the [◀◀] key is pressed, the player will return to the start of the currently playing index. When held depressed, the player will return to preceding index numbers.

During search operation, the number of the track being searched for will be displayed on the indicator. This allows you to monitor the progress of the search operation.

Index Search



NOTE:


- If the specified index number does not exist, the player will search for index 1.
- This operation cannot be performed during program entry.
- Some discs do not have index numbers recorded on them. In such cases index searching is not possible.

TO PLAY BACK TRACKS IN A DESIRED ORDER (PROGRAMMED PLAYBACK)

■ With this function, you can play back the tracks on a disc in any desired order.

■ You can select track numbers from 1 to 99, and program a playback sequence consisting of up to 24 steps.

Memorizing a program




1. During stop mode or playback mode, select a track with the TRACK NO. keys.
2. Press the PROGRAM key
3. Repeat steps (1) and (2)

Repeat the above operations for each track you want to be memorized, in the order in which you want the tracks to be played. The player can playback a sequence of up to 24 steps.

Each time you program a track, the program step, number of the programmed track, and the total time are displayed on the indicator.

Furthermore, when you program a track during playback, a display appears for just 5 seconds.

Programmed Playback



The PROGRAM indicator lights.

Operation example


To playback track 5, track 3 and track 8:

● Write in the program

Step	Key operations	Indicator display
01	[5] PROGRAM	05 TRACK # MIN SEC 05 05 32 LEVEL STEP 01
02	[3] PROGRAM	03 TRACK # MIN SEC 03 12 41 LEVEL STEP 02
03	[8] PROGRAM	08 TRACK # MIN SEC 08 18 23 LEVEL STEP 03

4. To play back this program, see "Playback Operation" on page 21.

Checking a program



Each time the TRACK SEARCH key is pressed, the next program step is displayed on the indicator. When the TRACK SEARCH key is pressed after the last program step has been reached, '0' will be displayed on the indicator, and the player will wait for another program entry to be made.

The indicator displays the program step and the programmed track number.

Operation example


- Checking a program

Program Check

Step	Key operations	Indicator display
01		
02		
03		
End of check		

*Press the key again, and it will return to [STEP 01] to repeat program check.

Revising a program



Revising the program to which belongs the currently displayed program step.

When a program is being checked, it can be revised with the TRACK NO. keys and the PROGRAM key.


Operation example

- Revising a program
(To change step 02, from track 3 to track 4.)

● Program Change

Step	Key operations	Indicator display
01		
02		
02 (Change)	4	
02	PROGRAM	

Adding to a program



New steps can be added until the total number of steps is equal to 24. This can also be done during programmed playback.

After displaying the last step while checking a program (0 will be displayed on the indicator), a new step can be added by pressing the PROGRAM key and the TRACK NO. keys.


Operation example

- Adding to a program
(To add track 10 and track 2 to a program.)
 - - -
 (Press until the indicator displays 00)

● Addition to Program

Step	Key operations	Indicator display
Waiting for additional step		
04	[1] [0] [PROGRAM]	
05	[2] [PROGRAM]	

Playback



1. Press the PLAY key to begin programmed playback.
2. Playback ends.

When the last programmed track finishes playing, the player enters stop mode. (All operations stop, and the player stops at the position of the first programmed track.)


- When the repeat playback function is on:
When the last programmed track finishes playing, the player returns to the first programmed track, and repeats programmed playback. Repeat playback will continue in this way until the REPEAT key is pressed once again, or the STOP key is pressed.

Operation example

- To start playback:

(Play 5th, 4th, 8th, 10th and 2nd programs in that order)

Cancellation of programmed playback and clearing a program:



- Pressing the OPEN/CLOSE key will cause playback to stop and the program stored in memory will also be cleared.
- Pressing the STOP key will cause playback to stop. In this case the program stored in memory will not be cleared. To clear the program, press the CLEAR key.
- If operations for direct track search are carried out, the program will be cleared.

● To stop playback	[STOP]
● To clear a program	[OPEN/CLOSE] or [STOP] - [CLEAR]
(Cancellation of (Clearing a program) playback)	

NOTE:
 If the CLEAR key is pressed during programmed playback, the program will be cleared and the player will enter normal playback mode and continue playback.

TO PROGRAM A PAUSE OPERATION (OPERATIONS FOR A PAUSE PROGRAM)

During programmed playback, these operations cause the player to pause at the beginning of tracks for which a pause has been specified.


[Application Example 1.]

When recording on both sides of a cassette tape, programming for a pause to occur after the completion of the last track, before the first side of the tape runs out, will enable recording of the next track to begin, after the tape has been turned over.

[Application Example 2.]

When recording on tape, programming for pauses to occur between tracks, will allow blank intervals or narration to be recorded on the tape, after which recording can be resumed.

Memorizing a pause program



1. During playback stop mode, select a track number.
2. Press the PROGRAM key.
3. Press the PAUSE key.
Operations 3 and 4 should be used only before those tracks before which a pause is desired.
● A pause is counted as one program step.
4. Press the PROGRAM key.
Programming another track by repeating operation 1, will result in a pause occurring during playback before the track is played back.
5. Repeat operations 1 to 4
Up to 24 steps can be programmed.

NOTE:
Two pause programs cannot be memorized in succession.

Operation example


To program the player to playback track 5, track 3, and track 8, and to pause at the beginning of track 8 after playing back track 3.

- Memorize the program

● **Pause Program**

Step	Key operations	Indicator display
01	[5] PROGRAM	
02	[3] PROGRAM	
03	PAUSE PROGRAM	
04	[8] PROGRAM	

Method of playback



1. Press the PLAY key to begin playback.
2. The player will pause before the track for which a pause has been specified.
3. To resume programmed playback, press the PLAY key or the PAUSE key.


Operation example

- To start and resume playback

PLAY :Player pause after playing track 3.
PLAY or PAUSE :Player resumes programmed playback.

TO CHANGE TO PROGRAMMED PLAYBACK DURING PLAYBACK (ADD-ON PROGRAM)

When a program is memorized during normal playback, the player automatically changes to programmed playback after finishing playing the current track. However, if the PLAY key is pressed during playback, the player immediately changes to programmed playback.



PROGRAM key

Operation example

During playback of track 5, program track 3 and track 8, and change to programmed playback.

- To memorize the program:

● **Advance Programming**

Step	Key operations	Indicator display
01	<p>[3]</p> <p>PROGRAM</p>	
After 5 seconds.		
02	<p>[8]</p> <p>PROGRAM</p>	


- To start programmed playback:

After track 5 finishes playing, programmed playback will begin automatically, or you may press the [PLAY] key.

PROGRAMMING TRACKS WHICH CAN BE PLAYED BACK WITHIN A DESIRED TIME (Auto program editing)

After the desired playback time has been determined, this function automatically programs the player so that tracks which can be played back within the specified time, are automatically played back in order from the first track. This is convenient for recording on tape.

Programming from track 1



1 During stop mode, press the AUTO PGM EDITING key.

2 Specify the time (in minutes) with the TRACK NO. keys.

The tracks which can be played back within the specified time, will be automatically programmed from track 1 in order.

To continue programming (to record on Side B of the tape).

3 Press the AUTO PGM EDITING key

4 Specify the time (in minutes) with the TRACK NO. keys.

After programming a pause, the tracks following the last track programmed with steps 1 and 2, which can be played back in the specified time, will be programmed in order.

The indicators will display the number of the last programmed track and the total playing time.

NOTE:

- To specify a time of 10 minutes or more, press the track number keys in succession within 2 seconds. If you take more than 2 seconds to press the keys, the specified time will be less than 10 minutes.
- It is not possible to program more than 30 tracks. In this case, you must finish after programming the 30th track.
- Correct programming may not be possible in the case of a disc with more than 24 tracks.
- If even a single track cannot be played back within the specified time, a program is not created.
- Auto programming is possible up to a maximum of 24 steps.

Operation example

To record tracks with a total time of less than 23 minutes on a C46 cassette tape (which can record for 23 minutes per side), from a compact disc with 10 tracks for a total time of 43 minutes and 27 seconds, we will program the player to play in order the tracks starting from track 1 that can be played for 23 minutes, and then to play the remaining tracks that can be played in 23 minutes.

● Auto Program Editing


Key operations	Indicator display
AUTO PGM	
[2] [3]	
After 0.8 sec	

Tracks 1 to track 5 are programmed to play back in 22 minutes and 20 seconds.

AUTO PGM	
[2] [3]	
After 0.8 sec	

After programming the pause, track 6 to track 10 are programmed to play back in 21 minutes and 07 seconds.

To program from a desired track



- 1 Select the track number with the TRACK NO. keys.
- 2 The following operations are the same as steps 1 - 4 of "Programming from track 1".

Operating example

Program to play back the tracks which can be played in 23 minutes starting from track 6.

● Programming From Desired Tracks


Key operations	Indicator display
[6]	
AUTO PGM	
[2] [3]	
After 0.8 sec	

Track 6 to track 10 are programmed to be played back in 21 minutes and 07 seconds.

Cancellation of auto program mode

Before specifying the time period, press the AUTO PGM EDITING key or STOP key. After specifying the time period, press the CLEAR key.

Method of playback



- 1 Press the PLAY key.
After playing back the first programmed tracks, the player will enter pause mode.
- 2 Press the PLAY key or the PAUSE key.
Playback will start from the first of the second set of tracks that were programmed.

Operation example

● To start playback

- [PLAY] ... Plays back track 1 - track 5 and then pauses.
- [PLAY] or [PAUSE] ... Plays back track 6 to track 10.


Stopping playback, and clearing a program

Use the same operations as for ordinary programmed playback.

When ending play at a desired time with a fade-out (time fade editing).


When the desired play time is specified, the music plays for only that time, fades out and enters the pause status. Convenient for dubbing without leaving any tape blank.

When playing for only a specified time starting with the first song.



- 1 In stop mode, press the **TIME FADE EDITING** key.
- 2 With the track number keys, specify the desired time period (in minutes).
When a time is specified, the number of seconds after a certain song the fade-out is to be made is calculated and displayed.

For playback only within a specific time period from the Desired Track



- 1 In stop mode, use the track number keys to specify the track number.
- 2 Now follow steps 1 and 2 in "When playing for only a specified time starting with the first song."

Operation Example

A compact disc with 10 tracks for a total time of 43 minutes and 27 seconds is recorded onto one side of a C-46 cassette tape. When the tape runs out after 23 minutes, the recording will fade out.

● **Time Fade Edit**

Key operation	Indicator display
TIME FADE	
2 3	
After 0.8 seconds.	

Plays from the first to the fifth song and ends by fading out at 2 minutes and 40 seconds of the fifth song.

Operation Example


This plays for 23 minutes starting with the sixth song and ends by fading out.

● **Fade Out from the Desired Track**

Key operation	Indicator display
6	
TIME FADE	
2 3	
After 0.8 seconds.	

When time fade editing a programmed song sequence

When a program is written for program playing, play continues automatically only for the specified time and ends with a fade-out.



- 1 Press the **TIME FADE EDITING** key while program play is stopped.
- 2 The following operation is the same as for "Playing only for a specified time starting with the first song."

Operation example


Use time fade editing when programming the second, third, fifth, seventh, eighth, tenth and twelfth songs.

● **Time Editing after Programming**

Key operation	Indicator display
TIME FADE	
2 3	
After 0.8 seconds.	

Track 10 will be played for 1 minute and 21 seconds and then it will fade out.

Method of playback



- 1 Press the **PLAY** key.

After playing back the specified time period, the player enters the pause mode while fading out.

Operation example

- To start playback **PLAY** ... Playback will start from track 1 and continue for 23 minutes. Then editing will be faded out and the player will enter the pause mode.

NOTE:


- If the time period is specified for more than 10 minutes, press the track number key within 2 seconds. If it is not pressed within 2 seconds, less than 10 minutes will be specified.
- Time fade editing is not possible when a specified time is longer than the total play time. In the same way, time fade editing is also not possible when a specified time is longer than the total play time of the programmed songs. Also, when a pause program is used, play will continue without pausing.
- When a Music Window has been programmed, or during playback and pause, and pressing the **TIME FADE EDITING** key will have no effect.
- Time fade editing is not possible when more than 24 songs are played by specifying the time.
- Use the manual search operation during play in the time fade editing mode and operate the fade-out when the fade-out starting point is passed.

Canceling the TIME FADE EDITING Mode

- Before specifying the time period, press the TIME FADE EDITING key or STOP key. After specifying the time period, press the CLEAR key.

When joining only the desired parts of the disc for smooth and continuous playback.
(Music Window Program)

Program the starting and ending points of the desired section (WINDOW).



1 Press the music window key at the desired place during normal play.

This will become the music window starting point. The music window "IN" indicator will light to show that the starting point has been entered.

2 Again press the music window key at the desired place.

This will become the music window ending point to complete the programming of one music window. The "OUT" indicator will light to indicate that the ending point has been entered. Five seconds later the indicator will go out to indicate a return to normal play.

3 Repeat the operations in items 1 and 2.

Up to 8 windows (8 steps) can be stored.


Operation Example

Program from 1 minute and 18 seconds to 1 minute and 48 seconds of the first song and from 2 minutes and 00 seconds to 2 minutes and 35 seconds of the fifth song.

● Music Window

Key operation	Indicator display
Press the key to fast forward.	
MUSIC WINDOW Enter the starting point.	
Press the key to fast forward, or allow the player to play for a while.	
MUSIC WINDOW Enter the ending point.	
After 5 seconds.	
Press the key to advance 5 tracks. Press the key to fast forward to the desired track, or allow the player to play for a while.	
MUSIC WINDOW Enter the starting point.	
Press the key to fast forward, or allow the player to play for a while.	
MUSIC WINDOW Enter the ending point.	
After 5 seconds.	

Playback Operation



- 1 **Press the play key to start play.**
Play will start while fading in from the starting point of the first desired programmed window.
- 2 **Play ends.**
The last programmed window will fade out right before playback ends. The player will then enter the stop mode.

■ **When repeat is on**

When play of the last programmed window ends, play repeats from the starting point of the first programmed window. This operation continues until the repeat key is turned off or the stop key is pressed.

■ **When advancing to the next programmed window starting point or returning to the starting point of the window currently being**

played or to the previous programmed window.

- Pressing the track search key [▶▶] once during music window play moves to the next programmed window starting point. Pressing this key continuously continues moving to the following window starting point.
- Pressing the track search key [◀◀] once during music window play moves to the starting point of the currently-playing window. Pressing this key continuously returns the player to the starting point of previous programmed windows.

Operation example

- Playback Start

PLAY -----		
Fade In Start	Playback	Fade Out End
Track 1, 1 min. 18 sec.	→	Track 1, 1 min. 48 sec.
Track 5, 2 min. 00 sec.	→	Track 5, 2 min. 35 sec.

TIMER START

If a disc is set on the disc tray beforehand, then, when power is turned ON, the player will automatically start playing from track 1.

If use is made of an audio timer, the player can be made to start playing from a specified time.

NOTE:

- When using an audio timer, leave the POWER switch of the player turned ON.
- If you operate the player by pressing any of the function keys before timer start, timer start will not occur.


CAUTIONS REGARDING USE OF REMOTE CONTROL UNIT

If use is made of the supplied remote control unit, operation from a distance is possible.

To use the remote control unit, aim it at the remote sensor.

The remote control unit can operate over a range of about 7 m, within angles of 30 degrees left and right.












- Even when the remote control unit is operated within the specified operating range, operation may not be successful if there are obstacles in the way, or if the angle is too great.
- Using the equipment near a device which emits infrared rays, or using another remote control unit which emits infrared rays, may result in misoperation. Conversely, use of the remote control unit when another device controlled by means of infrared rays is being used, may cause misoperation of that device.
- The life of the batteries used in the remote control unit will vary greatly depending on operating conditions, however when they begin to run down, the operating range will be reduced. When commands fail to be accepted when keys on the remote control unit are pressed, or when the operating range is greatly reduced, please replace the batteries.



TROUBLESHOOTING

Incorrect operations are often mistaken for trouble and malfunctions. If you think that there is something wrong with this component, check the points below. Sometimes the trouble may lie in another component. Investigate the other components and electrical appliances being used.

If the trouble cannot be rectified even after exercising the checks listed below, ask your nearest PIONEER authorized service center or your dealer to carry out repair work.

Symptom	Probable cause	Remedy
Disc tray is not expelled when OPEN/CLOSE switch is pressed.	<ul style="list-style-type: none"> Power plug is disconnected from outlet.  <ul style="list-style-type: none"> POWER switch is OFF. 	<ul style="list-style-type: none"> Connect plug to stereo amplifier or wall outlet.  <ul style="list-style-type: none"> Press POWER switch ON. 
When playback is started, it stops immediately. Pauses or stops playback	<ul style="list-style-type: none"> Disc is loaded upside down.  <ul style="list-style-type: none"> Contaminated disc, etc. 	<ul style="list-style-type: none"> Load the disc correctly with the label side UP.  <ul style="list-style-type: none"> Press the PLAY or PAUSE key.
No sound.	<ul style="list-style-type: none"> Output cords are connected incorrectly or loosely. Incorrect operation of stereo amplifier. Player is in pause mode. 	<ul style="list-style-type: none"> Connect properly. Check the settings of stereo amplifier switches and sound volume controls. Press the PLAY key. 
Sound is distorted, noise is output.	<ul style="list-style-type: none"> Incorrect connections. Pin plugs or amplifier input terminals are dirty. Interference is being picked up from a TV set. 	<ul style="list-style-type: none"> Connect to amplifier's CD or AUX terminals etc. Do not connect to PHONO input terminals. Clean away dirt. Switch OFF TV set, or move player away from TV set. 
With certain discs, loud noise is produced, or play stops.	<ul style="list-style-type: none"> Disc is badly scratched or warped.  <ul style="list-style-type: none"> Disc is extremely dirty. 	<ul style="list-style-type: none"> Replace the disc. Clean disc. 
Cannot operate player with remote control unit.	<ul style="list-style-type: none"> Batteries have run down. Remote control unit is too far away from player, or angle is wrong. There is an obstacle between remote control unit and player. 	<ul style="list-style-type: none"> Replace batteries. The operating range of the remote control unit, is up to about 7 m from, and within angles of 30 degrees left and right of the sensor window on the player. Operate the remote control unit from a different position, or remove the obstacle. 

SPECIFICATIONS

1. General

Type.....Compact disc digital audio system
Usable discs.....Compact Disc
Signal format.....Sampling frequency: 44.1 kHz
Quantized bit number: 16 bit linear
Power requirements
European models.....AC 220 V, 50/60 Hz
U.K., Australian models.....AC 240 V, 50/60 Hz
U.S., Canadian models.....AC 120 V, 60 Hz
Other models.....AC 110/120-127/220/240 V
(switchable), 50/60 Hz
Power consumption.....15 W
Operating temperature.....+5°C - +35°C
Weight.....4.3 kg (9 lb, 8 oz)
External dimensions.....
420(W) x 315(D) x 84(H) mm
16-1/2(W) x 12-2/5(D) x 3-1/4(H) in

2. Audio section

Frequency response.....4 Hz - 20 kHz (± 0.5 dB)
S/N.....104 dB or more (EIAJ)
Dynamic range.....95 dB or more (EIAJ)
Channel separation.....100 dB or more (EIAJ)
Total harmonic distortion.....0.0035% or less (EIAJ)
Output voltage.....2.0 V \pm 0.5 V (EIAJ)
Wow and flutter.....Limit of measurement
($\pm 0.001\%$ W.PEAK) or less (EIAJ)
Number of channels.....2 channels (stereo)
Digital output.....0.5 Vp-p (75 Ω)

3. Functions

- Play
- Pause
- Manual search
- Programmed playback
- Track search
- Index search
- Programmed repeat
- Pause program
- Direct track search
- All track repeat
- Add-on program
- Auto program editing
- Time fade editing
- Music window program
- Auto fade in/out
- OUTPUT level control
- Timer start

The above functions can be operated with the remote control unit.

4. Accessories

- Remote control unit.....1
- Size AAA/R03 dry batteries.....2
- Output cable.....1
- Operating instructions.....1

NOTE:

The specifications and design of this product are subject to change without notice, due to improvements.

PIONEER ELECTRONIC CORPORATION 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan
PIONEER ELECTRONICS [USA] INC. 2265 East 220th Street Long Beach, California 90810 U.S.A.
P.O. BOX 1720 Long Beach, California 90801-1720 U.S.A.

PIONEER ELECTRONICS OF CANADA, INC. 505 Cochrane Drive, Markham, Ontario L3R 6B8 Canada

PIONEER ELECTRONIC [EUROPE] N.V. Keetberglaan 1, 2740 Beveren, Belgium TEL: 03/775-28-08

PIONEER ELECTRONICS AUSTRALIA PTY. LTD. 178-184 Boundary Road, Braeside, Victoria 3195, Australia TEL: [03] 580-9911