


YAMAHA

KX-W582

KX-W482



Natural Sound Stereo Cassette Deck

OWNER'S MANUAL



IMPORTANT

Please record the serial number of your unit in the space below.

Model:


Serial No:

The serial number is located on the rear of the unit.


Retain this Owner's Manual in a safe place for future reference.

Thank you for purchasing the YAMAHA stereo cassette deck.

SAFETY INSTRUCTIONS



● Explanation of Graphical Symbols



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert you to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert you to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING

To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

- 1** Read Instructions — All the safety and operating instructions should be read before the appliance is operated.
- 2** Retain Instructions — The safety and operating instructions should be retained for future reference.
- 3** Heed Warnings — All warnings on the appliance and in the operating instructions should be adhered to.
- 4** Follow Instructions — All operating and other instructions should be followed.
- 5** Water and Moisture — The appliance should not be used near water — for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near swimming pool, etc.
- 6** Carts and Stands — The appliance should be used only with a cart or stand that is recommended by the manufacturer.
- 6A** An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.



7 Wall or Ceiling Mounting — The appliance should be mounted to a wall or ceiling only as recommended by the manufacturer.

8 Ventilation — The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug or similar surfaces that may block the ventilation openings; or placed in a built-in installation, such as a bookcase or cabinet that may impede the flow of air through the ventilation openings.

9 Heat — The appliance should be situated away from heat sources such as radiators, stoves, or other appliances that produce heat.

10 Power Sources — The appliance should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.

11 Power-Cord Protection — Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying attention to receptacles, and the point where they exit from the appliance.

12 Cleaning — The appliance should be cleaned only as recommended by the manufacturer.

13 No Use Periods — The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time.

14 Object and Liquid Entry — Care should be taken so that objects do not fall into and liquids not spilled into the inside of the appliance.

15 Damage Requiring Service — The appliance should be serviced by qualified service personnel when:

- A.** The power-supply cord or the plug has been damaged; or
- B.** Objects have fallen, or liquid has been spilled into the appliance; or
- C.** The appliance has been exposed to rain; or
- D.** The appliance does not appear to operate normally or exhibits a marked change in performance; or
- E.** The appliance has been dropped, or the cabinet damaged.

16 Servicing — The user should not attempt to service the appliance beyond those means described in the operating instructions. All other servicing should be referred to qualified service personnel.

17 Grounding or Polarization — The precautions should be taken so that the grounding or polarization of an appliance is not defeated.

CAUTION: READ THIS BEFORE OPERATING YOUR UNIT.

FCC INFORMATION (U.S.A.)

1. **IMPORTANT NOTICE: DO NOT MODIFY THIS UNIT!**
This product, when installed as indicated in the instructions contained in this manual, meets FCC requirements. Modifications not expressly approved by Yamaha may void your authority, granted by the FCC, to use the product.
2. **IMPORTANT:** When connecting this product to accessories and/or another product use only high quality shielded cables. Cables supplied with this product **MUST** be used. Follow all installation instructions. Failure to follow instructions could void your FCC authorization to use this product in the USA.
3. **NOTE:** This product has been tested and found to comply with the requirements listed in FCC Regulations, Part 15 for Class "A" digital devices. Compliance with these requirements provides a reasonable level of assurance that your use of this product, in a commercial environment, will not result in harmful interference with other electronic devices. However, operation of this product in a residential area is likely to cause interference in some form. In this case you, the user, bear the responsibility of correcting this condition.

This product generates/uses radio frequencies and, if not installed and used according to the instructions found in the users manual, may cause interference harmful to the operation of other electronic devices. Compliance with FCC regulations does not guarantee that interference will not occur in all installations. If this product is found to be the source of interference, which can be determined by turning the product "OFF" and "ON", please try to eliminate the problem using one of the following measures:

Relocate either the product generating the interference of the device that is being affected by the interference.

Utilize power outlets that are on different branch (circuit breaker or fuse) circuits or install AC line filter/s.

In the case of radio or TV interference, relocate/reorient the antenna. If the antenna lead-in is 300 ohm ribbon lead, change the lead-in to coaxial type cable.

If these corrective measures do not produce satisfactory results, please contact your local retailer that is authorized to distribute this type of product. If you cannot locate the appropriate retailer, please contact Yamaha Electronics Corp., U.S.A. 6600 Orangethorpe Ave, Buena Park, CA90620

The above statements apply **ONLY** to those products distributed by Yamaha Corporation of America or its subsidiaries.

We Want You Listening For A Lifetime

YAMAHA and the Electronic Industries Association's Consumer Electronics Group want you to get the most out of your equipment by playing it at a safe level. One that lets the sound come through loud and clear without annoying blaring or distortion – and, most importantly, without affecting your sensitive hearing. Since hearing damage from loud sounds is often undetectable until it is too late, YAMAHA and the Electronic Industries Association's Consumer Electronics Group recommend you avoid prolonged exposure to excessive volume levels.



1. This unit is a sophisticated stereo cassette deck. To ensure proper operation for the best possible performance, please read this manual carefully.
2. Choose the installation location of your unit carefully. Avoid placing it in direct sunlight or close to source of heat. Also avoid locations subject to vibration and excessive dust, heat, cold or moisture. Keep it away from sources of hum such as transformers or motors.
3. Do not open the cabinet as this may result in damage to the deck or electrical shock. If a foreign object should get into the deck, contact your local dealer.
4. Do not apply excessive force when operating switches and knobs.
5. When moving the deck, be sure to first pull out the power plug and remove all cords connecting the deck to other equipment.
6. Do not attempt to clean this unit with chemical solvents as this may damage the finish. Use a clean, dry cloth.
7. Never allow metallic items (e.g. screwdrivers, tools, etc.) to come near the record/playback head assembly. Doing so may not only scratch or damage the head's mirror-smooth finish, it may also change the magnetic characteristics of the heads, causing a deterioration in reproduction quality.
8. Although the record/playback head used in this unit is a high quality head with outstanding reproduction characteristics, it can become dirty through the use of old tapes or from dust accumulation over time. This can have a serious effect on reproduction quality. Clean the heads regularly with one of the commonly available head cleaners or with cleaning solutions as explained later in this manual.
9. Be sure to read the "Troubleshooting" section of this manual for advice on common operating errors before concluding that your unit is faulty.
10. Unplug the power cord from the wall outlet if the unit is not to be used for an extended period of time. To disconnect the cord, pull it out by grasping the plug. Never pull the cord itself.
11. Keep this manual in a safe place for future reference.
12. **Voltage Selector (General model only)**
The voltage selector on the rear panel of this unit must be set for your local mains voltage BEFORE plugging in the AC mains supply.

Please check the copyright laws in your country to record from records, compact discs, radio, etc. Recording of copyright material may infringe copyright laws.


TABLE OF CONTENTS

| | | | |
|--|----|---|------------|
| FEATURES | 4 | DUBBING | 16 |
| CONNECTIONS | 5 | CASSETTE TAPES | 17 |
| PLAYBACK | 6 | MAINTENANCE | 18 |
| Basic operation | 6 | OPTIONAL REMOTE CONTROL TRANSMITTER | 18 |
| SELECTION SEARCH | 8 | TROUBLESHOOTING | 19 |
| RELAY PLAYBACK | 9 | SPECIFICATIONS | Back cover |
| PLAY TRIM control adjustment | 9 | | |
| DIGITAL SUPER SURROUND (DSS) (KX-W582 only) | 10 | | |
| RECORDING | 11 | | |
| Basic operation | 11 | | |
| REC MUTE operation | 13 | | |
| REC RETURN operation | 13 | | |
| DUAL RECORDING | 14 | | |
| RELAY RECORDING | 15 | | |

FEATURES

- High Quality Hard Permalloy Recording/Playback Head in Both Decks
- Secure Holding Damper Cassette Stabilizer allows you to reduce unwanted vibration and modulation noise (KX-W582 only)
- Dolby HX Pro Dynamic Bias Servo
- Dolby B/C Noise Reduction
- Digital Super Surround (DSS) Function enables you to create an excellent audio sound field, applicable also for recording (KX-W582 only)
- Play Trim Control for improved playback compatibility with other decks
- Auto Tape Selector
- Dual Recording allows you to make the same recording on both decks simultaneously
- Relay Playback from DECK A to DECK B
- Relay Recording from DECK A to DECK B
- Selection Search
- Recording Mute Function
- Rec Return Operation
- Easy Dubbing Operation at Selectable Speed (Normal/High)
- Peak Level Meters with Peak Hold Function
- Remote Control Capability with Optional Remote Control Transmitter

CONNECTIONS



REAR PANEL CONNECTIONS

Make sure that power to both the deck and your amplifier/receiver is turned off before making any connections.


- The White plug on the paired connecting cables corresponds to the Left channel and the Red plug corresponds to the Right channel. Make sure that the left and right channel connections are properly made, and that the plugs are inserted firmly.
- The LINE OUT/PLAY jacks on the deck should be connected to the Tape PB (Playback/Input) jacks on your amplifier/receiver, and the LINE IN/REC jacks on the deck should be connected to the Rec Out (Recording/Output) jacks on your amplifier/receiver.
- Connect the power cord to an AC wall outlet or to an AC outlet on the rear panel of your amplifier/receiver (if provided).

PLAYBACK (Common to DECKS A and B)

Preparation for playback

- Turn on the POWER switch.
- Set your amplifier or receiver to cassette deck function mode.

Basic operation - To play back a cassette tape



| | | | |
|---|--|--|-----------------|
| <p>1</p> <p>Insert the cassette with the exposed tape side facing down. (The side facing you is called the forward side and the opposite side is called the reverse side.) To close the compartment, push in the compartment door until it locks shut.</p> | <p>2</p> <p>Press the DECK A/B button to select the deck to be operated. The corresponding indicator lights on the display.</p> | <p>3</p> <p>KX-W582 only</p> <p>Refer to the following description.</p> | |
| <p>4</p> <p>Refer to the following description.</p> | <p>5</p> <p>Refer to the following description.</p> | <p>6</p> <p>Select the tape running direction for DECK A or B. Each time this button is pressed, the tape running direction changes between forward (▷) and reverse (◁), and the corresponding indicator lights on the display.</p> | <p>7</p> |

To fast forward or rewind the tape

When the tape running indicator ▷ is lit:

Pressing the ▷▷ button fast forwards the tape while pressing the ◁◁ button rewinds the tape.

When the tape running indicator ◁ is lit:

Pressing the ◁◁ button fast forwards the tape while pressing the ▷▷ button rewinds the tape.

To stop playback

Press the STOP button. To remove the cassette tape, press the EJECT button. The cassette compartment door opens. To turn off the power, press the POWER button.

DOLBY NR selector setting (in step 4)

Be sure to set the DOLBY NR selector according to the system used for recording.

OFF: For a tape recorded with DOLBY NR OFF.

DB: For a tape recorded with DOLBY B NR.

DC: For a tape recorded with DOLBY C NR.

* Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation. "DOLBY" and the double-D symbol **DB** are trademarks of Dolby Laboratories Licensing Corporation.

REVERSE MODE selector setting (in step 5)

The auto reverse function allows the tape running direction to be reversed automatically. Select an auto reverse mode (↔), manual reverse mode (⇌) or RELAY playback mode.

⇌: When playback or fast forwarding (or rewinding) of one side of a tape is finished, the deck stops at the end of the tape.


↔: Both sides of the tape are repeatedly played back (up to 8 times).

- When the tape is fast forwarded to the end of a side, playback automatically starts from the other side. When the tape is rewound to the beginning of a side, playback automatically starts from the beginning.

RELAY: Cassette tapes loaded in DECKs A and B are played back sequentially. (See "RELAY PLAYBACK" on page 9.)

Display during playback


KX-W582



Peak level meters

Indicate the peaks of the signal levels during recording and playback over a -30 dB to +6 dB range. There are separate meters for each left and right channel. These level meters have a peak hold function which holds the peak level for about 1.5 seconds.

KX-W482



Peak level meters

Indicate the peaks of the signal levels during recording and playback over a -30 dB to +6 dB range. There are separate meters for each left and right channel. These level meters have a peak hold function which holds the peak level for about 1.5 seconds.

To adjust the volume level


Use the volume control of the amplifier or receiver.

Note

Never press the EJECT button during playback.

To use headphones


Insert the headphones plug into the PHONES jack. Since the sound is also heard from the speakers, operate the amplifier to cut off the sound from the speakers for private listening.




SELECTION SEARCH - To play back a desired selection by searching for the beginning of the selection

To search for the next selection

When the ▷ tape running indicator is lit:




When the ◁ tape running indicator is lit:




To search for the beginning of the current selection

When the ▷ tape running indicator is lit:




When the ◁ tape running indicator is lit:




To search for the selection located before the current selection

● Operate the following buttons when the beginning of the current selection is being played.

When the ▷ tape running indicator is lit:




When the ◁ tape running indicator is lit:




Notes

- The blank interval between selections must be at least 4 seconds long.
- Selection search may not operate properly with tapes recorded at a low recording level or which have excessive noise.
- Use the tape counter to aid in locating a point on a tape (0000 to 9999). To set the counter reading to "0000", press the RESET button.



RELAY PLAYBACK - To play DECK A and DECK B sequentially


Load the cassette tapes into DECKS A and B, start playback of DECK A.
Set the MODE selector to the RELAY position.




PLAY TRIM control adjustment

When the level of high frequencies is too boosted or absent while playing a tape recorded on another cassette deck, adjust the high frequency response with the PLAY TRIM control.

When high frequencies are too loud, attenuate the high frequencies.




When high frequencies are too soft, boost the high frequencies.




- ① High frequency sound is too loud.
- ② Flat
- ③ High-frequency sound is too soft.

DIGITAL SUPER SURROUND (DSS) (KX-W582 only)



This unit incorporates a sophisticated, multi-program Digital Super Surround function, which allows you to expand and shape the audio sound field, for a theater-like experience in the listening room.



Pressing the DSS button turns on and off the DSS effect.



Each time the DSS MODE button is pressed, the DSS program changes in the following order and the corresponding indicator lights:



Description of each Sound Field Program


- 🎧 : Programmed to provide largest sound field effects when listening through headphones.
- HALL:** A mode suitable for playing live recording of pop or rock concerts with vocals. The expansion and reverberation of concert hall are provided even when the speakers are installed close to each other.
- DISCO:** Crisp bass and solid, powerful sound reproduces the atmosphere of a disco.
- CHURCH:** Long echo time reproduces rich reverberation in a church. Suitable for vocal music.
- JAZZ CLUB:** A very rich presence is reproduced together with a three-dimensional feeling where each musical instrument asserts itself in the front line.

Note

To playback the tape recorded with this unit applying the DSS effect, be sure to turn off the DSS function. If the DSS is activated also for playback, the reproduced sound will be unnatural.

DSS monitor function

When the DSS button is pressed with any cassette inserted in neither of the decks, "dSS" appears on the display in position of the tape counters of both decks.



In this state, DSS effect can be applied to the input signal to the LINE IN jacks from any other source than cassette decks. The sound with DSS effect is output to the LINE OUT jacks.

- On the amplifier, select the source to apply the DSS effect with the REC OUT selector and set the input selector to the TAPE position. If the amplifier has no REC OUT selector, select the source with the input selector and set the amplifier to the TAPE MONITOR mode.
- Adjust the output level with the REC LEVEL control so that the reproduced sound is not distorted. For details, see "Setting the recording level" on page 12.


RECORDING

Preparation for recording


- Turn on the POWER switch.
- Set your amplifier or receiver to cassette deck function mode.










Basic operation - To record a program source

KX-W582



KX-W482



| | | | | |
|---|---|---|--|--|
| <p>1</p>  <p>Insert the cassette with the exposed tape side facing down. (The side facing you is called the forward side and the opposite side is called the reverse side.) To close the compartment, push in the compartment door until it locks shut.</p> | <p>2</p>  <p>Press the DECK A/B button to select DECK A or B. The corresponding indicator for the selected deck lights on the display.</p> | <p>3 KX-W582 only</p>  <p>Refer to the following description.</p> | <p>4</p>  <p>Refer to the following description.</p> | |
| <p>5</p>  <p>Refer to the following description.</p> | <p>6</p>  <p>Select the tape running direction. (Press the DIRECTION A button for DECK A and the DIRECTION B button for DECK B.) Each time one of these button is pressed, the tape running direction of the corresponding deck changes between forward (▷) and reverse (◁), and the indicator lights on the display.</p> | <p>7</p>  <p>The REC indicator lights on the display. The deck enters the rec pause mode.</p> | <p>8</p>  <p>Play the program source to be recorded and adjust the recording level and balance.</p> | <p>9</p>  <p>Recording starts.</p> |

Digital Super Surround (DSS) setting (in step 3)

The DSS function can be utilized also for recording. Press the DSS MODE button to turn on the DSS function, and select one of the DSS programs by pressing the DSS button so that the corresponding indicator lights up. By recording with this function, you can enjoy the sources with your preferred DSS effect even when played back on car audios or portable headphone stereo systems. For details on DSS, see page 10.

DOLBY NR selector setting (in step 4)

Set the DOLBY NR selector according to your purpose.

OFF: No noise reduction.

ⓀB: For recording the sources with Dolby B NR.

ⓀC: For recording the sources with Dolby C NR.

- Dolby noise reduction is an extremely effective method of reducing undesirable background hiss on tapes. This unit incorporates both Dolby B NR and the newer Dolby C NR system. Dolby C NR is approximately twice as effective as the earlier Dolby B NR.

REVERSE MODE selector setting (in step 5)

The auto reverse function allows the tape running direction to be reversed automatically. Select an auto reverse mode (↔), manual reverse mode (⇐) or RELAY recording mode.

⇐: When recording on one side of a tape is finished, the deck stops at the end of the tape.

↔: Both sides of a tape are recorded. After recording, the deck stops at the end of the tape.

- When the tape running direction is set to ⇐, only the reverse side is recorded.

RELAY: Cassette tapes loaded in DECKs A and B are recorded sequentially. (See "RELAY RECORDING" on page 15.)


Setting the recording level (in step 8)

Play the loudest passage of the source to be recorded and watch the meter readings.


Adjust the REC LEVEL control so that the highest peak reaches +4 of the optimum recording level. Normally, it is best to adjust the BALANCE control such that the left and right meter readings are even.

Display during recording

KX-W582




KX-W482



To stop recording:
Press the STOP button.

To stop recording temporarily:
Press the REC/PAUSE button. To resume recording, press the PLAY button.



REC MUTE operation - Inserting a blank space during recording

During recording:



During Rec mute operation, the REC indicator blinks.


A 4-second blank interval is automatically recorded on the tape and then the deck enters Rec pause mode. If a blank interval longer than 4 seconds is desired, keep pressing for as long as you want. When the MUTE/SEARCH button is released, the deck enters Rec pause mode after making a 4-second blank interval. To resume recording, press the PLAY button.

- If a blank interval shorter than 4 seconds is desired, press the PLAY button at the desired point during Rec mute mode. Recording will be resumed from that point.


REC RETURN operation - To return to the point at which the recording started

During recording:


When the ▷ indicator is lit:



When the ◁ indicator is lit:




- If the PLAY button is pressed during recording, Rec return operation automatically rewinds the tape to the point where the PLAY button was pressed. When the tape counter is reset to "0000" during recording, Rec return operation automatically rewinds the tape to the "0000" point. The tape then stops in both cases.



DUAL RECORDING - To record a program source on both decks simultaneously


To make the same tapes, use tapes of identical length.

- 1 Insert cassette tapes in both DECKS A and B.**
- 2 Press the DECK A/B button to select DECK A.**



- 3 Perform steps 3 through 5 of “Basic operation” to adjust the DSS, DOLBY NR and REVERSE MODE settings.**
For dual recording, Set the MODE selector to \rightleftarrows or \leftrightarrow position.


- 4 Select the tape running direction for both decks by pressing the DIRECTION A and B buttons.**



- 5 Press the REC/PAUSE button to enter the rec pause mode.**




- 6 Play the program source to be recorded and adjust the recording level and balance.**



Recording level for both decks is adjusted to the same level.


- 7 Press the DECK A/B button to select DECK B.**



- 8 Press the REC/PAUSE button to enter the rec pause mode.**




- 9 To start recording, press the PLAY button.**



Both decks start recording simultaneously. Once the dual recording starts, pressing the REC/PAUSE or STOP button or performing the REC RETURN/REC MUTE operation affects both decks simultaneously.


To stop recording in the middle of the tape
Press the STOP button of both decks on the front panel simultaneously. If the STOP button of one deck is pressed, the other continues recording.



RELAY RECORDING - To record a program source sequentially on DECK A and DECK B


Recording can be made sequentially on DECKs A and B. Start the relay recording always from the cassette in DECK A.

- 1 Insert cassette tapes in both DECKs A and B.
- 2 Press the DECK A/B button to select DECK A.




The DECK A indicator lights on the display.

- 3 Perform steps 3 and 4 of “Basic operation” to adjust the DSS and DOLBY NR settings.
- 4 Set the MODE selector to RELAY position.




- 5 Select the tape running direction for both decks by pressing the DIRECTION A and B buttons.



The tape running direction indicator of the corresponding deck (forward ▷ or reverse ◁) lights on the display.


To record on both sides of the tapes, rewind them to the beginning of the forward side and select forward (▷) with the DIRECTION A and B buttons respectively. When reverse (◁) is selected, the source is recorded only on the reverse side.

- 6 Press the REC/PAUSE button to enter the rec pause mode.




The REC indicator of the DECK A lights.

- 7 Play the program source to be recorded and adjust the recording level and balance.



Recording level for both decks is adjusted to the same level.


- 8 To start recording, press the PLAY button.



DOLBY HX PRO DYNAMIC BIAS SERVO SYSTEM

This unit incorporates the Dolby HX Pro system which automatically controls the effective bias to reduce distortion and noise, improving high frequency response during recording. Tapes recorded with this system retain the same high quality even when played back on any other cassette deck.

Dolby noise reduction and HX Pro headroom extension manufactured under license from Dolby Laboratories Licensing Corporation, HX Pro originated by Bang & Olufsen.

“DOLBY”, the double-D symbol  and “HX PRO” are trademarks of Dolby Laboratories Licensing Corporation.

DUBBING (From DECK B to DECK A)

You can make dubbing from DECK B to DECK A. Open the cassette compartments by pressing the EJECT buttons and load a blank cassette tape in DECK A and the original cassette tape in DECK B.

KX-W582

1 **2** **3** STOP

Display during dubbing

Lights during dubbing. NORM or HIGH indicator lights during dubbing.


KX-W482

1 **2** **3** STOP


Display during dubbing

Lights during dubbing. NORM or HIGH indicator lights during dubbing.


- 1 Set the MODE selector to \rightleftarrows or \leftrightarrow position.**
Setting the MODE selector to RELAY position results in the same function as to \rightleftarrows .



- 2 Set the DIRECTION buttons for DECKs A and B.**



- 3 Set the DUBBING speed to either NORM (normal speed) or HIGH (twice the normal speed) with the DUBBING buttons*. Dubbing starts automatically.**



The corresponding NORM or HIGH indicator lights on the display.

* Higher quality sound will be obtained with the NORM setting.

To stop dubbing

Press the STOP button. (When DECK A is selected with the DECK A/B button, both decks stop simultaneously and the dubbing mode is cancelled. When DECK B is selected, DECK B stops immediately and then DECK A stops after recording a 4-second blank section.)

When the tape in DECK A reaches its end, DECK A and DECK B stop at the same time.

When the tape in DECK B reaches its end, DECK B stops and DECK A stops after providing a blank section of about 4 seconds.

Available operations while dubbing

The Rec Return function can be carried out on DECK A. Refer to "REC RETURN operation" on the previous page. While dubbing, the buttons other than \triangleleft and \triangleleft buttons cannot be operated.

Note

During dubbing, the Dolby NR and the DSS are automatically set to OFF and the recorded tape can be dubbed as it is. (When the tape to be dubbed is recorded with Dolby NR and/or DSS, these effects are also dubbed.)

Synchronized recording function

When operating this unit in combination with the YAMAHA CD Player which has SYNCHRO button on its remote control transmitter, CD Synchronized recording function can be utilized. This function is operated with the remote control transmitter of the CD Player. (Regarding the operation, refer to the manual of the CD Player.) The SYNCHRO indicator lights when the SYNCHRO button of the remote controller is pressed.

CASSETTE TAPES

CASSETTE TAPES

There are many different types of cassette tapes available. However, they all conform to standard specifications so any brand may be used with the deck.

- **Classification of Cassette Tapes by Formulation:**

Cassette tapes are available in four basic types depending on their formulation, or type of magnetic material and manufacturing process. These four types are commonly known as Normal (Type I/NORM), Chrome (Type II/HIGH CrO_2), Ferrichrome (Type III/FeCr), and Metal (Type IV/METAL), and they each require specific tape deck adjustments for optimum performance.


- * YAMAHA does not recommend the use of 120 minute length cassettes since the extreme thinness of the tape makes them susceptible to mechanical and recording problems.

AUTO TAPE SELECTOR DETECTION SLOTS

The deck has a built-in Auto Tape Selector which automatically adjusts for the proper bias, level and equalization according to the tape formulation — all you have to do is to load a cassette and the Auto Tape Selector does the rest.

The Auto Tape Selector determines which type of tape is loaded by sensing detector slots in the top of the tape shell. Each tape formulation has its own characteristic hole markings standardized by the tape industry.


- Early model Metal (Type IV/Metal) tape formulation cassette shells do not have the slots for Auto Tape Selector operation. As a result, early model Metal type tapes recorded on another deck will be played back with the deck at the Chrome (Type II/HIGH CrO_2) settings. YAMAHA does not recommend using this kind of tape.
- The deck does not have the required setting for Ferrichrome (Type III/FeCr) tape, since this tape formulation is not widely used. Should you use a Ferrichrome tape, it will be recorded and played back at the Normal (Type I/NORM) settings, which will result in an unnatural high frequency emphasis. This effect may be compensated for somewhat by adjusting the PLAY TRIM control and/or the tone controls of your amplifier/receiver during playback.



PROTECTING YOUR RECORDINGS

All cassette tapes are provided with erasure protection holes to prevent accidental erasure of recorded contents. There is a small tab covering the hole on each side of the cassette, and it should be broken off after recording the tape. Without this tab covering the hole, it is impossible to record onto that tape. Thus, you can safely protect a recording for as long as you wish without fear of accidental erasure. Should you wish to use a cassette tape protected in this way for recording, simply covering the hole with adhesive tape will permit erasure and re-recording.


- When using Chrome (Type II/HIGH CrO_2) or Metal (Type IV/METAL) tapes, make sure you do not cover the hole intended for the Auto Tape Selector operation.



TAKING UP SLACK IN THE TAPE

As a precaution against tape entanglement and damage, remove any slack in the tape before inserting cassettes into the deck. This is accomplished by inserting a pencil, pen or similar object into one of the spools and gently winding it until all the slack is removed. You do not have to wind it too tightly.

Be careful not to touch the tape part itself. It is very delicate and touching it may damage the tape and its recorded contents.




STORING CASSETTES

After putting a cassette tape back into its case, store it in a location away from exposure to direct sunlight, humidity, high temperatures, and magnetic fields (away from television sets, speakers, etc.). High temperatures and humidity will damage the tape itself, while exposure to magnetic fields may cause a loss of recorded material. Avoid touching the tape surface with your fingers, since dirt or finger oil will contaminate the deck's heads.

MAINTENANCE

CLEANING OF THE TAPE PATH

Continued high quality performance of your deck is dependent upon periodic cleaning of the heads, capstan, pinch roller, and all surfaces over which the tape travels. Normal use will cause an accumulation of dirt and dust on the heads, capstans, and pinch rollers. This can lead to poor sound quality, drop outs (intervals with no sound), unsteady tape speed, loss of high frequency response, etc. Thus, clean the heads and all surfaces over which the tape travels with a commercially available cleaning cassette and fluid type cleaner.




DEMAGNETIZATION

After 20-30 hours of use, enough residual magnetism will build up on the heads to cause poor high frequency reproduction. At this time you should use a commercially available cassette tape-type head demagnetizer.


- When cleaning the tape path or demagnetizing the heads, be sure to follow carefully the instructions of the concerning materials such as cleaning fluid or head demagnetizer.

OPTIONAL REMOTE CONTROL TRANSMITTER

With the optional remote control transmitter RS-KX1, you can operate this unit at your listening position. For details, refer to the instruction manual supplied with the remote control transmitter.



REMOTE CONTROL OPERATION RANGE



TROUBLESHOOTING

If your cassette deck fails to operate normally, check the following table. It lists common operating errors and simple measures which you can take to correct the problem. If it cannot be corrected, or the symptom is not listed, disconnect the deck's power cord and contact your local YAMAHA dealer or authorized service center for help.

| Fault | Cause | Cure |
|--|---|--|
| Tape doesn't move in recording or playback. | <ul style="list-style-type: none"> ● Power plug is not properly plugged in. ● Cassette shell is warped or damaged. | <ul style="list-style-type: none"> ● Reinsert plug properly. ● Do not play damaged tapes. |
| REC/PAUSE button fails to function. | <ul style="list-style-type: none"> ● No cassette tape loaded. ● Protective tabs are broken off. | <ul style="list-style-type: none"> ● Load a cassette tape. ● Change tape or cover protective hole with adhesive tape. |
| Sounds become faint and sometimes inaudible. | <ul style="list-style-type: none"> ● Head is dirty. ● Head is magnetized. ● Tape is damaged or of poor quality. | <ul style="list-style-type: none"> ● Clean head. ● Demagnetize head using head demagnetizer. ● Change to a different tape. |
| Recorded sound is distorted. | <ul style="list-style-type: none"> ● Tape is bad (stretched, deformed, etc.). ● Cassette shell is warped. ● Recording level is too high. | <ul style="list-style-type: none"> ● Replace with a fresh tape. ● A warped cassette shell cannot be fixed. Replace with another tape and test. ● Check input level with signal level meter and use lower rec level when recording. |
| Tape is playing back, but no sound is heard. | <ul style="list-style-type: none"> ● Faulty connection between deck and stereo amplifier/receiver. | <ul style="list-style-type: none"> ● Check and secure connections. |
| Excessive noise. | <ul style="list-style-type: none"> ● Head is dirty. ● Head is magnetized. ● Worn out or poor quality tape. ● Connection(s) improperly made. ● Affected by external electrical noise. | <ul style="list-style-type: none"> ● Clean head. ● Demagnetize head with head demagnetizer. ● Change to better tape. ● Check input and output connections and reinsert properly. ● Move deck away from electrical appliances (TV, fluorescent light, electric blanket, etc.). |
| Excessive wow (wavering of the sound). | <ul style="list-style-type: none"> ● Dirty capstan, pinch roller, etc., or poor tape. ● Tape is wound unevenly. | <ul style="list-style-type: none"> ● Clean capstan and pinch roller, or change to better tape. ● Rewind tape. |
| Tape stops in the middle of recording or playback. | <ul style="list-style-type: none"> ● Slack tape, or tape spillage wound around capstan. | <ul style="list-style-type: none"> ● Insert pencil in hole in cassette shell and turn to take up slack. |
| Fails to record. | <ul style="list-style-type: none"> ● REC LEVEL control is set to too low. ● Protective tabs are broken off. | <ul style="list-style-type: none"> ● Adjust REC LEVEL control. ● Change tape or cover protective hole with adhesive tape. |
| Search does not operate correctly. | <ul style="list-style-type: none"> ● Blank section is too short. ● Recorded section has low-level portions. ● Conversation, etc. has been recorded. | <ul style="list-style-type: none"> ● Blank sections must be at least 4 seconds long. ● No remedy ● No remedy |
| High frequencies in the playback sound are emphasized and unpleasant to listen to, and noise level (hiss) is also high. | <ul style="list-style-type: none"> ● Dolby NR-recorded tape is played back in OFF position. | <ul style="list-style-type: none"> ● Play back in appropriate Dolby NR position. |
| Playback sound is muffled and high frequencies are inaudible. | <ul style="list-style-type: none"> ● Normally-recorded tape is played back in Dolby NR. ● Heads are dirty. ● Heads are magnetized. | <ul style="list-style-type: none"> ● Play back in OFF position. ● Clean heads and carry out demagnetization with head demagnetizer. |
| When playing back tapes recorded on other decks, meter deflections are greater (smaller) than when recorded. | <ul style="list-style-type: none"> ● Basic levels are different for different cassette decks. | <ul style="list-style-type: none"> ● This is not a fault. |
| The remote control transmitter cannot be operated. | <ul style="list-style-type: none"> ● The batteries are exhausted. ● The remote control transmitter is operated from an incorrect distance or angle. ● The remote control sensor is lighted strongly. | <ul style="list-style-type: none"> ● Replace batteries. ● Operate it from less than 7 meters (about 23 ft.) and 30°. ● Place the unit away from the strong light. |

SPECIFICATIONS

| | |
|--|--|
| Type | Auto reverse 4-track, 2-channel recording and playback stereo double cassette deck |
| Motors | DC servo motor x 2 (main) |
| Heads | Recording/playback: Hard Permalloy x 2 Erase: Double-gap Ferrite x 2 |
| Rapid Transport | 100 sec. (C-60) |
| Wow and Flutter | |
| WRMS | 0.08% |
| W.Peak | ±0.15% |
| Signal-to-Noise Ratio | |
| (Dolby NR off) | 58 dB |
| (Dolby B NR on) | 66 dB |
| (Dolby C NR on) | 74 dB |
| Frequency Response (-20 dB) | |
| Type I/Normal | 20 ~ 17,000 Hz ±3 dB |
| Type II/High (CrO ₂) | 20 ~ 18,000 Hz ±3 dB |
| Type IV/Metal | 20 ~ 20,000 Hz ±3 dB |
| Harmonic Distortion | less than 0.8% |
| Input Sensitivity/Impedance | |
| Line | 100 mV/40 k-ohms |
| Output Level | |
| Line | 570 mV/1.8 k-ohms |
| Phones | 0.23 mV/8 ohms |
| Channel Separation (1 kHz) | more than 40 dB |
| Crosstalk (125 Hz) | more than 55 dB |

GENERAL

Power Supply

U.S.A. and Canada model 120 V, 60 Hz

Europe model 230 V, 50 Hz

U.K. model and Australia model 240 V, 50 Hz

General model 110/120/220/240 V, 50/60 Hz

Power Consumption 19 W/9 W (POWER OFF) (KX-W582)

17 W/7 W (POWER OFF) (KX-W482)

Dimensions (W x H x D) 435 x 126 x 280 mm
(17-1/8" x 4-15/16" x 11")

Weight 5.1 kg (11 lbs. 4 oz.) (KX-W582)

5.0 kg (11 lbs.) (KX-W482)

Accessory

Audio cord 1 pair

* Specifications subject to change without notice.

YAMAHA

YAMAHA ELECTRONICS CORPORATION, USA 6660 ORANGETHORPE AVE., BUENA PARK, CALIF. 90620, U.S.A.

YAMAHA CANADA MUSIC LTD. 135 MILNER AVE., SCARBOROUGH, ONTARIO M1S 3R1, CANADA

YAMAHA ELECTRONIK EUROPA G.m.b.H. SIEMENSSTR. 22-34, D-2084 RELINGEN, BEI HAMBURG, F.R. OF GERMANY

YAMAHA ELECTRONIQUE FRANCE S.A. 17 RUE DES CAMPANULES, LOGNES 77321 MARNE LA VALLEE CEDEX 2 FRANCE

YAMAHA ELECTRONICS (UK) LTD. YAMAHA HOUSE, 200 RICKMANSWORTH ROAD WATFORD, HERTS WD1 7JS, ENGLAND

YAMAHA SCANDINAVIA A.B. J A WETTERGRENS GATA 1, BOX 30053, 400 43 VASTRA FRÖLUNDA, SWEDEN

YAMAHA MUSIC AUSTRALIA PTY, LTD. 17-33 MARKET ST., SOUTH MELBOURNE, 3205 VIC., AUSTRALIA

YAMAHA CORPORATION