



**POWER SUPPLY (PW) BENCH
CHECK JUMPERS**

YAMAHA CORPORATION OF AMERICA
6600 Orangethorpe Avenue, P.O. Box 6600
Buena Park, CA 90622-6600 (714) 522-9011

DISCLAIMER

Every reasonable effort has been made to insure that this document contains accurate information however, no responsibility is assumed for the use of this material or for any inaccuracies and/or omissions that may exist.

COPYRIGHT NOTICE

Copyright 2000

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, transmitted in any form by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of YAMAHA.

YAMAHA ® is a registered trademark

PW BENCH CHECK JUMPER

When bench testing the PW Power Supply without a console connected, you must jumper certain pin at the DC output plug. Please see the list below:

PW5000 POWER SUPPLY FOR PM5000 Connector Wiring

PIN	FUNCTION		PIN	FUNCTION
1	-16V		15	+16V
2	-16V		16	+ - 16V GND
3	FRAME G		17	+12VG
4	-16V		18	+12CG
5	-16V		19	+48V
6	+ - 16V GND		20	CAUTION LED
7	+12VG		21	+16V GND
8	REMOTE		22	+12V
9	+16V		23	+12V
10	+16V		24	+48V GND
11	+ - 16V GND		25	+12V
12	+12VG		26	+12V
13	REMOTE		27	+12V
14	+16V			

PW5000 for PM5000 **To bench test short pins:** **3, 6, 7, 8, 11, 12, 13, 16, 17, 18, 21, 24**

PW4000: Power supply for PM3500, PM3500M, PM4000 and PM4000M

Connector Wiring

PIN	FUNCTION	PIN N	FUNCTION	PIN N	FUNCTION
1	-19V (blue)	10	19 GND (Black)	19	PM CAUTION (+) (white)
2	-19V (blue)	11	19 GND (black)	20	+48V (orange)
3	FRAME GND (green)	12	12 GND (white)	21	48V GND (brow)
4	-19V (blue)	13	+19V (red)	22	+12V (purple)
5	-19V (blue)	14	+19V (red)	23	+12V (purple)
6	FRAME GND (green)	15	19 GND (black)	24	PW CAUTION (red)
7	FRAME GND (green)	16	19 GND (black)	25	REMOTE (red)
8	+19V (red)	17	12 GND (white)	26	REMOTE (white)
9	+19V (red)	18	12 GND (white)	27	+12V (purple)

Need 3 jumpers to turn on the Power Supply

- Jumper 1 Connected the Pin 3 and Pin 10 to Pin 25 and 26.**
- Jumper 2 Connected the Pin 7 to Pin 12.**
- Jumper 3 Connected the Pin 6 to Pin 21.**

PW3000M: Power Supply for M3000, M3000A and M2500

Connector Wiring

PIN 1	Power supply remote (brow)
2	+15 (red)
3	GND15V (black)
4	GND 48V (black)
5	-15V (blue)
6	+12V (yellow)
7	GND 12V (black)
8	Power supply remote (white)
9	48V (orange)
10	FRANE GND (black)

**Need 1 jumper to turn on the Power Supply
Connected Pin 1 to Pin 7 and Pin 8**

PW3000MA: Power Supply for M3000, M3000A and M2500

Connector Wiring

Pin 1	Power supply remote (brow)
2	+15 (red)
3	GND15V (black)
4	GND 48V (black)
5	-15V (blue)
6	+12V (yellow)
7	GND 12V (black)
8	Power supply remote (white)
9	48V (orange)
10	FRANE GND (black)

**Need 1 jumper to turn on the Power Supply
Connected Pin 1 to Pin 7 and Pin 8**

PW2000M Power Supply for M2000

Connector Wiring

PINS	FUNCTIONS
1	E 48V (GY)
2	E 12V (white)
3	E 17V (black)
4	+48V (orange)
5	+12V (brown)
6	+17V (red)
7	-17V (blue)
8	FRANE GND (green)
9	DETECT A (purple)
10	DETECT B (BLU)

**Need 1 Jumper for turn on Power Supply
Connected Pin 9 to Pin 10**

PW1800: Power Supply for PM1800 and PM1800A

Connector Wiring

PINS	FUNCTION
1	E 48V(black)
2	E 12V (white)
3	E 17V (black)
4	+48V (yellow)
5	+12V (brown)
6	+17V (red)
7	-17V (blue)
8	FRANE GND (green)
9	DETECT A (purple)
10	DETECT B (GREEN)

**Need 1Jumper for turn on Power Supply
Connected Pin 1 to Pin 10**

PW3000 and PW3000A for PM3000

Connector Wiring

CONNECTOR A		CONNECTOR B	
PIN	FUNCTION	PIN	FUNCTION
1	+20V	1	+12V
2	DETECT A	2	+48V
3	-20V	3	E(+48V)
4	+20V	4	+12V
5	+20V	5	+12V
6	-20V	6	E(+12V)
7	-20V	7	E(+12V)
8	E (+ 20V)	8	GND
9	E (+20V)	9	DETECT B
10	E (+20V)	10	E(12V)

The PW3000 and PW3000A need to 2 Jumpers for tune on power.

Jumper 1 Connector A Pin 2 to Connector B Pin 9.

Jumper 2 Connector A Pins 8, 9 and 10 to Connector B Pins 3, 6, 7, 8 and Pin 10

PW800 Power Supply for PM5D

Connector Wiring

PIN	FUNCTION		PIN	FUNCTION
1	+24V		13	GND
2	+24V		14	GND
3	+24V		15	GND
4	+24V		16	GND
5	+24V		17	GND
6	+24V		18	GND
7	+24V		19	CAUTION (+)
8	+24V		20	CAUTION (-)
9	+24V		21	DETECT A
10	GND		22	DETECT B
11	GND		23	DETECT GND
12	GND			Frame GND

PW800 need 1 Jumpers

Short Pins

Pin 21, 22 and pin 23