

AUGUSTA CM45

High-Power FM/AM/Cassette Receiver with CD Changer and Detachable Face

Autoradio/Cassette AM/FM de Forte Puissance à Face Amovible avec Changeur du CD

Receptor FM/AM/Reproductor de Cassette de Alta Potencia y con Carátula Desmontable y Cambiador de CD

Rádio FM/AM/Toca-Fitas de Alta Potência com Face Removível e Cambiador CD



BLAUPUNKT®

Bosch Group

FCC Warning

The equipment has been tested and found to comply with the limits for a Class B device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and, if not installed and used in accordance with instructions, may cause harmful interference with radio communications. However, there is no guarantee that radio interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet or circuit different from that which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

Owner's Record

The model and warranty numbers are located on the top of the unit. Record the serial number in the space provided below. Refer to these numbers whenever you call upon your Blaupunkt dealer regarding this product.

Warranty Number _____

Attach Sales Receipt Here

Table of Contents

English

FCC Warning	2
Owner's Record	2
Features	4
Precautions	4
Detachable Face	5
Electrical Connections and Installation	6
Installation	8
Maintenance	10
Specifications	11
Location of Controls	12
Instructions—General Operation	13
Radio Operation	14
Cassette Player Operation	16
CD Changer Operation	17
Troubleshooting Guide/Error Codes	19

Features

Congratulations on your purchase of this Blaupunkt FM/AM/Cassette Receiver. Its Optimum Reception Control (ORC III) quartz FM and AM Tuner and high-quality, multi-featured cassette tape player provide the ultimate in sound reproduction. The 2 x 25/4 x 7 watt amplifier and 2 RCA preamp outputs provide you with many system configuration possibilities. Its ability to control a Blaupunkt CDC-M7 (or CDC-M5) Changer provides you with the ability to have superior CD playback through your car's audio system.

- Tuner Features:
 - ORC III Tuner
 - 12 FM/6 AM Station Presets, Including 6 FM & 6 AM Travel Store Presets
 - Station Scan & Preset Scan
 - Automatic and Manual Tuning
 - Local/Distant Reception Control
 - ASU Impulse Noise Quieting
- Cassette Features:
 - Auto-Reverse Cassette Mechanism
 - True Fast-Forward/Rewind
 - Hard Permalloy Tape Head
 - Radio Monitor
- CD Changer-Control Features:
 - Controls a Blaupunkt CDC-M7 or CDC-M5 CD Changer
 - Disc and Track Up/Down
 - Disc and Track Mix, Repeat, and Scan
 - Cue/Review
 - Pause/Play
- Audio Features:
 - 2 x 25/4x7 Watt Integrated Amplifier
 - 2-Channel RCA Preamp Output: 2.2 volts max. with less than 1% THD @ 100% Modulation
 - Dual-Level Fader
 - Volume/Balance/Fader Controls
 - Adjustable Turn-On Volume-Level
 - Loudness Button
 - Separate Bass and Treble Controls
- General Features:
 - Fully-Detachable Faceplate for Security
 - Smooth-Profile Hardshell Case
 - Switchable Clock/Function LCD Display
 - Ignition-Off Clock Recall
 - Amber Illumination
 - Detachable Wire Harness w/Bullet Connectors
 - 178 x 50 x 152 mm (7 x 2 x 6 in.) DIN/ISO Chassis
 - Snap-In DIN Sleeve & Mounting Hardware

Your unit's fully-detachable front faceplate makes the unit useless to would-be thieves.

Precautions

- If your vehicle was parked in direct sunlight resulting in a considerable rise in temperature inside the vehicle, allow the unit to cool off before operating your unit.
- If no power connection is supplied to the unit, check the connections first. If everything is in order, check the fuse.
- If no sound comes from the speakers of a two-speaker system, set the fader control to the center position.
- You are cautioned that any changes or modifications not expressly approved in this manual could void your warranty.
- If you have any questions or problems concerning your unit that are not covered in this manual, please contact your Blaupunkt dealer.

Detachable Face

Detaching & Attaching the Face:

The face of this unit can be detached and taken with you to prevent it from being stolen.

Detaching the Face:

Before detaching the face, be sure to press the PWR Button first. Then press the REL (Release) Button and detach the face by gently pulling it off as illustrated.

Note: Do not pull it straight out from the chassis. Be sure not to drop the face when detaching it from the chassis.

Attaching the Face:


Apply the right hand side of the face to the chassis by sliding (part B) of the face to (part A) at the front of the chassis. Gently push the left side of the face against the front of the chassis until it snaps into place.

Note: Make sure that the face is inserted right side up. Do not press against the display window. Do not press hard against the face when attaching it to the chassis, it may be easily attached with gentle pressure. When carrying the face with you, put it in the carrying case. Do not expose the face to direct sunlight, heat sources such as hot air ducts or leave it in a humid place. Never leave it on the dash board of a vehicle parked in direct sunlight, where there may be a considerable rise in temperature inside the vehicle.

Affixing Faceplate For Retail Display:

The faceplate can be affixed to the unit's chassis, which is desirable for a retail display, for example. **This should only be done in situations where the unit can be accessed from behind the mounting surface. Once the faceplate is affixed, the release keys cannot be used to remove the chassis.**

To affix the faceplate: A Unscrew the bolt at the left front side of the unit. (See* below.)
B. Attach Faceplate C. Obtain longer black bolt from hardware pack and screw it into the same hole.



Electrical Connections and Installation

! To avoid the aggravation of costly mistakes and serious damage that could make you feel this way, please carefully read all of the instructions before you begin. Carefully follow all instructions. You'll be glad you did!

GENERAL RECOMMENDATIONS

- If you're not confident that you can install the unit correctly, have it installed by a qualified Blaupunkt installation technician.
- Use this unit only with negative ground 12 Volt (11-16 Volt) direct current (DC).
- Be sure to detach the faceplate before you start to connect or install the unit.
- We recommend making and testing all electrical connections before installing the unit. Connect the leads (wires) according to instructions and diagram below.

ELECTRICAL CONNECTION INSTRUCTIONS

1. Disconnect the vehicle battery's negative terminal before making connections.
2. Connect the speakers and/or external amplifiers (if you have any) following the guidelines in the SPEAKER CONNECTION section below.
3. Connect the blue (trigger output) lead to the amplifier's trigger input terminal and/or antenna motor trigger input terminal (if you have either or both of these items). The combined total amperage required for triggering the antenna motor and/or amplifier must not exceed 100 mA. DO NOT connect the blue lead to the antenna's and/or amplifier's power supply input.
4. Connect the black (power ground) lead to a grounded metal part on the vehicle. We recommend grounding all audio system black ground leads (head unit, external amplifier, etc.) to a common grounding point, preferably a non-painted surface under the instrument panel.
5. Connect the yellow (constant power) input lead to a source of constant battery power, preferably a terminal to an appropriate slot in the fuse box.
6. Connect the red (turn-on power) input lead only after the other leads are connected. Be sure to connect the red lead to a positive (+) 12 Volt power terminal that is energized only when the ignition key is set to the on position or accessory position.
7. Cover the ends of any unused leads with electrical tape. This will prevent them from touching the vehicle or each other and causing a short-circuit and damage to the radio or vehicle.
8. Reconnect the vehicle's battery.
9. Verify that no fuses have blown.
10. Plug the harness into the unit.
11. Attach the faceplate and test the unit.

Once the connections have been successfully made, you can begin to mount the unit.

SPEAKER CONNECTIONS

The unit's Dual-Level Fader allows you to fade between the front speaker leads and the rear speaker leads and/or the rear preamp outputs, providing you flexibility in configuring your speaker arrangement:

- You can connect a speaker (regular, co-axial or tri-axial speakers or component speaker system, all hereafter referred to simply as "speaker") to each of the units' four pairs of speaker leads and realize 4 x 7 watt output.

If you wish to have the speaker leads provide 2 x 25 watts to one pair of speakers, connect each speaker *as shown on the bridge mode diagram*. (See BRIDGE MODE diagram.) The unit will then fade between these speakers and the preamp outputs.

- You can connect the 2 RCA preamp outputs to external amplifiers and power speakers through the amplifiers. (Blaupunkt amplifiers and speakers available separately).

Connecting the Speaker Leads


To prevent short circuits or serious damage to the unit and/or speakers:

- Connect the speaker leads only as indicated in the wiring diagram.
- Only use speakers that have impedance ratings of 4 ohms or higher and have power-handling capabilities greater than the head unit's stated power level.
- The unit's internal amplifier is designed to handle a 4-ohm load on each pair of speaker leads.
- DON'T connect two speakers to a single pair of speaker leads ("in parallel") unless both speakers each have at least 8 ohms impedance.
- DON'T connect the left and right speaker leads to each other or to the same speakers.
- DON'T connect the negative speaker leads to each other.
- DON'T connect the positive speaker leads to each other.
- DON'T connect any active speakers (with built-in amplifiers) to the speaker leads.

Connecting the Pre-Amp Outputs to External Amplifier(s)

To prevent short circuits or serious damage to the head unit, amplifier, and/or speakers:

- Follow the amplifier's instructions on how to connect the unit's preamp outputs to the amplifier(s) and connect the speaker(s) directly to the amplifier.



CD Changer Connection

Follow the instructions that come with the changer.

Resetting the Unit


After all of the electrical connections have been completed, but before operating the unit for the first time (or after reconnecting the car battery, etc.) hold down the SENS button for 5 seconds while the unit is off. "—" will appear when reset begins.

Installation

Recommendations


- Carefully choose the mounting location so that the unit won't interfere with normal driving.
- Avoid mounting locations where the unit would be subject to high temperatures, such as from direct sunlight or hot air from the heater, or where it would be subject to dust, dirt or excessive vibration.
- The illustration below shows a typical installation, however, you may need to adjust the installation, depending on the unit. If you have questions or need additional installation hardware, consult your Blaupunkt dealer.
- Make sure the unit is firmly anchored (preferably at both front and back) and does not vibrate.


Mounting Hardware



Mounting The Unit in Most Dashboards

- 1 Install the Sleeve (1) in the dashboard.
- 2 Select and bend the appropriate tabs to hold the sleeve firmly in place.
- 3 A. Attach the Mounting Strap (2) to the underside of the dashboard, using screw.
B. Attach the back of the unit to the mounting strap using the support stem bolt and hardware.







Mounting the Unit in a Japanese Car


You may have difficulty mounting this unit in some Japanese cars that have ISO mounting features. In this case, consult your Blaupunkt dealer.

- 1 Run a blade along the slits on the back of the front trim ring and separate it from the unit. Discard the trim ring.
- 2 Use the vehicle's own mounting hardware to attach the unit.



Removing the Unit

Use the Release Key as shown below. Keep it in a safe place in case you need it in the future.



Release Key Instructions

1. Insert the key into the left side.
2. Use key to pull left side of unit slightly away from dashboard, out of locked position.
3. Insert the key into the right side.
4. Use key to pull right side of unit slightly away from dashboard, out of locked position.
5. Pull unit straight out from the bracket.

Maintenance

Fuse Replacement

When replacing the fuse, be sure to use one with the correct amperage, which will be stated on the fuse case. Never use a fuse that has a stated amperage exceeding the one supplied for this unit, as this could cause malfunction and serious damage to the unit.

Cleaning the Connectors

The unit may not operate properly if the connectors between the unit and the face are contaminated with dirt. In order to prevent this from happening, remove the face from the unit by pressing the REL (Release Button), then detach it and clean the connectors from time to time. Clean the connectors with a cotton swab and isopropyl alcohol (90% or higher). Be sure to clean them with a horizontal motion. Never clean them vertically, because this could damage the contact points.

Specifications

Audio Power Specifications

Power Output and Total Harmonic Distortion: 5.5 watts per channel minimum continuous average output into 4 ohms, 4 channels driven, from 30-15,000 Hz with no more than 1% total harmonic distortion. (14 watts per channel in Bridge Mode)

Other Specifications

Tuner

FM

Tuning Range:	87.5 - 107.9 MHz
Intermediate Frequency:	10.7 MHz
FM Mono Sensitivity:	18 dBf
Seek lo sensitivity:	51 dBf
Seek sensitivity:	31 dBf
Selectivity:	80 dB at 400 kHz
Signal-to-Noise Ratio:	65 dB (stereo), 70 dB (mono)
Harmonic distortion at 1 kHz:	0.7% (stereo), 0.5% (mono)
Separation:	30 dB
Frequency Response:	30 - 15,000 Hz \pm 3 dB

AM

Tuning Range:	530 - 1,710 kHz
Seek lo sensitivity:	50 dB μ V
Seek sensitivity:	30 dB μ V
Intermediate Frequency:	450 kHz
Signal-to-Noise Ratio:	45 dB

Audio

Speaker Impedance:	4-8 ohms
Maximum Amp Power (at 14.4V):	2 x 25/4x7 Watts (at 4 ohms)
RMS Power:	2 x 14/4x5.5
Bass Control:	\pm 10 dB @ 100 Hz
Treble Control:	\pm 10 dB @ 10 kHz
Loudness:	+ 14 dB @ 100 Hz & + 3 dB @ 8 kHz
Preamp Outputs:	2-CH RCA
Preamp Output Voltage:	2.2 volts maximum @ 100% Modulation with < 1% Total Harmonic Distortion

Cassette


Signal-to-Noise Ratio:	55 dB
Tape Wow and Flutter:	0.10%
Tape Frequency Response:	30-18,000 Hz \pm 3 dB

General

Dimensions (w/o projecting parts/controls):	178 x 50 x 152 mm 7 x 2 x 6 in.
Mass:	Approx. 1.4 kg (3.0 lb.)
Power Requirement (neg. grnd.):	12 V DC car battery
Operating Temperature:	15°F to 120°F, -10°C to 50°C
Supplied Accessories:	<ul style="list-style-type: none">• Unit• Faceplate• Faceplate Carrying Case• DIN Sleeve• Mounting Hardware• Owner's Manual in English, French, Spanish and Portuguese

Design and specifications subject to change without notice.

Location of Controls



- | | |
|--|---|
| <ol style="list-style-type: none"> 1. REL (Release) Button 2. PWR (Power) Button 3. Cassette Eject Button 4. Cassette Door 5. FR (Fast-Rewind) Button 6. FF (Fast-Forward) Button 5&6 PROG (Program Change) Buttons 7. SENS (Reception Sensitivity)/
LD (Loudness) Button/Changer Reset 8. + Button:
Volume +
Bass +
Treble +
Balance Left
Fade To Front 9. - Button:
Volume -
Tone +
Balance Right
Fade to Rear 10. ^ Button
Seek and Manual Radio Tuning (Up)
Preset Scan
Clock Hour Adjustment | <ol style="list-style-type: none"> 11. V Button
Seek and Manual Radio Tuning (Down)
Station Scan
Clock Minute Adjustment 12. SRC (Source Select)/TS (Travel Store)
Button
Clock 00.00 13. AUD (Audio Select)/Clock Button
Temporary Display Change
Bass Mode
Treble Mode
Balance Mode
Fader Mode
Volume Mode
Display Priority Change
Clock Adjustment Access 14. LCD Display Window 15. FM/AM Preset Buttons 16. (CD) DISC ^ / RM (Radio Monitor) Button 17. (CD) RPT (Repeat) Button 18. (CD) MIX Button 19. (CD) DISC v / Button 20. (CD) SCAN 21. (CD) Pause Button |
|--|---|

Instructions — General Operation

Turning Unit On

Vehicle ignition must be on. To turn unit on, press PWR Button (2) or insert a tape.

Turning Unit Off

Press the PWR Button (2) to turn the unit off.

SRC Button

Press the SRC (Source Button) as needed to access the following sources

FMI → FMII → AM → Cassette (if already inserted) → CD Changer (if connected)

Volume

Press the + and – Buttons (8 & 9) to quickly increase or decrease the volume to the desired level. The volume level is indicated in the Display Window (14). To make a fine adjustments to the volume level, press the other volume button before the volume level disappears from the display. You can then gradually adjust the volume in either direction, making precise adjustment easy.

Adjustable Turn-On Volume

First adjust the volume to the (maximum) volume level desired when the unit is turned on. Press and hold the PWR Button (2) for more than two seconds. The unit turns off and the turn-on volume level is memorized. When the unit is turned on, the volume will be at the memorized level, even if the unit was turned off while the volume was at a higher level. However, if the volume is turned off when the volume level is lower than the stored Turn-On volume level, the volume will be at the lower level when the unit is turned back on.

Loudness Button

Press the LD Button (7) to increase sound level of low frequencies, especially when listening at low volume levels. (The increase is centered at 100 Hz, where the increase is 14 dB.) The "LOUD" indicator appears in the display. To cancel, press this button again.

Setting the Clock

Turn the unit on. Press the AUD Button (13) for four seconds until the clock starts blinking. (The display will change after two seconds. Ignore this and continue to hold for two more seconds.) Once the clock starts blinking, Press the \wedge (10) to set the hour, and press the V Button (11) to set the minutes. (To change the minute indicator to the nearest hour (:00), you can press the BND Button. The clock re-activates when the AUD Button is pressed or after 10 seconds.

Changing the Information Displayed

- **To change the display priority** from clock to function or function to clock, press the AUD Button (13) for two seconds. The display priority changes. In the radio mode, the display priority choices are clock and radio frequency. In the CD mode, the display priority choices are clock, track number, and elapsed track time.
- **To change the display temporarily** from clock to function or function to clock, press and release the AUD Button (13).* After *five* seconds, the display changes back to the priority information.

Ignition-Off Clock Recall


You can check the time when the vehicle ignition is off by simply pressing the AUD Button. The time stays displayed for five seconds.

Bass and Treble

Press AUD (Audio Select) Button (13) twice to select the Bass mode, three times for the Treble mode. The level is indicated in the Display Window (14). Press the + Button (8) or – Button (9) to increase or decrease the level.*

Balance

Press AUD Button (13) four times to select the Balance mode. The balance is indicated in the Display Window (14). Press the + Button (8) to increase the left speaker output or press the – Button (9) to increase the right speaker output to the desired level.*



Fader

Press AUD Button (13) five times to select the Fader mode. The level of output for front and back speakers is indicated in the Display Window (14). Press the + Button (8) to decrease the rear speaker output. Press the – Button (9) to decrease the front speaker output.*

* Five seconds after you complete your adjustments, the unit will automatically return to the volume mode and the display will revert back to the priority display, clock or function. You can also press and release AUD as needed to return to VOLUME, which appears after FADER in the AUD Button cycle.

AUD Button Summary

- Pressing and releasing the AUD Button accesses these modes in this succession:
- Temporary Display Change, Bass, Treble, Balance, Fader, Volume. Pressing the AUD Button for two seconds changes the display priority between clock and function.
- Pressing the AUD Button for four seconds accesses the time adjustment mode.
- While in any AUD mode, if no button is pressed for *four* seconds, the unit returns to the volume adjustment mode and priority display.

Radio Operation

Band Selection

The indicator for the active band (FMI, FMII or AM) appears in the Display, along with the radio frequency being received.

Automatic Stereo/Mono Reception Adjustment

When an FM stereo program with a signal strength of at least 50 dBf is tuned in, the stereo indicator ("Ⓞ") appears in the Display Window. If the FM stereo program is weak and noisy, the unit automatically blends the signals, eliminating the noise and gradually converts to the monaural or "mono" mode. The stereo symbol will disappear from the Display.

Search Sensitivity

To have the seek and station scan tuning stop only at strong local stations, press the LD Button (7) for two seconds intervals, as needed, until "SEEK and lo" appear in the display.

To allow all receivable stations to be received, press the LD Button (7) for two seconds intervals, as needed, until "lo" disappears in the display. Automatic tuning will now stop at ALL receivable stations, weak or strong.

Automatic Seek Tuning

Select the desired band AM or FM. Press and release the \wedge and V Buttons (10 and 11) to seek the next receivable station. To stop seeking and return to the previous frequency, press the other of the \wedge and V Buttons.

Adjusting The Tuning Criteria

Pressing the LD Button (7) for two seconds to advance to the next step in the following cycle of Tuning options:

“SEEK lo” (local stations) —> “SEEK” (distant stations as well as local stations)...

Manual Tuning

Press the \wedge or V Button for between 1/2 and 3 seconds to activate manual tuning and locate nearby frequencies. If the button is released within that time, the unit remains in the manual tuning mode for 10 seconds. This allows you to easily manually access additional frequencies, such as when storing remote stations on preset buttons. To more quickly return to seek tuning, press the SENS Button for 2 seconds. (If the \wedge is held for more than three seconds, Preset Scan is activated. (If the V is held for more than three seconds, Station Scan is activated.)

Station Scan Tuning

To review all receivable stations on a band, select AM or FM band, as desired, then press the V Button (11) for 3 seconds. (During the 3 seconds unit goes into manual tuning. Scan begins after three seconds at the frequency at which manual tuning began.) Each station receivable under the current tuning mode will be scanned, in order, for 8 seconds. To stop the scanning and listen to the station being received, press the V Button again.

Preset Tuning

Up to 12 FM and 6 AM stations can be stored in preset memory.

1. Tune in a desired station, either manually or automatically, on the desired Band, AM, FMI, and FMII.
2. Press and hold any one of the six Preset Buttons (15). The Preset Button number will appear in the Display Window. After two seconds, the frequency will blink twice, indicating that the station has been stored in the Button's memory storage for that Band.
3. Repeat the above procedure with the rest of the presets for each Band, as desired.
4. To select a preset station, select the desired band, then press and release the desired Preset Button.


Preset Scan

To review the stations stored in the Preset Buttons, select AM or FM band, as desired, then press the \wedge Button (10) for 3 seconds. (During the 3 seconds unit goes into manual tuning. Scan begins after three seconds. Scan begins after three seconds at the frequency at which manual tuning began.) Once all of the presets stations have been scanned, the unit returns to seek tuning. All of the stations stored in memory will be scanned, in order, for the 8 seconds. If any of the preset frequencies are not receivable with a signal strength of at least 20 dBf, they will be skipped over. To stop the scanning and listen to the station being received, press \wedge Button (10) again.

Travel Store

This feature allows you to automatically store 6 receivable FM and 6 receivable AM stations, which is especially handy when you travel to a different reception area.

Select the desired band, FM or AM. Then press the TS Button for two seconds. Beginning with the last station that was received on that band, the unit automatically scans the band first for stations receivable with a minimum 90 dBf sensitivity, then with the lo and distant seek sensitivity levels. The unit stores the six most-receivable stations and switches to preset 1 on the that band. The presets on the other bands will not be affected.



Cassette Player Operation

Cassette Tape Play:

- Insert cassette into Cassette Door (4). Note: Make sure that the side of the cassette with the tape exposed is facing to the right side and that all slack has been removed from the tape prior to insertion.
- The insertion of the cassette will automatically override the radio, and the cassette will begin to play. When the cassette deck is being used, the display will indicate which direction the tape is going.
- The tape will continue to play until ejected after which the radio will play.

Auto-Reverse Tape Function

- Automatic: When the end of the tape (side A or B, program 1 or 2) is reached, the tape will automatically reverse direction and play the other side of the tape.
- Manual: To reverse tape direction during playback, press the PROG (Program) Buttons (5 & 6). The change in direction and in tape program will be confirmed in the Display.

Fast Winding of Tape

- To fast-rewind the tape, press the FR Button (5).
- To fast-forward the tape, press the FF Button (6).
- When the unit is fast-winding, the display blinks.
- To stop fast winding, press the other fast-wind button, FR or FF.

Ejecting The Tape

Press the Cassette Eject Button (3) to eject the tape.

Radio Monitor — This feature allows you to have the radio play when a tape is being rewound or fast-forwarded. To activate, press the RM Button (16). RM appears in the Display when the cassette tape is in use. To deactivate, press this button again.

CD Changer Operation

This unit can control either a Blaupunkt CDC-M7 or CDC-M5 CD Changer. (Please note that this unit is not designed to control the CDC-M5's Disc Naming and Track Program Memory features.)

Resetting the Unit

After all of the electrical connections have been completed, but before operating the unit for the first time (or after reconnecting the car battery, etc.) hold down the SENS button for 5 seconds. "—" will appear when reset begins.

Loading the CD Changer

Insert discs into the changer's magazine following the changer's instructions.

To Activate Your CD Changer

Press the SRC Button (12) as many times as needed to locate and activate the CD changer. Once the changer is activated, the Display then shows the Disc Number and the Track Number. If you press the SRC Button (12) during CD play, the CD play will automatically stop and the next available audio source will be activated (FM).

FM1 → FM2 → AM → Cassette → CD Changer...

Track Up/Down

To go to the next track, press the Track \wedge Control (10). Track number appears in the Display. To go back to the beginning of the track being played, press the Track \vee Control (11).

Cue and Review

- To move ahead within a track, press and hold the Track \wedge Control (10) for audible cue.
- To go back within a track, press and hold the Track \vee Control (11) for review.

Changing the Information Displayed

(See page 13)

Pause

Press the Pause Button (21) during playback. Play will stop. Press again to resume play.

At the End of the Disc

The track number returns to "1" and the disc is repeated from the beginning of the disc.

Disc Up/Down

- To move ahead to the next disc, press the DISC \wedge Control (16).
- To go back to the previous disc, press the DISC \vee Control (19).

Track Scan

Press the SCA Button (20) to hear the first 10 seconds of each track before automatically advancing to the next track. The track number blinks in the Display to indicate that Track Scan is underway. Press this button again to listen to the desired track. If the SCA Button (20) is pressed during MIX play, the first 10 seconds of every track will be played randomly.


Disc Scan

To play the first 10 seconds of every disc, press the SCA Button (20) for two seconds during CD playback. The disc number blinks in the Display to indicate that scanning is underway. To cancel, press it again.

If the SCA Button (20) is pressed during MIX play, the first 10 seconds of every disc will be played randomly.

Repeat

Track Repeat — To play the currently selected track repeatedly, press the RPT Button (17) as needed until "RPT" appears in the Display.



Disc Repeat — To play the currently selected disc repeatedly, press the RPT Button (17) as needed until “dRPT” appears in the Display.

To cancel RPT or dRPT, press this button one or more times, as needed, to remove all RPT indications from the Display.

Mix Play

1-Disc Track Mix — To play the tracks on the currently-selected disc in random order, press the MIX Button (18) as needed until “MIX” appears in the Display. (You can use also MIX with dRPT to continuously mix the tracks on a single disc.)

All-Disc Track Mix — To play the tracks on all of the discs in the changer in random order, press the MIX Button (18) as needed until “dMIX” appears in the Display.

To cancel MIX or dMIX, press this button one or more times, as needed, to remove all MIX indications from the Display.

Troubleshooting Guide/Error Codes

The following check will assist in the correction of most problems which you may encounter with your unit. Before going through the check list below, refer back to the connection and operating procedures.

General

Trouble	Cause/Solution
No sound.	<ul style="list-style-type: none"> Adjust the volume with the + button. Set the fader control to the center position on the 2-speaker system.
Indications do not appear on the display window.	<ul style="list-style-type: none"> Remove the front panel and clean the connectors. See "Cleaning the Connectors" of "Maintenance" for details.

Radio reception

Trouble	Cause/Solution
Preset stations are not receivable.	<ul style="list-style-type: none"> The broadcast is too weak.
Automatic tuning is not possible.	<ul style="list-style-type: none"> The broadcast is too weak. → Use manual tuning.
Travel Store feature does not complete storing of six stations.	<ul style="list-style-type: none"> Not enough broadcast frequencies are receivable.

CD Operation

Trouble	Cause/Solution
Changer cannot be selected (using SRC Button).	<ul style="list-style-type: none"> Changer not connected properly.
No CD sound.	<ul style="list-style-type: none"> Changer not connected properly.
Error Code is displayed.	<ul style="list-style-type: none"> See Error Displays section below.
The sound stops due to vibration.	<ul style="list-style-type: none"> The changer is not installed on a sturdy part of the car. The road is unusually bumpy.

Error Displays

EJ	No magazine has been inserted.	The unit automatically moves to previous radio source.
no_d	There are no discs in magazine.	The unit automatically moves to previous radio source.
E-01 through E-10	The disc is dirty or upside down. (-01 to -10 indicates the disc number.)	The unit moves to the next disc.
E-90	Mechanical error.	The unit automatically shuts off. Make sure changer is properly connected. Before turning the unit on, press LD Button for 5 seconds to reset the unit. "----" appears in display. Turn the unit on again. Access CD changer via SRC Button. If it still shows error, contact your Blaupunkt dealer.
E-99	Electrical error.	The unit automatically shuts off. Make sure changer is properly connected. Before turning the unit on, press LD Button for 5 seconds to reset the unit. "----" appears in display. Turn the unit on again. Access CD changer via SRC Button. If it still shows error, contact your Blaupunkt dealer.

If the above mentioned solutions do not help to improve the situation, consult your nearest **Blaupunkt** dealer.