

NAD Digital Phono/USB Preamp PP 3



- Low noise, wide band MC/MM phono stage
- Connect your Turntable to most Amplifiers, Receivers, and PCs
- Switched Line Level Input
- Highly accurate Analog-to-Digital Converter
- USB interface to PC for Vinyl-to-Hard Drive recording, USB cable included
- Analog Line Level Output
- External 24V DC power supply

www.NADelectronics.com

INSTALLATION & OPERATION: Digital Phono/USB Preamp NAD PP 3

To Connect the Turntable to the PP 3

- Please make sure all ancillary equipment is turned off and that the NAD PP 3 is not yet connected to its dedicated Power Supply.
- Connect the leads from the turntable to the appropriate input sockets on the back of the NAD PP 3; MC for moving coil, MM for moving magnet cartridge. Make sure you connect the Right channel to the Right input; the Left channel to the Left input. Normally, Red connector denotes the Right Channel; White denotes the Left channel. Once the turntable leads are connected, set the MC/MM switch on the back of the NAD PP 3 to the correct input setting.

To Connect the PP 3 to an Amplifier or Receiver

- Connect suitable RCA leads from the NAD PP 3 to the amplifier or receiver. Always use a so-called "Line-Level" input such as CD, AUX, Tuner or Tape. Never connect the lead from the NAD PP 3 to an input marked Phono or turntable. Again, make sure to connect the Red plug to the Right channel, and the White plug to the Left channel of the amplifier or receiver.

- If the lead from your turntable is equipped with a separate earth (GND) lead, connect this directly to a ground connection on the NAD PP 3. Use the thumb screw terminal "GND" which provides the grounding.

Now connect the Power Supply to the PP 3

- Connect the dedicated Plug-in Power Supply to the NAD PP 3 (marked 24V).
- Insert the Plug-in Power Supply to a live mains socket; the green LED on the NAD PP 3's front panel will light up.
- Installation is now complete. As the power consumption of the NAD PP 3 is negligible, it can always be left switched on. It is recommended however that you disconnect the Plug-in Power supply from the mains if you are not going to use the NAD PP 3 for a prolonged period of time (such as a holiday).

To connect the PP 3 to a Personal Computer

- Connect the supplied USB cable (or any approved USB cable) between the USB socket of the PP 3 and the USB socket of your PC. Your PC should automatically recognize the PP 3 as a 'new device', and the Amber LED of the PP 3 will illuminate confirming the connection.
- Place the supplied "Vinyl Studio" CD in your PC's CD drive and follow the instructions to load the program into your PC. Open the program and follow the instructions to get started recording your LP's to your PC's Hard Disc Drive or other digital device.

Further information:

- Please visit <http://NADelectronics.com/warranty> to register your PP3.

Troubleshooting:

- Always turn down the volume to a low level or turn off all equipment before checking.

PROBLEM	CAUSE	SOLUTION
No sound	(LED is not illuminated) Power Supply not connected to either NAD PP 3 or mains socket.	Plug in dedicated Power Supply.
	(LED is illuminated) Wrong input on amplifier/receiver selected.	Select input to which NAD PP 3 is connected.
	Plugs from turntable and/or lead from NAD PP 3 to amplifier/receiver sockets not properly fitted.	Check to see if the MM/MC selector switch is set correctly for your type of turntable cartridge (make sure to turn off all equipment beforehand). Check all connections (make sure to turn off all equipment beforehand).
Sound in one channel only.	Plugs from turntable and/or lead from NAD PP 3 to amplifier/receiver sockets not properly fitted.	Check all connections (make sure to turn off all equipment beforehand).
Hum or Buzz noise.	No connection from turntable to ground.	Connect the turntable's earth (GND) lead directly to a ground connection or to NAD PP 3's thumb screw terminal "GND" which provides the grounding.
	Earth loop present.	If connected, disconnect turntable's earth lead from amplifier/receiver.
	Interference from nearby equipment	Move NAD PP 3 and cables further away from other equipment.

MM SPECIFICATIONS

Input impedance (R and C)	47k Ω + 200 pF
Gain at 1 kHz	35 dB
Input sensitivity for 300 mV output	5 mV
Signal to noise	76 dB (A weighted, with cartridge connected)
Input overload (20Hz/1kHz/20kHz)	10/100/900 mV
Total Harmonic Distortion	<0.03% (20 Hz – 20 kHz at 3V output)
RIAA response accuracy	+/- 0.3 dB
Infrasonic filter	-14 dB (5 Hz)
	-3 dB (10 Hz)
Digital output (USB)	16 bit linear PCM
Sampling frequency	48 kHz
Dynamic range	89 dB

MC SPECIFICATIONS

Input impedance (R and C)	100 Ω + 180 pF
Gain at 1 kHz	58 dB
Input sensitivity for 300 mV output	0.38 mV
Signal to noise	78 dB (A weighted, with cartridge connected)
Input overload (20 Hz/1kHz/20kHz)	0.65/6.5/60 mV
Total Harmonic Distortion	<0.03% (20 Hz – 20 kHz at 3V output)
RIAA response accuracy	+/- 0.3 dB
Infrasonic filter	-14 dB (5 Hz)
	-3 dB (10 Hz)
Digital output (USB)	16 bit linear PCM
Sampling frequency	48 kHz
Dynamic range	86 dB

GENERAL SPECIFICATIONS

Power supply External 24V DC (analogue circuitry)
+5 V from USB (digital circuitry)

Unit dimensions (W x H x D) 135 x 43 x 72 mm

www.NADelectronics.com

NAD reserves the right to change specifications or design at any time without notice. All specifications are those in effect at the time of printing & packing. Custom manufactured to NAD specifications in China. NAD is a trademark of NAD Electronics International, a division of Lenbrook Industries Limited. © NAD All Rights Reserved

