

Service Service Service



Service Manual



TABLE OF CONTENTS

	Page
Location of pc boards & Version variations	1-2
Technical Specifications	1-3
Measurement setup	1-4
Service Aids, Safety Instruction, etc.	1-5
Disassembly Instructions & Service positions	2
Service Test Program	3-1
Region code, Software version & upgrades	3-2
Set Block diagram	4-1
ECO Board	5
Front Board	6
AV Board	7
Module SD6.1 PL 2CH	8
Set Mechanical Exploded view & parts list	9
PSU Board (For Information only)	10

© Copyright 2004 Philips Consumer Electronics B.V. Eindhoven, The Netherlands
All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or
transmitted, in any form or by any means, electronic, mechanical, photocopying, or otherwise
without the prior permission of Philips.

Published by BB0435 Service AV Systems Printed in The Netherlands Subject to modification

**CLASS 1
LASER PRODUCT**




3139 785 30660

Version 1.0



PHILIPS

LOCATION OF PC BOARDS



VERSION VARIATIONS:

Type /Versions: Features & Board in used:	DVP762				
	/00	/02	/05	/78	
Aux-In					
Digital In					
TV-In					
Audio Out (Stereo L/R)	x	x	x	x	
Audio Out (Coaxial/Optical)	x	x	x	x	
CVBS Output	x	x	x	x	
S-Video Output	x	x	x	x	
SCART	x	x	x		
Y/Pb/Pr (YUV) Component Video Output	x	x	x	x	
Progressive Scan	x	x	x	x	
ECO Standby	x	x	x	x	
Voltage Selector					
Card Reader (Digital Media Reader)	x	x	x	x	

SPECIFICATIONS**GENERAL:**

Mains voltage : 220-240V for /00/02/05
 110-127V/220-240V for /78

Mains frequency : 50/60Hz

Power consumption : < 14W
 < 0.3W at Standby mode

Dimension centre unit : 435 x 46 x 310mm

AUDIO PERFORMANCE:**Normal Mode Stereo L/R**

Output Voltage : 2Vrms ± 1.5dB

Channel Unbalance (1kHz) : < 0.85dB

Crosstalk : > 100dB (1kHz)
 > 95dB (20Hz-20kHz)

Freq. Response (20Hz-20kHz) : ± 0.2dB max

Signal to Noise Ratio : > 90dB (A-weighted)

Distortion and Noise : > 85dB (1kHz)
 > 80dB (20Hz-2kHz)
 > 75dB (4kHz-20kHz)

AUDIO FORMAT:

MPEG/AC-3/PCM : Compressed Digital
 16, 20, 24 bits
 fs, 44.1, 48, 96 kHz

MP3 (ISO 9660) : 96, 112, 128, 256 kbps & variable
 bit rate fs, 32, 44.1, 48 kHz

VIDEO FORMAT:

Digital Compression : MPEG-2 for DVD, SVCD
 MPEG-1 for VCD
 MPEG-4/DivX


VIDEO PERFORMANCE:

CVBS ¹⁾ : 1.0V_{p-p}
 YPbPr ¹⁾ : 0.7V_{p-p}
 RGB (Scart) ¹⁾ : 0.7V_{p-p}

¹⁾ Output terminals to be terminated with 75Ω


MEASUREMENT SETUP

Tuner FM



Use a bandpass filter to eliminate hum (50Hz, 100Hz) and disturbance from the pilottone (19kHz, 38kHz).


Tuner AM (MW,LW)



To avoid atmospheric interference all AM-measurements have to be carried out in a Faraday's cage.
Use a bandpass filter (or at least a high pass filter with 250Hz) to eliminate hum (50Hz, 100Hz).


CD

Use Audio Signal Disc SBC429 4822 397 30184
(replaces test disc 3)



Recorder

Use Universal Test Cassette **CrO₂** SBC419 4822 397 30069
or Universal Test Cassette **Fe** SBC420 4822 397 30071



SERVICE AIDS


Service Tools:

Universal Torx driver holder	4822 395 91019
Torx bit T10 150mm	4822 395 50456
Torx driver set T6 - T20	4822 395 50145
Torx driver T10 extended	4822 395 50423

Compact Disc:

SBC426/426A Test disc 5 + 5A	4822 397 30096
SBC442 Audio Burn-in Test disc 1kHz	4822 397 30155
SBC429 Audio Signals disc	4822 397 30184
Dolby Pro-logic Test Disc	4822 395 10216

HANDLING CHIP COMPONENTS



**WARNING**

All ICs and many other semi-conductors are susceptible to electrostatic discharges (ESD). Careless handling during repair can reduce life drastically.

When repairing, make sure that you are connected with the same potential as the mass of the set via a wrist wrap with resistance. Keep components and tools also at this potential.

ESD**F ATTENTION**

Tous les IC et beaucoup d'autres semi-conducteurs sont sensibles aux décharges statiques (ESD). Leur longévité pourrait être considérablement écourtée par le fait qu'aucune précaution n'est prise à leur manipulation.

Lors de réparations, s'assurer de bien être relié au même potentiel que la masse de l'appareil et enfiler le bracelet serti d'une résistance de sécurité.

Veiller à ce que les composants ainsi que les outils que l'on utilise soient également à ce potentiel.

D**WARNUNG**

Alle ICs und viele andere Halbleiter sind empfindlich gegenüber elektrostatischen Entladungen (ESD). Unsorgfältige Behandlung im Reparaturfall kann die Lebensdauer drastisch reduzieren. Veranlassen Sie, dass Sie im Reparaturfall über ein Pulssarmband mit Widerstand verbunden sind mit dem gleichen Potential wie die Masse des Gerätes. Bauteile und Hilfsmittel auch auf dieses gleiche Potential halten.

**WAARSCHUWING**

Alle IC's en vele andere halfgeleiders zijn gevoelig voor electrostatische ontladingen (ESD). Onzorgvuldig behandelen tijdens reparatie kan de levensduur drastisch doen verminderen. Zorg ervoor dat u tijdens reparatie via een polsband met weerstand verbonden bent met hetzelfde potentiaal als de massa van het apparaat.

Houd componenten en hulpmiddelen ook op ditzelfde potentiaal.

**AVVERTIMENTO**

Tutti IC e parecchi semi-conduttori sono sensibili alle scariche statiche (ESD). La loro longevità potrebbe essere fortemente ridotta in caso di non osservazione della più grande cauzione alla loro manipolazione. Durante le riparazioni occorre quindi essere collegato allo stesso potenziale che quello della massa dell'apparecchio tramite un braccialetto a resistenza. Assicurarsi che i componenti e anche gli utensili con quali si lavora siano anche a questo potenziale.

**ESD PROTECTION EQUIPMENT:**

Complete Kit ESD3 (small tablemat, wristband, connection box, extention cable and earth cable) 4822 310 10671
Wristband tester 4822 344 13999



Safety regulations require that the set be restored to its original condition and that parts which are identical with those specified, be used

Safety components are marked by the symbol Δ .



Veiligheidsbepalingen vereisen, dat het apparaat bij reparatie in zijn oorspronkelijke toestand wordt teruggebracht en dat onderdelen, identiek aan de gespecificeerde, worden toegepast.

De Veiligheidsonderdelen zijn aangeduid met het symbool Δ



Les normes de sécurité exigent que l'appareil soit remis à l'état d'origine et que soient utilisées les pièces de rechange identiques à celles spécifiées.

Less composants de sécurité sont marqués Δ



Bei jeder Reparatur sind die geltenden Sicherheitsvorschriften zu beachten. Der Original zustand des Geräts darf nicht verändert werden; für Reparaturen sind Original-Ersatzteile zu verwenden.

Sicherheitsbauteile sind durch das Symbol Δ markiert.



Le norme di sicurezza esigono che l'apparecchio venga rimesso nelle condizioni originali e che siano utilizzati i pezzi di ricambio identici a quelli specificati.

Componenti di sicurezza sono marcati con Δ



After servicing and before returning set to customer perform a leakage current measurement test from all exposed metal parts to earth ground to assure no shock hazard exist. The leakage current must not exceed 0.5mA.

**Warning !**

Invisible laser radiation when open.
Avoid direct exposure to beam.

**Varning !**

Osynlig laserstrålning när apparaten är öppnad och spärren är urkopplad. Betrakta ej strålen.

**Varoitus !**

Avatussa laitteessa ja suojalukituksen ohittaaessa olet alittiina näkymättömälle laserisäteilylle. Älä katso sääteeseen!

**Advarse !**

Osnylig laserstråling ved åbning når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling.



"Pour votre sécurité, ces documents doivent être utilisés par des spécialistes agréés, seuls habilités à réparer votre appareil en panne".

DISMANTLING INSTRUCTIONS

Dismantling of the DVD Loader

- 1) The tray can be manually open by inserting a minus screw driver and push the lever in the direction as shown in Figure 1 to unlock the tray before sliding it out.
- 2) Slide out the tray and remove the Tray Front assembly (pos 110 + pos 111) as shown in Figure 2.
- 3) Loosen 5 screws to remove the Cover Top (pos 240).
 - 1 screw each on the left & right side
 - 3 screws on the rear
- 4) Loosen 4 screws B (see Figure 4) to remove the DVD Loader.




Figure 1




Figure 2

Dismantling of the AV Board, SD6.1 PL 2CH Board and PSU Board

- 1) Loosen 8 screws A (see Figure 3) and uncatch 2 catches C1 (see Figure 4) to remove the AV Board (pos 1001).
- 2) Loosen 4 screws D (see Figure 4) to remove the SD6.1 PL 2CH Board.
- 3) Loosen 2 screws E and uncatch 2 catches C2 (see Figure 4) to remove the PSU Board (pos 1004).




Figure 3




Figure 4

Detaching the Front Cabinet assembly and the Card Reader

- 1) Loosen 2 screws F (see Figure 4) and 2 screws G (see Figure 5) at the bottom to detach the Front Cabinet assembly from the Bottom Frame (pos 161) by sliding it out towards the front.
 - see Service position C
- 2) The Card Reader (pos 175) can be detach from the Front Cabinet assembly by pushing in the direction as shown in Figure 6 to loosen it before sliding it out in the direction as shown in Figure 7.



Figure 5





Figure 6




Figure 7

SERVICE POSITIONS


Service position A




Service position B



Service position C



SERVICE TEST PROGRAM



Reprogramming of DVD version Matrix

After repair, the customer setting and region code may be lost. Reprogramming will put the set back in the state in which it has left the factory, ie. with the default setting and the allowed region code.

Model	Region	Region Code	TV System
DVP762/00	Europe	2	PAL
DVP762/02	Europe	2	PAL
DVP762/05	Europe	2	PAL
DVP762/78	Latam	4	MULTI

To reprogram do as follows:

- 1) Power up the set.
- 2) Open tray by press "OPEN/CLOSE" button on the set or press and hold "STOP" button on the RC.
- 3) Press the following buttons on the Remote Control:
 <9> <9> <9> <9> <AUDIO> <1> for DVP762/00
 <9> <9> <9> <9> <AUDIO> <3> for DVP762/02
 <9> <9> <9> <9> <AUDIO> <4> for DVP762/05
 <9> <9> <9> <9> <AUDIO> <7> for DVP762/78
- 4) The display shows 'YYY-ZZ' and the tray will close.
 YYY = model number (eg. 762, etc.)
 ZZ = stroke version (eg. 00, 02, 05, etc.)

Procedure for check Software version

- 1) Power up the set.
- 2) Open tray by press "OPEN/CLOSE" button on the set or press and hold "STOP" button on the RC.
- 3) Press "DISPLAY" button on the Remote control.
- 4) The TV screen will shows:

SD6.1 Vxx YYY-ZZ P QQ
SERVO: GGGGGGGG REG:D

xx = version number
 YYY = model number (eg. 762, etc.)
 ZZ = stroke version (eg. 00, 02, 05, etc.)
 P / D = region code
 QQ = version number of front uProcessor
 GGGGGGGG = version for servo code

Procedure to upgrade software

- 1) Power up the set.
- 2) Open tray by press "OPEN/CLOSE" button on the set or press and hold "STOP" button on the RC.
- 3) Place upgrade CD-ROM onto tray and close.
- 4) The set will response and display the following:
 - LOAD [After the disc is read, the tray will open for you to remove the disc]
 - ERASE
 - WRITE
 - ERROR [if upgrade is unsuccessful]
 - UPG END -> PHILIPS [if upgrade is successful]
 - DISC->CLOSE->LOAD [Tray will close indicating that the upgrade process is completed]
- 5) The whole process should not take more than 5 minutes.

Caution: Do not unplug the set until upgrade is completed.

Trade Mode


Trade mode is a feature that will block all set keys when enabled. It is for dealers to prevent customers from removing disc, changing source etc using the set keys. Rotary and Remote Control (RC) keys are still allowed in Trade mode.

To activate Trade Mode:

- 1) Power up the set.
- 2) Open tray by press "OPEN/CLOSE" button on the set or press and hold "STOP" button on the RC.
- 3) Then press buttons <2> <5> <9> on the RC.
- 4) The display shows 'TRA ON' and the tray will close.
 Trade Mode is now enabled.

To deactivate Trade Mode:

- 1) Power up the set.
- 2) Open tray by press and hold "STOP"button on the RC.
- 3) Then press buttons <2> <5> <9> on the RC.
- 4) The display shows 'TRA OFF' and the tray will close.
 Trade Mode is now disabled.

SET BLOCK DIAGRAM


TECHNICAL REMARKS

ECO BOARD



TABLE OF CONTENTS

Circuit Diagram	5-2
Component & Chip Layout	5-3
Electrical parts list.....	5-3

ECO BOARD - CIRCUIT DIAGRAM



1300 C2
 1701 B5
 2701 B5
 2702 B7
 2703 B5
 2704 F7
 2708 F8
 2709 G7
 2713 G8
 2714 B7
 2715 E4
 3700 B4
 3701 C5
 3709 F7
 3711 F8
 3713 G8
 3714 E4
 6600 F8
 7700 B6
 7701 G7

ECO BOARD - COMPONENT LAYOUT**ECO BOARD - CHIP LAYOUT****ELECTRICAL PARTS LIST - ECO BOARD****MISCELLANEOUS**

1300	2422 025 18364	Flex Connector 16P
1701	2422 540 98518	RES CER 8MHz

DIODES

6600	4822 130 11397	BAS316
------	----------------	--------

TRANSISTORS & INTEGRATED CIRCUITS

7700	3139 240 50831	TMP87C809BM - 'LX3950S50831'
7701	5322 130 60159	BC847B



Note : Only the parts mentioned in this list are normal service spare parts.

FRONT BOARD

TABLE OF CONTENTS

FTD Display Pin Connection	6-1
Front Display part - Component & Chip Layout	6-2
Front Display part - Circuit Diagram	6-3
Standby part - Layout & Circuit diagram	6-4
Electrical parts list	6-4


FTD DISPLAY PIN CONNECTION




	7G	6G	5G	4G	3G	2G	1G
P1	a	a	a	a	a	a	a
P2	j, p						
P3	h	h	h	h	h	h	h
P4	k	k	k	k	k	k	k
P5	b	b	b	b	b	b	b
P6	f	f	f	f	f	f	f
P7	m	m	m	m	m	m	m
P8	g	g	g	g	g	g	g
P9	c	c	c	c	c	c	c
P10	e	e	e	e	e	e	e
P11	r	r	r	r	r	r	r
P12	n	n	n	n	n	n	n
P13	d	d	d	d	d	d	d
P14	-	-	col	-	col	-	-
P15	s	s	s	s	s	s	s

FRONT DISPLAY BOARD - COMPONENT LAYOUT


1100 A1 1102 A3 1104 A4 1106 A6 1108 A6 1110 A1 2102 A6 2110 A3 2114 A4 7102 A3
 1101 A6 1103 A4 1105 A6 1107 A1 1109 A6 2100 A5 2106 A3 2112 A5 2115 A4

**FRONT DISPLAY BOARD - CHIP LAYOUT**

2101 A2 2108 A5 3100 A1 3105 A4 3110 A5 3115 A5 3120 A1 3125 A1 3130 A6 3136 A1 4102 A6 4107 A1 4112 A1 6101 A4 6106 A4 6111 A6 7103 A1 7108 A1
 2103 A1 2109 A6 3101 A4 3106 A4 3111 A5 3116 A4 3121 A3 3126 A6 3132 A1 3137 A4 4103 A1 4108 A1 4113 A1 6102 A3 6107 A4 6112 A6 7104 A1 7109 A1
 2104 A1 2111 A2 3102 A4 3107 A4 3112 A5 3117 A1 3122 A3 3127 A1 3133 A6 3138 A4 4104 A1 4109 A6 4114 A1 6103 A5 6108 A1 6113 A6 7105 A1 7110 A1
 2105 A4 2113 A1 3103 A4 3108 A6 3113 A5 3118 A1 3123 A1 3128 A1 3134 A1 4100 A1 4105 A1 4110 A6 4120 A4 6104 A5 6109 A1 7100 A6 7106 A1 7112 A5
 2107 A4 2116 A4 3104 A4 3109 A5 3114 A5 3119 A1 3124 A1 3129 A1 4101 A1 4106 A1 4111 A1 6100 A1 6105 A5 6110 A6 7101 A4 7107 A6




FRONT DISPLAY BOARD - CIRCUIT DIAGRAM




STANDBY BOARD - CIRCUIT DIAGRAM

1200 A1 1201 A2 1202 B1 1203 A2 2220 A2 5001 A3




STANDBY BOARD - COMPONENT LAYOUT

1200 A1 1202 A2
1201 A2 1203 A1

STANDBY BOARD - CHIP LAYOUT

2220 A2 5001 A2



ELECTRICAL PARTS LIST - FRONT BOARD

MISCELLANEOUS

1100	3139 240 50661	FTD HNV-07SS56T	6107	4822 130 11397	DIO SIG SM BAS316
1102	2422 025 16586	FLEX CONNECTOR 9P	6108	3198 020 55680	DIO REG SM PDZ5.6B
1103	2422 025 18364	FLEX CONNECTOR 16P	6109	3198 020 55680	DIO REG SM PDZ5.6B
1105	4822 276 13775	TACT SWITCH	6110	3198 020 55680	DIO REG SM PDZ5.6B
1106	4822 276 13775	TACT SWITCH	6111	3198 020 55680	DIO REG SM PDZ5.6B
1107	4822 276 13775	TACT SWITCH	6112	3198 020 55680	DIO REG SM PDZ5.6B
1108	4822 276 13775	TACT SWITCH	6113	3198 020 55680	DIO REG SM PDZ5.6B
1109	4822 276 13775	TACT SWITCH			
1201	4822 276 13775	TACT SWITCH			

RESISTORS

3100	4822 117 11152	△ RST SM FUSE 1206 4R7 5%	7100	9322 186 03671	IC SM UPD16312GB-3B4
			7101	5322 130 60159	BC847B
			7102	9322 155 82667	IR RECEIVER TSOP2236LL1
			7103	4822 130 42804	BC817-25
			7104	4822 130 60373	BC857B

COILS & FILTERS

5001	3198 018 52280	FXD IND SM 0603 2U2 10%	7105	5322 130 60159	BC847B
			7106	4822 130 60373	BC857B
			7107	4822 130 60373	BC857B
			7108	4822 130 60373	BC857B
			7109	4822 130 60373	BC857B

DIODES

6100	3198 020 55680	DIO REG SM PDZ5.6B	7110	4822 130 60373	BC857B
6101	3198 020 55680	DIO REG SM PDZ5.6B			
6102	9340 548 54115	DIO REG SM PDZ6.2B			
6103	3198 020 55680	DIO REG SM PDZ5.6B			
6105	3198 020 55680	DIO REG SM PDZ5.6B			
6106	4822 130 11397	DIO SIG SM BAS316			

Note : Only the parts mentioned in this list are normal service spare parts.

AV BOARD

TABLE OF CONTENTS

Brief Introduction of the AV Board	7-1
Block Diagram	7-1
Top View Layout	7-2
Bottom View Layout	7-3
Circuit Diagram (Part 1)	7-4
Circuit Diagram (Part 2)	7-5
Circuit Diagram (Part 3)	7-6
Electrical parts list	7-7

BRIEF INTRODUCTION OF THE AV BOARD

The AV Board consists of the following features :


A. VIDEO OUTPUT

- CVBS
- S-Video
- YUV
- Scart RGB (For Europe Model)
- Progressive Scan

B. AUDIO OUTPUT


- Stereo / 6 Channel
- Coaxial / Optical

AV BOARD - BLOCK DIAGRAM




AV BOARD - BOTTOM VIEW LAYOUT

1103 D7	1113 D4	1302 D1	1308 D3	2118 D6	2133 C7	2153 D4	2200 A2	2215 C2	2235 B3	2248 B1	2268 B2	2305 C9	2325 B8	2346 B8
1109 D6	1202 A3	1303 B9	2109 C6	2120 C8	2136 C5	2154 C5	2201 A1	2217 B3	2236 C3	2255 B1	2271 B2	2306 C8	2335 D8	2347 B9
1110 D7	1203 A5	1304 A9	2113 B7	2124 D7	2145 C7	2156 D4	2206 B2	2222 C3	2241 B1	2256 C1	2272 B4	2320 A3	2337 D9	5301 D9
1111 D5	1300 D2	1305 A9	2115 D6	2125 C7	2147 C8	2168 D5	2207 C2	2229 B1	2243 C1	2262 B1	2274 A1	2321 C4	2342 A8	7301 C9
1112 A8	1301 A6	1307 D9	2116 C6	2130 C5	2149 D4	2171 C8	2214 B2	2230 C1	2247 B2	2263 C1	2275 A1	2324 B9	2344 C2	7311 D8




AV BOARD - CIRCUIT DIAGRAM (PART 1)




1103-A	A14	3162 F12
1103-B	A13	3163 F11
1109	B14	3164 G1
1110	C14	3165 G3
1111	C13	3166 G5
1112	D1	3167 G6
1113	F13	3168 G1
2100	A13	3169 G4
2101	A11	3170 G9
2102	B11	3171 G4
2108	B4	3172 G5
2109	B9	3173 G3
2110	B13	3174 G1
2111	B1	3175 F1
2113	B2	3176 G3
2114	B13	3177 G9
2115	B11	3178 G12
2116	B7	3179 G1
2117	C13	3180 G10
2118	C11	3181 F11
2119	C1	3182 G10
2120	C2	3183 G11
2121	C13	3184 H5
2124	C11	3185 H5
2125	C9	3186 H7
2127	C6	3187 H3
2129	D4	3188 H5
2130	D7	3189 H6
2132	E5	3190 H5
2133	E9	3191 H8
2135	E4	3192 H8
2136	F7	3193 H8
2137	F12	3194 H3
2140	F5	3195 H3
2143	F12	3196 H5
2144	G13	3197 H6
2145	G5	3198 H4
2147	G9	3199 I4
2149	G11	4100 A9
2150	G12	4101 B11
2151	G13	4102 B3
2153	G11	4103 B11
2154	H7	4104 C9
2155	H12	4105 C11
2156	H11	4106 C5
2159	I13	4107 B5
2168	I11	4108 D3
2170	I13	4109 B5
2171	A11	4110 B6
2172	H1	4111 D9
3100	A7	4112 E5
3101	G7	4113 E3
3102	G9	4114 F4
3103	G10	4115 F9
3104	G12	4116 G5
3105	I5	4118 G12
3106	A7	4119 H12
3107	A7	4121 H12
3108	B9	4123 I11
3109	B3	4124 D5
3110	B9	4125 D3
3111	B12	4126 E4
3112	B9	4127 E3
3113	B10	4128 F4
3114	B10	4129 H4
3115	B10	5100 B1
3116	B7	5103 B1
3117	B12	5104 H1
3118	C7	6100 A12
3119	C8	6101 A11
3120	C8	6102 B12
3121	C8	6104 C12
3122	C8	6105 C12
3123	C12	6107 G13
3125	D9	6108 G13
3126	D9	6109 G12
3127	D10	6110 H13
3128	D10	6111 H13
3129	D10	6112 H13
3130	D7	6114 I13
3131	D5	7100 A8
3132	D6	7103 B7
3133	D3	7104 B9
3134	D4	7105 B4
3135	D7	7106 B8
3136	E8	7107 C9
3137	E8	7108 C5
3138	E8	7109 D3
3139	E8	7110 D8
3140	E9	7111 E9
3141	E9	7112 E5
3142	E5	7113 E3
3143	E5	7115 F8
3144	E9	7116 F12
3145	E10	7117 F5
3146	E10	7119 F12
3147	E10	7120 G3
3148	F7	7123 G9
3149	F3	7124 G4
3150	F4	7127 H8
3151	F11	7138 H3
3152	F12	7139 H5
3153	F11	7140 H4
3154	F7	7141 I5
3155	F8	7142 I6
3157	F8	
3158	F8	
3159	F3	
3160	F11	
3161	F3	

AV BOARD - CIRCUIT DIAGRAM (PART 2)



AV BOARD - CIRCUIT DIAGRAM (PART 3)




1300 A10
1301 B7
1302-1 C10
1302-2 D10
1303 C1
1304 C4
1305 E1
1307 G11

1308 F1
2304 A9
2305 A3
2306 A3
2309 A4
2314 B9
2315 C3
2318 C5
2319 C9
2320 F4
2321 F5
2322 C9
2324 E2
2325 E4
2326 E4
2327 D9
2329 C3
2330 E9
2331 G9
2332 E9
2333 F9
2334 H10
2335 H10
2337 G9
2338 G9
2339 G10
2340 H10
2342 C5
2344 F5
2345 B8
2346 C4
2347 C3
2348 E3
2349 E3
2350 C2
3302 A9
3309 A9
3310 A9
3311 B9
3312 B9
3313 B9
3314 C9
3315 C9
3316 F4
3317 C9
3318 F3
3319 C9
3320 C9
3321 D9
3322 E2
3323 D9
3325 E3
3326 E3
3327 F3
3328 E9
3329 E9
3330 G8
3331 E9
3332 E9
3336 G8
3337 H9
3338 F9
3339 F9
3340 E4
3341 G10
3342 E2
3343 C4
3344 C2
3345 C4
3346 C2
3347 C4
4303 D4
4304 D4
4306 G3
4307 G3
4308 G3
4309 G3
4310 H3
4311 G3
4312 G3
4314 G3
4315 B2
4316 B3
5301 G9
6300 A8
6301 C8
7300 A9
7301 A3
7302 B9
7303 B4
7304 C9
7305 C9
7306 E3

MODULE SD6.1 PL 2CH


TABLE OF CONTENTS

SD6.1 PL 2CH Board - Top View Layout.....	8-2
SD6.1 PL 2CH Board - Bottom View Layout	8-3
SD6.1 PL 2CH Board - Circuit Diagram (Part 1)	8-4
SD6.1 PL 2CH Board - Circuit Diagram (Part 2)	8-5
Exploded View & parts list	8-6
Electrical parts list.....	8-7


SD6.1 PL 2CH BOARD - BOTTOM VIEW LAYOUT


1102	B1
1103	A1
1106	A4
1107	A1
1108	A2
2101	A2
2103	A1
2104	A1
2105	E1
2107	E1
2114	B2
2126	D3
2130	B2
2138	D1
2141	B1
2145	C1
2149	E2
2180	D1
2182	D1
2184	C1
2193	E1
2195	E1
2196	E1
2302	A3
2308	A4
2311	A2

SD6.1 PL 2CH BOARD - CIRCUIT DIAGRAM (PART 1)




SD6.1 PL 2CH BOARD - CIRCUIT DIAGRAM (PART 2)



EXPLODED VIEW - MODULE SD6.1 PL 2CH

Module SD6.1 PL 2CH_3139 117 10931_dd wk0433

EXPLODED VIEW - MODULE DVD LOADER ASA+DV34 PL**MODULE SD6.1 PL 2CH PARTS LIST**

0001	3139 117 10691	MODULE DVD LOADER ASA+DV34 PL
1001	3139 118 58091	PCBAS SD6.1 PL 2CH PHIL USB
1101	3139 111 04021	FFC FOIL 24P/220 AD 0.5MMP FLD

Note : Only the parts mentioned in this list are normal service spare parts.

Module DVD Loader ASA+DV34 PL_3139 117 10691_dd wk0409

ELECTRICAL PARTS LIST - SD6.1 PL 2CH BOARD**MISCELLANEOUS**

1101	2422 025 17529	Flex Connector 24P	7111	9322 201 94668	IC SM MM1646XH
1104	2422 025 16388	Flex Connector 16P	7112	9322 203 35671	IC SM MT1389EE
1105	2422 025 17768	Flex Connector 9P	7301	9322 189 04668	IC SM M24C16-RDW6
1106	2422 025 16727	Flex Connector 4P	7302	9322 166 67668	IC SM MT48LC4M16A2TG-7E
1107	2422 025 16727	Flex Connector 4P	7302	9322 199 38671	IC SM IS42S16400A-7T
1301	2422 025 17451	Flex Connector 30P	7303	3139 110 53701	FLASH + EMBEDDED SW
			7306	9352 687 20125	IC SM 74LVC1G125GW


COILS & FILTERS

5101	2422 549 45618	IND FXD 0603 100MHz 60R
5102	2422 549 45618	IND FXD 0603 100MHz 60R
5103	4822 157 71206	FXD IND 0805 100MHz 600R
5104	4822 157 71206	FXD IND 0805 100MHz 600R
5105	2422 549 43062	FXD IND 0603 100MHz 600R
5106	2422 549 43062	FXD IND 0603 100MHz 600R
5107	4822 157 71206	FXD IND 0805 100MHz 600R
5108	2422 549 45618	IND FXD 0603 100MHz 60R
5109	2422 549 43062	FXD IND 0603 100MHz 600R
5111	4822 157 71206	FXD IND 0805 100MHz 600R
5112	2422 549 45618	IND FXD 0603 100MHz 60R
5115	2422 549 43062	FXD IND 0603 100MHz 600R
5116	2422 549 43062	FXD IND 0603 100MHz 600R
5117	2422 549 43062	FXD IND 0603 100MHz 600R
5118	2422 549 43062	FXD IND 0603 100MHz 600R
5119	2422 549 43062	FXD IND 0603 100MHz 600R
5122	2422 549 43062	FXD IND 0603 100MHz 600R
5123	2422 549 45618	IND FXD 0603 100MHz 60R
5124	3198 018 31090	FXD IND SM 0805 10U 10%
5125	3198 018 31090	FXD IND SM 0805 10U 10%
5126	2422 549 43062	FXD IND 0603 100MHz 600R
5130	2422 543 01393	RES XTL 27MHz 10P CX8045
5131	3198 018 41880	FXD IND SM 1210 1U8 5%
5132	3198 018 41880	FXD IND SM 1210 1U8 5%
5133	3198 018 41880	FXD IND SM 1210 1U8 5%
5134	3198 018 41880	FXD IND SM 1210 1U8 5%
5135	3198 018 41880	FXD IND SM 1210 1U8 5%
5136	3198 018 41880	FXD IND SM 1210 1U8 5%
5151	2422 549 43062	FXD IND 0603 100MHz 600R
5300	2422 549 43062	FXD IND 0603 100MHz 600R
5301	2422 549 43062	FXD IND 0603 100MHz 600R
5305	2422 549 43062	FXD IND 0603 100MHz 600R
5310	2422 549 43062	FXD IND 0603 100MHz 600R
5311	2422 549 43062	FXD IND 0603 100MHz 600R

Note : Only the parts mentioned in this list are normal service spare parts.

TRANSISTORS & INTEGRATED CIRCUITS

7101	4822 209 17398	IC SM LD1117DT33
7102	9322 165 15685	IC SM NCP303LSN30
7103	9351 875 80118	IC SM 74HCU04PW
7106	4822 130 11565	TRA POW SM 2SB1132
7107	4822 130 11565	TRA POW SM 2SB1132
7108	9340 547 13215	FET SIG SM BSH103
7109	9340 547 13215	FET SIG SM BSH103
7110	9340 219 30115	TRA SIG SM BC817-25W

SET MECHANICAL EXPLODED VIEW

MECHANICAL & ACCESSORIES PARTS LIST - MAIN UNIT

0101	3139 244 05351	CABINET FRONT	
0105	3139 247 51831	BADGE PHILIPS ASSY SILVER	
0110	3139 247 58371	TRAY FRONT	
0111	3139 244 05011	TRAY STRIP	
0121	3139 247 58481	BUTTON STANDBY TOP	
0122	3139 244 03411	BUTTON STANDBY BOTTOM	
0123	3139 247 58461	BUTTON OPEN/CLOSE	
0124	3139 247 58442	BUTTON CLUSTER TOP	
0125	3139 247 58451	BUTTON CLUSTER BOTTOM	
0129	3139 244 04661	WINDOW CENTRE	
0130	3139 247 58621	WINDOW SIDE	
0165	3139 243 10080	CUSHION FOOT	
0175	2822 062 00033	CARD READER WRITER USB1.1 B	
0180	3139 240 40061	SPACER - 8MM	
0181	3139 240 40061	SPACER - 8MM	
0182	2422 015 19894	SADDLE WIRE NY6/6 NT 9.9MM B	
0190	4822 532 60948	BUSH	
0333	3139 248 72071	REMOTE CONTROL	
0336	2422 070 98231	△ MAINS CORD	/00/02/78
0336	3103 140 25882	△ MAINS CORD	/05
0337	3139 128 73010	△ MAINS PLUG ADAPTER	/78
0338	2422 076 00304	CABLE CINCH 1M5 YE/RD/WH	/78
0342	2422 076 00445	△ CABLE SCART 1M1 SCART 21P	/00/02/05
1001	3139 248 83191	PCBAS AV	/00/02/05
1001	3139 248 83181	PCBAS AV	/78
1002	3139 248 83211	PCBAS FRONT	
1003	3139 248 83031	PCBAS ECO BOARD	
1004	3139 248 72061	MODULE PSU DVD HE 2004 MIT	
1101	3139 241 00541	FFC FOIL 30P/120/30P AD 1MMP	
1102	3139 111 02361	FFC FOIL 16P/180/16P AD 1MMP	
1105	3139 241 00521	FFC FOIL 09P/140/09P AD 1MMP	
1106	3139 241 00551	FFC FOIL 16P/100/16P AD 1MMP	
1108	3139 241 00821	FFC FOIL 04P/140/04P AD 1MMP	

Note : Only the parts mentioned in this list are normal service spare parts.

SCREW LISTS - MAIN UNIT

250	D3 x 8
251	M3 x 6
252	M3 x 4
253	M3 x 4
254	M3 x 4
255	M3 x 4
256	D3 x 8
257	D3 x 8
258	D3 x 8
259	D3 x 8
260	D3 x 8 /00/02/05
261	D3 x 8
263	M3 x 6
264	M3 x 6
265	M3 x 4
266	M3 x 4
267	M3 x 4

PSU BOARD

(For Information only)

It is not recommended for component repair on this board but to replace the board when it becomes defective.
Therefore no service parts list is published in this chapter.

The only service part available for replacement is:
Module PSU DVD HE 2004 MIT 3139 248 72061

TABLE OF CONTENTS

Circuit Diagram	10-2
-----------------------	------

PSU BOARD - CIRCUIT DIAGRAM

