

Service Service Service



Service Manual



Internet Radio

TABLE OF CONTENTS

Location of PCBS	1-1	PB - KEYS & IR	8
Specifications	1-2	Circuit diagram	8-1
Measurement Setup	1-3	Layout diagram	8-2..8-3
Service Aids, Safety Instruction, etc.	1-4	PB - Audio In/Out	9-1
Instructions On CD Playability	1-5 to 1-6	PB - Headphone	10-1
Software & Firmware Upgrade	2-1..2-2	PB - Wifi - Light	11-1
Malfunction Check Chart	2-3	PB - Wesli - 08	12
Service Test Program.....	3-1..3-2	Circuit diagram	12-1..12-9
Disassembly Diagram	4-1	Layout diagram	12-10..12-11
Block Diagram	5-1	Explode View	13-1
Wiring Diagram.....	6-1	Service Partlist	13-2
PB - AF & AMP.....	7		
Circuit diagram	7-1..7-4		
Layout diagram.....	7-5..7-6		

© Copyright 2008 Philips Consumer Electronics B.V. Eindhoven, The Netherlands
 All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form or by any means, electronic, mechanical, photocopying, or otherwise without the prior permission of Philips.

Published by DB 0821 Service Audio Printed in The Netherlands Subject to modification

**CLASS 1
LASER PRODUCT**


© 3141 785 32890

Version 1.0



PHILIPS

Location of PCBS



VERSION VARIATIONS :

Type /Versions:		MCI300							
		/05	/12	/37					
Board in used:	Service policy	M	M						
SMPS BOARD		M	M						
TUNER MODULE		M	M						
AF& BOARD		M	M						
AUDIO IN&OUT BOARD		M	M						
HEADPHONE BOARD		M	M						
KEYS&IR BOARD		M	M						
WIFI-LIGHT BOARD		M	M						
WESLI-08 BOARD		M	M						
Type /Versions:		MCI300							
		/05	/12	/37					
Features	Feature diffrence	M	M						
RDS									
VOLTAGE SELECTOR									
ECO STANDBY - DARK									

* TIPS : C -- Component Lever Repair.
M -- Module Lever Repair
✓ -- Used


TECHNICAL SPECIFICATION

General	Tuner
AC Power	FM wave range..... 87.5-108MHz
..... 230V±10%.../05/12/79	FM aerial 75ohm xoaxial wire/T-antenna wire
..... 120V±10%.../37	
..... 120V/240V±10%.../55/97	
Dimensions(w x h x d)	Internet Radio
185 x 210 x 248mm	Internet service Rhapsody
Weight(with/without speakers)	Streaming protocols HTTP,RTSP-T,MMS-T/MMS-U
8.303kg/3.35kg SHOUTcast
Power consumption	
Active.....	CD player
<45W	Frequency range 60-20,000 Hz, -3 dB
Standby	Signal-to-noise ratio 72 dBA (IEC)
<15W	MPEG 1 Layer 3 (MP3-CD) MPEG AUDIO
Eco standby.....	MP3-CD bit rate 32-320 kbps, VBR
<1W	WMA bit rate up to 160 kbps
Amplifier	Sampling frequencies 32, 44.1, 48 kHz
Out power.....	
2 x 40W	USB player
Frequency response.....	USB 12Mb/s,V1.1
350Hz - 14KHz,-3dB	Support format..... MP3,WMA,AAC
Signal to noise.....	USB class..... MSC,MTP
≥ dB (IEC)	Number of albums/folders maximun 99
Input sensitivity	Number of tracks/titles..... maximum 999
AUX IN	
500mV(0dB)	
Impedance Speakers	
12ohm	
Impedance headphone.....	
16 Ohm-150 Ohm	
Wireless	
Wireless standard.....	
802.11g,compatible to 802.11b	
Wireless security	
WEP (64 or 128bit),WPA-PSK	
Frequency Range	
2412-2462 MHz (CH1-CH11)	
Wired(LAN/Ethernet)	
Wired standard	
802.3/802.3u	
Speed	
10/100MBit/s	
Mode	
half/full duplex	
Crossover detection(Auto MDIX).....	
yes	
uPnP support format	MP3/WMA/AAC/ADPCM/PCM
Internet rhapsody services(via ECD)	
.....streaming,add to library,media playback,my rhapsody	
..... subscription management,DRM metering,search	
.....channels,dynamic playlists,playlist creation/access	

*Specifications and external appearance are subject to change without notice.


MEASUREMENT SETUP

Tuner FM



Use a bandpass filter to eliminate hum (50Hz, 100Hz) and disturbance from the pilottone (19kHz, 38kHz).


Tuner AM (MW,LW)



To avoid atmospheric interference all AM-measurements have to be carried out in a Faraday's cage.
Use a bandpass filter (or at least a high pass filter with 250Hz) to eliminate hum (50Hz, 100Hz).


CD

Use Audio Signal Disc SBC429 4822 397 30184
(replaces test disc 3)



Recorder

Use Universal Test Cassette **CrO₂** SBC419 4822 397 30069
or Universal Test Cassette **Fe** SBC420 4822 397 30071



SERVICE AIDS



WARNING

All ICs and many other semi-conductors are susceptible to electrostatic discharges (ESD). Careless handling during repair can reduce life drastically.

When repairing, make sure that you are connected with the same potential as the mass of the set via a wrist wrap with resistance. Keep components and tools also at this potential.



Safety regulations require that the set be restored to its original condition and that parts which are identical with those specified, be used

Safety components are marked by the symbol \triangle .

ESD



**CLASS 1
LASER PRODUCT**

INFORMATION ABOUT LEAD-FREE SOLDERING

Philips CE is producing lead-free sets from 1.1.2005 onwards.

IDENTIFICATION:

Regardless of special logo (not always indicated) one must treat all sets from **1 Jan 2005** onwards, according next rules:



- On our website www.atyourservice.ce.Philips.com you find more information to:
 - * BGA-de-/soldering (+ baking instructions)
 - * Heating-profiles of BGAs and other ICs used in Philips-sets
 - * Lead free

You will find this and more technical information within the "magazine", chapter "workshop news".


For additional questions please contact your local repair-helpdesk.

SERVICE INSTRUCTION

Safety regulations require that after a repair, the set must be returned in its original condition. Pay in particular attention to the following points:

- Route the wire trees correctly and fix them with the mounted cable clamps.
- Check the insulation of the AC Power lead for external damage.
- Check the strain relief of the AC Power cord for proper function.
- Check the electrical DC resistance between the AC Power Plug and the secondary side (only for sets which have a AC Power isolated power supply):
- 1. Unplug the AC Power cord and connect a wire between the two pins of the AC Power plug.
- 2. Set the AC Power switch to the "on" position (keep the AC Power cord unplugged!).
- 3. Measure the resistance value between the pins of the AC Power plug and the metal shielding of the tuner or the aerial connection on the set. The reading should be larger than 4.5 Mohm (For U.S. it should be between 4.2 Mohm and 12 Mohm).
- 4. Switch "off" the set, and remove the wire between the two pins of the AC Power plug.
- Check the cabinet for defects, to avoid touching of any inner parts by the customer.

INSTRUCTIONS ON CD PLAYABILITY



① - ④ For description - see following pages

INSTRUCTIONS ON CD PLAYABILITY

(1)

PLAYABILITY CHECK

For sets which are compatible with **CD-RW** discs
 use CD-RW Printed Audio Disc 7104 099 96611
 TR 3 (Fingerprint)
 TR 8 (600 μ Black dot) **maximum at 01:00**

- playback of these two tracks without audible disturbance
 playing time for: Fingerprint \geq 10seconds
 Black dot from 00:50 to 01:10
- jump forward/backward (search) within a reasonable time

For all other sets
 use CD-DA SBC 444A 4822 397 30245
 TR 14 (600 μ Black dot) **maximum at 01:15**
 TR 19 (Fingerprint)
 TR 10 (1000 μ wedge)

- playback of all these tracks without audible disturbance
 playing time for: 1000 μ wedge \geq 10seconds
 Fingerprint \geq 10seconds
 Black dot from 01:05 to 01:25
- jump forward/backward (search) within a reasonable time

(2)

CUSTOMER INFORMATION

It is proposed to add an addendum sheet to the set which informs the customer that the set has been checked carefully - but no fault was found.
 The problem was obviously caused by a scratched, dirty or copy-protected CD. In case problems remain, the customer is requested to contact the workshop directly.
 The lens cleaning (method ③) should be mentioned in the addendum sheet.

The final wording in national language as well as the printing is under responsibility of the Regional Service Organizations.

(4)


LIQUID LENS CLEANING

Before touching the lens it is advised to clean the surface of the lens by blowing clean air over it.
 This to avoid that little particles make scratches on the lens.

Because the material of the lens is synthetic and coated with a special anti-reflectivity layer, cleaning must be done with a non-aggressive cleaning fluid. It is advised to use "Cleaning Solvent"

The actuator is a very precise mechanical component and may not be damaged in order to guarantee its full function. Clean the lens gently (don't press too hard) with a soft and clean cotton bud moistened with the special lens cleaner.

The direction of cleaning must be in the way as indicated in the picture below.



SOFTWARE UPGRADING PROCEDURE

Software Version Verification Procedure

It is important to write down the system version information of your Center before you start the upgrade procedure. This information is also useful in case you need to call Philips Customer Care Center.

1. Press **MENU**.
2. Press **▲/▼** to select “**Information**”. Press **OK**.
3. Press **▲/▼** to select “**System**”. Press **OK**.
4. The software version number is shown on the display.
5. If the software version is not the latest one, you need to upgrade waC3500D.

There are 3 ways to update the software.

- A) Using CD-Rom
- B) Using WADM

A. Using CD-Rom

1. Software Upgrade Disc Preparation

Tools Required : You will need the following items :

- PC (Pentium III 300MHz processor or higher)
- CD-R/RW writer and writing application software
- Blank CD-R or CDRW disc
- Broadband / High speed internet connection

2. How to download the software to your computer


1. To download free firmware and software upgrades for your product, please login to www.club.philips.com
Download the firmware upgrade files and store them on your PC
2. Unzip the .zip file and extract files into your PC.

Note:

- Please do not rename the filename.
- If you do not have the software to open the .zip file, please visit below website to download the software.
<http://www.winzip.com/>

3. Steps to upgrade the waC3500D

1. Make sure the Audio Station has connected to the Audio Center.
2. Burn the file to blank CD-R or CDRW. Finalize the disc. (The application may do this automatically.)
3. Turn on the Audio Center and turn on the Audio Station, insert the CD to the slot loader, CD graphic printed side facing you.



4. The Audio Center will upgrade automatically.
 - The message “**Updating firmware, please wait....**” and the “**process bar**” show on the display of the Audio Center.
 - The upgrade process of the Center will reboot twice

Note: Do NOT power off the Audio Center or eject the disc at this stage.

5. It takes around 5 mins to complete the firmware upgrade for the Audio Center.
6. When done, the Audio Center will go to the HD mode automatically.


4. After the upgrade

Do confirm the software version by checking the system version.
Please follow the procedure described in the section “**Software Version Verification Procedures**”.

B. Upgrading firmware

The supplied PC Installer CD Wireless Audio Device Manager (WADM) helps you get the upgrades for WAC3500 Center.

- 1 Register your Philips Wireless Music Center with www.club.philips.com
- 2 Download the firmware upgrade files and store them on your PC
- 3 Place Center on a flat and firm surface
- 4 Connect Center to power supply
→ HD screen appears on Center
- 5 Connect Center to your PC via the supplied ethernet cable.
- 6 Install and launch WADM (see **Connect to your PC** section B)
- 7 Click **Device Configuration**, and then click the **Firmware upgrade** sub-menu
- 8 As prompted, click **Browse** and indicate the location where you kept the firmware upgrade files on PC



- 9 Click **Apply** to start upgrading firmware **On Philips Wireless Music Center:**
 - The display shows “**Updating firmware, please wait...**”
 - Center will reboot itself during the installation process
 - When Center returns to HD screen, the installation is completed

IMPORTANT!

On Philips Wireless Music Center

- **Never interrupt the firmware upgrading before its completion.**
- **Before finishing the installation, never operate other functions.**

* Hints: Restoring previous firmware

After the Center's firmware is upgraded, you can restore it to its previous version as desired.

- 1 Select HD mode, and then select **Restore firmware**
 - a. Press **MENU** to enter the MENU screen
 - b. Press the navigation controls **▲** or **▼** and **►** to enter **Settings**, **Firmware** and **Restore firmware** one by one.
- 2 Press **►** to select **Yes**

Helpful hint:

- After restoration to previous firmware, the set will lost Wi-Fi links to associated stations or external network.

* Reset

When to reset the Center:

- Resetting the Center helps to re-establish the Wi-Fi connection between the Center and Station.
- Change the way the Center connects to an external Wi-Fi/wired network.

- 1 Check that the set is switched on (see **5.Basic functions**).
- 2 Press **MENU** to enter the menu screen
- 3 Press the navigation controls **▲** or **▼** and **►** to enter **Settings** followed by **Restore settings**.



- 4 Press **►** to select **Yes**
 - The set is rebooted. Language selection screen appears.
- 5 Select your desired language: **English**, **Français**, **Español**, **Nederlands**, **Italiano** or **Deutsch**
 - The set enters Installation Mode
 - The search for Center starts. The Wi-Fi connection is being re-established

Helpful hint:

- After restoration to default settings, the network mode will go back to Ad-Hoc mode.
- Restoring to default settings does not delete any stored music tracks

Gracenote CD Information

The Gracenote music recognition service enables the set to look up CD track information (including album, artist, genre, track information) from its built-in database. It allows the recorded CD tracks to be properly categorized (for example, under Artists, Albums, Genres or All tracks) and also be merged with the existing tracks in the hard disk.

12.1 Gracenote music recognition database

A 800 MB CD database (contains 800,000 most popular CDs) is embedded in every WAC3500 Center for quick look-up on track information. An update file that contains newly released CDs is available quarterly on www.club.philips.com for download.

12.1.1 To update Gracenote music recognition database


- 1 Use your PC to register your product on www.club.philips.com and go to "Show Upgrades & Support" page to download Gracenote Music recognition database update. Note that the updates are posted quarterly and each update is independent of each other; i.e. a later update could be installed without an earlier update.
- 2 After storing the file on your PC, you can either burn a CD with the update file using your favorite CD burning software and drop the CD into the WAC3500 Center for automatic update, or you can use WADM's Gracenote update option if you have connected your PC to WAC3500 Center.

12.2 Gracenote Internet Query

If the CD track information of your new CD disc cannot be displayed on the WAC3500, the quickest and surest solution is to look it up from the internet by following steps below.

12.2.1 Connecting to the Internet

- 1 Check that you have connected the Center to an Access Point or Router with Internet access or connect the Center to an ADSL modem with Internet access directly.




Helpful hint:

- Make sure that no dial-up, user name or password is required for the Internet access.
- 2 Set DNS and Gateway
 - If you are using a DHCP* enabled Access Point, Router or ADSL modem, the DNS and Gateway can be got automatically, so you need only to set the Center to Automatic (DHCP) mode by following steps below:
*DHCP stands for Dynamic Host Configuration Protocol. It is a protocol for assigning dynamic IP addresses to devices on a network.
 - a. Press MENU
 - b. Press ▲ or ▼ and ► to select Settings > Network > Wired
 - c. Press ► to continue
 - d. Press ▲ or ▼ and ► to select Automatic (DHCP).

- If there is no DHCP, set the DNS and Gateway manually by following steps below: On your PC, carry out the following steps:

- a. Click Start > Run



- b. Type cmd and click OK
- c. Type ipconfig/all

- d. Write down the DNS and Gateway of the current connection

```
C:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\philips>ipconfig/all
Windows IP Configuration


Host Name . . . . . : Test42
Primary Dns Suffix . . . . . :
NetBIOS Namespace . . . . . : Hybrid
IP Routing Enabled . . . . . : No
WINS Proxy Enabled . . . . . : No

Ethernet adapter Local Area Connection:
   Connection-specific DNS Suffix . . . . . : 3Com 3C920 Integrated Fast Ether
   Controller (3C905C-TX Compatible)
   Physical Address . . . . . : 00-06-58-50-A0
   DHCP Enabled . . . . . : No
   IP Address . . . . . : 172.31.107.5
   Subnet Mask . . . . . : 255.255.0.0
   Default Gateway . . . . . :

C:\Documents and Settings\philips>
```

On the Center

- a. Press MENU to enter the menu screen
- b. Press ▲ or ▼ and ► to enter Settings > Network > Internet
- c. Press ► to continue
- d. Set DNS



- 1) Enter the DNS server you wrote down
- 2) Press OK►II to confirm
- 3) Press OK►II to skip Set DNS2

Helpful hint:

- If necessary, follow Steps 1) to 2) above to set a secondary DNS server in Set DNS2

- e. Set Gateway
- 1) Enter the Gateway you wrote down
- 2) Press OK►II to confirm

- f. Set proxy
If you are using a proxy server to visit websites, enable Proxy and proceed with the proxy setting as prompted, then press OK►II to confirm
Otherwise, press OK►II to skip


- 3) Choose to apply the settings as prompted
→ Settings will change. **Connection to station could be lost** appears.


12.2.2 Looking up CD track information


When the internet connection is made, insert the CD disc that you want to look for its information into the CD loader on the Center. Searching starts immediately. It will search from local Gracenote CD database firstly. If it can't find the CD track information, online searching will then start. The searching results will be shown on the Center's display,

Helpful hint:

If the internet query failed due to failure in internet connection, the error message "Check the internet setup for Gracenote online" will appear. Check if your internet connection is correct (see **12.2.1** above)

Malfunction Check Chart

SERVICE TEST PROGRAM

SERVICE TEST PROGRAM

DISASSEMBLY INSTRUCTION

1. Remove Left & Right Cabinet

- remove screws M3x10 - 4 pcs **(A)**




- Pull the left or right cabinet and then lift it.



2. Remove Top Cabinet

- a. remove screws M3x8 - 2 pcs **(B)** & 2 pcs **(C)**
- b. lift the Top Cabinet




3. Separate Front and Back Cabinet.

- a. remove screws T3x8 - 2 pcs. **(D)**
- b. remove screws T3x6 - 2 pcs. **(E)**




c. release the catches. **(F)**





5. Remove Amplifier board

- a. remove screws T3x4 - 1 pcs **(J)**



4. Separate rear and bottom Cabinet.

- a. remove screws T3x6 - 6 pcs. **(G)**
- b. remove screws T3x6 - 4 pcs. **(H)**
- b. remove screws M3x10 - 1 pcs. **(I)**




6. Attention - Jump is set on slave part.




Block Diagram


Blockdiagram MCi-300




Wiring Diagram




PB - AF & AMP - Circuit Diagram - PART1




PB - AF & AMP - Circuit Diagram - PART2


PB - AF & AMP - Circuit Diagram - PART3




PB - AF & AMP - Circuit Diagram - PART4




1102 A9	5013 F4
1108 E1	5014 E5
1110 E1	5021 E8
1110 A1	5026 E4
1401 D9	5027 F8
1520 F4	5039 E8
1521 D2	5040 F8
1522 D6	5041 A4
1523 D5	5709 F8
1524 E4	5710 F8
2205 A1	5711 C3
2240 A8	5712 C1
2901 E5	5713 C3
2958 B1	5714 D3
2961 A1	5715 D3
2963 B2	5716 D3
2967 B2	6206 B7
2968 B3	6207 E3
2969 A3	6208 E3
2970 A3	6209 E2
2971 B2	6210 E3
2972 B4	6211 E2
2973 B2	6212 E3
2974 D8	7211 B8
2975 F2	7212 A7
2976 A2	7610 A3
2977 C3	7611 B7
2978 C4	F301 E8
2979 F4	F302 E1
2980 C1	F303 E8
2981 C7	F304 E8
3205 B7	F305 E5
3206 D3	F306 E1
3211 D3	F307 E8
3242 D7	F308 E5
3243 D7	F309 E4
3244 A4	F310 E1
3245 B8	F311 E5
3247 B8	F312 E8
3253 A7	F313 E1
3258 E8	F314 E5
3259 E8	F315 E8
3300 A2	F316 F5
3301 A3	F317 F1
3302 A2	F318 F8
3303 B3	F319 F1
3304 B4	F320 F8
3306 B4	F321 F8
3307 B3	F322 F4
3309 A2	F323 F8
3310 A2	F324 F1
3311 A8	F326 F1
3312 B7	F327 F1
3317 D8	F328 F1
3318 D7	F329 D8
3319 F2	F330 D9
3320 E8	F331 D9
3321 E8	F332 E9
3322 E8	F333 A9
3323 E8	F334 A8
3324 F2	F335 E8
3325 F4	
3327 E5	
3328 E4	
3329 F4	
3332 D3	
3333 D5	
3334 D5	
3335 D8	
3336 D8	
3337 D8	
3338 E8	
3339 F8	
3340 A8	
3341 B7	
3342 B7	
3343 C7	
3344 A8	
4002 C8	


PB - AF& - Layout Diagram - Top View




PB - AF& - Layout Diagram - Bottom View



PB - Keys & IR - Circuit Diagram




PB - Keys & IR - Layout Diagram - Top View





00002	N3
00033	N2
00034	N2
00035	M1
00036	M3
1100	E3
1101	S3
1102	S3
1103	H3
1104	H3
1105	H3
1106	H3
1107	H3
1108	H3
1109	H3
1110	H3
1111	H3
1112	H3
1113	H3
1114	H3
1115	H3
1116	H3
1117	H3
1118	H3
1119	H3
1120	H3
1121	H3
1122	H3
1123	H3
1124	H3
1125	H3
2101	H3
2102	H3
2103	H3
2104	H3
2105	H3
2106	H3
2107	H3
2108	H3
2109	H3
2110	H3
2111	H3
2112	H3
2113	H3
2114	H3
7101	H3
7102	H3
7103	H3
7104	H3
7105	H3
7106	H3
7107	H3
7108	H3
7109	H3
7110	H3
7111	H3
7112	H3
7113	H3
7114	H3
9001	H3
9002	H3
9003	H3
9004	H3
9005	H3
9006	H3
9007	H3
9008	H3
9009	H3
9010	H3
9011	H3
9012	H3
9013	H3
9014	H3
9015	H3
9016	H3
9017	H3
9018	H3
9019	H3
9020	H3
9021	H3
9022	H3
9023	H3
9024	H3
9025	H3
9026	H3
9027	H3
9028	H3
9029	H3
9030	H3
9031	H3
9032	H3
9033	H3
9034	H3
9035	H3
9036	H3
9037	H3
9038	H3
9039	H3
9040	H3
9041	H3
9042	H3
9043	H3
9044	H3
9045	H3
9046	H3
9047	H3
9048	H3
9049	H3
9050	H3
9051	H3
9052	H3
9053	H3
9054	H3
9055	H3
9056	H3
9057	H3
9058	H3
9059	H3
9060	H3
9061	H3
9062	H3
9063	H3
9064	H3
9065	H3
9066	H3
9067	H3
9068	H3
9069	H3
9070	H3
9071	H3
9072	H3
9073	H3
9074	H3
9075	H3
9076	H3
9077	H3
9078	H3
9079	H3
9080	H3
9081	H3
9082	H3
9083	H3
9084	H3
9085	H3
9086	H3
9087	H3
9088	H3
9089	H3
9090	H3
9091	H3
9092	H3
9093	H3
9094	H3
9095	H3
9096	H3
9097	H3
9098	H3
9099	H3
90100	H3
90101	H3
90102	H3
90103	H3
90104	H3
90105	H3
90106	H3
90107	H3
90108	H3
90109	H3
90110	H3
90111	H3
90112	H3
90113	H3
90114	H3
90115	H3
90116	H3
90117	H3
90118	H3
90119	H3
90120	H3
90121	H3
90122	H3
90123	H3
90124	H3
90125	H3
90126	H3
90127	H3
90128	H3
90129	H3
90130	H3
90131	H3
90132	H3
90133	H3
90134	H3
90135	H3
90136	H3
90137	H3
90138	H3
90139	H3
90140	H3
90141	H3
90142	H3
90143	H3
90144	H3
90145	H3
90146	H3
90147	H3
90148	H3
90149	H3
90150	H3
90151	H3
90152	H3
90153	H3
90154	H3
90155	H3
90156	H3
90157	H3
90158	H3
90159	H3
90160	H3
90161	H3
90162	H3
90163	H3
90164	H3
90165	H3
90166	H3
90167	H3
90168	H3
90169	H3
90170	H3
90171	H3
90172	H3
90173	H3
90174	H3
90175	H3
90176	H3
90177	H3
90178	H3
90179	H3
90180	H3
90181	H3
90182	H3
90183	H3
90184	H3
90185	H3
90186	H3
90187	H3
90188	H3
90189	H3
90190	H3
90191	H3
90192	H3
90193	H3
90194	H3
90195	H3
90196	H3
90197	H3
90198	H3
90199	H3
90200	H3
90201	H3
90202	H3
90203	H3
90204	H3
90205	H3
90206	H3
90207	H3
90208	H3
90209	H3
90210	H3
90211	H3
90212	H3
90213	H3
90214	H3
90215	H3
90216	H3
90217	H3
90218	H3
90219	H3
90220	H3
90221	H3
90222	H3
90223	H3
90224	H3
90225	H3
90226	H3
90227	H3
90228	H3
90229	H3
90230	H3
90231	H3
90232	H3
90233	H3
90234	H3
90235	H3
90236	H3
90237	H3
90238	H3
90239	H3
90240	H3
90241	H3
90242	H3
90243	H3
90244	H3
90245	H3
90246	H3
90247	H3
90248	H3
90249	H3
90250	H3
90251	H3
90252	H3
90253	H3
90254	H3
90255	H3
90256	H3
90257	H3
90258	H3
90259	H3
90260	H3
90261	H3
90262	H3
90263	H3
90264	H3
90265	H3
90266	H3
90267	H3
90268	H3
90269	H3
90270	H3
90271	H3
90272	H3
90273	H3
90274	H3
90275	H3
90276	H3
90277	H3
90278	H3
90279	H3
90280	H3
90281	H3
90282	H3
90283	H3
90284	H3
90285	H3
90286	H3
90287	H3
90288	H3
90289	H3
90290	H3
90291	H3
90292	H3
90293	H3
90294	H3
90295	H3
90296	H3
90297	H3
90298	H3
90299	H3
90300	H3
90301	H3
90302	H3
90303	H3
90304	H3
90305	H3
90306	H3
90307	H3
90308	H3
90309	H3
90310	H3
90311	H3
90312	H3
90313	H3
90314	H3
90315	H3
90316	H3
90317	H3
9031	


PB - Keys & IR - Layout Diagram - Bottom View



PB - Audio in/out




2202	A2
2203	B3
2204	C2
2205	C2
2206	B1
2207	B3
2208	C1
3202	B2
3203	B1
3204	B2
3205	B2
3206	B3
3207	B3
3208	B2
3209	C3
5202	B2
5203	B2





0002 C3
1200 C2
1201 B1


10-1

PB - Headphone


10-1




11-1

PB - Wifi - Light


11-1



2400 A1



PB - Wessli - 08 - Circuit Diagram - melody part




Ref Des	MC130
3078	31980310 15K
3087	NOT US


Ref Des		MC1300-USA-TUV/2
3006	319803101030 10K	NOT USED
3015	NOT USED	319803101030 10K
3022	319803101030 10K	319803101030 10K

PB - Wessli - 08 - Circuit Diagram - Flash & SDRAM part

0606 G5 2201 A5 2204 A6 2209 H3 2212 E4 3200 B6 3201-3 B6 3206 B6 3209-1 C6 3209-4 C6 3215 C6 3217-2 F5 3221-1 G5 3221-4 F5 3225-3 G5 3229-2 F5 3235 G3 3251 C12 5012 B12 5203 A12 5201 E4 5211 C12 5214 C12 5217 C12 5220 C12
 1202 C12 2202 A5 2205 A6 2210 A6 2213 A13 3201-1 B6 3201-4 B6 3207 B6 3209-2 C6 3212 C3 3216 C6 3217-3 G5 3221-2 F5 3225-1 G5 3229-3 G5 3236 G3 3252 D13 5200 A12 5204 A11 5202 B13 5201 A12 5210 A12 5212 C12 5215 C12 5218 C12 5219 C12
 2200 A5 2203 A6 2206 A12 2211 B12 2214 E4 3205 B6 3208 C6 3209-3 C6 3214 C6 3217-1 G5 3217-4 F5 3221-3 G5 3225-2 F5 3229-4 G5 3230 G3 4201 B3 5202 B13 7200 A4 7201 A12 7203 A9 7204 A11 7205 A12 7206 A12 7207 A12 7208 A12 7209 A12 7210 A12 7211 A12 7212 A12 7213 A12 7214 A12 7215 A12 7216 A12 7217 A12 7218 A12 7219 A12




PB - Wessli - 08 - Circuit Diagram - Ethernet part




PB - Wessli - 08 - Circuit Diagram - EPLD part

2801 A9	2806 B9	3800 A4	3802-4 D7	3810 B4	3813-4 B4	3818-3 C7	3819-4 C4	3827-1 C4	3832-2 C7	3833-3 C4	3841-4 D4	3844-1 D7	3851 D4	3855-4 D4	3862-1 D4	3870 A3	7800 A5	F805 A9
2802 B9	2807 B10	3801 E7	3804 A2	3812 B3	3814 C7	3818-4 C7	3826-1 C7	3827-2 C4	3832-3 C7	3833-4 C4	3842-1 D7	3844-2 D7	3853 D4	3856-1 D7	3862-2 D4	3871 D7	F801 B3	
2803 B9	2808 B10	3802-1 A4	3805 A2	3813-1 C4	3816 C7	3819-1 C4	3826-2 B4	3827-3 C4	3832-4 C7	3841-1 D4	3842-2 D7	3844-3 D7	3855-1 D4	3856-2 D7	3862-3 E4	5800 A9	F802 B3	
2804 B9	2809 B10	3802-2 A4	3806 A2	3813-2 C4	3818-1 C7	3819-2 C4	3826-3 C7	3827-4 B4	3833-1 D4	3841-2 D4	3842-3 D7	3844-4 D7	3855-2 D4	3856-3 D7	3862-4 E4	5801 A10	F803 B3	
2805 B9	2810 A3	3802-3 B4	3807 A2	3813-3 C4	3818-2 C7	3819-3 C4	3826-4 C7	3832-1 C7	3833-2 C4	3841-3 D4	3842-4 D7	3849 D4	3855-3 D4	3856-4 D7	3863 E7	5804 A10	F804 B3	




PB - Wessli - 08 - Circuit Diagram - mPCI & ATA Connector part

1500-A C5	2500 A2	2521 D3	2525 F6	3502 C7	3506 C12	3511 C12	3516 E12	3521 C12	3525 C12	3529 D6	3533-1 F6	3534 F11	3539 D4	3543 E4	3548 G11	3552 E4	3553-4 E6	3557 D12	3561 D12	3565 E4	3569 E12	3574 E4	3582-1 F4	3583 E12	3587-3 F6	3598 F4	4502 G6	5501 A2	6500 E12
1500-B C5	2501 B12	2522 D6	2526 F3	3503 C7	3507 B12	3512 C12	3517 E12	3522 D4	3526 C12	3530 C12	3532-2 F6	3535 D4	3540 D6	3544 E6	3549 F12	3553-1 E6	3554 C12	3558 D12	3562 D12	3566 E6	3570 E6	3582-2 F4	3586 F6	3587-4 F6	3599 F4	4503 G4	5502 A2	F501 A3	
1506 B14	2519 D3	2523 E3	3500 A11	3504 C12	3508 D4	3513 C12	3518 C12	3523 D6	3527 E2	3531 F4	3533-3 F6	3536 D6	3541 F12	3545 F12	3550 C4	3553-2 E6	3555 C12	3559 D12	3563 E4	3567 E4	3571 E6	3575 E6	3582-3 F4	3587-1 F6	3596 F4	4504 D13	5503 A12	F502 A13	
1507 D14	2520 D6	2524 E6	3501 B12	3505 D6	3509 D6	3514 D6	3519 D4	3524 C12	3528 C12	3532 D4	3533-4 F6	3538 F11	3542 F12	3547 E4	3551 F12	3553-3 E6	3556 E3	3560 D12	3564 E12	3568 E12	3572 E12	3581 E6	3582-4 F4	3587-2 F6	3597 F4	4501 G6	5500 A2	5504 D6	



PB - Wessli - 08 - Circuit Diagram - I/O Interface part


1107 G4	1627 F4	2615 B5	2621 B5	2627 F8	2634 D3	2643 B12	3012 C8	3616 C11	3632-2 A3	3633-4 B3	3657 F8	3663 B3	3676 F3	3682 F10	3688 G9	5617 C3	5633 F13	5639 A13	5645 B13	5651 D14	7002 D8	7008 G10	F676 A14	F683 B14	F691 C14	
1108 H4	1628 F14	2616 A5	2622 B5	2628 F8	2638 G12	2644 B12	3021 C8	3617 C10	3632-3 A3	3634-1 B3	3659 F9	3668 F9	3677 F3	3683 G8	3689 G10	5618 C5	5634 F13	5640 A13	5646 B13	5650 D13	7000 G9	7001 G9	F677 A14	F684 B14	F692 C14	
1600 G4	2609 G9	2617 B5	2623 B5	2629 Q3	2639 G12	2645 B13	3002 C11	3610 C10	3632-4 A3	3634-2 B3	3650 F9	3669 C4	3678 F3	3684 G8	4008 H4	5620 Q2	5635 F13	5641 A13	5647 B13	5653 D13	7003 G9	7002 G9	F678 A14	F697 D14	F693 C14	
1604 C1	2612 D8	2618 B5	2624 A5	2631 C5	2640 B12	2646 B13	3006 C12	3622 A5	3633-1 A3	3634-3 B3	3660 F8	3670 G8	3678 C10	3685 G10	4601 F10	5622 E4	5636 F13	5642 A13	5648 B13	5654 C13	7003 C4	7004 D11	F654 F4	F680 A14	F688 B14	F694 C14
1608 A1	2613 C10	2619 B5	2625 A5	2632 D4	2641 B12	2647 B13	3614 C8	3631 D12	3633-2 B3	3634-4 B3	3661 F8	3671 G8	3680 D11	3686 G10	4602 D10	5623 F3	5637 A13	5643 B13	5649 C11	5655 D13	7004 D11	7005 F4	F655 F4	F681 A14	F689 C14	F695 B14
1609 B14	2614 A5	2620 B5	2626 A5	2633 F4	2642 B12	2648 C9	3615 C8	3632-1 A3	3636 S3	3662 H9	3673 D5	3681 F10	3687 H8	5604 B8	5624 F3	5638 A13	5644 B13	5650 D14	6606 G10	7006 H8	F656 F4	F682 A14	F690 C14	F696 B14		



Ref Des	LCD-BL-DIM	LCD-BL-DIM-NO
3670	319802151010 0805 100R	319802153390 0805 33R


Ref Des	BK_LIGHT_ON	DIM NO	DIM
3671	X	319802153390 0805 33R	
	1	ON	OFF
	HZ	-	MEDIUM
	0	OFF	HIGH

PB - Wessli - 08 - Circuit Diagram - AF part




1705 B8	3770 B4
1706 G13	3771 C4
2703 B3	3772 C4
2704 B3	3773 D4
2705 D9	3774 D3
2706 E10	3775 E3
2707 E8	3776 E3
2708 E10	3777 E4
2709 E13	3778 E4
2710 E10	3779 E4
2711 E10	3780 E4
2712 E8	3781 E4
2713 E10	3782 E4
2714 E7	3783 E4
2715 F9	3784 F4
2716 G8	3785 F4
2717 G4	3786 F4
2719 G5	3787 I3
2720 G8	3788 I3
2721 G5	3789 I13
2722 G7	3790 I13
2723 G4	3791 I13
2724 G9	3792 I13
2725 H9	3793 E7
2727 H7	3794 E7
2729 H5	4703 D2
2731 H9	4706 I2
2734 H7	4707 E2
2735 H7	4709 I2
2736 H7	4711 G5
2737 H4	4715 H5
2738 H9	4716 G13
2739 H11	4717 G13
2741 H5	5022 A6
2742 H4	5710 I10
2743 I9	5715 E10
2744 I5	5717 G7
2745 G3	5719 H11
2747 G11	5720 H1
2748 H2	5721 H1
2749 H12	5724 H1
2750 H2	5727 H13
2751 H12	5730 H13
2753 A12	5731 I13
2754 B13	5734 H13
2755 B10	5735 H13
2756 B13	5736 H13
2757 B13	5738 A5
2758 B13	5740 A11
2759 B10	5741 B12
2760 C13	5742 B13
2762 C11	5743 B12
2763 C12	5744 D4
2764 A5	5745 E4
2765 B6	5746 E4
2767 B7	5747 E4
2768 B5	5748 F5
2769 D3	5750 G1
2770 D2	5751 H1
2771 E2	6700 B3
2772 E3	7704 E13
2773 B7	7705 D9
2774 C6	7706 F3
2775 F5	7707 G2
3706 B3	7708-1 G5
3712 A4	7708-2 H5
3713 B3	7709 G4
3715 B4	7710 G8
3716 E12	7711 B3
3717 E12	7712 A5
3718 E7	7713 A12
3719 E12	7714 F5
3720 E12	7715 D3
3722 E7	7716 D4
3723 F2	7702 B2
3725 E13	7704 E13
3726 F3	7725 E7
3727 E2	7729 G2
3728 G2	7764 F5
3730 G10	7765 B7
3731 G6	7766 B7
3732 H5	7767 B7
3733 H5	7713 H1
3734 H11	3735 H11
3737 I3	3738 I3
3739 I3	3740 I3
3741 I3	3742 I3
3743 H10	3744 H6
3745 I5	3746 I5
3747 G3	3755 H13
3751 H13	3754 H13
3754 H13	3755 H13
3755 H13	3756 H13
3756 H13	3757 H13
3757 H13	3758 H13
3758 H13	3759 G12
3760 G12	3761 G12
3762 H9	3763 I9
3766 C3	3767 A4
3768 B7	3769 B5

PB - Wessli - 08 - Circuit Diagram - SUPPLY part




1901 A2
1902 B3
1903 A1
1904 B1
1905 E1
1906 E1
2900 A4
2901 A4
2902 A4
2903 A4
2904 B8
2905 B8
2906 B9
2907 B9
2908 B6
2909 B3
2910 C3
2911 C4
2912 C4
2913 E7
2914 D2
2915 D3
2916 D4
2917 E2
3900 A4
3901 A4
3902 A4
3903 A4
3904 A4
3905 B7
3906 B7
3908 D6
3909 E6
3910 E3
3911 B9
3912 B8
3913 B7
3914 B8
3915 C9
4902 D6
4903 A3
5900 A7
5901 A7
5902 A8
5903 B3
5904 B3
5905 C2
6900 B7
7900 A5
7901 B3
7902 D6
7903 D3
7904 E6
7905 E3
7906 C8
F901 B2
F902 B2
F903 B2
F904 B2
F905 A9
F906 E4
F907 D7
F910 B4
F911 D4


PB - Wessli - 08 - Circuit Diagram - TUNER part




PB - Wessli - 08 - Layout Diagram - Layer 1



PB - Wessli - 08 - Layout Diagram - Layer 2



Explode Diagram



ACCESSORIES PARTS LIST

456	242207600687	ANT FM DIP SD-2380 B
457	314107870351	CD ROM INSTALL SW MCI300/12
460	313923817261	RC2023629/01
469	242207098147	MAINSCORD UK 2A5 1M5 DET 2P B(FOR /05)
469	242207098151	MAINSCORD EUR 2A5 1M5 DET 2P B(FOR /12)
470	314107850183	BOX SPK ASSY WAC3500D

MISCELLANEOUS PARTS LIST

201	314107751541	CAB F PRE-ASSY MCI300/12
202	314107751191	CABINET TOP PRE-ASSY WAC3500D
208	314107403761	PANEL LEFT WAC3500D/12
209	314107403772	PANEL RIGHT WAC3500D/12
210	314107751561	CD DOOR PRE-ASSY MCI300/12
211	314107401841	FOOT RUBBER WAC5
246	314107404331	ISOLATOR PIN WAC3500D
247	314107403851	HOLDER ANTENNA WAC3500D
8002	314107021691	FFC 10P/430/10P BD 1.25mm FOLD
8005	314107021941	FFC 23P/200/23P 1MM BD FOLD
8006	314107021951	FFC 26P/280/26P 1MM BD FOLD
8007	314107021621	CBLE 5P PH/250 /USB-A (REC)
8008	314107021721	CBLE IDE 40P/165/20P
1000	314107802971	PBAS AF& MCI300_RDS
1002	282203100065	FAN 12VDC 0.8W 3100RPM B
1000	314107802941	PBAS WessLi-08 (BW) MCI300/12
1001	282206502109	WMOD WIFIG MPC1 PM101_US B
1004	314107850311	MODULE SMPS MCI300/05
1005	242254200049	TUN FM ENG07826QF EUR B
1006	314107050441	DVDROM 16D2P+FW EPT4 WAC3500D
1007	272217100524	LCD MODULE PCE2035-02 (VARI) Y
1008	242207600717	ANT WIFI 2450MHZ 50R Y
1009	242254900668	ANT WIFI WAS5 B
1011	314107802991	PBAS 9 - Keys&RC MCI300
1012	314107802341	PBAS - AUDIO in/out WAC3500D
1013	314107802351	PBAS 7 - Headphone WAC3500D
1014	314107802361	PBAS 6 - WiFi-light WAC3500D

Note: Only these parts mentioned in the list are normal service parts.