

**Service  
Service  
Service**



# Service Manual



## TABLE OF CONTENTS

Handling chip components .....	1-1
Leadfree and safety information .....	1-2
Technical specification .....	2-1
Service tools .....	2-1
Service measurement setup .....	2-2
Connections and controls.....	3-1...3-2
Dismantling instructions .....	4-1...4-3
Block diagram.....	5-1
Wiring diagram .....	6-1
Main Board	
circuit diagram .....	7-1...7-2
layout diagram.....	7-3...7-4
C Music Board	
circuit diagram .....	8-1...8-2
layout diagram.....	8-3...8-4
VFD Board	
circuit diagram.....	9-1
layout diagram.....	9-2
Cassette Board	
circuit diagram.....	10-1
layout diagram .....	10-2
Tuner Board	
circuit diagram.....	11-1
layout diagram.....	11-2
Rectifier Board	
circuit diagram.....	12-1
layout diagram.....	12-2
Exploded view diagram .....	13-1
Mechanical partslist.....	13-2
Electrical partslist .....	14-1...14-5
Supplier Bomlist	

© Copyright 2007 Philips Consumer Electronics B.V. Eindhoven, The Netherlands  
All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form or by any means, electronic, mechanical, photocopying, or otherwise without the prior permission of Philips.

Published by LX 0717 Service Audio Subject to modification

GB 3141 785 31790


**Version 1.0**



**CLASS 1  
LASER PRODUCT**

**PHILIPS**

## HANDLING CHIP COMPONENTS



### (GB) WARNING

All ICs and many other semiconductors are susceptible to electrostatic discharges (ESD). Careless handling during repair can reduce life drastically. When repairing, make sure that you are connected with the same potential as the mass of the set via a wristband with resistance. Keep components and tools at this potential.

### (F) ATTENTION

Tous les IC et beaucoup d'autres semi-conducteurs sont sensibles aux décharges statiques (ESD). Leur longévité pourrait être considérablement écourtée par le fait qu'aucune précaution n'est prise à leur manipulation. Lors de réparations, s'assurer de bien être relié au même potentiel que la masse de l'appareil et enfilez le bracelet relié à une résistance de sécurité. Veiller à ce que les composants ainsi que les outils que l'on utilise soient également à ce potentiel.

### (GB)

Safety regulations require that the set be restored to its original condition and that parts which are identical with those specified be used.

Safety components are marked by the symbol

### (F)

Les normes de sécurité exigent que l'appareil soit remis à l'état d'origine et que soient utilisées les pièces de rechange identiques à celles spécifiées.

Les composants de sécurité sont marqués



### (D) WARNUNG

Alle IC's und viele andere Halbleiter sind empfindlich gegenüber elektrostatischen Entladungen (ESD). Unsorgfältige Behandlung im Reparaturfall kann die Lebensdauer drastisch reduzieren. Sorgen Sie dafür, daß Sie im Reparaturfall über ein Pulsschleife mit Widerstand mit dem Massepotential des Gerätes verbunden sind. Halten Sie Bauteile und Hilfsmittel ebenfalls auf diesem Potential.



### (NL) WAARSCHUWING

Alle IC's en vele andere halfgeleiders zijn gevoelig voor elektrostatische ontladingen (ESD). Onzorgvuldig behandelen tijdens reparatie kan de levensduur drastisch doen verminderen. Zorg ervoor dat u tijdens reparatie via een polsband met weerstand verbonden bent met hetzelfde potentiaal als de massa van het apparaat. Houd componenten en hulpmiddelen ook op ditzelfde potentiaal.

### (I) AVVERTIMENTO

Tutti IC e parecchi semi-conduttori sono sensibili alle scariche statiche (ESD). La loro longevità potrebbe essere fortemente ridotta in caso di non osservazione della più grande cautela alla loro manipolazione. Durante le riparazioni occorre quindi essere collegato allo stesso potenziale che quello della massa dell'apparecchio tramite un braccialetto a resistenza. Assicurarsi che i componenti e anche gli utensili con quali si lavora siano anche a questo potenziale.

### (NL)

Veiligheidsbepalingen vereisen, dat het apparaat in zijn oorspronkelijke toestand wordt teruggebracht en dat onderdelen, identiek aan de gespecificeerde, worden toegepast. De Veiligheidsonderdelen zijn aangeduid met het symbool

### (I)

Le norme di sicurezza estigono che l'apparecchio venga rimesso nelle condizioni originali e che siano utilizzati i pezzi di ricambio identici a quelli specificati.

Componenti di sicurezza sono marcati con

**CLASS 1  
LASER PRODUCT**

**(GB) DANGER:** Invisible laser radiation when open.  
AVOID DIRECT EXPOSURE TO BEAM.

**(S) Warning !**  
Osynlig laserstrålning när apparaten är öppnad och spärren är urkopplad. Betrakta ej strålen.

**(DK) Advarsel !**  
Usynlig laserstrålning ved åbning når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling.

**(GB)** After servicing and before returning the set to customer perform a leakage current measurement test from all exposed metal parts to earth ground, to assure no shock hazard exists.

The leakage current must not exceed 0.5mA.

**(FIN) Varoitus !**  
Avattessa laitteessa ja suojalukituksen ohittaa olet alittiin näkymättömälle laserisäteilylle. Älä katso säteeseen !

**(F)** Pour votre sécurité, ces documents doivent être utilisés par des spécialistes agréés, seuls habilités à réparer votre appareil en panne".

## INFORMATION ABOUT LEAD-FREE SOLDERING

Philips CE is producing lead-free sets from 1.1.2005 onwards.

### IDENTIFICATION:

Regardless of special logo (not always indicated) one must treat all sets from **1 Jan 2005** onwards, according next rules:



### Example S/N:



Bottom line of typeplate gives a 14-digit S/N. Digit 5&6 is the year, digit 7&8 is the week number, so in this case 2005 wk12

So from **0501** onwards = from 1 Jan 2005 onwards

***Important note: In fact also products of year 2004 must be treated in this way as long as you avoid mixing solder-alloys (leaded/ lead-free). So best to always use SAC305 and the higher temperatures belong to this.***

Due to lead-free technology some rules have to be respected by the workshop during a repair:

- Use only lead-free solder alloy Philips SAC305 with order code 0622 149 00106. If lead-free solder-paste is required, please contact the manufacturer of your solder-equipment. In general use of solder-paste within workshops should be avoided because paste is not easy to store and to handle.
- Use only adequate solder tools applicable for lead-free solder alloy. The solder tool must be able
  - To reach at least a solder-temperature of 400°C,
  - To stabilize the adjusted temperature at the solder-tip
  - To exchange solder-tips for different applications.
- Adjust your solder tool so that a temperature around 360°C – 380°C is reached and stabilized at the solder joint. Heating-time of the solder-joint should not exceed ~ 4 sec. Avoid temperatures above 400°C otherwise wear-out of tips will rise drastically and flux-fluid will be destroyed. To avoid wear-out of tips switch off un-used equipment, or reduce heat.
- Mix of lead-free solder alloy / parts with leaded solder alloy / parts is possible but PHILIPS recommends strongly to avoid mixed solder alloy types (leaded and lead-free).
   
If one cannot avoid or does not know whether product is lead-free, clean carefully the solder-joint from old solder alloy and re-solder with new solder alloy (SAC305).
- Use only original spare-parts listed in the Service-Manuals. Not listed standard-material (commodities) has to be purchased at external companies.
- Special information for BGA-ICs:
  - always use the 12nc-recognizable soldering temperature profile of the specific BGA (for de-soldering always use the lead-free temperature profile, in case of doubt)
  - lead free BGA-ICs will be delivered in so-called 'dry-packaging' (sealed pack including a silica gel pack) to protect the IC against moisture. After opening, dependent of MSL-level seen on indicator-label in the bag, the BGA-IC possibly still has to be baked dry. (MSL=Moisture Sensitivity Level). This will be communicated via AYS-website.
  - Do not re-use BGAs at all.
- For sets produced before 1.1.2005 (except products of 2004), containing leaded solder-alloy and components, all needed spare-parts will be available till the end of the service-period. For repair of such sets nothing changes.
- On our website [www.atyourservice.ce.Philips.com](http://www.atyourservice.ce.Philips.com) you find more information to:
  - BGA-de-/soldering (+ baking instructions)
  - Heating-profiles of BGAs and other ICs used in Philips-sets

You will find this and more technical information within the "magazine", chapter "workshop news".

For additional questions please contact your local repair-helpdesk.

## SERVICE INSTRUCTION

Safety regulations require that after a repair, the set must be returned in its original condition. Pay in particular attention to the following points:

- Route the wire trees correctly and fix them with the mounted cable clamps.
- Check the insulation of the AC Power lead for external damage.
- Check the strain relief of the AC Power cord for proper function.
- Check the electrical DC resistance between the AC Power Plug and the secondary side (only for sets which have a AC Power isolated power supply):
- 1. Unplug the AC Power cord and connect a wire between the two pins of the AC Power plug.
- 2. Set the AC Power switch to the "on" position (keep the AC Power cord unplugged!).
- 3. Measure the resistance value between the pins of the AC Power plug and the metal shielding of the tuner or the aerial connection on the set. The reading should be larger than 4.5 Mohm (For U.S. it should be between 4.2 Mohm and 12 Mohm).
- 4. Switch "off" the set, and remove the wire between the two pins of the AC Power plug.
- Check the cabinet for defects, to avoid touching of any inner parts by the customer.

## TECHNICAL SPECIFICATIONS

### AMPLIFIER

Output power .....	2 x 50 W RMS*
Signal-to-noise ratio .....	≥62 dBA (IEC)
Frequency response .....	40 – 15000 Hz, ± 3 dB
Impedance loudspeakers .....	6 Ω
Impedance headphones .....	32 Ω
* (4 Ω, 1 kHz, 10% THD)	

### CD/MP3-CD PLAYER

Number of programmable tracks .....	20
Frequency range .....	20 – 20000 Hz
Signal-to-noise ratio .....	75 dBA
Channel separation .....	≥60 dB (1 kHz)
Total harmonic distortion .....	< 0.003%
MPEG 1 Layer 3 (MP3-CD) .....	MPEG AUDIO
MP3-CD bit rate .....	32-256 kbps (128 kbps advised)
Sampling frequencies .....	32, 44.1, 48 kHz

### USB PLAYER

USB .....	12Mb/s,V1.1
..... support MP3 and WMA files	
Number of albums/folders .....	maximum 99
Number of tracks/titles .....	maximum 500

### TUNER

FM wave range .....	87.5 – 108 MHz
LW wave range .....	153 – 279 kHz
MW wave range .....	531 – 1602 kHz
Sensitivity at 75 Ω	
– mono, 26 dB signal-to-noise ratio .....	2.8 µV
– stereo, 46 dB signal-to-noise ratio .....	61.4 µV
Selectivity .....	≥28 dB
Total harmonic distortion .....	≤5%
Frequency response ....	63 – 12500 Hz (± 3 dB)
Signal-to-noise-ratio .....	≥50 dBA

## SERVICE TOOLS


<b>TORX T10</b> screwdriver with shaftlength 150mm.....	4822 395 50423
<b>TORX screwdriver set</b> SBC 163.....	4822 295 50145
<b>Audio signal disc</b> SBC 429.....	4822 397 30184
<b>Playability test disc</b> SBC 444.....	4822 397 30245
<b>Test disc 5</b> (disc without errors ) +	
<b>Test disc 5A</b> (disc with dropout errors, black spots and fingerprints) SBC 426/426A.....	4822 397 30096
<b>Burn in test disc</b> (65 min. 1kHz signal at -30 dB level without “pause”)....	4822 397 30155
<b>Universal test cassette Fe</b> SBC 420 .....	4822 397 30071

## AVAILABLE ESD PROTECTION EQUIPMENT

<b>anti-static table mat</b> large	1200x650x1.25mm	4822 466 10953
small	600x650x1.25mm	4822 466 10958
<b>anti-static wristband</b>		4822 395 10223
<b>connection box</b> (3 press stud connections, 1MΩ)		4822 320 11307
<b>extendible cable</b> (2m, 2MΩ, to connect wristband to connection box)		4822 320 11305
<b>connecting cable</b> (3m, 2MΩ, to connect table mat to connection box)		4822 320 11306
<b>earth cable</b> (1MΩ, to connect any product to mat or to connection box)		4822 320 11308
<b>KIT ESD3</b> (combining all 6 prior products - small table mat)		4822 310 10671
<b>wristband tester</b>		4822 344 13999


## SERVICE MEASUREMENT

### Tuner FW



Use a bandpass filter to eliminate hum (50Hz, 100Hz) and disturbance from the pilottone (19kHz, 38kHz).


### Tuner AM (MW,LW)



To avoid atmospheric interference all AM-measurements have to be carried out in a Faraday's cage.  
Use a bandpass filter (or at least a high pass filter with 250kHz) to eliminate hum (50Hz, 100Hz).


### CD

Use Audio Signal Disc SBC429 4822 397 30184  
(replaces test disc 3)





### RECORDER

Use Universal Test Cassette Fe SBC420 4822 397 30071



## CONNECTION AND CONTROLS

### Controls (main set illustrations on page 3)



**(4) PROGRAM**  
for CD/MP3-CD/USB...to programme disc tracks.  
for Tuner .....to programme preset radio stations.

**(5) RDS/CLOCK SET**  
for Tuner .....to activate RDS news.  
for Clock .....(on the system only) to set the clock function.

**(6) TUNING ▶▶▶◀◀◀**  
for CD/MP3-CD/USB

.....to select a desired track  
.....(press and hold) o search backward/forward.  
for Tuner .....to tune to a lower or higher radio frequency.  
for Tape .....to rewind or fast forward.

**(7) ALBUM/RESET ▶◀**  
for MP3-CD/USB to select previous/next album.  
for Tuner .....to select a preset radio station.

**(8) STOP ■**

for CD/MP3-CD/USB...to stop playback or to clear a programme.  
for Tape .....to stop playback or recording.

**(9) PLAY/PAUSE ▶■■**

for CD/MP3-CD/USB...to start or interrupt playback.  
for Tuner .....to open tape compartment.

**(10) TAPE DECK**

**(11) OPEN/CLOSE ▲**  
- to open tape compartment.  
for Tape .....to start playback.

**(12) DBB/BIS**

- to create a super-enhanced stereo effect.  
- to enhance the bass.

**(13) DSC (Digital Sound Control)**

- to select the desired sound effect :OPTIMAL,  
ROCK,JAZZ, or POP.

**(14) VOLUME (VOL + / -)**

- to increase or decrease the volume.  
- (on the system only) to adjust the hours and minutes for the clock/timer functions.

**(15) SOURCE**

- to select the respective sound source : CD, USB TUNER, TAPE or AUX.

### Controls on the system and remote control

**(1) STANDBY-ON/ECO POWER**

- to switch the system on or to Eco Power standby/normal standby mode with clock display.

**(2) Display screen**

- to view the current status of the system.  
**(3) BAND/DISPLAY**  
for Tuner .....to select waveband: FM, MW or LW.  
for CD/MP3-CD/USB...to select disc information display mode.

## CONNECTION AND CONTROLS

### Controls (*main set illustrations on page 3*)

---

**⑯ REC**

- to start recording.

**⑰ iR sensor**

- infrared sensor for remote control.

**⑱ OPEN/CLOSE ▲**

- to open or close the disc tray.

**⑲ ♀ Headphone**

- Plugs in the headphones jack. The speakers output will be cancelled.

**⑳ USB DIRECT ↪•**

- jack for the external USB mass storage device.

**㉑ Display**

- to select disc information display mode.

**㉒ Disk tray**

**㉓ MUTE**

- to interrupt and resume sound reproduction.

**㉔ TIMER**

- to activate/deactivate the timer function.

**㉕ SLEEP**

- to activate/deactivate or set the sleep timer.

**㉖ ⏻**

- to switch the system to standby mode.

**㉗ REPEAT**

- to play track(s)/program repeatedly.


**㉘ SHUFFLE**

- to turn on/off the random play mode.


**Notes for remote control:**

- **First select the source you wish to control by pressing one of the source select keys on the remote control (for example CD, TUNER).**
- **Then select the desired function (for example ▶ II, |◀◀/▶▶|).**

## SET BLOCK DIAGRAM




## SET WIRING DIAGRAM




# CIRCUIT DIAGRAM - MAIN BOARD


## PART 1




**CIRCUIT DIAGRAM - MAIN BOARD  
PART 2**




LAYOUT DIAGRAM - MAIN BOARD  
COMPONENT SIDE




LAYOUT DIAGRAM - MAIN BOARD  
COPPER SIDE



**CIRCUIT DIAGRAM - C MUSIC BOARD  
PART 1**




**CIRCUIT DIAGRAM - C MUSIC BOARD  
PART 2**









## CIRCUIT DIAGRAM - VFD BOARD




## LAYOUT DIAGARM - VFD BOARD



## CIRCUIT DIAGRAM - CASSETTE BOARD

Variant Parts between AR and NAR version : please refer to table below










## CIRCUIT DIAGRAM - RECTIFIER BOARD


CAUTION: SAFETY USE ONLY THOSE DESCRIBED IN PART LIST  
BECAUSE THE COMPONENTS MARKED BY !




### REMARK:

- 1 - ALL RESISTANCE VALUES ARE INDICATED IN "ohm".  
(k = 1,000ohm; M = 1,000,000ohm.)
- 2 - ALL CAPACITANCE VALUES ARE INDICATED IN "F".  
(U = 0.000001F; P = 0.000001UF.)

## LAYOUT DIAGRAM - RECTIFIER BOARD



## EXPLODED VIEW DIAGRAM



## MECHANICAL PARTSLIST

1	996510002333	TOP CABINET
3	996510000871	CD TRAY LOADER
4	996510002348	BRACKET CD DOOR
5	996510002345	CD DOOR
6	996510002349	CD TRAY
14	996510002347	BRACKET -TOP BUTTON
15	996510002338	POWER KEY
16	996510002341	TOP KEY CLUSTER BUTTONS
17	996510002339	MODE KEY CLUSTER BUTTONS
18	996510002332	FRONT CABINET
19	996510002342	POWER LENS
20	996510002343	DISPLAY LENS
21	996510002337	VOLUME KNOB
22	996510002344	CONTROL PANEL
25	996510002346	CASSETTE DOOR
26	994000004801	BRACKET - CASSETTE DOOR
27	996510002331	CASSETTE DOOR SPRING
30	996510002340	CD CONTROL KEY CLUSTER BUTTONS
34	994000001434	CASS DECK MECHANISM W991S
35	994000001409	CD DOOR GEAR HOLDER
36	996510002350	CASSETTE DOOR DAMPING GEAR
57	994000003257	DC BRUSHLESS FAN JD6025MS11150W0
63	994000003234	RUBBER FOOT 11x11x6mm
65	996510002336	REAR CABINET
75	996510002334	LEFT CABINET
78	994000005773	TRANSFORMER EI-76 230V 50HZ
84	996510002335	RIGHT CABINET
88	996510001074	CD SPRING DIM:0.5MM
89	996510001075	CD SPRING DIM:0.6MM
89	996510000868	CD DAMPER PINK 658F HARDNESS 40JIS
90	994000005786	CD MECHANISM DA11VF (SANYO)
	994000005777	SWITCH SPRING FOR PUSH LOCK SUS304

## ACCESSORIES

SPEA	996510002351	WOODEN SPEAKER (LEFT+RIGHT) ONE SET
RC	996510002352	REMOTE CONTROL FOR #MCM726
ANT	994000003268	PIG TAIL ANTENNA WIRE BLACK
AML	994000001419	AM LOOP FRAME ASSY INJ. BLACK
ACL	994000001451	6 FEET VDE APPROVED POWER CORD

**Note:** Only these parts mentioned in the list are normal service parts.

**ELECTRICAL PARTSLIST - MAIN BOARD****- IC & TRANSISTORS -**

IC501	994000003198	IC HEF4069UBT SOT108-1 SMT
IC401	994000003199	I.C. HEF4094BT
IC403	994000003199	I.C. HEF4094BT
IC801	996500039259	I.C. PT4800(L) DIP-8 PIN
IC402	994000003201	I.C. TC4052BF SWITCHING
IC203	996510002327	I.C.KIA7806API-U/P TO-220IS
IC201	994000005724	I.C. VOL. REGULATOR LD1117AL-3.3V-D
IC701	994000005726	IC TDA7296 MULTIWATT15V
IC702	994000005726	IC TDA7296 MULTIWATT15V
Q203	994000001436	TRANSISTOR 2SB1566-F LEAD FREE
Q208	994000005727	TRANSISTOR 2SB562C TO-92MOD
Q408	994000005729	TRANSISTOR KTA1273 TO-92L
Q402	996500004928	TRANSISTOR ON4986 (9340-447-50126)
Q403	996500004928	TRANSISTOR ON4986 (9340-447-50126)
Q404	996500004928	TRANSISTOR ON4986 (9340-447-50126)
Q405	996500004928	TRANSISTOR ON4986 (9340-447-50126)

**- MISCELLANEOUS -**

996510002328	16P FFC CABLE 100MM P=1.0MM WHITE
994000003259	6P FFC CABLE L=120MM
994000005767	20 PINS FFC CABLE TYPE A
994000005768	FFC CABLE 12PINS L=180M
994000003263	FFC CABLE 180MM 7P WHITE TYPE B
PCB7	994000005769      8PINS FFC CABLE L=190MM
	996510002326      MCM726 MAIN PCB ASSY

**Note:** Only these parts mentioned in the list are  
normal service parts.

## ELECTRICAL PARTSLIST - CASSETTE BOARD

---

### - MISCELLANEOUS -

---

994000005719	I.C. SM AN17150A-E2V(MATJ)
994000003199	I.C. HEF4094BT
994000001433	TRANSISTOR (FET) J112
PCB1	994000003192 CASS PCB ASSY

**Note:** Only these parts mentioned in the list are  
normal service parts.

## ELECTRICAL PARTSLIST - RECTIFIER BOARD

---

### - MISCELLANEOUS -

---

PCB2	△ 996510002317	RECIFIER PCB ASSY
	△ 996510000389	FUSE 2.5A 250V D5X20MM GLASS
	△ 994000003224	FUSE 6.3A 250V D5X20MM GLASS
	△ 994000003225	FUSE 0.315A 250V D5X20MM GLASS
	994000003226	AC LINE FILTER 400UH +-30%
	994000001448	9V DC RELAY 10A ME-7-009-HL LEAD
	994000003228	TRANSISTOR 2N5401 TO-92 (WTC)
	△ 994000005772	TRANS. 230V 50HZ 12V@0.1A EI-28

**Note:** Only these parts mentioned in the list are  
normal service parts.

**ELECTRICAL PARTSLIST - C MUSIC BOARD****- IC & TRANSISTORS -**

IC901	996510002330	IC PROGRAMMED FOR MCM726
U202	996510000738	IC EPROM FOR (MCM720) ICE27C512-70
U201	994000005747	IC OTI6888-G LQFP-64
IC907	994000005748	I.C. 74HC02DB SSOP14
IC906	994000005749	I.C. 74HC4094DB SSOP16
IC905	994000005751	I.C. 74HC4520DB SSOP16
IC908	996510001069	I.C. D6208 SOP8
IC902	994000005753	I.C. D9258PH (LEAD FREE)
IC903	994000003272	I.C. M24C01-RDW6T
IC904	994000003215	RDS IC SAA6581T/V1 SOT162-1
Q901	996510000378	TRANSISTOR BST50 (SMD) LEAD FREE
Q204	994000005729	TRANSISTOR KTA1273 TO-92L

**- MISCELLANEOUS -**

PCB8	996510002329	MCM726 C MUSIC ASSY
Y1	994000005741	CRYSTAL 14.318 MHZ 20PF +/-20PPM
X902	994000003208	CRYSTAL 32.768KHZ 12.5PF +/-10 PPM
X903	994000003209	CRYSTAL 4.332MHZ HC-49/S LEAD FREE
X901	994000005742	CRYSTAL 8.4672 MHZ 20PF+-30PPM

**Note:** Only these parts mentioned in the list are  
normal service parts.

**ELECTRICAL PARTSLIST**

PCB3	994000005732	<b>TUNER P.C.B. ASSY</b>
	994000005736	I.C. TEA5762H/V1 LEAD FREE
	994000005737	FM TUNER MODULE #MCM390
PCB4	996510002318	<b>MCM726 TOP KEY PCB ASSY-1</b>
LED701	994000005763	LED INDICATOR RED CL-3R4SD-16
SW701	996510002319	TACT SWITCH EVQ11L04M
SW703	996510002319	TACT SWITCH EVQ11L04M
SW704	996510002319	TACT SWITCH EVQ11L04M
SW705	996510002319	TACT SWITCH EVQ11L04M
PCB5	996510002320	<b>MCM726 TOP KEY PCB ASSY-2</b>
RS701	994000005759	INFRARED RECEIVER IRM502H-S
VFD701	994000005761	VFD DISPLAY
LED1	994000005762	LED BLUE (1L0345B22E0CB002)
LED2	994000005762	LED BLUE (1L0345B22E0CB002)
LED3	994000005762	LED BLUE (1L0345B22E0CB002)
U1	994000003214	VFD DRIVER IC PT6315 L.F.
LCD	994000005757	LCD BRACKET
PCB5	996510002321	<b>MCM726 KEY PCB ASSY-1</b>
HP801	996510002322	3.5MM STEREO JACK TC38-103-DG-010
Q801	996510002323	TRANSISTOR S8550 SMD TYPE
PCB6	996510002324	<b>MCM726 KEY PCB ASSY-2</b>
EN701	996510002325	ENCODER EC121102F2B-HA1-009
SW702	994000001444	TACT SWITCH TSA-065001-150
SW706	994000001444	TACT SWITCH TSA-065001-150
SW707	994000001444	TACT SWITCH TSA-065001-150
SW708	994000001444	TACT SWITCH TSA-065001-150
SW709	994000001444	TACT SWITCH TSA-065001-150
SW710	994000001444	TACT SWITCH TSA-065001-150
SW711	994000001444	TACT SWITCH TSA-065001-150
SW712	994000001444	TACT SWITCH TSA-065001-150
SW713	994000001444	TACT SWITCH TSA-065001-150
SW714	994000001444	TACT SWITCH TSA-065001-150

**Note:** Only these parts mentioned in the list are normal service parts.













3	ERECR8K2006JLTA	CARBON RESISTOR 8.2 K OHM 1/6 W J% TAPE 碳膜电	
3	ETRDTBC847BLA	TRANSISTOR BC847B (SMD) LEAD FREE 三極管	
*替代料*	ETRDTBC847BZA	TRANSISTOR BC847B	Ref No:
3	ETRDTBC857BLA	TRANSISTOR BC857B (SMD) LEAD FREE 三極管	
*替代料*	ETRDTBC857BZA	TRANSISTOR BC857B	Ref No:
3	ETRPBSB1566FA	TRANSISTOR 2SB1566-F LEAD FREE 三極管	
3	ETRPT2SB562CA	TRANSISTOR 2SB562C TO-92MOD 三極管	
*替代料*	ETRPTSB562CZA	TRANSISTOR 2SB562C TO-92NL	Ref No:
3	ETRPT8050CTZA	TRANSISTOR KTC-8050C(KEC) 三極管	
3	ETRPT8550DTZA	TRANSISTOR 8550D TAPE FORM 三極管	
3	ETRPTB23740A	TRANSISTOR BC327-40 TAPE FORM 三極管	
3	ETRPTKTA1273A	TRANSISTOR KTA1273 TO-92L 三極管	
3	ETRPTON4986ZA	TRANSISTOR ON4986 (9340-447-50126) 三極管	
3	EWRU060Z01BK26ADA	UL WIRE 60MM BLACK AWG#26 UL 线	
3	EWRU090Z01BK26ADA	UL WIRE 90MM BLACK AWG#26 (UL1007) (CP) UL 线	
3	EWRU120Z01BK26ADA	UL WIRE 120MM BLACK AWG#26 UL 线	
3	EWRW220F02AS26ACC	2P HOU'G ASSY P=2MM L=220MM 組裝線	
*替代料*	EWRW220F02AS26ACF	2P HOU'G ASSY P=2MM L=220MM UL-1007	Ref No:
3	EWRW230Z01BK26ADA	WIRE ASSY L=230MM BLACK AWG#26 UL1007 組裝線	
3	EWRW250F04GY26LCV	(HING FUNG)ASSY WIRE 250MM 4P P=2.0 组裝線	
1	115MCM726V12J-MUS	MANUAL INSERTION ASSEMBLY 手插零件底板組裝	
2	115MCM726V12J-EET	PCBA ELECTRICAL PARTS PHANTOM 底板組裝電子料	
3	115MCM726V12J-ATS	AUTO INSERTION ASSEMBLY 機插零件底板組裝	
4	EPBPCM726C00A	MCM726 C MUSIC PCB T=1.6MM 底板	
3	A600041	BARE COPPER WIRE DIA:0.5MM (LB) 錫水銅線	
3	ECACD101G0603JCTA	CHIP CAP. 100PF50V (0603) J% NPO 微型电容	
3	ECACD102G0603KBTA	CHIP CAP. 1000PF50V (0603) K% Y5P 微型电容	
3	ECACD103G0603KDTA	CHIP CAP. 0.01UF50V (0603) K% Y5R 微型电容	
3	ECACD104D0603KDTA	CHIP CAP. 0.1UF16V (0603) K% Y5R 微型电容	
3	ECACD105D0603KBTA	CHIP CAP. 1UF16V (0603) K% Y5P 微型电容	
3	ECACD220G0603JCTA	CHIP CAP. 22PF50V (0603) J% NPO 微型电容	
3	ECACD222G0603KDTA	CHIP CAP. 2200PF50V (0603) K% Y5R 微型电容	
3	ECACD223E0603KDTA	CHIP CAP. 0.022UF25V (0603) K% Y5R 微型电容	
3	ECACD225D0805ZFTA	CHIP CAP. 2.2UF 16V (0805) Z% Y5V 微型電容	
*替代料*	ECACD225E0805ZFTA	CHIP CAP. 2.2UF25V (0805) Z% Y5V	Ref No:
3	ECACD330G0603JCTA	CHIP CAP. 33PF50V (0603) J% NPO 微型电容	
3	ECACD331G0603JCTA	CHIP CAP. 330PF50V (0603) J% NPO 微型电容	
3	ECACD471G0603JCTA	CHIP CAP. 470PF50V (0603) J% NPO 微型电容	
3	ECACD472G0603KDTA	CHIP CAP. 4700PF50V (0603) K% Y5R 微型电容	
3	ECACD561G0603JCTA	CHIP CAP. 560PF50V (0603) J% NPO 微型电容	
3	ECACD682G0603KBTA	CHIP CAP. 6800PF50V (0603) K% Y5P 微型电容	
3	ECAER106D5011MATA	AL.E.CAP 10UF 16V 5X11MM M% 85C TAPE 电解电容	
3	ECAER107D5011MATA	AL.E.CAP 100UF 16V 5X11MM M% 85C TAPE 电解电容	
3	ECAER108D1016MABA	AL.E.CAP 1000UF 16V 10X16MM M% 85C 电解电容	
3	ECAER226D5011MATA	AL.E.CAP 22UF 16V 5X11MM M% 85C TAPE 电解电容	
3	ECAER226D5011MATJ	(J-J) AL.E.CAP 22UF 16V 5X11MM M% 85C 电解电容	
3	ECAER227D6012MATA	AL.E.CAP 220UF 16V 6X12MM M% 85C TAPE 电解电容	
3	ECAER476D5011META	AL.E.CAP 47UF 16V 5X11MM M% 105C TAPE 电解电容	
3	ECAER476G6012MATA	AL.E.CAP 47UF 50V 6X12MM M% 85C TAPE 电解电容	
3	ECRR14M318A20FBA	CRYSTAL 14.318 MHZ 20PF +/-20PPM HC-49/S 晶體	
3	ECRR32K768A10DBA	CRYSTAL 32.768KHZ 12.5PF +/-10 PPM 晶体	
3	ECRR4M3320A20FBA	CRYSTAL 4.332MHZ HC-49/S LEAD FREE 晶体	
3	ECRR8M4672A30FBA	CRYSTAL 8.4672 MHZ 20PF +/-30PPM 1X3.5MM 晶體	
3	EDDEPTTC2V7ZZA	ZENER DIODE 2V7 1/2W (TC2V7) 二極管	
3	EDDEPTTC3V9ZZA	ZENER DIODE 3V9 1/2W (TC3V9) 二極管	
3	EDDEPTTC5V1ZZA	ZENER DIODE 5V1 1/2W (TC5V1) TAPE FORM 二極管	
3	EDDEPTTC9V1ZZA	ZENER DIODE 9V1 1/2W (TC9V1) 二極管	
3	EDDSDT1N4148ZA	DIODE 1N4148 (SMD) FDLL4148 二極管	
3	EDDSPT1N4148ZA	DIODE 1N4148 TAPE FORM 二極管	
3	EFB010BTSBK160A	FERRITE BEAN SMD SBK160808T-601Y-S 小磁珠	
3	EJA112HR06PBC	6 PINS HEADER P=2.0MM 插座	
3	EJA250FR07PBA	7P FPC CONNECTOR P=1.25MM 插座	
3	EJA251FR06PBA	6P FPC CONNECTOR P=1.25MM 插座	
3	EJA338HR05PBF	5PINS HEADER P:2MM STRAIGHT TYPE 插座	
3	EJA366FR12PBR	12P FFC CONNECTOR P=1MM VERTICAL TYPE FFC插座	
3	EJA374HR04PBD	(TANG HAN) 4 PINS HEADER P=2.0MM 插座	
3	EJA376FR16PBJ	16P FFC SOCKET P=1.0MM (ANGLE TYPE) 插座	
3	EJA431FR20PBJ	(TPG) FFC CONNECTOR 20PINS P=1.25MM FFC插座	
3	ENCAPAA7838HN3ZA	IC PROGRAMMED FOR MCM726 已寫碼集成塊	
4	ENCDPSAA7838HN3A	PHILIPS C MUSIC PLUS IC SAA7838H/N3,112 集成塊	







2	KFUAMCM726V12BA	QUICK START GUIDE B 附加說明書	
2	KFUAMCM726V12CA	QUICK START GUIDE C 附加說明書	
2	KFUNMCM726V12AA	INSTRUCTION SHEET A #MCM726/12 說明書	
2	KFUNMCM726V12BA	INSTRUCTION SHEET B #MCM726/12 說明書	
2	KFUWAX2400V85CA	GUARANTEE BOOKLET 保証書	
2	KGLCLWAZ2060AA	CD TRAY LASER WARNING LABEL CD盤鐳射警告貼紙	
2	KGLCZLAZ3300AA	CZECH LABEL FOR #3300 CZECH貼紙	
2	KGLHUNAZ3300AA	HUNGARY LABEL FOR #3300 HUNGARY貼紙	
2	KGLLWLAZ2060AA	CZECH LASER WARNING LABEL #AZ2060 捷克鐳射警告貼	
2	KGLPHI046012DA	PHILIPS LABEL 46x12MM 飛利浦貼紙	
2	KGLPOLAZ101ZAA	POLAND LABEL FOR #AZ101 POLAND貼紙	
2	KGLQCL013000AA	Q.C. PASSED LABEL DIA. 1/2 IN QC貼紙	
2	KGLSLOMCM510AA	SLOVAK LABEL FOR #MCM510 SLOVAK LABEL貼紙	
2	KGLWHT064021AA	BLANK LABEL WHITE 64 X 21 MM 白貼紙	
2	KMLGMCM726V12AA	GIFT BOX LABEL (MADE IN CHINA) 彩盒貼紙	
2	KMLMMCM726V12AA	MODEL NO. LABEL (MADE IN CHINA) 機型貼紙	
2	KPBPL064127NAA	POLYBAG 2 1/2 X 5 IN (PE04) 膠袋	
2	KPBPL114278NAA	POLYBAG 114X278MM (PE04) FOR AC 膠袋	
2	KPBPL155203NAA	POLYBAG 155X203MM (PE04) FOR AM 膠袋	
2	KPBPL203305NAA	POLYBAG 203X305MM (PE04) FOR I/B 膠袋	
2	KPBPL580450HAA	POLYBAG 580X450MM (PE04) THK=0.04MM 膠袋	
2	KPBPS1M2045RBA	POLY STRIP L1200XW45XTHK.0.04MM 膠帶	
2	KPTPMCM726V12AA	POLYFORM LEFT FOR MAIN UNIT 左發泡膠(成品機用)	
2	KPTPMCM726V12BA	POLYFORM RIGHT FOR MAIN UNIT 右發泡膠(成品機用)	
2	MWDWBBCM726AA	WOODEN SPEAKER (LEFT+RIGHT) ONE SET 音箱	
1	MCM726/12-PEL	PACKING ELECTRICAL PARTS PHANTOM 包裝電子件	
2	ERCMCM726PHIAA	REMOTE CONTROL FOR #MCM726 遙控器	
2	EWRW1M0Z01BK26ACC	PIG TAIL ANTENNA WIRE BLACK FOR#390 豬尾天線	
2	PZMC15010ZZZCA	AM LOOP FRAME ASSY INJ. BLACK 天線環	