
Circuit Change

Some customers require the headphones to be on and the speakers at the same time.

The headphone socket switch is normally closed to allow the speaker relays to operate. When the headphones are plugged in the switch opens turning off the speaker relays.

By wiring a jumper across this switch the speaker relays will always have power. The headphones will have no affect on the speaker relays.

Locate connector CZ705 on the headphone and standby board. Solder a wire on the bottom of the board across pin number 1 and 2, labelled SW and SWG respectively. Test headphones and check speakers are still on.

Contact:

NAD Electronics International
633 Granite Court
Pickering, ON Canada L1K 3K1
Voice: 905-831-0799 FAX 905-837-6357
www.nadelectronics.com



Circuit Change

PROBLEM: *There is a small residual output when the volume is set to minimum.*

CAUSE: *Not enough attenuation of the volume control when the input level is high.*

SOLUTION: *Increase the attenuation of the volume control by changing the value of R514 and R614 from 3R0 to any value up to 3R6.*

PRODUCTION:

This circuit change has been implemented in production from serial number: H08C37000055.

Contact:

NAD Electronics International
633 Granite Court
Pickering, ON Canada L1K 3K1
Voice: 905-831-0799 FAX 905-837-6357
NAD@www.NADelectronics.com

ERRATUM SERVICE MANUAL

Although the manual has been thoroughly checked before printing there is an error in the part list.

<u>Ref no.</u>	<u>Old part</u>	<u>New part</u>
RV3	09-16203-22M	09-16103-12M

This reference can be found on page 15 of the manual.

Circuit Change

Some customers require the headphones to be on and the speakers at the same time.

The headphone socket switch is normally closed to allow the speaker relays to operate. When the headphones are plugged in the switch opens turning off the speaker relays.

By wiring a jumper across this switch the speaker relays will always have power. The headphones will have no affect on the speaker relays.

Locate connector CZ705 on the headphone and standby board. Solder a wire on the bottom of the board across pin number 1 and 2, labelled SW and SWG respectively. Test headphones and check speakers are still on.

Contact:

**NAD Electronics International
633 Granite Court
Pickering, ON Canada L1K 3K1
Voice: 905-831-0799 FAX 905-837-6357
www.NADelectronics.com**