AP-Q41/C

QUARTZ IND PCB
PI018A501E

ARM POSITION SENSOR (LED) PCB
PI018A501F

ARM POSITION SENSOR (TR) PCB
PI018A501G

SIZE SENSOR PCB
PI018A501H

START/CUT PCB
PI018A501C

ANTI VR PCB
PI018A501D

SERVO/SYSCON PCB PI018A501 to 3A

MAIN MOTOR

IC1 NJM4558S

IC2 TC4016BP

IC3 TC9142P

IC4 NJM4558S

IC5 LM6405A-035

INTERMEDIATE PCB
PI018A501I

FUSE PCB PI018A503B

FUSE PCB PI018A502B

FUSE PCB PI018A502B

FUSE PCB PI018A502B

FUSE PCB PI018A501B

FUSE PCB PI018A502B

X	F3	F4
U	0.8A 250V	0.8A 250V
J	0.8A 250V	0.8A 250V
C, A	0.8A 125V	0.8A 125V
B, S, E, V	T0.8A 250V	T0.8A 250V

2SD313 2SD863 — 2SA1015 2SC1815 — 2SK30A — 2SB764

WARNING: ⚠ INDICATES SAFETY CRITICAL COMPONENTS. FOR CONTINUED SAFETY, REPLACE SAFETY CRITICAL COMPONENTS ONLY WITH MANUFACTURER'S RECOMMENDED PARTS

AVERTISSEMENT: ⚠ IL INDIQU LES COMPOSANTS CRITIQUES DE SÛRETÉ. POUR MAINTENIR LE DEGRÉ DE SECURITÉ DE L'APPAREIL NE REMPLACER LES COMPOSANTS DONT LE FONCTIONNEMENT EST CRITIQUE POUR LA SECURITÉ QUE PAR DES PIECES RECOMMANDEES PAR LE FABRICANT

NOTE
UNLESS OTHERWISE SPECIFIED
ALL RESISTORS IN OHMS 1/4W(J)
ALL CAPACITORS IN μF 50WV(J)

AP-Q41/C SCHEMATC DIAGRAM NO. 1640814A