

irDock




Connections and Quickstart Guide



Contents

Power Adaptor Setup	4
Docking your iPod	5
Charging	6
Standalone operation	8
Connections for any amplifier	8
Remote control (CR1)	9
Arcam Solo Mini	10
Connections	10
Remote control	11
Arcam Solo Music	12
Connections	12
Setup	13
Remote control	14
Arcam Solo Movie	16
Connections — SCART version	16
Connections — Component Video version	17
Setup	18
Remote control	19
Arcam T32	20
Connections	20
Remote control	21
Arcam AVR600, AV888	22
Connections	22
Setup OSD	23
Remote control	24
Navigation from the Front Panel	26
Song Selection	26
Changing Selection	27
Navigation from the On Screen Display	28
Song Selection	28
Changing Selection	29



Power Adaptor Setup




Docking your iPod

The docking adaptor is supplied with your iPod. It is important to fit the correct docking adaptor for your particular model of iPod. Failure to do so may result in damage to the irDock connector.

Spare docking adaptors are available from Apple.




Charging



Ⓒ charging on	red	charging off	blue
Ⓕ chargement en cours	rouge	chargement terminé	bleu
Ⓓ Ladevorgang ein	rot	Ladevorgang aus	blau
Ⓔ laden aan	rood	laden uit	blauw

Standalone operation

Connections for any amplifier















Remote control (CR1)

The supplied remote control can be used to control your iPod when the irDock is not connected to a supported Arcam product. If you are using the irDock with a supported Arcam product, use the Arcam system remote instead.


Please remove the plastic tab to connect the supplied batteries before use.




-  Turn the dock on/off.
-  Go to previous menu (Albums, Artists, Playlists etc.)
-  Mute the volume.
-  Increase or
-  decrease the volume.
-  Select music by playlist, artist etc.
-  Activate repeat and
-  shuffle playback modes.
-  Activate/deactivate iPod charging.
-  Start or pause playback.
-  Jump to the next track, track start or previous track in the current selection.
- 

Arcam Solo Mini

Connections




Remote control — Solo Mini




Arcam Solo Music


Connections



Setup — Solo Music




Remote control — Solo Music




Arcam Solo Movie





Connections — SCART version




Connections — Component Video version



Setup — Solo Movie




Remote control — Solo Movie (CR100)




Arcam T32

Connections

irDock




Remote control — T32 (CR90)



Arcam AVR600, AV888

Connections



Setup — On Screen Display


Input Config	
General Setup	
Auto Setup	
Spkr Types	
Spkr Distance	
Spkr Levels	
Video Inputs	
Video Outputs	
Mode	
Zone Settings	
Network	

Audio in iPod : TAPE

iPod Accessory

rLead
rDock
> irDock

Select the Arcam iPod accessory



Remote control — AVR600, AV888 (CR102)

1 points to the AMP button.

2 points to the RND button.

VOLUME points to the volume control buttons.

Playback control

- ▶ Play
- Stop
- ⏸ Pause
- ⏮ Skip back
- ⏭ Skip forward


SUBT (INFO)

- Song name
- Artist name
- Album name
- Track no.

RND (Random play)	SHIFT+RND = RPT (Repeat play)
Shuffle play Off	Repeat play Off
Shuffle Songs	Repeat Song
Shuffle Albums	Repeat Album

Navigation from the Front Panel

Song Selection




† +/- = Solo remote

◀/▶ = CR90/CR100/CR102

* Solo Music, Solo Mini & T32 only

Changing Selection






† -/+ = Solo remote

◀/▶ = CR90/CR100/CR102

* Solo Music, Solo Mini & T32 only

Navigation from the On Screen Display

Song Selection



Changing Selection




Track

- All
- Eleanor Rigby/Julia [Transition]
- Blackbird/Yesterday**
- Lady Madonna
- All You Need Is Love

Track : Eleanor Rigby/Julia [Transition] ▶

Artist : The Beatles 00:07

Album : Love



Make Selection

Playlist

- Artist**
- Album
- Genre
- Song

3 of 9

Track : Eleanor Rigby/Julia [Transition] ▶

Artist : The Beatles 00:07

Album : Love

ARCAM

<http://www.arcam.co.uk>

Pembroke Avenue, Waterbeach, CAMBRIDGE, CB25 9QR, England