


Grundig 1004 W und WL

ECH 42

EF 41

EAF 42

EL 41



ZF=468 kHz u. 10,7 MHz Meßinstrument: 1 kΩ/V

Schalter	2	3	8	9	10	11	12	12	13	13	17	17	25	29	31	33	35	36	41	43	45
UKW	24	6	9	10	11	12	13	13	14	14	18	19	26	30	32	36	36	38	42	45	46
Kurz	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Mittel	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
TA	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×

