




1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97



Wahlbereiche
 BANDS
 GAMMES D'ONDES
 GAMME D'ONDE

LW / 00 / DL 165 100 kHz
 MW / P2 / DM 570 1820 kHz
 KW / SW / OC 5.85 10.2 MHz
 87.5 10.2 MHz

Ferritkernantenne
 FERRITE AERIAL
 ANTEENNE FERRITE COMP.
 ANTENNA DI FERRITA COMP.

Wahltransistor
 MAINS TRANSFORMER
 TRANSFORMATEUR
 TRANSFORMADORE

1 1000000 1 AA 112
 2 1000000 2 AA 112
 3 1000000 3 AA 112
 4 1000000 4 AA 112
 5 1000000 5 AA 112

1 1000000 1 BE 102/2V1
 2 1000000 2 BE 102/2V1
 3 1000000 3 BE 102/2V1

Voltages measured without signal
 EN Ug = 7.5 V (A MINUS)
 EN MAINS OPERATION 220 V AC

Tensions mesurées sans signal
 (en Ug = 7.5 V (A MINUS)
 (en PUNCT SW SECTEUR 220 V)

Tensioni misurate senza segnale
 (con Ug = 7.5 V (A MINUS)
 (con ALIMENTAZIONE DI RETE 220 V)

Änderungen vorbehalten
 ALTERATIONS RESERVEES
 MODIFICAZIONI RISERVATE
 CON RISERVA DI MODIFICAZIONE



GRUNDIG
Yacht-Boy 1100
 (15029-906.00)