

Service Bulletin development since 4/1/97

Harman/kardon

NUMBER	PRODUCT(S)	SUBJECT	DATE COMPLETE
9703	FL8300	DEAD UNIT, NO DISPLAY	8/97
9704	AVR70/80	UNIT SHUTS DOWN AFTER 5 MINUTES	6/97
9705	AVR85	NO OUTPUT DUE TO BAD CONNECTIONS	8/97
9706	AVR10,20,25, AVI, etc.	REMOTE CONTROL STOPS WORKING	11/97
H/K9707	FESTIVAL 60	WAKE TIMER WILL NOT TURN OFF	12/97
H/K9708	SIGNATURE 2.0	COMPLAINTS RELATED TO VERSION 2.0 - 2.3 SOFTWARE	12/97
H/K9709	SIGNATURE 2.0	TURN-ON/TURN-OFF "THUMP"	12/97
H/K9801	AVR55	UNIT SWITCHES TO STANDBY	5/98
H/K9802	FESTIVAL 300/500	BUZZING	4/98
H/K9803	AVR55	VARIOUS COMPLAINTS RELATED TO SOFTWARE	4/98
H/K9604 Rev1	FL8300	DIGITAL OUTPUT LEVEL	10/98
H/K9804	AVR35/45/65	REMOTE CONTROL FUNCTIONS DO NOT WORK	12/98
H/K9903	AVR35/45/65	VIDEO INTERFERENCE	8/99
H/K9904	SIGNATURE 2.0	DTS UPGRADE	9/99
H/K9905	AVR10/HK3250	DEAD UNIT, NO DISPLAY	7/99
HK2000-02 Rev1	AVR300/500	NOISE, ERRATIC OUTPUT IN DTS MODE	1/2001
HK2000-03 Rev1	AVR7000	VIDEO INTERFERENCE	6/2000
HK2000-05	AVR300/500	VOLUME CHANGES	5/2000
HK2000-06	AVR7000	SWITCHED AC ACCESSORY OUTLET DEAD	5/2000
HK2000-07	SIGNATURE 2.0	REMOTE CONTROL WORKS INTERMITTENTLY	7/2000
HK2000-08 Rev1	CDR2	COMPLAINTS RELATED TO EARLY SOFTWARE	1/2001
HK2000-09	FL8350/8550	CAROUSEL DOES NOT STOP	11/2000
HK2000-01 Rev1	AVR35/45/65	NO OUTPUT IN SURROUND MODES	4/2001
HK2001-01	AVR110/210/310/510 AVR3000/4000/5000	UNIT GOES INTO PROTECTION	6/2001
HK2001-02	AVR35/45/65	LEFT, RIGHT, OR CENTER CHANNEL DEAD	6/2001
HK2001-03	AVR110/210/310/510	NO OUTPUT IN SURROUND MODE	6/2001
HK2001-04	CDR20	DELAY IN READING BLANK DISC	10/5/01
HK2001-06	CDR20	NOISE WHEN DUBBING AT X4 SPEED	12/3/01
HK2001-05 Rev1	DVD50	SOFTWARE UPGRADE VERSION 2.0	1/4/02
HK2002-02	DVD50	FAULTY 23 PIN FLAT CABLE	7/10/02
HK2002-03	AVR320	HUM OR BUZZ FROM TRANSFORMER	4/15/02
HK2002-04	AVR8000	UNIT OVERHEATING/PROTECTION CIRCUIT ENGAGES	10/31/02
9701 Rev1	AVR70/80	VOLUME CHANGES	11/21/02
HK2002-05	DVD5	STANDBY MODE, DISC ERROR	11/21/02
H/K9901 Rev1	FL8350/8550	"NO DISC" READING IN DISPLAY	11/21/02
HK2002-06	AVR7000	LOW OR NO OUTPUT FROM SUB OUTPUT JACK	10/2/02
HK2002-07	AVR320	INTERMITTENT OUTPUT	10/7/02
HK2000-08 Rev2	CDR2	COMPLAINTS RELATED TO EARLY SOFTWARE	10/21/02
H/K9805 Rev2	AVR65	HUM or BUZZ	1/03
HK2003-02	AVR310,510	DAMAGED CAPACITORS	2/11/03
HK2000-04 Rev1	AVR500/AVR7000	LOGIC 7 DISTORTION	2/2003
HK2003-03	CDR25/26	IMPROVE AUDIBLE NOISE	4/22/03

JBL

NUMBER	PRODUCT(S)	SUBJECT	DATE COMPLETE
JBL9701	PSW1000/1200	PREMATURE MUTING	6/97
JBL9702	PSW1000/1200	CYCLING ON & OFF	6/97
JBL9703	HLS SERIES	REMOVING & REPLACING HLS DRIVERS	10/97
JBL9704	ESC550 (SOURCE)	JUMPS TO SURROUND MODE DURING CD SEARCH	11/97
JBL9706	BASS 550	UNIT STAYS IN PROTECT MODE	9/97
JBL9801	GTx SERIES	SPECIAL PRIMER & ADHESIVE FOR RECONING	5/98
JBL9802	MEDIA SUB2000	FALSE TRIGGERING	5/98
JBL9803	P-7520	DEFECTIVE WIRING HARNESS	8/98
JBL9804	HARMONY	DISASSEMBLY PROCEDURE	8/98
JBL9808	HARMONY	LOSS OF CONTROL FUNCTIONS - BATTERY CIRCUIT	9/98
JBL9809	HARMONY	SLEEP MODE DISPLAY BRIGHTNESS	9/98
JBL9810	TLX271P	LED COLOR CYCLING INCORRECTLY	9/98
JBL9901	SCS125	AMP PLATE OVERHEATING or BLOWING FUSES	1/99
JBL9904	HARMONY	WEAK FM RECEPTION	10/99
JBL9905	HARMONY	CD DRAWER NOT OPENING	6/99
JBL9906	HARMONY	NOISE WHEN PLAYING CD's	6/99
JBL9907	TLX PS-10, PS-12	PREMATURE MUTING	9/99
JBL2000-02	N26, N26AW	DISTORTION	3/2000
JBL2000-04	BP300/600/1200	MUTING DURING INTENSE BASS PASSAGES	11/2000
JBL2001-02	PSW-D112/115	CHECK RIBBON CABLE CONNECTION	2/2001
JBL2001-06	PSW-D110	CONNECTORS ON REPLACEMENT AMPLIFIER	8/17/2001
JBL2000-01 Rev3	PSWD,ARC,DS,DPS	FAILURE OF C6	10/29/2001
JBL2001-03 Rev1	PB10, PB12	UNIT WILL NOT SWITCH TO STANDBY MODE	1/2002
JBL9902 Rev1	PSW-D110	GRILLE REMOVAL	1/30/2002
JBL9903 Rev1	PSW-D & ARCSUB	CHECK SOLDER JOINTS IN EVENT OF FAILURE	1/30/2002
JBL2001-01 Rev1	HLS SERIES	TWEETER FAILURE, PROTECTION DEVICE	1/30/2002
JBL2001-05 Rev2	PB12	POPPING EVERY FEW SECONDS DURING PLAY	2/2002
JBL2001-07 Rev1	PB12	POSSIBLE MISSING DIODE D4	2/22/02
JBL2002-01	DVD600II	WILL NOT PLAY ENHANCED CD'S	11/4/02
JBL2002-02	S4A	MISWIRED CONNECTOR	11/12/02
JBL2003-01	DVD600II	UNIT STAYS IN STANDBY MODE	3/17/2003
JBL2003-02	N28, N38, ND310	TWEETER REPLACEMENT	2/11/2003
JBL2001-04 Rev2	PB10	HUM, BUZZ, "THUMPING"	2/2003
JBL2003-03	SDEC1000/SDEC1000A SDEC2500/SDEC2500A	SDP-40/SDP-5 TRIGGER OUTPUT CONNECTION	3/6/2003
JBL2003-06	S120PII	DISTORTION WHEN COMING OUT OF STANDBY	4/16/2003

Infinity

NUMBER	PRODUCT(S)	SUBJECT	DATE COMPLETE
INF9702	RS10/12	FAILURE OF C102/104	10/97
INF9703	EMIM 902-0012	DIAPHRAGM REPLACEMENT	10/97
INF9704	OVR 1,2,3	PREMATURE MUTING	11/97
INF9705	OVR 1,2,3	UNIT CYCLING ON & OFF	11/97
INF9706	KAPPA 40.50,60 CS	TWEETER DAMAGE	12/97
INF9707	EPSILON	GRILLE REMOVAL	1/98
INF9708	COMP. PRELUDE	SPEAKER IS PICKING UP RADIO STATIONS	2/98
INF9801	OUTRIGGER JR.	BROKEN FRONT BAFFLE	2/98
INF9802	OVERTURE3	FAILURE OF CAPACITOR C5	6/98
INF9901	RS-8/10	OVERHEATING; IDLING CURRENT REDUCTION	3/99
INF9903	VARIOUS DRIVERS	OVERSIZE REPLACEMENT DRIVERS	6/99
INF2000-02 Rev1	BU80	BLOWING FUSES	6/2000
INF2000-03	BASSLINK	WILL NOT TURN OFF	10/2000
INF2000-04	IL60	AIR LEAK OR BUZZING FROM FRONT BAFFLE	12/2000
INF2000-05 Rev1	IM 2.6	HUM	1/2001
INF2000-01 Rev2	BU80, BU120 HTS-10, HTS-20 (both HTS rev A)	FAILURE OF C6	2/2001
INF9902 Rev1	BU80, BU120	CHECK SOLDER JOINTS IN EVENT OF FAILURE	2/2001
INF2001-01 Rev1	HPS500/1000	LOW OUTPUT	3/2001
INF2001-03	INTERLUDE 120S	NO OUTPUT	9/13/2001
INF2001-04	IM 1.2s	NO OUTPUT	1/30/2002
INF9701 Rev1	KAPPA 255a	DAMAGED OUTPUT TRANSISTORS	1/30/2002
INF2001-02 Rev1	KAPPA 255a	SUBWOOFER OUTPUT DEAD	1/3/2002
INF2002-01	MODULUS MSW-1	NO OUTPUT	2/12/02
INF2002-02	IL50, IL100	NO OUTPUT	2/12/02
INF2002-03	IM 3.5c	NO OUTPUT	2/12/02
INF2002-04	IM 2.6	NO OUTPUT	2/12/02
INF2002-05 Rev4	IL50	RELIABILITY UPGRADE	10/30/02
INF2002-06 Rev3	MODULUS MSW-1	RELIABILITY UPGRADE	10/30/02
INF2002-07 Rev3	IL100S	RELIABILITY UPGRADE	10/30/02
INF2003-01	BASSLINK BASSLINK X	DEAD OR NO POWER	1/7/2003

Tech Tips – All Brands

NUMBER	PRODUCT(S)	SUBJECT	DATE COMPLETE
H/K			
HKTT2000-01	AVR7000	REMOTE CONTROL STOPS WORKING	8/15/2000
HKTT2000-02	CDR2	UNIT WILL NOT FINALIZE	12/3/2001
HKTT2001-02 Rev1	CDR2	POWER FAILURE DURING A RECORDING SESSION	12/18/2001
HKTT2002-01	AVR100-500,7K,8K AVR110-510 AVR120-520	AVR-CABLEASSYII	6/1/2002
HKTT2002-02	AVR8000	REMOTE CONTROL DOES NOT WORK	7/22/2002
HKTT2003-01	AVRX10,X20,7000	BACKUP MEMORY ON AVRS	2/19/03
HKTT2003-02	FL8300	CAROUSEL NOT STOPPING IN CORRECT POSITION	03/03/2003
JBL			
JBLTT2000-01	ARC SUB8/10	REPLACING FRONT PANEL COMPONENTS	1/26/2000
JBLTT2000-02	N SERIES, S SERIES	LOOSE PORT TUBES	3/6/2000
JBLTT2000-03 Rev1	HT/SVA SERIES	SERVICING COMPONENTS	3/27/2001
JBLTT2003-01	DCR600/600II	BACKUP MEMORY ON DCR600/600II	2/19/03
JBLTT2003-02	DVD600	OPENING TRAY WITHOUT POWER	2/19/03
JBLTT2003-03	DVD600II	OPENING TRAY WITHOUT POWER	2/19/03
JBLTT2003-04	PB10, PB12	REPLACING Q18,Q22	3/28/03
INFINITY			
INFTT2000-01	BU SERIES SUBS	REPLACING FRONT PANEL COMPONENTS	3/9/2000
INFTT2000-02	OVERTURE 1	CAUSE OF "FLUTTERING" SOUND	4/14/2000
INFTT2001-01	SSW210/212	NO OUTPUT	4/20/2001
INFTT2001-02	RS1/RS1B	GENERAL SERVICE TIPS	6/15/2001
INFTT2001-03	HTS-10,HTS-20, BU80E	DISASSEMBLY-POWER AMP MODULE	12/12/2001
INFTT2003-01	HTS-20	NO OUTPUT OR HUM	03/03/2003
INFTT2003-02	ENTRA SUB TWO	REPLACING Q18,Q22	3/28/03
ALL			
HCG2002-01	ALL	DAMAGED PRINTED CIRCUIT BOARDS	4/4/2002