



Hitachi HA 1100

- NOTES
- 1. S1a,b
 - S2a-d
- POWER SPEAKERS
- ① ON
 - ② OFF
 - 2. A SPEAKERS
 - 3. B SPEAKERS
 - 4. C SPEAKERS
 - 5. A+B SPEAKERS
 - 6. A+C SPEAKERS
- FUNCTION
- ① PHONO-2
 - ② PHONO-1
 - ③ TUNER
 - ④ AUX-1
 - ⑤ AUX-2
 - ⑥ A+C SPEAKERS
- TAPE MONITOR
- ① TAPE-1
 - ② SOURCE
 - ③ TAPE-2
 - ④ TAPE-1-2
 - ⑤ SOURCE
 - ⑥ TAPE-2-1
- TAPE COPY
- ① ON
 - ② OFF
- LOUDNESS
- ① -20dB
 - ② OFF
- GAIN SELECTOR
- ① -10dB
 - ② OFF
- GAIN SELECTOR
- ① -5 dB
 - ② OFF
- MODE
- ① REVERSE
 - ② STEREO
 - ③ L+R
 - ④ L
 - ⑤ R
- HIGH FILTER
- ① 1.6kHz
 - ② OFF
 - ③ 3.8kHz
 - ④ 1.0kHz
- LOW FILTER
- ① 1.0kHz
 - ② 3.0kHz
 - ③ 3.0kHz
 - ④ 2FEAT
- TONE DEFEAT
- ① 1.6kHz
 - ② 3kHz
 - ③ 1.5kHz
- TREBLE TURNOVER
- ① 1.50Hz
 - ② 300Hz
 - ③ 3.60Hz
- BASS TURNOVER
- RELAY
- ① SP ON
 - ② SP OFF
 - ③ ON
 - ④ OFF
- PHONO-2 LEVEL
- BALANCE
- LEVEL ATTENUATOR
- B SPEAKERS LEVEL
- BASS CONTROL
- TREBLE CONTROL
- IDLE CURRENT ADJUST
- DISTORTION ADJUST
3. UNITS
- RESISTANCE : Ω
- CAPACITANCE : F

TERMINAL GUIDE OF TRANSISTORS

