


Schematic Diagram

AX-E77BK Main Amplifier Section





FOR WEST GERMANY FOR OTHER COUNTRIES			
PART NO.	IC, UNF.C.		
RN7, 748	001	NONE	
C727, 728	001	NONE	
C303, 304	470P	100P	
ENH-060	B	A	
C 4 01	0.0022	220 P	
C 4 04	56P	NONE	
C730, 731	68P	NONE	

D105 ~ D108
S.L.P. 55U50F24
S.L.R. 55V50F24

ENH-067-2

■ AX-E77BK SEA & Power Supply Section



- Notes:**
1. — indicates positive B power supply.
 2. - - - indicates negative B power supply.
 3. □ indicates signal path.
 4. □ shows DC voltage to the chassis with no signal input.
 5. When replacing the parts in the darkened area () and those marked with Δ, be sure to use the designated parts to ensure safety.
 6. This is the standard circuit diagram.
- The design and contents are subject to change without notice.