



- S₁ SP切换**
1. OFF
 2. H. PHONE
 3. SYSTEM 1
 4. SYSTEM 2
 5. SYSTEM 1+2
- S₂ VU.SENSI.**
1. 30 db
 2. 20 db
 3. 10 db
 4. 0 db
- S₃ DF. CONT.**
1. DF 50
 2. DF 5
 3. DF 0.5
- Component List:**
- X₁₀₁ ~ X₁₀₂, X₃₀₁ ~ X₃₀₂ 2SC458LGC
 - X₄₀₁ ~ X₄₀₂, X₄₀₄ 2SC458LC
 - X₁₀₃ ~ X₁₀₄, X₃₀₃ ~ X₃₀₄ 2SC484Y
 - X₄₀₅ 2SC484Y
 - X₁₀₅, X₃₀₅ 2SA537A
 - X₄₀₃ 2SC497
 - X₁ ~ X₄ 2SD203

指定ナキ抵抗ハ 1/2 Wトスル