


Qc1-3: 2SC458(D)  
 Qc4-7: 2SC945(Q)  
 Dc1-10: 1N60

Qj1,2: 2SA620WL4  
 Qj3,4: 2SC1345E or F



Qii,2: 2SC1000 BL

TONE AMP (X11-1030-01)

POWER SUPPLY (X00-1170-10)

Dk1: SR-V0-6B, Qk1: 2SD220  
 Dk2-5: U05Bx4, Qk2,3: 2SC945Q  
 Dk6: SIRB10, Dk7: IS338T, Dka: DZ-140

MAIN AMP (X07-1100-00)

Qe1-4: 2SA620WL4  
 Qe5,6: 2SC983 O or Y  
 Qe7,8: 2SC1212A (B) or (C)  
 Qe9,10: 2SA743A (B) or (C)  
 Qe11-14: 2SC1111  
 Qe15: 2SC983R  
 Qe16,18,9: 2SC1213A (B) or (C)  
 Qe17: 2SA673A (B) or (C)  
 De3,4: STV-3  
 De11,12: V0-6B  
 De13: YZ-140

De1,2,5,6,7-10: IS1555 or IS2076

KENWOOD  
 KR-5200 (K)