回路図

So-7

Q001
HI10004030
SLP-1328

Q401 ～ Q404
HF201301M0
2SK130A (M)

Q405, Q406
Q439 ～ Q442
HT322401B0
2SC2240(BL)

Q407～Q410
HT109701B0
2SA970(BL)

Q411, Q412
HT322401A0
2SC2240(G,R)

Q413, Q414, Q419, Q420
HT108722D0
2SA872A (D or E)

Q415～Q418
HT317752D0
2SC1775A (D or E)

Q421, Q422
HT407571C0
2SD757 (C)

Q423, Q424
HT207171C0
2SB717 (C)

Q425, Q426
HV00002060
VD1212

Q427～Q432, Q437
HD20003210
IS2471

Q433, Q434
HV00006120
MV203 (Y)

Q435, Q436
HV00004060
VD1210

Q751, Q752, Q755
Q756, Q769, Q770
HT107501B0
2SA750(E)

Q753, Q754, Q757
Q758, Q767, Q768
HT314001E0
2SC1400(E)

QM01, QM02
HF201472A0
2SK147(GR,BL)

QM03, QM04
HT109701A0
2SA970(GR)

QM05, QM06
HT406661C0
2SD666(C)

QM07, QM08
HT206461C0
2SB646(C)

QM09, QM10
HV00006120
MV203(Y)

QM11
HT403132P0
2SD313
(D or E)

QM12
HT205072P0
2SB507(D or E)

PM01 MC AMP ASSY

PL00

P400 PHONO AMP ASSY

PV00
REAR PANNEL ASSY

PHONO 1 MC
PHONO 2
TUNER
AUX
TAPE 1 IN / MONITOR OUT
TAPE 2 IN / MONITOR OUT
SCOPE OUT
PRE OUT 1 2

PF00 TONE ASSY

PF00 TONE ASSY

PF01

PE00

P800.

TONE AMP

PJ00 SELECTOR ASSY

PK00 TAPE EQ BUFFER AMP ASSY

QK01, QK02
HT108722D0
2SA872A (D or E)

QK03, QK04
HT317752D0
2SC1775A (D or E)

QK09, QK10
HT406661C0
2SD666(C)

QK11, QK12
HT206461C0
2SB646(C)

Q7~Q432,Q437	Q433,Q434	Q435,Q436	Q751,Q752,Q755 Q756,Q769,Q770	Q753,Q754,Q757 Q758,Q767,Q768	Q759~Q762	Q763~Q766	Q771,Q772	Q773,Q774	Q775	Q776	Q801,Q802	Q803	Q804	Q805	Q806	Q807	Q808	Q809,Q810	Q811
0003210	HV00006120	HV00004060	HT10750180	HT31400IE0	HV00006120	HV00002060	HT403132P0	HT205072P0	HE20001080	HD30030090	HF20030IC0	HT31509IQ0	HT10777IQ0	HT403132P0	HT205072P0	HT322402A0	HT109702A0	HE10001030	HD30008010
471	MV203(Y)	VD1210	2SA750(E)	2SC1400(E)	MV203(Y)	VD1212	2SD313(D or E)	2SB507(D or E)	RB-152	WZ177	2SK30A(Y)	2SC1509(Q)	2SA777(Q)	2SD313(D or E)	2SB507(D or E)	2SC2240(GR or BL)	2SA970(GR or BL)	DS133B-L	HZ-6L(B)

QD01
HT110152A0
2SA1015(D or Y)

QD02,QD03
HT318152A0
2SC1815(O or Y)

QD05,QD06
HD20003210
IS2471

PG00 VOLUME ASSY

QG01,QG02
HT108722D0
2SA872A(D or E)

QG03,QG04
HT317752D0
2SC1775A(D or E)

QG05,QG06
HT322401A0
2SC2240(GR)

QG07,QG08
HT109701A0
2SA970(GR)

QG09,QG10
HT406661C0
2SD666(C)

QG11,QG12
HT206461C0
2SB646(C)

P750
HEAD PHONE
AMP ASSY.

PF01

PE00

TONE AMP

PRE AMP

QH01,QH02
HT108722D0
2SA872(D or E)

QH03,QH04
HT317752D0
2SC1775(D or E)

QH05,QH06
HT322401A0
2SC2240(GR)

QH07,QH08
HT109701A0
2SA970(GR)

QH09,QH10
HT406661C0
2SD666(C)

QH11,QH12
HT206461C0
2SB646(C)

PW00

QE01~QE04	QE05~QE08	QE09,QE10	QE11,QE12	QE13,QE14	QE29,QE30	QE31,QE32
QE15~QE18	QE19~QE22	QE23,QE24	QE25,QE26	QE27,QE28	QE33,QE34	QE35,QE36
HF201172B0	HT108722D0	HT317752D0	HT406661C0	HT206461C0	HD20003210	HV00009120
2SK117(Y or GR)	2SA872A(D or E)	2SC1775A(D or E)	2SD666(C)	2SB646(C)	IS2471	MV103(W)

notes(2002):

*1 : drawing corrected
*2 : GND is DC isolated with additional C405 (in actual unit)

scan: Ti(2012)

SC7 Preamp

marantz