



# SCHEMATIC DIAGRAM FOR Model SC-8

Q804 Q805, Q806 Q807 Q808 Q809, Q810 Q811~Q814  
 L 2SA970G or BL 2SK30Y 2SC1775A DorE 2SA872A DorE HZ6BL W06B


QL08, QL11, QL12, QL17, QL18 QL09, QL10, QL15, QL16, QL27, QL28 QL13, QL14, QL19, QL20, QL25, QL26  
 2SC1775A DorE 2SA872A DorE


1 ~ QL24  
 B1






  
 2SC2240B, 2SA970BL  
 2SA872A D.E., 2SC1775A D.E.  
 2SC2320E F, 2SA970GR  
 2SA1050 O.Y., 2SC2545E  
 2SA1083E, 2SK30Y  
 2SD666C, 2SB646C


  
 2SJ72BL, 2SK147BL


  
 2SC2238 O.Y., 2SA968 O.Y.






CAUTION  
 (F),(n) SINGLE SHIELDED LINE.  
 (U) DUAL SHIELDED LINE.  
 TERMINAL No. 1S (U) TYPE ONLY.


change for modification without notice.



# marantz

Q401, Q402 2SK147BL	Q403, Q404 2S72BL	Q409, Q410, Q415, Q416 2SC2240BL	Q411 ~ Q414 2SA970BL	Q417, Q418 2SA872 DoF	Q419, Q420 2SC1775A DoF	Q421, Q422 2SC2320 E or F	Q423, Q424 2SC2238 O.Y	Q425, Q426 2SA968 O.Y	Q427 ~ Q430 1SS81	Q801 2SC2238 O.Y	Q802 2SA968 O.Y	Q803 2SC2240GR or		
QD01 2SA1050 OrY	QD02 2SC232C E or F	QD03, QD07 ~ QD10 1S1555	QD05 2SK30Y	QD06 HZ27L	QE01, QE02 2SC2240GR	QE03, QE04 2SA970GR	QE05, QE06 2SA872A DoF	QE07, QE08 2SC1775A DoF	QE09, QE10 2SC2320 E or F	QE11, QE12 2SD666C	QE13, QE14 2SB646C	QL01, QL02 2SK150GR	QL03, QL04 2SC2259	QL05 1S1555
QL29, QL30 2SC2320 E or F	QL31, QL32 2SD666C	QL33, QL34 2SB646C	QL35, QL36 2SC2238 O.Y	QL43 W06B	QM01, QM02, QM05, QM06 2SC2545E	QM09, QM10, QM13, QM14, QM17, QM18 2SA1083E	QM19 ~ QM22 2SC2545E	QM23, QM24 2SD666C	QM25, QM26 2SB646C	QM27 2SC2238 O.Y	QM28 2SA968 O.Y	QL06 1S1555	QL07 1S1555	QL08 1S1555






**NOTE ON SAFETY :**  
 Symbol  $\triangle$  Fire or electrical shock hazard. Only original parts should be used to replace any part marked with symbol  $\triangle$ . Any other component substitution (other than original type), may increase risk of fire or electrical shock hazard.

Components and wiring are subject to




# SCHEMATIC DIAGRAM

Q9, Q410, Q415, Q416 C22A08L	Q411~Q414 2SA970BL	Q417, Q418 2SA872 DorE	Q419, Q420 2SC1775A DorE	Q421, Q422 2SC2320 E or F	Q423, Q424 2SC2238 O.Y	Q425, Q426 2SA968 O.Y	Q427~Q430 1SS81	Q801 2SC2238 O.Y	Q802 2SA968 O.Y	Q803 2SC2240G R or BL	Q804 2SA970G R or BL	Q805, Q806 2SK30Y	Q807 2SC1775A DorE	Q808 2SA872A DorE	Q809, Q810 HZ68BL	Q811~Q814 W06B
QD03, QD07~QD10 IS1555	QD05 2SK30Y	QD06 HZ27L	QE01, QE02 2SC2240GR	QE03, QE04 (G)	QE05, QE06 2SA872A DorE	QE07, QE08 2SC1775A DorE	QE09, QE10 2SC2320 E or F	QE11, QE12 2SD666C	QE13, QE14 2SB646C	QL01, QL02 2SK1506R	QL03, QL04 2SC2259	QL05~QL08, QL11, QL12, QL17, QL18 IS1555	QL09, QL10, QL15, QL16, QL27, QL28 2SC1775A DorE	QL13, QL14, QL19, QL20, QL25, QL26 2SA872A DorE		
QL33, QL34 2SB646C	QL35, QL36 2SC2238 O.Y	QL43 W06B	QM01, QM02, QM05, QM06 2SC2545E	QM09, QM10, QM13, QM14, QM17, QM18 2SA1083E	QM19~QM22 2SC2545E	QM23, QM24 2SD666C	QM25, QM26 2SB646C	QM27 2SC2238 O.Y	QM28 2SA968 O.Y	QL21~QL24 1SS81						







Components and wiring are subject to change for modification without notice.