

Q001
H110004030
SLP-132B

Q101, Q102, Q201, Q202, Q307,
HT326341T0
2SC2634(T)

Q103 ~ Q110, Q203 ~ Q210,
Q601, Q651, Q901, Q902, Q921, Q922
HT326341T0
2SC2634(S)


Q111, Q112, Q211, Q212
HD10003020
20A90

Q301, Q943
HD20020080
M1-151R


Q302, Q944
HD20019080
M1-151

Q303
HD30048090
WZ210


Q304
HT4030
2SD331



Ka&N TYPE ONLY



AaT TYPE ONLY



SWITCHES

- S001 POWER SWITCH(ON)
- S006 PLAY MUTE SWITCH
- S005 REC MUTE OFF SWITCH
- S010 MOTOR SWITCH(OFF)
- S090 FF/REW SWITCH(OFF)
- S101 REC/PLAY SWITCH(REC)
- S201 REC/PLAY SWITCH(OFF)
- S303 DOLBY SWITCH(OFF)
- S301 EQ SWITCH(OFF)
- S302 BIAS SWITCH(OFF)

Note on safety: The parts marked with Δ are important parts on the safety. Please use the parts having the designated parts number without fail.

