


* () VOLTAGE IS CLASS "A"
 [] VOLTAGE IS CLASS "B"



Note on safety: The parts marked with Δ are important parts on the safety. Please use the parts having the designated parts number without fail.

Components and wiring are subject to change

SCHEMATIC DIAGRAM FOR MODEL Sm-6

