

# NAD C160/C300/C320

---

---

## Circuit Change

---

---

### ***PROBLEM:***

You may receive a complaint where the unit keeps some or all inputs active. As a result the output signal consists of several different input signals all at once.

---

### ***CAUSE:***

A leaky capacitor in the input selection circuit keeps the input active.

---

### ***SOLUTION:***

Change the following capacitors from 10nF/50V to 10nF/100V

**C160:** C1, C5, C6, C506, C507, C508, C509, C510, C511, C512, C754

**C300:** C112, C212, C509, C708, C723, C724

**C320:** C1, C2, C4, C5, C6, C57, C514, C515, C516, C517, C518, C519, C520

---

### ***PRODUCTION:***

This modification will be implemented into production from serial:

H04C16002191  
H04C30009750  
H04C32026880