



Service Information T562

Software Upgrade (REVISED)

When upgrading the T562 it is important to make sure the video switch is set to S-video before turning on the unit. This is necessary as setting it to composite will cause the screen to go blank when upgrading the unit. If the front panel keys or remote keys are pressed during the upgrade this will permanently delete the software for the unit and the unit will not come out of standby mode.

Insert the software upgrade cd-r disc. It will prompt you after loading to press the cursor up key on the front panel. After pressing the cursor up key it will take several minutes to complete. No further action is required during this time. After completion the message will come up again, press the up key, DO NOT press this key. At this point the software upgrade is complete and you can remove the disc.

Contact:

NAD Electronics International
633 Granite Court
Pickering, ON Canada L1K 3K1
Voice: 905-831-0799 FAX 905-837-6357
www.nadelectronics.com

03/28/03

T562

Region Setting

The above model is delivered factory set to either R1 or R2 depending on the version. To change the region code to your own area please perform the following,

- 1. Turn on the unit and remove any discs .*
- 2. Call up the OSD menu and select “Settings”.*
- *3. Enter the numbers , 741130 .*
- 4. After these numbers are entered a screen will appear showing a number of regions to select.*
- 5. After selecting the region press enter, then turn the unit off for this procedure to take effect.*

** Note: Enter this sequence of numbers as quick as possible .*

This completes the region setting.

Software Upgrade

When upgrading the T562 it is important to make sure the video switch is set to S-video before turning on the unit. This is necessary as setting it to composite will cause the screen to go blank when upgrading the unit. If the front panel keys or remote keys are pressed during the upgrade this will permanently delete the software for the unit and the unit will not come out of standby mode.

Insert the software upgrade cd-r disc. It will prompt you after loading to press the cursor up key on the front panel. After pressing the cursor up key it will take several minutes to complete. No further action is required during this time. After completion the message will come up again, press the up key. At this point the software upgrade is complete and you can remove the disc.

Contact:

NAD Electronics International
633 Granite Court
Pickering, ON Canada L1K 3K1
Voice: 905-831-0799 FAX 905-837-6357
www.nadelectronics.com

T752/T562/ Future Models

Trigger Switch Operation

On the rear panel of these two models and on our future models you will find a switch labelled, Auto Trigger. This switch has two positions marked auto or on and off. This allows the user to hook up other NAD products, which have a corresponding Trigger socket, together in order to have one product turn the other on and off.

With this type of configuration, when the auto trigger switch is set to auto or on, the product will now only be turned on by an external 12v signal. The product will not respond to IR signals or front panel control in this case.

In the off position the auto trigger switch will have no affect to the unit and the product will operate normally.

The factory setting is normally off, allowing the user to set it for external on/off control. However, it is recommended to check this switch if you tried the product and it will not turn on.

Contact:

**NAD Electronics International
633 Granite Court
Pickering, ON Canada L1K 3K1
Voice: 905-831-0799 FAX 905-837-6357
www.nadelectronics.com**