

Hi-Fi LOUDSPEAKER BOX 5427


Service manual




3097A

35 litres
332 x 610 x 246mm


TO OPEN L.S. BOX



3152A



1839A



1971A




CS36916

Subject to modification

4822 726 11148

Printed in the Netherlands



1836A

-S- 

S426	2.1 mH	4822 152 20479
S427	2.1 mH	4822 152 20479
S428	0.2 mH	4822 157 30197
S429	0.35 mH	4822 157 50595

-C- 


C726	50 μ F	4822 124 40091
C727	50 μ F	4822 124 40091
C728	8 μ F	4822 124 40102
C730	24 μ F	4822 124 40099

-C- 

C729	6.8 μ F	4822 121 40252
------	-------------	----------------

-R- 

R501	5.6 Ω	4822 112 20047
------	--------------	----------------



31510

1			4822 426 60055
2			4822 264 30041
3	LS401	4 Ω	4822 240 50089
4	LS402	4 Ω	4822 240 70003
5	LS403 LS404	8 Ω	4822 240 60023
6			4822 462 70531