





| Sk 3   |              |
|--|--------------|
| verbundener Kontakt bei:<br>closed contact at: |              |
| Vorlauf<br>forward                             | Halt<br>stop |
| 301-303  | 303-306-307  |
| 302-306  |              |
| 304-305  |              |



| Sk 4   |           |                 |           |
|--|-----------|-----------------|-----------|
| verbundener Kontakt bei:<br>closed contact at: |           |                 |           |
| Spur 2-3                                       | Spur 1-4  | Stereo          | Parallel  |
| 401 - 403                                      | 401 - 403 | 403 - 405       | 401 - 403 |
| 402 - 404                                      | 402 - 404 | 404 - 406       | 402 - 404 |
| 410 - 412                                      | 411 - 413 | 407 - 408       |           |
| 411 - 413                                      | 412 - 414 | 409 - 410 - 411 |           |
| 416 - 418                                      | 415 - 417 | 412 - 414       | 415 - 417 |
| 419 - 421                                      | 416 - 418 | 415 - 417       |           |
| 420 - 422                                      | 421 - 422 | 421 - 422       | 419 - 421 |
| 425 - 427                                      | 423 - 425 | 423 - 425       |           |
| 426 - 428                                      | 424 - 426 | 424 - 426       |           |
|  |           | 427 - 429       |           |
|  |           | 428 - 430       |           |
|  |           | 431 - 432       |           |






| Sk 6   |           |           |
|--|-----------|-----------|
| verbundener Kontakt bei:<br>closed contact at: |           |           |
| Multiplay                                      | Normal    | Duoplay   |
| 603-607  | 601 - 608 | 603 - 607 |
| 605-606  | 615 - 616 | 605 - 606 |
| 609-613  |           | 609 - 613 |
| 610 - 612                                      |           |           |



Kontaktfedern von Printseite aus gesehen!  
(contact springs viewed from the print side)




| Sk  | Funktion  |
|-----|---|
| 0   | Netzschalter<br>mains switch                                  |
| 1   | A/W-Schalter<br>rec/playswitch linker Kanal<br>left channel   |
| 101 | A/W-Schalter<br>rec/playswitch rechter Kanal<br>right channel |
| 2   | Geschwindigkeitsumschalter<br>speed selector                  |
| 3   | Vorlaufschalter<br>forward switch                             |
| 4   | Spurumschalter<br>track selector                              |
| 5   | Spannungswähler<br>voltage adapter                            |
| 6   | Multiplay - Duoplay   |
| 7   | Lautsprecherschalter<br>loudspeaker switch                    |



Sk 5 (Ansicht auf Lötflügel)  
(view on solder tags)

□ 1/8W □ 1/4W □ 1/2W □ 1W









Bu 1  
MP1 MP101  
Bu 101  
MORO R  
Bu 3  
P1 P2  
Bu 2  
RABO P1 P2

Bu 4  
Sk 7  
Bu 104  
Bu 5

Bu 104  
Ls 101

Bu 104  
Ls 101



3103 206 01191