

AZ1048

/12(Europe) /55(Latam)

OCX      CLR+MLR

stroke version

repair policy

PCM Code

Safety

Level Pos. No.

12Nc

Description

Mechanical Partlist

1	1	996510018794	HANDLE		502-7050XX-000	X
1	14	996510003634	CD DOOR SPRING		479-AZ1000-000	X
1	15	996510038928	POWER TRANSFORMER UB4623FS 230V	\$	152-004623-230	X
1	16	996510038958	BOTTOM CABINET		502-7802XXX-XXX	X
1	17A	996510038894	BATTERY SPRING (+-)		479-001027-010	X
1	17B	996510038922	BATTERY SPRING (+) ZX200		763-200000-001	X
1	17C	996510038911	BATTERY SPRING(+)+39/82/383A/		764-821800-000	X
1	17D	996510038915	BATTERY SPRING(-) S200		765-200000-000	X
1	18L	996510038896	SPEAKER CLIP(LEFT)		459-102701-000	X
1	18R	996510038913	SPEAKER CLIP (RIGHT)		459-102702-000	X
1	19	996510018793	BATTERY DOOR		502-704XXX-000	X
1	20	996510038923	SPEAKER 3.5" 8OHM 2W ROHS		154-AZ1022-506	X
1	21	996510038959	VOLUME KNOB		502-7074XX-000	X
1	22	996510038952	DBB KNOB		502-7072XX-000	X
1	24	996510003632	CD MECHANISM		356-112350-091	X
1	2L	996510018795	HANDLE COVER (L)		502-737000-001	X
1	2R	996510018796	HANDLE COVER(R)		502-737000-002	X
1	3	996510018797	CD DOOR		502-7490XX-XXX	X
1	31	996510038878	LCD BRACKET		502-731000-000	X
1	36	996510038946	FRONT CABINET		504-601XXX-XXX	X
1	37	996510038886	RIGHT SPEAKER GRILLE		762-104600-000	X
1	38	996510038951	LCD LENS		504-680400-XXX	X
1	39	996510038897	LEFT SPEAKER GRILLE		761-104600-000	X
1	4	996510038926	FM ANTENNA		155-AZ1027-000	X
1	41	996510015932	AC SOCKET TC08-115-02		158-000230-012	X
1	42	994000001741	LEAF SWITCH LS-N35		217-200035-050	X
1	43	996510008111	FFC CABLE 16P "K" 1.0mm 90mm		235-160090-110	X
1	44	996510034403	RECORDING BRACKET		500-022000-000	X
1	45	996510001995	CASS DOOR GEAR HOLDER		5AZ-121200-000	X
1	46	996510032641	AC SOCKET COVER		5AZ-125100-000	X
1	47	996510038953	TUNING LENS		502-771XXX-XXX	X

1	48	996510038904	DIAL TRAY	502-727000-000	X
1	49	996510038945	PLAY KEY	504-6502XX-002	X
1	5	996510038954	TUNING KNOB	502-7060XX-000	X
1	50	996510038955	MODE KEY	504-6512XX-006	X
1	51	996510038956	PROG. KEY	502-6518XX-006	X
1	52	996510038957	PAUSE KEY	504-6508XX-002	X
1	53	996510038949	PANNEL	504-6072XX-000	X
1	54	996510038948	FUNCTION KNOB	502-7088XX-000	X
1	55	996510038944	BAND KNOB	502-7082XX-000	X
1	56	996510001994	CASS DOOR GEAR	5AZ-121100-000	X
1	57	996510038895	METALS AND PACKING LIST	1048-PSL00-02	X
1	58	996510038927	TOOTH WASHER	453-025060-060	X
1	59	996510009868	RUBBER CUSHION 1	458-AZ1022-220	X
1	6	996510038947	TOP CABINET	5027-1110XX-XXX	X
1	60	996510009869	RUBBER CUSHION 2	458-AZ1022-230	X

**MAIN BOARD Partlist**

1	PCBA1	996510038899	MAIN BOARD ASSY	AZ10-02800-00	X
2	D302	996510032578	RECTIFIER IN-4001 ALL MODEL	206-304001-000	X
2	D304	996510032594	RECTIFIER IN5817	206-305817-000	X
2	D310	996510032594	RECTIFIER IN5817	206-305817-000	X
2	FS1104	996510038876	FUSE 1A/125V 30TS	\$ 231-922100-129	X
2	IC301	996510038909	IC UTC8227	210-008227-002	X
2	IC501	996510018091	IC-3	210-004052-000	X
2	IC705	996510032597	SMT I.C. ET8861	310-008861-152	X
2	IC901	996510038885	SMT IC AIC1526	310-001526-100	X
2	IC902	996510038916	SMT IC TO-252-2(1)	310-001117-104	X
2	IC903	996510038914	SMT IC EN25F20 8PINS	310-002520-008	X
2	IC904	996510038889	SMD IC M5673 128PINS	310-005673-100	X
2	IC905	996510008103	I.C. KA7805 POSITIVE VOLTAGE	210-007805-022	X
2	IC906	996510008924	SMT I.C SA5888	310-005888-100	X
2	Q102	996510038912	SMT TRANSISTOR 8050C/D	307-008050-030	X
2	Q301	996510008797	SMT TRANSISTOR 9014C	307-009014-030	X
2	Q302	996510008797	SMT TRANSISTOR 9014C	307-009014-030	X
2	Q303	996510038907	TRANSISTOR 9018-H	307-009018-080	X
2	Q304	996510038924	TRANSISTOR 8550D TO-92	207-008550-092	X

2	Q305	996510038912	SMT TRANSISTOR 8050C/D	307-008050-030	X
2	Q306	996510008797	SMT TRANSISTOR 9014C	307-009014-030	X
2	Q307	996510008797	SMT TRANSISTOR 9014C	307-009014-030	X
2	Q309	996510038917	TRANSISTOR 2SB772 TO-92 3P	207-002772-003	X
2	Q901	996510038924	TRANSISTOR 8550D TO-92	207-008550-092	X
2	Q904	996510038912	SMT TRANSISTOR 8050C/D	307-008050-030	X
2	SW301	996510038919	SLIDE SW.SK24D01G4	219-124201-104	X
2	SW302	996510038882	PUSH SWITCH PS-8.5X8.5-180G	218-085085-180	X
2	VR301	996510038883	SHAFT VOLUME 50K A 16MM	225-162050-172	X
2	X901	996510038898	CRYSTAL 16.9344 MHZ 3.5MM+-0.1	229-169344-002	X
2	ZD402	996510038902	ZENER 5.6V 1/2W +-5%	206-200056-102	X
2	ZD403	996510038906	ZENER 6.2V 1/2W	206-200062-102	X

#### TUNER BOARD Partlist

1	PCBA2	996510038901	TUNER BOARD ASSY	AZ10-01800-21	X
2	AMANT	996510038918	AM COIL 120:15T WIRE 4X140MM	212-120015-140	X
2	CF101	996510038893	CERAMIC FILTER 465 B KHZ 3PIN	208-346530-000	X
2	CF102	996510008794	CERAMIC FILTER 10.7 MA5-A 3PIN	208-010730-518	X
2	CF103	994000005015	CER. FILTER 10.7 MCI-A 2P	208-010720-118	X
2	FMANT1	996510038925	CONTACT PIN RT-01T-1.0B 1MM	410-100000-001	X
2	IC101	996510038908	IC SILAN SA2111 3V	210-002111-000	X
2	L101	996510008796	FM COIL 3.5T 3.9 x 0.6 mm	213-035039-060	X
2	L102	996510008107	FM COIL 3.5T 4.5 x 0.7 mm	213-035045-070	X
2	PVC101	996510038921	P.V.C AM/FM DF443DF02-A04	211-412112-444	X
2	Q101	996510038888	TRANSISTOR KRC-111M KEC	207-000111-013	X
2	SW102	994000001768	SLIDE SW. SK22F03G6 0306	219-122335-506	X
2	T101	996510038903	I.F.T. AM IFT AH26-10002T S35	209-230002-007	X
2	T103	996510038905	I.F.T OSC 1010 RED 10MM	209-181010-010	X
2	VP101	996510038929	SMT IND 0603ESDA-LF	326-230000-202	X

#### CONTROL BOARD Partlist

2	LCD701	996510038884	LCD DISPLAY 3.3V 12P 12OCLOCK	220-124224-120	X
2	SW701	994000002786	TACT SWITCH 2P	217-060650-500	X
2	SW702	994000002786	TACT SWITCH 2P	217-060650-500	X
2	SW703	994000002786	TACT SWITCH 2P	217-060650-500	X
2	SW704	994000002786	TACT SWITCH 2P	217-060650-500	X

2	SW705	994000002786	TACT SWITCH 2P		217-060650-500	X
2	SW706	994000002786	TACT SWITCH 2P		217-060650-500	X
2	SW707	994000002786	TACT SWITCH 2P		217-060650-500	X
2	SW708	994000002786	TACT SWITCH 2P		217-060650-500	X

**USB BOARD Partlist**

2	JK601	996510029442	USB CONNECTOR USB-A-02		253-000002-000	X
---	-------	--------------	------------------------	--	----------------	---

**RECTIFIER BOARD Partlist**

2	C1105	996510032614	ELECT CAP 3300 UF/25V +-20%		004-083382-225	X
2	D1101	996510032578	RECTIFIER IN-4001 ALL MODEL		206-304001-000	X
2	D1102	996510032578	RECTIFIER IN-4001 ALL MODEL		206-304001-000	X
2	D1103	996510032578	RECTIFIER IN-4001 ALL MODEL		206-304001-000	X
2	D1104	996510032578	RECTIFIER IN-4001 ALL MODEL		206-304001-000	X
2	FS1101	996510038887	GLASS FUSE 1.6A 250V 50T	\$	231-902160-253	X
2	Q308	994000005041	TRANSISTOR 8050C/D		207-008050-030	X
2	Q401	994000005022	TRANSISTOR KSD882Y		207-000882-250	X
2	ZD401	996510038931	ZENER 9.1V 1/2W		206-200091-102	X

**HEADPHONE BOARD Partlist**

2	JK602	996510038877	STEREO EARPHONE JACK JY-3561		240-135610-902	X
---	-------	--------------	------------------------------	--	----------------	---

**Accessory Partlist**

1	40	996510031369	AC CORD LINE	\$	151-220230-012	X
1	11	996510031369	AC CORD LINE	\$	151-220230-012	X

**History List:**

V1.0 Initial release partlist for /12 /55 (8/30/2010)