

<u>Level</u>	<u>Pos. No.</u>	<u>12Nc</u>	<u>Description</u>	<u>Safety</u>	<u>stroke version</u> <u>repair policy</u> <u>PCM Code</u>	<u>AZ1137</u> <u>/12(APAC)</u> <u>CLR + MLR</u>	<u>/55(ATAM)</u> <u>CLR + MLR</u>
<b>Mechanical Partlist</b>							
1	M1	996510055166	SPEAKER 3" 8 OHM 2W ARG1837		2303-08023-E010	X	X
1	M10	996510055203	CD DOOR SPRING		3540-18040-E010	X	X
1	M11	996510056675	TOP CABINET		4600-04457-1011	X	X
1	M12	996510056673	CD DOOR ABS PC-4457		4601-04457-0014	X	
1	B	996510056856	CD DOOR		4601-04457-0011		X
1	M13	996510055219	LCD LENS		4603-04457-0010	X	
1	M14	996510055224	DUST COVER		4607-04457-0010	X	
1	M15	996510056676	BOTTOM CABINET		4620-04457-1011	X	
1	T2	996510056802	BOTTOM CABINET		4620-04458-0011		X
1	M16	996510056666	BATTERY DOOR		4622-04457-1011	X	X
1	M2	996510056679	CD DECK ( DA11BBV)		2560-08050-E010	X	X
1	M3	996510055187	ANTENNA(ARG1837/77)		3302-04458-E010	X	X
1	M4	996510056671	SPEAKER NET(L)		3454-04457-E011	X	X
1	M5	996510056665	SPEAKER NET(R)		3454-04457-E021	X	X
1	M6	996510056674	BATTERY SPRING "+/-" -A		3540-04458-E010	X	X
1	M7	996510056672	BATTERY SPRING "+/-" -B		3540-04458-E020	X	X
1	M8	996510056677	BATTERY PLATE "+"		3540-04458-E030	X	X
1	M9	996510056667	BATTERY SPRING "-"		3540-04458-E040	X	X
1	M1	996510056688	TRANSFORMER 110-127V/60HZ/220-240V/50HZ	\$	2295-54458-E100		X
<b>PCB ASSEMBLY</b>							
1	PCB1	996510056668	MANI PCB ASSY		1237-14457-ET000	X	
1	PCB1	996510056801	MAIN PCB ASSY		1237-14457-ET001		X
1	PCB2	996510056664	DISPLAY PCB ASSY		1237-14457-ET501	X	
1	PCB2	996510056855	DISPLAY PCB ASSY		1237-14457-ET502		X
1	PCB3	996510056678	POWER PCB ASSY		1237-14458-ET600		
1	PCB3	996510056799	CD PCB ASSY		1237-14457-ET801		X
<b>Accessory Partlist</b>							
1	B	996510056669	PC-4457(ALIM5671) ADAPTOR	\$	2295-54458-E000	X	

**History List:**

V1.0 Initial release (06/06/2012) partlist for /12