

<u>Level</u>	<u>Pos. No.</u>	<u>AlternativeSuffix12Nc</u>	<u>Description</u>	<u>Safety</u>	<u>PCM Code</u>	<u>AZ1852</u>			
<u>Mechanical Partlist</u>						<u>/98</u>	<u>/61</u>	<u>/93</u>	<u>/79</u>
1		996510032619	ROD ANT 4SECTION L=875MM ; Ø6.5		155-500047-875	X	X	X	X
1		996510032637	ROD ANTENNA		155-185246-233	X			
1		996510032605	CD DOOR		518-549000-000	X	X	X	X
1		996510032588	HANDLE		518-580500-000	X	X	X	X
1		996510032603	TOP CABINET		518-511000-000	X	X	X	X
1		996510032602	POINTER BRACKET		518-530000-000	X	X	X	X
1		996510032634	TUNING KONB		518-506000-000	X	X	X	X
1		996510032636	VOLUME KNOB		518-580740-000	X	X	X	X
1		996510032593	FUNTION KNOB		518-580880-000	X	X	X	X
1		996510032616	CASS KNOB		518-510000-000	X	X	X	X
1		996510032613	BOTTOM CABINET		518-502000-000	X	X	X	X
1		996510032618	TUNING DRUM		518-523000-000	X	X	X	X
1		996510032627	CASS DECK JS-21VB9109-SGS		156-885139-910	X	X	X	X
1		996510032591	TUNING KONB GEAR		518-524000-000	X	X	X	X
1		996510032595	POINTER		518-509000-000	X	X	X	X
1		996510032584	DIAL LENS		518-571000-000	X	X	X	X
1		996510032615	CASS DOOR		518-513000-000	X	X	X	X
1		996510032647	BATTERY COVEER		518-580400-000	X	X	X	X
1		996510032626	CD KNOB		518-550000-000	X	X	X	X
1		996510032606	DUST PREVENTION COVER		518-520213-342	X	X	X	X
1		996510032629	DISPLAY LENS		518-504000-000	X	X	X	X
1		996510032601	DBB KNOB		518-507000-000	X	X	X	X
1		996510032717	LCD BRACKET		518-531000-000	X	X	X	X
		996510033547	DISPLAY PCB BRACKET		518-532000-000			X	X
1		996510032633	AC SOCKET TC08-115-02	\$	158-000230-013	X	X	X	X
1		996510032582	CD MECHANISM COVER		500-995213-342	X	X	X	X
1		994000001759	CASS DOOR GEAR		539-121100-000	X	X	X	X
1		994000001761	CASS DOOR GEAR HOLDER		539-121200-000	X	X	X	X
1		996510032623	CD KNOB COVER		518-501900-000	X	X	X	X
1		996510032608	DISPLAY RING		518-512000-000	X	X	X	X
1		996510032631	CASS DOOR COVER		518-516000-000	X	X	X	X
1		996510032639	CASS KNOB ADAPTION		518-527300-000	X	X	X	X
1		996510032641	AC SOCKET COVER		5AZ-125100-000	X	X	X	X
1		996510032643	BAND SWITCH COVER		518-525100-000	X	X	X	X

1		996510032611	BAND SWITCH PLATE	5G2-000110-000	X	X	X	X
1		994000001741	LEAF SWITCH LS-N35	217-200035-050	X	X	X	X
1		996510032635	USB RUBBER	458-185200-000	X	X	X	X
1		996510032644	CASS DOOR SPRING	479-185200-040	X	X	X	X
1		996510032642	CD DOOR SPRING	479-185200-000	X	X	X	X
1		996510032645	BATTERY SPRING(+/-)	763-420170-010	X	X	X	X
1		996510032646	BATTERY SPRING(+)	764-300160-010	X	X	X	X
1		996510032649	BATTERY SPRING(-)	765-300200-010	X	X	X	X
1		996510032621	SLIDE SW.SSJ-12J01-G6	219-102112-300	X			
1		996510032609	FFC CABLE 8PINS 158MM 1.0MM /B	235-081158-210	X	X	X	X
1		996510032628	FFC CABLE 16P"JST"1.0MM 200MM	235-160200-210	X	X	X	X
1		996510003632	CD MECHANISM	356-112350-091	X	X	X	X
1		996510032648	FRONT CABINET	518-500000-000	X	X	X	X
1	SPK	996510032583	SPEAKER 3" 40 8OHM 2W BLACK	154-388020-409	X	X	X	X
1	TRA	996510032598	POWER T.F FS/C 120V-230V	\$ 152-575369-300	X	X	X	X

Main Board Partlist

1	PCBA1	996510032612	MAIN BOARD	AZ18-02800-27	X			X
1	PCBA1	996510033549	MAIN BOARD ASSY /61	AZ18-02800-27/61		X		
1	PCBA1	996510033548	MAIN BOARD ASSY /93	AZ18-02800-27/93			X	

Tuner Board Partlist

1	PCBA2	996510032579	TUNER BOARD	AZ18-01800-11	X	X		X
---	-------	--------------	-------------	---------------	---	---	--	---

Control Board Partlist

1	PCBA3	996510032622	CONTROL BOARD	AZ18-03800-61	X	X	X	X
2	IC701	996510032597	SMT I.C. ET8861	310-008861-152	X	X	X	X
2	L13	996510032716	LCD DISPLAY SDL-H01210PPR-0	220-001210-014	X	X	X	X
2	Q701	994000002791	DIODE RPM-7100 (ROHM)	206-107100-000	X	X	X	X
2	SW701	994000002786	TACT SWITCH 2P	217-060650-500	X	X	X	X
2	SW702	994000002786	TACT SWITCH 2P	217-060650-500	X	X	X	X
2	SW703	994000002786	TACT SWITCH 2P	217-060650-500	X	X	X	X
2	SW704	994000002786	TACT SWITCH 2P	217-060650-500	X	X	X	X
2	SW705	994000002786	TACT SWITCH 2P	217-060650-500	X	X	X	X
2	SW706	994000002786	TACT SWITCH 2P	217-060650-500	X	X	X	X
2	SWDBB701	996510008115	PUSH SWITCH PSA-22D02 2P2T	218-060060-000	X	X	X	X

RECTIFIER BOARD Partlist

1	PCBA4	996510032585	RECTIFIER BOARD		AZ18-12800-10	X	X	X	X
2	C1105	996510032614	ELECT CAP 3300 UF/25V +-20%		004-083382-225	X	X	X	X
2	D1101	996510032578	RECTIFIER IN-4001 ALL MODEL		206-304001-000	X	X	X	X
2	D1102	996510032578	RECTIFIER IN-4001 ALL MODEL		206-304001-000	X	X	X	X
2	D1103	996510032578	RECTIFIER IN-4001 ALL MODEL		206-304001-000	X	X	X	X
2	D1104	996510032578	RECTIFIER IN-4001 ALL MODEL		206-304001-000	X	X	X	X
2	D401	996510032594	RECTIFIER IN5817		206-305817-000	X	X	X	X
2	FS1100	996510008120	GLASS FUSE 2A 250V 5T	\$	231-902200-251	X	X	X	X
2	FS1101	996510032592	FUSE HOLDER 5X9 MM		406-050090-000	X	X	X	X
2	Q308	994000005041	TRANSISTOR 8050C/D		207-008050-030	X	X	X	X
2	Q401	996510008103	I.C. KA7805 POSITIVE VOLTAGE		210-007805-022	X	X	X	X
2	Q403	996510008094	TRANSISTOR B772Y		207-000772-250	X	X	X	X
2	ZD401	996510032638	ZENER 4.3V 1/2W		206-200043-102	X	X	X	X
2	ZD402	996510032604	ZENER 5.1V 1/2W		206-200051-102	X	X	X	X

HEADPHONE JACK BOARD Partlist

2	JK601	996510032586	PHONE JACK/CKX-3.5-28(BLACK)		240-003528-000	X	X	X	X
2	JK602	996510032586	PHONE JACK/CKX-3.5-28(BLACK)		240-003528-000	X	X	X	X

USB BOARD Partlist

2	USB JACK1	996510029442	USB CONNECTOR USB-A-02		253-000002-000	X	X	X	X
---	-----------	--------------	------------------------	--	----------------	---	---	---	---

RECORDING BOARD Partlist

1	PCBA7	996510032587	RECORDING BOARD		AZ18-13800-23	X	X	X	X
2	IC201	996510032625	IC AN7323(CSC7323)		210-007323-014	X	X	X	X
2	Q802	996510032624	TRANSISTOR BC337-25		207-000337-000	X	X	X	X
2	SW201	996510008805	RECORDING SW.PS-62D01-S		218-662205-007	X	X	X	X
2	T801	996510032589	L.F.T 0400 7MM BLACK		209-220400-007	X	X	X	X

ACCESSORY Partlist

1	RC	996510032596	REMOTE CONTROL 12KEYS AZ1856		RC12-716029-025	X	X	X	X
1		996510008129	POWER CORD	\$	151-230230-152	X			
1		996510031369	AC CORD LINE	\$	151-220230-012		X		
1		996510033546	POWER CORD SET	\$	151-230230-310			X	

CORD	996510009870	POWER CORD	\$ 151-240230-203	X
Packing Partlist				
47	996510034943	DISPLAY BOX	891-185211-020	X
48	996510034942	OUTER CARTON	895-AZ1852-000	X
49	996510034941	PAPER PULP	874-185200-000	X

History List:

1,0	8-2-2010	Initial
1,1	3/1/2010	Add partlist for /61/93
1,2	25-3-2010	1.Change power cord for /98 2.Add packing list for /93
	29-3-2010	Change power cord for /61
1,3	15-7-2010	Add partlist for /79