

Level	Pos. No.	Alternative Suffix	2Nc	Description	Safety	PCM Code	BDP7500S2					
Mechanical Partlist							/12	/51	/93	/98	/55	/05
1	B005		996510032734	POWER BOARD POW318C-12	\$	32001105	X					
1	B005		996510034437	POWER BOARD POW318C-51	\$	32001103		X				
1	B005		996510035521	POWER BOARD POW318C-93 ASSY	\$	32001115			X			
1	B005		996510035517	POWER BOARD POW318C-98 ASSY	\$	32001118				X		
1	B006		996510032741	BLU-RAY DRIVER(TRV412VH5)		31000225	X	X	X	X		
1	B007		996510032732	BR DECODER BOARD BDP7500B2-12		32001106	X					
1	B007		996510034436	BR DECODER BOARD BDP7500B2-51		32001102		X				
1	B007		996510035523	BLU-RAY DECODER BOARD ASSY		32001116			X			
1	B007		996510035518	BR DECODER BOARD ASSY		32001119				X		
1	B008		996510032729	DIGITAL SIGNALS BOARD		32001120	X	X	X	X		
1	B009		996510032968	ALUMINIUM TOP COVER		37-BDP7500-01A102	X		X			
1	B009		996510034566	ALUMINIUM TOP COVER		37-BDP7500-01A103		X		X		
1	B010		996510026592	BDP7500 FRONT CABINET/HIPS		39-BDP7500-01A101	X	X	X	X		
1	B011		996510026611	BDP7500 DVD DOOR/ABS		39-BDP7500-02A100	X	X	X	X		
1	B012		996510032742	BDP7500 DISPLAY LENS		39-BDP7500-03A104	X	X	X	X		
1	B013		996510026607	BDP7500 BUTTON BRACKET/ABS		39-BDP7500-04A100	X	X	X	X		
1	B014		996510026594	BDP7500 BUTTON LENS/PMMA		39-BDP7500-05A101	X	X	X	X		
1	B015		996510026605	BDP7500 LIGHT-GUIDE(PMMA)		39-BDP7500-07A100	X	X	X	X		
1	B016		996510026601	BDP7500 DVD DOOR LENS/PMMA		39-BDP7500-08A101	X	X	X	X		
1	B017		996510026612	BDP7500 USB DOOR/HIPS		39-BDP7500-09A101	X	X	X	X		
1	C001		996510032743	FLAT FLEXIBLE CABLE 5PX50A		25004403	X	X	X	X		
1	C002		996510032744	FLAT FLEXIBLE CABLE 8PX90B		25004276	X	X	X	X		
1	VFDandMCU		996510041919	DISPLAY BOARD AND MCU BOARD ASSY		03-BDP7500-05A101	X	X	X	X		

DISPLAY BOARD AND MCU BOARD Partlist

2	B001		996510032737	BDP7500S2 MCU BOARD		07-BDP7500S-01A101						
3	D101		996510032733	CHIP DIODE 5819		16000406	X	X	X	X		
3	D102		996510013857	DIODE IN60-52		16000375	X	X	X	X		
3	D103		996510013857	DIODE IN60-52		16000375	X	X	X	X		
3	J101		996510026585	USB JACK A-TYPE 4P FEMALE/W		24000562	X	X	X	X		
3	LED102		996510026575	LED μ3X5.2(3C2DW64C-2A) WHITE		16000440	X	X	X	X		
3	LED103		996510026575	LED μ3X5.2(3C2DW64C-2A) WHITE		16000440	X	X	X	X		
3	LED104		996510026575	LED μ3X5.2(3C2DW64C-2A) WHITE		16000440	X	X	X	X		
3	U101		996510026608	IC R5F21266NFP		19000667	X	X	X	X		
2	B002		996510032735	BDP7500S2 VFD DISPLAY BOARD		07-BDP7500S-02A101						
3	IR201		996510026606	IR SENSOR(1MP61620CT0001WR)36K		21000086	X	X	X	X		
3	LED201		996510028939	LED 3R28E11C-2B-S02(HIGH-RED)		16000455	X	X	X	X		
3	SW201		996510000020	LIGHT TOUCH SW.		23000034	X	X	X	X		
3	U201		996510026603	IC PT6312BLQ iLFO1C KBAB9		19000665	X	X	X	X		
3	VFD201		996510026572	VFD DISPLAY 2007S-2A23		29000415	X	X	X	X		
2	VFDtoMCU		996510041926	28 CABLE 245 2.0/14PX2		25004209			X			

BDP7500S2 TOUCH BOARD Partlist

2	U801		996510026589	IC WT5700(SOP16)		19000669	X	X	X	X		
---	------	--	--------------	------------------	--	----------	---	---	---	---	--	--

BDP7500S2 LED BOARD Partlist

2	LED401		996510028929	LED 2X3X4 23004BCH09-357/BLUE		16000376	X	X	X	X		
---	--------	--	--------------	-------------------------------	--	----------	---	---	---	---	--	--

Accessory Partlist

1	ACC01		996510026588	YKF258-003 REMOTE CONTROL		32001031	X		X	X		
1	ACC01		996510027995	REMOTE CONTROL(YKF258-001)		32001060		X				
1	ACC02		996510026574	AV WIRE 1.5m RCA/2P(RED/WHITE)		27000502	X	X	X	X		
1	ACC03		994000004988	AC LINE CORD 1.8M	\$	26000016	X	X		X		
1	ACC03		994000005166	AC LINE CORD 1.8M	\$	26000014			X			
1	ACC04		994000005078	AUDIO SINGLE WIRE W/RCA 1.5M		27000043	X	X	X	X		
1	ACC06		996510026597	HDMI CABLE 9P/M180jã/1.5M/V1.3		27000527		X		X		

Packing Partlist

1	PACKING1		996510035533	PAPER PULP		41008243			X			
1	PACKING2		996510035524	CARTON BOX		41009032			X			
1	PACKING3		996510035522	DISPLAY BOX		P41009033-A101			X			

History List:

1,0	18-3-2010	Initial
1,1	26-3-2010	Add partlist for /51
1,2	28-4-2010	Add partlist for /93/98
1,3	22-2-2011	combine VFD display board and MCU board