



3-HEAD  
CASSETTE TAPE DECK

# CT-F1000

KCU





- SWITCHES:
- S101 ERASE PREVENT DETECTOR (NO HOLE — HOLE)
  - S102 CHROME TAPE DETECTOR (NO HOLE — HOLE)
  - S103 CASSETTE HALF DETECTOR (OFF — ON)
  - S104 TAPE COUNTER (OFF — ON)
  - S105 MEMORY STOP/PLAY (OFF — ON)
  - S106 POWER (OFF — ON)

- S107 REW (OFF — ON)
- S108 F.F (OFF — ON)
- S109 PLAY (OFF — ON)
- S110 REC (OFF — ON)
- S111 PAUSE (OFF — ON)
- S112 LIMITER (OFF — ON)
- S113 BIAS (STO / Fe-Cr — Cr-O<sub>2</sub>)
- S114 EQ (Cr-O<sub>2</sub> — STO — Fe-Cr)
- S115 DOLBY NR / MPX FILTER (ON / ON — OFF / OFF — ON / OFF)
- S116
- S117

