

# 9. JB-100

## SPECIFICATIONS

|                     |   |
|---------------------|---|
| Matching impedance  | 4 to 16Ω  |
| Rated input         | 5V (When used in combination with SE-100)                             |
| Maximum input       | 10V (When used in combination with SE-100)                            |
| Output changeover   | Switch system (0dB, 6dB, 12dB and speaker)                            |
| Connecting cord     | 3.2 ft/1m   |
| External dimensions | 4-1/2 (W) x 3-1/8 (H) x 8-9/16 (D) inch<br>114(W) x 80(H) x 217(D) mm |
| Weight              | 3 lb./1360 g  |
| Accessories         | Speaker connecting plug, two each                                     |

### NOTE:

Specifications and the design subject to possible modification without notice due to improvements.

## PARTS LIST

| Key No. | Description                     | Part No.  |
|---------|---------------------------------|-----------|
| 1       | Front Panel                     | M21-671-0 |
| 2       | Wooden Case                     | M32-626-0 |
| 3       | Rotary Switch                   | S15-606-0 |
| 4       | 4-P Socket                      | K72-625-0 |
| 5       | Knob                            | A12-631-0 |
| 6       | Plug                            | K72-642-0 |
| 7       | Transformer                     | STV-001-0 |
| 8       | Resistor (30Ω, 5W)              | C91-628-0 |
| 9       | Rubber Foot                     | E31-615-A |
| 10      | Connection Cord                 | D12-639-0 |
| 11      |                                 |           |
| 12      | Cord Crammer                    | SNB-007-0 |
| 13      | Positive Thermistor             | SCN-002-A |
| 14      | Socket                          | K72-624-0 |
|         | Packing Case                    | H93-640-0 |
|         | Styrol Protector                | H92-608-0 |
|         | Operating Guide (SE100, JB-100) | SRB-009-0 |



