


# STEREO DISPLAY

## SD-1000


ROUND LABEL UNIT	F					
AF OSC UNIT	W18-039					
FM FRONT END						
FM IF UNIT						
MPX UNIT						
V-H AMP UNIT	W18-037					
MUTING UNIT						
METER AMP UNIT	W18-038					
CONTROL AMP UNIT						
MAIN AMP UNIT						
POWER SUPPLY UNIT	W16-037					
SWITCH UNIT	W18-040					
SWITCH UNIT						
SWITCH UNIT						
TONE COLOR UNIT						
CONTROL UNIT						
MIC AMP UNIT						
REVERBE AMP UNIT						
REVERBE UNIT						






AF OSCILLATOR UNIT

AF OSCILLATOR UNIT  
W18-039



V. H. AMP UNIT




V. H. AMP UNIT  
W18-037



# METER AMP UNIT

METER AMP  
ATTENUATOR  
SWEEP TIME  
& MIC AMP  
UNIT

W1B-038



POWER SUPPLY UNIT

W16 - 037

POWER SUPPLY UNIT

