

ELECTRONIC CROSSOVER NETWORK

SF-700

ROUND LABEL UNIT	FV	KC	KL			
FM FRONT END						
FM IF UNIT						
MPX UNIT						
AM TUNER UNIT						
MUTING UNIT						
HEAD AMP UNIT						
CONTROL AMP UNIT						
MAIN AMP UNIT						
POWER SUPPLY UNIT						
SWITCH UNIT						
SWITCH UNIT						
SWITCH UNIT						
TONE COLOR UNIT						
CONTROL UNIT						
MIC AMP UNIT						
FILTER UNIT	W38-002	W38-002	W38-002			
REVERBE UNIT						



SF-700

SWITCHES

S₁ CROSSOVER FREQ. SELECTOR (MID-HIGH)

- 1) OFF
- 2) 1kHz
- 3) 2kHz
- 4) 4kHz
- 5) 8kHz
- 6) 8kHz

S₂ CROSSOVER FREQ. SELECTOR (LOW-MID)

- 1) 13.5kHz
- 2) 250kHz
- 3) 500kHz
- 4) 700kHz
- 5) 1kHz
- 6) OFF

S₃ ~ S₄ SLOPE SELECTOR

- S₃ HIGH S₄ MID HIGH
- S₃ MID-LOW S₄ LOW
- 1) 6dB/oct
- 2) 12dB/oct
- 3) 18dB/oct
- S₁ POWER SWITCH

RESISTORS

NONMARK Ω OHM


K KILLOHM

M MEGOHM

CAPACITORS

NONMARK μF

P P



SF-700 for KC, KL model

SF-700

SWITCHES

- S₁ CROSSOVER FREQ. SELECTOR (MID-HIGH)
 1) OFF
 2) 1kHz
 3) 2kHz
 4) 4kHz
 5) 6kHz
 6) 8kHz
- S₂ CROSSOVER FREQ. SELECTOR (LOW-MID)
 1) 125Hz
 2) 250Hz
 3) 500Hz
 4) 700Hz
 5) 1kHz
 6) OFF

- S₃~S₄ SLOPE SELECTOR
 S₃ HIGH S₄ MID-HIGH
 S₅ MID-LOW S₆ LOW
 1) 6dB/oct
 2) 12dB/oct
 3) 18dB/oct
- S₇ POWER SWITCH

- RESISTORS
 NONMARK: ΩHM
 K: KILOHM
 M: MEGOHM
- CAPACITORS
 NONMARK: μF
 P: pF

