


AM/FM STEREO TUNER TX-700

ROUND LABEL UNIT	FV	FVZ				
FM FRONT END	W11-037	AWB-004				
FM IF UNIT	W31-002	W31-002				
MPX UNIT	AWD-001	AWD-001				
AM TUNER UNIT						
MUTING UNIT						
AF UNIT	W15-071	W15-071				
CONTROL AMP UNIT						
MAIN AMP UNIT						
POWER SUPPLY UNIT						
SWITCH UNIT	W18-018	W18-018				
PRESET UNIT	W18-020	W18-020				
SWITCH UNIT						
TONE COLOR UNIT						
CONTROL UNIT						
MIC AMP UNIT						
REVERBE AMP UNIT						
REVERBE UNIT						




TX-700



ITEM No.	VACANT
R ₁ ~ R ₁₂	
C ₁ ~ C ₁₉	


➔ : DC VOLTAGE
 ⇄ : DC CURRENT

LEFT
 RIGHT TAPE REC
 LEFT
 RIGHT OUTPUT



FM FRONT END


FM FRONT END
W11 - 037



- B₁ : +12V
- B₂ : 2.7V~26V
- AGC : 0V (NORMAL)
- AFC : 0V (NORMAL)
- B₃ : 45~50V

FM FRONT END for FVZ model

FM FRONT END
AWB - 004




- B₁ : +12V
- B₂ : 2.7V~26V
- AGC : 0V (NORMAL)
- AFC : 0V (NORMAL)
- B₃ : 45~50V


TUNER UNIT

TUNER UNIT


W31-002




MPX UNIT



AF UNIT



SWITCH UNIT



PRESET UNIT

