


AM/FM STEREO TUNER TX-900

ROUND LABEL UNIT	FV	KC	KL			
FM FRONT END	W11-033	W11-033	W11-033			
FM IF UNIT	W12-034	W12-034	W12-034			
MPX UNIT	AWD-001	W13-025	W13-025			
AM TUNER UNIT	W14-011	W14-011	W14-011			
MUTING UNIT						
AF UNIT	W15-067	W15-067	W15-067			
CONTROL AMP UNIT						
MAIN AMP UNIT						
POWER SUPPLY UNIT	W16-020	W16-020	W16-020			
SWITCH UNIT	W15-066	W15-066	W15-066			
SWITCH UNIT						
SWITCH UNIT						
TONE COLOR UNIT						
CONTROL UNIT						
MIC AMP UNIT						
REVERBE AMP UNIT						
REVERBE UNIT						
INDICATOR UNIT	W18-010	W18-010	W18-010			





SWITCHES

- S₁ SELECTOR
 - 1) AM
 - 2) FM MONO
 - 3) FM AUTO
- S₂ POWER SWITCH

POTENTIOMETERS

- VR₁ AM CONTROL
- VR₂ FM CONTROL
- VR₃ MUTING CONTROL
- VR₄ SEPARATION CONTROL


RESISTORS


- NON MARK : OHM
- K : KILOHM
- M : MEGOHM

CAPACITORS

- NON MARK : μF
- P : μμF


T52-155







FM FRONT END

FM FRONT END
W11-033




FM IF UNIT


FM IF UNIT
W12-034



MPX UNIT for FV model




MPX UNIT



AM TUNER UNIT

AM TUNER UNIT


W14-011



AF UNIT

AF UNIT


W15-067



POWER SUPPLY UNIT

POWER SUPPLY UNIT


W16-020



DEMI SWITCH UNIT

DEMI SWITCH UNIT

W15 - 066



INDICATOR UNIT

INDICATOR UNIT

W18 - 010

