



- PH5052A  
123456789101112
- TA7061AP  
1234567
- HA1138  
87654321  
910111213141516
- PA1310P  
141312111098  
1234567
- 2SC710  
2SA725  
2SC711  
2SC1312  
2SC738
- 2SC1318
- 2SC1384
- 2SC945  
2SA733
- 2SC1342  
2SC1344
- 2SD313
- 2SK30A
- TA7060P  
12345
- KML6607  
12345678
- 3SK39  
G1  
D
- 3SK45  
S  
D

NOTE  
Fuse (F7\*) is attached only to CSA approved version.

NOTES  
SWITCHES  
S1 FUNCTION (AM position)  
1. AM  
2. FM AUTO  
3. FM MONO  
S2 POWER (OFF position)  
OFF → ON

CAPACITORS  
IN μF UNLESS OTHERWISE NOTED. P=pF.  
RESISTORS  
IN OHM, 1/4 W, ±5% TOLERANCE UNLESS OTHERWISE NOTED. K = KΩ, M = MΩ.

→ A : DC CURRENT AT NO INPUT SIGNAL.  
( V ) : DC VOLTAGE AT NO INPUT SIGNAL.  
V : SIGNAL VOLTAGE AT 100% MOD.

NOTE  
De-emphasis switch of MPX AF AMP ASS'Y is factory-set at:  
75μs for FW model.  
50μs for FVZW model.