



# SCHEMATIC DIAGRAM



- SELECTOR S<sub>i</sub> (α-j)**
- 1. PHONO
  - 2. FM AUTO
  - 3. AM
  - 4. AUX
- S<sub>1a</sub>, S<sub>1b</sub> SPEAKER** 1.OFF 2.A 3.B 4.A+B
- S<sub>2a</sub>, S<sub>2b</sub> TAPE MONITOR (1)** 1.OFF 2.ON
- S<sub>3a</sub>, S<sub>3b</sub> TAPE MONITOR (2)** 1.OFF 2.ON
- S<sub>4</sub> MODE** 1.STEREO 2.MONO
- S<sub>5a</sub>, S<sub>5b</sub> LOUDNESS** 1.ON 2.OFF
- S<sub>6</sub> HIGH FILTER** 1.OFF 2.ON
- S<sub>7</sub> ANTENNA** 1.DISTANCE 2.LOCAL
- S<sub>8</sub> MUTING** 1.OFF 2.ON
- CAPACITOR**
- OIL
  - MYLAR
  - ⊠ TANTALUM
  - ⊠ STYROL
  - ⊠ CERAMIC
  - MICA
- RESISTORS**
- ⊗ ALL RESISTORS 1/4 WATT UNLESS OTHERWISE NOTED
  - ⊗ VOLTAGE AND CURRENT CHECK AT CIRCUIT METER 1V/20KΩ
  - ⊗ ( ) INDICATE ONLY THE STEREO TUNING

