



→ 7 2 3 4 5 6 7 8 9 10 11
UKW ● ● ● ● ● ● ● ● ● ● ● ●
NW ● ● ● ● ● ● ● ● ● ● ● ●
LW ● ● ● ● ● ● ● ● ● ● ● ●
TA ● ● ● ● ● ● ● ● ● ● ● ●

Gezeichnete Schalterstellung: UKW.

Abb. 3. Telefunken-Capriccio 50 UKW mit Pendelaudion bei UKW-Empfang

