


SERVICE MANUAL

STEREO HEADPHONES

HA-FX77-B/S/W-E

The "Product Exchange System" is applicable to this product. For limited spare parts, refer to the parts list.



SPECIFICATION

Туре	Moving coil	
Frequency response	5Hz - 25,000Hz	
Nominal impedance	14 ohms	
Sensitivity	95dB/1mW	
Max.input capability	nput capability 200mW	
Cord length	0.8m (2.6ft) with 3.5mm dia. stereo miniplug	
Mass	4g (0.14oz) without cord 10g (0.35oz) with cord	
Accessory	essory Extension code(0.7m) L type stereo miniplug,Ear piece:3pairs(small,medium,large)	

Design and specifications subject to change without notice.

Parts list

[M][1][M][M]

\triangle	SYMBOL	PARTS NO.	PARTS NAME	Q'TY	DESCRIPTION
	1	J34457-001	Ear Piece(for -B/-S)	1	Color:Black
					Size:S,M,L (The set containes pairs of each size.)
	1	J34458-001	Ear Piece(for -W)	1	Color:White
					Size:S,M,L (The set containes pairs of each size.)
	2	J34646-001	Extension code(for -B/-S)	1	Color:Metallic dark gray
	2	J34646-002	Extension code(for -W)	1	Color:White

^{*} Parts marked (Δ) are safety parts. When replacing, be sure to use the specifide one.

