


Exploded view of general assembly and parts list

Block No.M1MM



Parts List

Block No. [M][1][M][M]

△ Symbol No.	Part No.	Part Name	Description	Local
1	J34278-001	Headband Ass'y	with connecting wire	
2	J34220-001	Elastic Band		
3	J34279-001	Housing(L) Ass'y	with sponge(J/C Model)	J,C
3	J34279-002	Housing(L) Ass'y	with sponge(G Model)	G
4	J34210-001	Housing(R)	(J/C Model)	J,C
4	J34210-002	Housing(R)	(G Model)	G
5	J34211-001	Housing Bottom L		
6	J34212-001	Housing Bottom R		
7	J34213-001	Speaker Holder	Black Color(J/C Model)(x2)	J,C
7	J34213-002	Speaker Holder	Silver Color(G Model)(x2)	G
8	J34280-001	Driver unit	(x2)	
9	J47306-001	Ear pad	(x2)	
10	J47307-001	Bar cushion Front	(x2)	
11	J47402-001	Bar cushion Rear Left		
12	J47402-002	Bar cushion Rear Right		
13	J34218-001	Swihch Stopper		
14	J47308-001	Headband spring	(x2)	
15	J47374-001	Rechargeable Battery	Ni-MH 2.4V	
16	J47403-001	Speaker pad	(x2)	
17	J34216-001	Ball joint	(x2)	
18	QYSPSF2005N	Screw	(x8)	
19	QYSDSF2012N	Screw		
20	QYSPSFT1703M	Screw	(x6)	
21	QYSPSF2008N	Screw	(x3)	
22	QYWSS225003N	WASHER	(x2)	
23	J34217-001	Charge P.C.B Holder		


Electrical parts List

Block No. [0][1]

△ Symbol No.	Part No.	Part Name	Description	Local
△ PW1	J34221-001	Main P.C.B Ass'y	for J/C Model Adjusted	J,C
△ PW2	J34221-002	Main P.C.B Ass'y	for G Model Adjusted	G
△ PW3	J34222-001	Switch P.C.B Ass'y		
△ PW4	J34223-001	Charge P.C.B		
D1	J47400-001	LED	Power Indicator	
VR1	J47401-001	Variable Resistor	Volume control 100 kΩ X 2	
△ S300	J46463-001	Switch	Power Switch,ABU8302S	
△ J301	J47424-001	Battery Terminal	Jack	

Packing materials and accessories parts list / G Model

Block No.M2MM




Packing and accessories

Block No. [M][2][M][M]

△ Symbol No.	Part No.	Part Name	Description	Local
1	J22180-001	Packing case		
2	J22181-001	Packing Holder		
△ 3	QPC02504515P	Poly Bag	for transmitter	
4	QPA01506005	Poly Bag	for receiver(headphones)	
5	QPA00503005	Poly Bag	for connection cord	
6	QPA01202005	Poly Bag	for AC Adaptor	
△ 7	QPA01702505P	Poly Bag	for Instructions	
8	LNT0018-001A	Instructions		
9	BT-54008-4	GUARANTY CARD		
△ 10	J47311-001	AC Adaptor		
11	J47404-001	Connection cord		
12	J47405-001	Plug adaptor		
△ 13	J22176-002	Transmitter Unit	for G Model	

Packing materials and accessories parts list / J/C Model

Block No.M3MM



Note:

These parts which was marked *(Blister cover/Blister tray/Blister bottom/Front sheet/Inner sheet/sheet/AC Adaptor box/PE bag)

will not be able to supply as our service parts.

Because the blister cover and the blister bottom together of this package are adhesive by welder.

Packing and accessories

Block No. [M][3][M][M]

△ Symbol No.	Part No.	Part Name	Description	Local
1	LNT0017-001A	Instructions		
2	BT-51007-6	Warranty card	for (J) model	
2	BT-52006-2	Warranty card	for (C) model	
△ 3	J47310-001AC	AC Adaptor		
4	J47404-001	Connection cord		
5	J47405-001	Plug adaptor		
△ 6	J22176-001	Transmitter Unit	for J/C Model	