


# Service Manual

PMD505 /U1B

Cassette Deck



DOLBY B-S NR HX PRO

## REMARK :

This service manual shows only the differences between the model PMD505/U1B and the model SD4050/U1B.

The most significant change from SD4050/U1B to PMD505/U1B is the exterior parts.

All other information is described in the service manual of the model SD4050 (Code number 286W855010).

The dispatch of the parts for after sales service has to be referred to these service manuals, with the first priority.

For this reason, please use this service manual with referring to the model SD4050 service manual without fail.

The change parts are the following. Other parts are the same.

## PARTS LIST

POS. NO.	VERS. COLOR	PART NO. (FOR EUR)	DESCRIPTION	PART NO. (MJI)
25	/U1B		PANEL FRONT PMD505	286W248080
	/U1B		PANEL REAR PMD505/U1B	nsp
	/U1B		<b>PACKING</b>	
	/U1B		USER GUIDE PMD505	286W851280
	/U1B		<b>NOT STANDARD SPEAR PARTS</b>	
	/U1B		CARTON BOX INNER PMD505	286W801030

NOTE : "nsp" PART IS LISTED FOR REFERENCE ONLY, MARANTZ WILL NOT SUPPLY THESE PARTS.

Please use this service manual with referring to the user guide ( D.F.U. ) without fail.

修理の際は、必ず取扱説明書を準備し操作方法を確認の上作業を行ってください。

# marantz®