



MINI SWITCH UNIT

AWS-025




DECODER UNIT

AWM-031




LOGIC UNIT

AWM-032




BALANCE VOLUME UNIT

AWX-035




LEVEL CONTROL UNIT


AWX-034




TONE CONTROL UNIT

AWG-014







AWG - 013




MIC AMP UNIT W21 - 003





AWM - 036




MAIN AMP UNIT AWH - 015





QX-9900



SWITCHES

S₁ - INPUT SELECTOR

1. AM
2. FM MONO
3. FM AUTO
4. PHONO 1
5. PHONO 2
6. AUX 1
7. AUX 2

S₂ - MODE SELECTOR

1. 2CH. STEREO
2. 4CH. MATRIX REGULAR
3. 4CH. MATRIX SQ
4. 4CH. DISCRETE

S₃ - REVERBERATION MODE

1. FRONT
 2. REAR
 3. OFF
 4. MIC
- S₄ - PRE & MAIN SWITCH
1. INTERCOUPLED
 2. SEPARATED

S₅ - POWER SWITCH

1. OFF-ON
2. RELAY

POTENTIOMETERS

- VR₁ - MIC. VOLUME
VR₂ - MIC. VOLUME
VR₃ - REVERBERATION VOLUME

NOTES

- RESISTORS
IN Ω
K = KΩ
CAPACITORS
IN μF
P = pF

