

NOTICE


OVERHANG GAUGE

This unique accessory is designed not only the adjustment of the overhang gauge but also the head shell stand.

- Insert the head shell to the hole of the gauge.
- Move the cartridge forward or backward turning the overhang screw, and adjust the stylus position to the top surface of the gauge as shown in the picture.

NOTE

This gauge is exclusively designed for Technics direct drive player systems which have tonearm, so that model SL-110 and SL-120 do not include this gauge.



STROBO DOTS

There is a change in the incoming frequency used for a strobo neon lamp or a fluorescent lamp, the strobo dots may then begin to move, although very slightly. Though commercial electric is widely thought to be very stable, without frequency fluctuation, if precisely measured over a period of time, there will be observed slight changes which amount to an average of 0.2%, which causes strobo dots to move.

This, of course, will never spoil sound reproduction in the least as the turntable revolution is still stable.