


Service Manual

THE FISHER®



440-T

CHASSIS SERIAL NUMBERS
BEGINNING 20001

PRICE \$1.00

FISHER RADIO CORPORATION • LONG ISLAND CITY 1 • NEW YORK

CAUTION: This is a FISHER precision high-fidelity instrument. It should be serviced only by qualified personnel — trained in the repair of transistor equipment and printed circuitry.

EQUIPMENT AND TOOLS NEEDED

The following are needed to completely test and align modern high-fidelity instruments such as amplifiers, tuners and receivers.

Test Instruments

Vacuum-Tube Volt-ohmmeter DC VTVM
Audio (AC) Vacuum-Tube Voltmeter (AC VTVM)
Oscilloscope (Flat to 100 kc minimum)
Audio (Sine-wave) Generator
Intermodulation Analyzer
Sweep (FM) Generator (88 to 108 mc)
Marker Generator
Multiplex Generator (preferably with RF output — FISHER Model 300 or equal).

Miscellaneous

Adjustable-Line-Voltage Transformer or line-voltage regulator
Load Resistors (2) — 8-ohm, 50-watt (or higher)
Stereo source (Turntable with stereo cartridge or Tape Deck)
Speakers (2) Full-range, for listening tests
Soldering iron (with small-diameter tip). Fully insulated from power line.

PRECAUTIONS

Many of the items below are included just as a reminder—they are normal procedures for experienced technicians. Shortcuts can be taken but often they cause additional damage—to transistors, circuit components or the printed-circuit board.

Soldering—A well-tinned, hot, clean soldering iron tip will make it easier to solder without damage to the printed-circuit board or the many many circuit components mounted on it. It is not the wattage of the iron that counts—it is the heat available at the tip. Low-wattage soldering irons will often take too long to heat a connection—pigtail leads will get too hot and damage the part. Too much heat, applied too long, will damage the printed-circuit board. Some 50-watt irons reach temperatures of 1,000° F—others will hardly melt solder. Small-diameter tips should be used for single solder connections—larger pyramid and chisel tips are needed for larger areas.

- When removing defective resistors, capacitors, etc., the leads should be cut as close to the body of the circuit component as possible. (If the part is not being returned for in-warranty factory replacement it may be cut in half—with diagonal-cutting pliers—to make removal easier.)
- Special de-soldering triplets are made for unsoldering multiple-terminal units like IF transformers and electrolytic capacitors. By unsoldering all terminals at the same time the part can be removed with little chance of breaking the printed-circuit board.
- Always disconnect the chassis from the power line when soldering. Turning the power switch OFF is not enough. Power-line leakage paths, through the heating element, can destroy transistors.

Transistors—Never attempt to do any work on the transistor amplifiers without first disconnecting the AC-power linecord—wait until the power supply filter-capacitors have discharged.

- Guard against shorts—it takes only an instant for a base-to-collector short to destroy that transistor and possibly others direct-coupled to it. [In the time it takes for a dropped machine screw, washer or even the screwdriver, to glance off a pair of socket terminals (or between a terminal and the chassis) a transistor can be ruined.]
- DO NOT bias the base of any transistor to, or near, the same voltage applied to its collector.
- DO NOT use an ohmmeter for testing transistors. The voltage applied through the test probes may be higher than the base-emitter breakdown voltage of the transistor.

Output Stage and Driver—Replacements for output and driver transistors, if necessary, must be made from the same beta group as the original type. The beta group is indicated by a colored dot on the mounting flange of the transistor. Be sure to include this information, when ordering replacement transistors.

- If one output transistor burns out (open or shorts), always remove all output transistors in that channel and check the bias adjustment, the control and other parts in the network with an ohmmeter before inserting a new transistor. All output transistors in one channel will be destroyed if the base-biasing circuit is open on the emitter end.

- When mounting a replacement power transistor be sure the bottom of the flange, the mica insulator and the surface of the heat sink are free of foreign matter. Dust and grit can prevent perfect contact. This reduces heat transfer to the heat sink. Metallic particles can puncture the insulator and cause shorts—ruining the transistor.


- Silicone grease must be used between the transistor and the mica insulator and between the mica and the heat sink for best heat conduction. Heat is the greatest enemy of electronic equipment. It can shorten the life of transistors, capacitors and resistors. (Use Dow-Corning DC-3 or C20194 or equivalent compounds made for power transistor heat conduction.)

- Use care when making connections to speakers and output terminals. Any frayed wire ends can cause shorts that may burn out the output transistors—they are direct-coupled to the speakers. There is no output transformer—nothing to limit current through the transistors except the fuses. To reduce the possibility of shorts at the speakers, lugs should be used on the exposed ends—at least the ends of the stranded wires should be tinned to prevent frayed wire ends. The current in the speakers and output circuitry is quite high. Any poor contact or small-size wire, can cause power losses in the speaker system. Use 14 or 16 AWG for long runs of speaker-connecting wiring.

DC-Voltage Measurements—These basic tests of the transistor circuitry are made without the signal generator. Without any signal input measure the circuit voltages—as indicated on the schematic. The voltage difference between the base and the emitter should be in the millivolt range—a sensitive DC meter is needed for these readings. A low-voltage range of 1 volt, full scale—or lower—is needed.

Audio-Voltage (gain) Measurements—The schematic and printed-circuit board layout diagrams are used. Input signals are injected at the proper points—found most quickly by using layout of the printed-circuit board instead of the schematic. An AUDIO (AC) VTVM connected to the test points should indicate voltages close to those values shown in the boxes on the schematic. Many of the signal levels in the input stages are only a few millivolts—they can not be read on the AC ranges supplied on most Vacuum-Tube AC/DC Volt-ohmmeters (VTVMs). Even with a 1-volt range a signal level of 100 millivolts (.1 volt) will be the first 1/10 of the meter scale. A reading of 1 millivolt (.001 volt) will hardly even move the meter needle.

DIAL STRINGING PROCEDURE




DIAL STRINGING

- Turn tension-relief screw to its maximum clockwise position. With the screw set to its maximum-IN position the dial cord may be pulled as tightly as possible (just before securing the loose end) without stretching the tension spring. *This is not an adjustment screw.* It is used only for easier dial-cord stringing.
- Rotate the tuning-capacitor drive-drum to its maximum clockwise position.
- Attach the dial cord to the ear inside the tuning-capacitor drive-drum as shown in detail drawing (lower right).
- Run dial cord through slot in rim of the tuning-capacitor drive drum.
- Set dial cord in INNER groove and guide it around the lower pulley, flywheel shaft and over guide pulleys.
- Position dial cord on other pulleys and over the top of the tuning-capacitor drive-drum.
- Pull dial cord taut and wrap two complete turns around the OUTER groove of the tuning-capacitor drive-drum.
- Run dial cord through slot in the rim of the drive drum.
- Wrap the end of the dial cord around the body of the machine screw in the hub of the drive drum and tighten. The dial cord goes under the flat washer.

CAUTION – When securing the end of the dial cord the adjusting screw must be in contact with the screw stop.

- Back out the tension-relief screw (turn it counter clockwise) to let the spring hold the dial cord under proper tension. The tension relief screw must clear the screw stop to allow free movement of the pulleys while providing non-slip drive.



DIAL STRINGING ADJUSTMENTS

- When the dial cord slips, where it is wrapped around the flywheel drive shaft, move the tension spring to a higher locating hole.
- If the flywheel does not rotate freely and smoothly, move the spring to a lower locating hole to reduce tension.

NOTE: Nylon pulleys generally do not need lubrication. If roughness or noise occurs during tuning, silicone or other high-temperature lubricant may be applied to the moving parts. Accumulations of dust should be removed before any lubricant is applied. Often cleaning will eliminate the need for lubrication.

MAIN CHASSIS PARTS DESCRIPTION LIST

CAPACITORS

Symbol	Description	Part No.	R57, 58	R59, 60	R61, 62	R63, 64	R65, 66	R67, 68	R69, 70	R71, 72	R73, 74,	R75, 76	R77, 78,	R79, 80	R81, 82,	R83, 84	R85, 86	R87, 88	R89, 90	R50DC272J	R12DC105J	-- --	R50DC390J	R50160-142-2	R50DC102J	R50DC122J	R50DC560J	R50DC470J	R50DC151J	RL300WR50J	RC20BF330K	R50DC152J	RW200W331J				
C1, 2	Ceramic, 47pF, 10%, N750, 1000V	C50070-4	2.7K, 1/2W	1M	-Deleted-	39, 1/2W	Pot., 100, 20%, 2W Bal. Adj.	1K, 1/2W	1.2K, 1/2W	56, 1/2W	47, 1/2W		150, 1/2W			Wirewound, 0.5, 5%, 3W	Composition, 33, 10%, 1/2W	1.5K, 1/2W	Wirewound, 330, 5%, 2W																		
C3	Ceramic, 2700pF, 20%, 1000V	C50071-5																																			
C4	Electrolytic, 10uF, 35V	C50483-2																																			
C5, 6	Ceramic, .02uF, +80 -20%, 100V	C50095-1																																			
C7	Mylar, .22uF, 20%, 250V	C50B575-3																																			
C8	Mylar, .22uF, 10%, 250V	C50B575-2																																			
C9	Molded, .01uF, 20%, 600V	C2747																																			
C10, 11	Electrolytic, 100uF, 25V	C50483-6																																			
C12	Electrolytic, 1000uF, 50V	C50180-80																																			
C13	Electrolytic, 1000uF, 50V	C50180-82																																			
C14, 15	Electrolytic, 200uF, 35V	C50483-7																																			
C16	Electrolytic, 50uF, 50V	C50283-13																																			
C17, 18	Mylar, .22uF, 10%, 250V	C50B575-2																																			
C19, 20	Electrolytic, 500uF, 10V	C50483-9																																			
C21, 22	Ceramic, 56pF, 5%, N1500, 1000V	C50070-38																																			
C23, 24	Electrolytic, 50uF, 10V	C50483-15																																			
C25, 26	Mylar, .33uF, 10%, 250V	C50B575-4																																			
C27, 28	Ceramic, 3300pF, 10%, 1000V	C50072-11																																			
C29, 30	Electrolytic, 1500uF, 50V	C50180-84																																			

RESISTORS AND POTENTIOMETERS

Deposited Carbon in ohms, 5% tolerance, 1/8 Watt
unless otherwise noted. K - Kilohms, M - Megohms

Symbol	Description	Part No.
R1, 2	Composition, 68K, 10%, 1/2W	RC20BF683K
R3, 4	Composition, 120K, 10%, 1/2W	RC20BF124K
R5, 6	Composition, 220K, 10%, 1/2W	RC20BF224K
R7, 8	220K	R12DC224J
R9, 10	4.7K	R12DC472J
R11	Composition, 270, 10%, 1/2W	RC20BF271K
R12	10K	R12DC103J
R13	680	R12DC681J
R14	Pot., 1K, 30%, Separation Cont.	R50150-51
R15	100K	R12DC104J
R16	15K	RC20BF153K
R17	† 120, 1/2W	R50DC121J
R18	1.8K	R12DC182J
R19	100	R12DC101J
R20, 21	68K	R12DC683J
R22, 23	18K	R12DC183J
R24, 25	-Deleted-	- - -
R26	-Deleted-	- - -
R27	2.2K	RC20BF153K
R28	220K	R12DC224J
R29	Composition, 100K, 10%, 1/2W	RC20BF104K
R30	Composition, 6.8K, 10%, 1/2W	RC20BF682K
R31	Composition, 18K, 10%, 1/2W	RC20BF183K
R32	Pot., 1K, 30%, Meter Adj.	R50150-51
R33	Pot., 5K, 30%, Muting Adj.	R50150-11
R34	Composition, 270, 10%, 1/2W	RC20BF271K
R35A, B	Pot., Dual, 50K, Volume Cont.	R50160-151FX
R36	Composition, 820K, 10%, 1/2W	RC20BF824K
R37	Wirewound, 220, 5%, 2W	RW200W221J
R38	Wirewound, 330, 5%, 3W	RL300W331J
R39	Wirewound, 39, 5%, 2W	RW200W390J
R40	Wirewound, 220, 5%, 2W	RW200W221J
R41	Composition, 1.2K, 10%, 1/2W	RC20BF122K
R42	Composition, 2.2K, 10%, 1/2W	RC20BF222K
R43	Composition, 220, 10%, 1/2W	RC20BF221K
R44	-Deleted-	- - -
R45, 46	5.6W, 1/2W	R50DC562J
R47, 48	56K, 1/2W	R50DC563J
R49, 50	82, 1/2W	R50DC820J
R51, 52	10K, 1/2W	R50DC103J
R53, 54	180K, 1/2W	R50DC184J
R55, 56	56, 1/2W	R50DC560J


MISCELLANEOUS

Symbol	Description	Part No.
CR1	Rectifier, Silicon Bridge	S1B50B794-1
CR2	Diode, Zener Regulator	ZR50B793-1
CR3	Diode, Zener Regulator	ZR50B793-3
CR4, 5	Stabistor Module, Dual Silicon	SIT50B843-1
F1	Fuse, Line 1.5A Slo-Blo	F684-143
F2	Fuse, 4A	F3319-4
I1, 2	Lamp, Dial	I50441-1
I3	Lamp, Meter	I50009-8
I4	Lamp, Stereo Beacon	part of AS946B237
M1	Meter, Tuning	M946B213
PC1, 2	Printed Circuit, Equalization	PC50B187-29
*Q1, 2, 3, 4	Transistor, 36642	TR36642
*Q5, 6, 7, 8	Transistor, 36643	TR36643
Q9, 10	Transistor, 2N3638A	TR2N3638A-2
Q11, 12, 13	Transistor, 2N2924	TR2N2924
R14, 15	Transistor, 2N2925	TR2N2925
Q16	Transistor, 40245	TR40245
S1	Switch, Selector	S1340C121
S2	Switch, Mode, Tape Monitor	S1340C160
S3, 4, 5, 6	Switch, Rocker	S50C200-15-1
S7	Switch, Power (part of R35)	R50160-151FX
T1	Transformer, Power	T1340C115
T2	Transformer, Driver, Right	T1340C169-1
T3	Transformer, Driver, Left	T1340C169-2
- - -	Front End, FM	FE50D797
- - -	Printed-circuit Board, MPX	P1242-1
- - -	Printed-circuit Board, Tone Control	P1278
- - -	Printed-circuit Board, Preamplifier	P1285
- - -	Printed-circuit Board, IF Amplifier	P1381
- - -	Antenna FM Dipole	AS50227-1
- - -	Dress Panel Assembly	AS1340A149
- - -	Dial Glass, Screened	N1340B107
- - -	Knob, Volume, Balance	
- - -	Mode/Tape Monitor, Selector	E50B562-1
- - -	Knob, Dual, Top, Bass, Treble	E50B563
- - -	Knob, Dual, Bottom, Bass, Treble	E50B564
- - -	Knob, Tuning	E50B566-2
- - -	Terminal Strip, Speaker	E50A803
- - -	Screw, Heat Sink Cover	H50A598-10CX
- - -	Screw, Top Cover	H50A598-7CX
- - -	Screw, Bottom Cover	H325S141AA
- - -	Screw, Bottom Cover	H181S314AA
- - -	Jack, Phone	J50B545
- - -	Insulator, Transistor, (Q1-Q4)	E50510
- - -	Socket, Transistor, (Q1-Q4)	X50509
- - -	Socket, Transistor (Q5-Q10)	X50A841-2
- - -	Heat Sink, Transistor (Q5-Q8)	A50B842-3

* Output Stage and Driver—Replacements for output and driver transistors, if necessary, must be made from the same beta group as the original type. The beta group is indicated by a colored dot on the mounting flange of the transistor. Be sure to include this information, when ordering replacement transistors.

† In units with serial numbers ending with X the value of R17 should be 1K, 1/2W (FISHER Part No. R50DC102J).


FM FRONT END



PARTS DESCRIPTION LIST

Symbol	Description	Part No.
C760, 774	Ceramic, .1uF +80-20%, 12V	C50331-6
R751	Dep. Carbon, 220, 5%, 1/8W	R12DC221J
R753	Dep. Carbon, 100K, 5%, 1/8W	R12DC104J
R754	Dep. Carbon, 2.7K, 5%, 1/8W	R12DC272J
R755	Dep. Carbon, 8.2K, 5%, 1/8W	R12DC822J
R756	Dep. Carbon, 15K, 5%, 1/8W	R12DC153J
R757	Dep. Carbon, 2.2K, 5%, 1/8W	R12DC222J
R758	Dep. Carbon, 680, 5%, 1/8W	R12DC681J
R759	Dep. Carbon, 27, 5%, 1/8W	R12DC270J

With the exception of the above electronic components and normal realignment procedures, front-end service is not recommended. Should any defect occur that can not be remedied by realignment or by replacing one of the above electronic components the unit should be returned to the manufacturer.



FRONT-END ALIGNMENT

- Set dial pointer to zero (0) calibration mark on logging scale. If dial pointer does not coincide with the 0 without forcing the TUNING knob reposition pointer assembly on the dial cord and cement pointer in place.
- Connect DC VTVM to TP301 on the IF board.
- Connect RF generator (with two 120-ohm composition resistors in series with the leads—Figure 1) to the LOC antenna terminals. DO NOT use modulation (AM or FM).
- Set generator frequency and tuning dial to 90 mc. Adjust the oscillator-coil core first—then adjust the RF and Antenna-coil cores for maximum VTVM reading.
- Set generator frequency and tuning dial to 106 mc. First adjust oscillator trimmer and then the RF and Antenna-coil trimmers for maximum VTVM reading.
- Repeat steps above several times until dial calibration is accurate when VTVM reading is maximum. Keep the output of the generator as low as possible during all adjustments.






Figure 1. Generator connections to antenna terminals.

1285 PREAMPLIFIER



PARTS DESCRIPTION LIST

CAPACITORS		
Symbol	Description	Part No.
C101, 102	Mylar, .33uF, 10%, 250V	C50B638-10
C103, 104	Electrolytic, 4uF, 35V	C50B637-1
C105, 106	Mylar, .33uF, 10%, 250V	C50B638-10
C107, 108	Electrolytic, 160uF, 6V	C50B637-3

RESISTORS		
Symbol	Description	Part No.
R101, 102	Dep. Carbon, 1M	R12DC105J

R103, 104	Composition, 2.7K, 10%, 1/2W	RC20BF272K
R105, 106	Dep. Carbon, 150K	R12DC154J
R107, 108	Dep. Carbon, 470	R12DC471J
R109, 110	Dep. Carbon, 820K	R12DC824J


MISCELLANEOUS		
Symbol	Description	Part No.
-	Printed Circuit Board	P1285
-	Printed Circuit	PC50B187-28
-	Socket, Transistor	X50B779-2
Q101, 102	Transistor, SE4010	TR4010-2
Q103, 104	Transistor, 2N2924	TR2924-18

OUTPUT-STAGE INTERMODULATION TEST

- Connect an 8-ohm, 50-watt resistor across the LEFT SPKRS terminals.
- In parallel to the load resistor connect the input leads of an IM (Inter-Modulation) distortion analyzer.
- Connect the IM-analyzer generator output to the left MON IN jack.
- Apply AC power and rotate VOLUME control to its maximum clockwise position—full volume.
- Increase signal input (from IM-analyzer generator) for 20-watts output (12.5 VAC across 8-ohm load resistor). AFTER ONE FULL MINUTE OF WARM-UP TIME PROCEED TO NEXT STEP. (The warm-up time is very important (to get proper adjustment) — the characteristics of the transistors change slightly as their internal temperature rises. Once they are warm the tests and adjustments should be completed without delay — before they can cool off.

- Reduce IM-analyzer generator output for 5 watts output from the amplifier (5.16 VAC across 8-ohm load resistor).
 - Adjust LEFT channel BIAS ADJUST control for minimum IM distortion (less than 0.8%) across the 8-ohm load resistor.
 - Increase IM-analyzer generator output for 35 watts—about 16 VAC across the 8-ohm load resistor. REPEAT all the steps above for RIGHT channel BIAS ADJUST.
- NOTE—If any of the above instructions differ from those in the IM analyzer instruction manual it is best to follow those in the IM manual. If a load resistor of 50-watts rating is built into the IM analyzer, a separate load resistor is not required for the channel under test—one should be wired across the other channel as a precaution. For best results the IM-analyzer range switch should be set to a range that gives a reading in the center to full-scale portion of the meter scale to get the greatest accuracy.

1381 IF AMPLIFIER



* CAPACITORS LABELLED Cn CONSIST OF TWO PARALLEL STRIPS ON THE PRINTED CIRCUIT BOARD.

PARTS DESCRIPTION LIST

CAPACITORS			
Symbol	Description	Part No.	
C301	Ceramic, 330pF, 10%, 1000V	C50B569-1	R306 6.8K
C302	Ceramic, 5000pF, 20%, 500V	C50B567-2	R307 3.3K
C303	Ceramic, 1000pF, 10%, 1000V	C50B569-3	R308 22
C304	Ceramic, .01uF, +80-20%, 500V	C50B570-1	R309 6.8K
C305	Ceramic, 5000pF, 20%, 500V	C50B567-2	R310 15K
C306	Ceramic, 1000pF, 20%, 1000V	C50B569-4	R311 47K
C307	Ceramic, 5000pF, 20%, 500V	C50B567-2	R312 8.2K
C308	Ceramic, .02uF, +80-20%, 100V	C50B570-2	R313 6.8K
C309	Electrolytic, 4uF, 35V	C50483-1	R314 3.3K
C310	Ceramic, 100pF, 10%, N1500, 1000V	C50B568-3	R315 1.5K
C311	Ceramic, .01uF, +80-20%, 500V	C50B570-1	R316 220
C312	Ceramic, 5000pF, 20%, 500V	C50B567-2	R317 1K
C313	Ceramic, 3pF, 10%, NPO, 1000V	C50070-28	R318 12K
C314	Ceramic, 5000pF, 20%, 500V	C50B567-2	R319 6.8K
C315	Ceramic, .01uF +80-20%, 500V	C50B570-1	R320 4.7K
C316, 317	Ceramic, 330pF, 10%, 1000V	C50B569-1	R321 1.5K
C318	Electrolytic, 10uF, 35V	C50483-2	R322 100
C319	Ceramic, .02uF, +80-20%, 500V	C50095-1	R323, 324 1K
C320	Ceramic, .01uF, +80-20%, 500V	C50B570-1	R325, 326 6.8K
			R327 22K

RESISTORS			MISCELLANEOUS		
Symbol	Description	Part No.	Symbol	Description	Part No.
R301	6.8K	R12DC682J	CR301, 302	Diode, AA112	V50260-16
R302	3.3K	R12DC332J	Z301, 302	Transformer, I. F.	ZZ50C210-71
R303	22	R12DC220	Z303	Coil, Limiter	ZZ50C210-70
R304	3.3K	R12DC332J	Z304	Transformer, Ratio Detector	ZZ50C210-68
R305	12K	R12DC123J	Q301, 302, 303, 304	Transistor 2N2654	TR2N2654
				Transistor Mtg. Pads	A50618
				Printed Circuit Board	P1381




FIGURE 1.






FIGURE 2.

FIGURE 3.

FIGURE 4.

Generator connections to antenna terminals

1381 IF AMPLIFIER



IF ALIGNMENT

- Connect 10.7-mc generator output lead to the collector of Q302. DO NOT use modulation (AM or FM).
- Connect DC VTVM across C318 (ratio-detector filter). Use 100K resistor in series with each lead—DO NOT ground VTVM.
- Adjust Z303 (bottom core) and Z304 (top and bottom cores) for maximum DC VTVM reading. Readjust generator output, during alignment, to keep DC VTVM reading between 4 and 5.5 volts.
- Connect DC VTVM and scope leads (through 100 K resistors) to TP301. Disconnect jumper between 3F and 3G on printed-circuit board.
- Connect sweep generator to point 3B of IF amplifier board. Adjust top and bottom cores of Z301 and Z302,

and bottom core of Z303 for maximum gain and a symmetrical response curve (Figure 1) on scope. Adjust generator output during alignment to keep DC VTVM reading between -0.5 and -2.0 volts.

- Connect sweep generator output lead to TP751 (front end). Adjust top and bottom cores of Z751 for maximum gain and a symmetrical response curve on the scope. Generator output must be adjusted during alignment to keep DC VTVM reading between -0.5 and -1.5 volts. The IF response curve should now be like that in Figure 2.
- Unsolder C7 (at terminal strip near socket of Q15).
- Connect scope vertical input to point 3N on the printed-circuit board and adjust the top core of Z303 for maximum gain and a response curve like that in Figure 3.
- Resolder C7.
- Reconnect jumper between 3F and 3G.

- Connect scope vertical input to the left or right REC OUT jack. Ratio-detector response curve should be like that in Figure 4.

TUNING METER CALIBRATION


- Connect RF-generator output leads to the LOC antenna terminals through two 120-ohm composition resistors—one connected in series with each lead.
- Set generator output to 100 mV, ± 22.5 kc deviation at 400 cps.
- Adjust tuning meter calibration control (R29) for a meter reading of 4.5.

MUTING ADJUSTMENT

- Connect FM-generator output leads to LOC antenna terminals through two 120-ohm composition resistors—one connected in series with each lead.
- Set generator frequency and tuner dial to 98 mc. Modulate generator with 400 cps, ± 25 kc deviation.
- Set FM-generator output-attenuator for 16 μ V and make a note of the signal amplitude (AC VTVM reading) at the right or left REC OUT jack—MUTING off.
- With MUTING on, adjust muting level control for a reading of 1 to 5 db lower than that previously noted.
- Reduce FM-generator output to zero—no signal (400 cycle modulation) or noise should be present at the REC OUT jacks.
- Increase FM-generator output to 20 μ V. This should now be approximately the same as the reading obtained on the AC VTVM, with muting off.

INS312

1242 MULTIPLEX DECODER



PARTS DESCRIPTION LIST


CAPACITORS		
Symbol	Description	Part No.
C401	Ceramic, 330pF, 10%, 1000V	C50B569-1
C402	Mica, Silver, 4700pF, 5%, 100V	C50B571-2
C403	Ceramic, 18pF, 5%, 1000V, P100	C50B568-15
C404	Polystyrene, 220pF, 5%, 33V	C50B636-3
C405	Polystyrene, 120pF, 5%, 33V	C50B636-8
C406	Mylar, .1uF, 10%, 250V	C50B638-7
C407	Mylar, .022uF, 10%, 250V	C50B638-3
C408	Electrolytic, 4uF, 35V	C50B637-1
C409	Mylar, .1uF, 10%, 250V	C50B638-7
C410	Mylar, .015uF, 10%, 250V	C50B638-2
C411	Electrolytic, 1uF, 70V	C50B637-2
C412, 413	Polystyrene, 1000pF, 5%, 33V	C50B636-9
C414, 415	Polystyrene, 1500pF, 5%, 33V	C50B636-24
*C416	Mylar, .1uF, 20%, 250V	C50B575

RESISTORS AND POTENTIOMETERS		
In ohms, 5% tolerance, 1/8 watt unless otherwise noted. K = Kilohms, M = Megohms.		
Symbol	Description	Part No.
R401	Potentiometer, Trigger Control 100K, 30%	R50150-65

R402	Dep. Carbon, 39K
R403	Dep. Carbon, 22K
R404	Dep. Carbon, 15K
R405	Composition, 1K, 10%, 1/2W
R406, 407	Dep. Carbon, 15K
R408, 409	Dep. Carbon, 10K
*R410	Dep. Carbon, 560

MISCELLANEOUS		
Symbol	Description	Part No.
-	Printed Circuit Board	P1242
-	Printed Circuit	PC50B187-27
-	Socket, Transistor	X50B779-2
-	Ring Demodulator	V50260-23B
L401, 402, 403	Choke, Coil, 20mh	L50334-6
Q401, 404	Transistor, 2N2924	TR2N2924-18
Q402, 403	Transistor, 2N2614	TR2N2614
Z401	Transformer, 19kc	ZZ50B210-80
Z402	Transformer, 19kc	ZZ50B210-76
Z403	Transformer, 19kc	ZZ50B210-74
Z404	Transformer, 38kc	ZZ50B210-75

R12DC393J
R12DC223J
R12DC153J
RC20BF102K
R12DC153J
R12DC103J
R12DC561J



1242 MULTIPLEX DECODER

MULTIPLEX DECODER TESTS

- Modulate FM generator with 19 kc, ± 6.5 kc deviation. (Use external modulation if necessary.)
- Connect the FM generator output to the antenna terminals of the unit under test.
- With the FM generator set for an output of 25 μ V at the antenna terminals the stereo indicator should light up. If the generator output is reduced to 5 μ V, at the antenna terminals, the indicator light should remain ON.
- Reduce FM generator output to zero and the indicator light should go OFF.
- If the stereo indicator light does not respond properly to the tests above, readjust the trigger control (R401) until the stereo indicator lamp just turns ON with a 4 μ V signal applied to the antenna terminals.

PREFERRED ALIGNMENT INSTRUCTIONS

(Using multiplex generator with RF and 19 kc outputs and with 1 kc modulation)

In Table 1, below, a multiplex generator with an RF output is used. This is the better method of alignment since the multiplex circuitry is connected to the tuner with which it will be used. Check the alignment of the IF stages before making multiplex adjustments. Poor IF alignment can make proper multiplex operation impossible.

TEST EQUIPMENT: Multiplex Generator, Audio (AC) Vacuum-Tube Voltmeter (RMS type preferred), Vacuum-Tube Voltmeter (DC VTVM), Oscilloscope (100 kc minimum) with external sweep input.

WARNING: Use only the proper alignment tool to prevent core breakage.





FIGURE 1. Multiplex-alignment pass filter circuit.

ALTERNATE ALIGNMENT INSTRUCTIONS

(For multiplex generators without an RF output)

Disconnect the ratio detector from the multiplex unit before using this procedure. A low-pass filter (Figure 1) is used between the MPX generator output and the input to the multiplex circuitry. It has about the same loading effect as the output of the ratio detector in the tuner.

TABLE 1

MULTIPLEX-GENERATOR RF OUTPUT CONNECTED TO ANTENNA TERMINALS


STEP	GENERATOR MODULATION	RF DEV.	INDICATOR TYPE AND CONNECTION	ALIGNMENT	
				ADJUST	INDICATION
1	70 to 76 kc (connect external audio generator to SCA input of multiplex generator.)	± 25 kc	Audio (AC) VTVM input to TP404 with 10-pF capacitor in series with test lead.	---	Read minimum AC voltage between 70 and 76 kc.
2	19 kc pilot only	± 6.5	AC VTVM to TP403	Z401, 402, 403 and 404	Maximum AC voltage (38 kc)
3	Composite MPX signal 1 kc on left channel only	± 75 kc	Audio (AC) VTVM and oscilloscope vertical input to left channel output lug (4H)	Z402	Maximum AC voltage with clean 1 kc sine wave on oscilloscope
4	Composite MPX signal 1 kc on right channel only	± 75 kc	Same as Step 3	MPX Separation Control (located on chassis).	Minimum reading on Audio (AC) VTVM—should be at least 35db below reading obtained in Step 3.
5	Same as Step 4	± 75 kc	Audio (AC) VTVM and oscilloscope vertical input to right channel output lug (4K)	---	Same Audio (AC) VTVM reading as obtained in Step 3 (± 2 db); clean 1kc sine wave on scope.
6	Same as Step 4	± 75 kc	Same as Step 5		Minimum reading on Audio (AC) VTVM should be at least 35db below reading in Step 5.

TABLE 2


COMPOSITE OUTPUT OF MULTIPLEX GENERATOR CONNECTED TO INPUT OF MPX DECODER THROUGH LOW-PASS FILTER

STEP	GENERATOR MODULATION	LEVEL (RMS)	INDICATOR TYPE AND CONNECTION	ALIGNMENT	
				ADJUST	INDICATION
1	70 to 76 kc.	100mV	Audio (AC) VTVM input to TP404 with 10-pF capacitor in series with test lead.	---	Read minimum AC voltage between 70 and 76 kc.
2	19 kc pilot only	50mV	AC VTVM to TP403	Z401, 402, 403 and 404	Maximum AC voltage (38 kc)
3	Composite MPX signal 1 kc on left channel only	300mV	Audio (AC) VTVM and oscilloscope vertical input to left channel output lug (4H)	Z402	Maximum AC voltage with clean 1 kc sine wave on oscilloscope
4	Composite MPX signal 1 kc on right channel only	300mV	Same as Step 3	MPX Separation Control (located on chassis).	Minimum reading on Audio (AC) VTVM—should be at least 35db below reading obtained in Step 3.
5	Same as Step 4	300mV	Audio (AC) VTVM and oscilloscope vertical input to right channel output lug	---	Same Audio (AC) VTVM reading as obtained in Step 3 (± 2 db); clean 1kc sine wave on scope.
6	Same as Step 4	300mV	Same as Step 5		Minimum reading on Audio (AC) VTVM should be at least 35db below reading obtained in Step 5.

1278 CONTROL AMPLIFIER



LEFT CHANNEL
 RIGHT CHANNEL AND GROUND




PARTS DESCRIPTION LIST

CAPACITORS		
Symbol	Description	Part No.
C201, 202, 203, 204, 205, 206	Electrolytic, 1uF, 70V	C50B637-2
C207, 208	Ceramic, 680pF, 10%, 1000V	C50B569-2
C209, 210	Mylar, .33uF, 10%, 250V	C50B638-10

RESISTORS AND POTENTIOMETERS		
Symbol	Description	Part No.
R201, 202	Dep. Carbon 18K	R12DC183J
R203	Pot., 1M, Balance	R50160-182
R204, 205	Dep. Carbon, 18K	R12DC183J
R206, 207	Dep. Carbon, 56K	R12DC563J
R208, 209	Dep. Carbon, 330K	R12DC334J
R210, 211	Composition, 4.7K, 10%, 1/2W	RC20BF472K
R212, 213	Dep. Carbon 150	R12DC151J
R214, 215	Pot. 100K, Treble, Bass	R50160-183
R216, 217	Dep. Carbon, 680K	R12DC684J
R218, 219	Composition, 4.7K, 10%, 1/2W	RC20BF472K
R220, 221	Composition, 1.8K, 10%, 1/2W	RC20BF182K

MISCELLANEOUS		
Symbol	Description	Part No.
---	Printed Circuit Board	P1278
---	Printed Circuit, Tone-Control	PC50B187-25
---	Printed Circuit, High-Filter	PC50B187-32
---	Socket, Transistor	X50B779-2
Q201, 202, 203, 204	Transistor, 2N2924	TR2N2924-18

MAIN CHASSIS



† In units with serial numbers ending with X the value of R17 should be 1K, 1/2W (FISHER Part No. R50DC102J).

SWITCH POSITIONS		
POS NO.	S1 SELECTOR SWITCH	S2 MODE TAPE MONITOR
1	TAPE HEAD	MONO
2	PHONO MAG.	STEREO
3	FM-AUTO	STEREO TAPE
4	FM-MONO	MONO TAPE
5	AUX	

- NOTES:
1. FOR ALL VOLTAGE AND CURRENT MEASUREMENTS LINE VOLTAGE = 117 VAC.
 2. DC VOLTAGE MEASURED WITH DC-VTVM TO CHASSIS, UNLESS OTHERWISE INDICATED, WITH NO SIGNAL INPUT.
 3. USE AC VTVM FOR 1KHz SIGNAL TRACING; VOLUME CONTROL MAXIMUM CLOCKWISE, FILTERS OFF, ALL OTHER CONTROLS NORMAL.
 4. □ INDICATES 1KHz SIGNAL LEVELS FROM PHONO INPUT = 4.2 mV TO PA OUTPUT = 11.8V ACROSS 4Ω LOAD (1 kHz = 1kc)

LAST	R90	C30	Q16
------	-----	-----	-----

FISHER RADIO CORPORATION
NEW YORK, N. Y.

SCHEMATIC P-1340

DO NOT SCALE THIS DRAWING

AW2412

Because its products are subject to continuous improvement the manufacturer reserves the right to modify any design or specification without notice and without incurring any obligation.

TROUBLESHOOTING GUIDE

Does not go on (pilot or dial lamps do not light)

- Check:
- Power switch, S7, Fuse, F1
 - AC power cord and wall outlet (use test lamp in rear chassis outlet).

No audio output (earphones normal)

- Check:
- Speaker connections.
 - Position of SPEAKERS switch.

No audio output (earphones and speakers) signal at RCDR jacks normal.

- Check:
- Position of MODE/MONITOR switch S2.
(Set to STEREO or MONO positions only – MONITOR positions for tape recorder with separate record and playback heads only.)

Distortion (both channels) in any position of SELECTOR switch and VOLUME control.

Hum, Weak or
No audio output

- Check:
- Fuse F2, Power-supply.
 - DC voltages (for hum and distortion use scope) at F2, R33, C7; R34, R35, C10; R35, R36, R37, C11; R36, CR2; Emitter of Q9.
 - Audio control amplifier subchassis.

Distortion (LEFT channel only) in PHONO and FM positions of SELECTOR.

Hum, Weak or
No audio output

- Remove plug from LEFT RCDR OUTPUT jack.
- Check:
- Position of BALANCE control.
 - Speaker connections.
 - Audio control amplifier subchassis.
 - Preamplifier subchassis.
 - Q10, Q6, Q5, Q4.

Distortion (RIGHT channel only) in PHONO and FM positions of SELECTOR.

Hum, Weak or
No audio output

- Remove plug from RIGHT RCDR OUTPUT jack.
- Check:
- Position of BALANCE control.
 - Speaker connections.
 - Audio control amplifier subchassis.
 - Preamplifier subchassis.
 - Q11, Q1, Q2, Q3.

Hum (VOLUME turned up only—hum disappears when VOLUME is turned down.) In any position of SELECTOR switch S1.

- Remove plugs from RCDR OUTPUT jacks.
- Check:
- Audio control amplifier subchassis.
 - Preamplifier subchassis.

Distortion (either or both channels) in FM positions of SELECTOR only.

Hum, Weak or
No audio output

- Tune to other stations
- Check:
- Antenna position and connections.
 - Voltage supply to front-end, IF amplifier and Multiplex Decoder subchassis.


Distortion (either or both channels) FM STEREO positions only.

- Tune to other stations
- Check:
- Antenna position and connections.
 - Multiplex Decoder subchassis—realign.

FM STEREO does not work (STEREO BEACON lights)

- Set MODE/MONITOR to STEREO position
- Check:
- Multiplex Decoder SEPARATION CONTROL.

COMPONENT CONNECTIONS



INS 319

POWER OUTPUT MEASUREMENT

The power-output stage of this unit is designed to deliver its full-rated power with program material (voice or music) into 4-to-16-ohm loads for indefinite periods.


When a constant audio tone is used as a signal to measure the *continuous RMS power output* certain precautions must be taken.

- Measure the power output of one channel at a time.
- Limit the measurement period to 10 minutes (with a load resistance between 4 and 16 ohms).


Should it ever be necessary to measure the power output of *both channels simultaneously*, use a load of 4 or 8 ohms (per channel), limit measurement to a period *not longer than 1 minute* for a 4-ohm load or to *5 minutes* for an 8-ohm load.

CHASSIS LAYOUT

TOP



BOTTOM



FISHER RADIO CORPORATION • NEW YORK

