

Technical Manual

NON-SWITCHING DC SERVO STEREO INTEGRATED AMPLIFIER

RA-700

TABLE OF CONTENTS

- Alignment 2
- Addenda 3
- Specifications 3
- Parts List 4
- Chassis Layout 5
- P-c Board Diagrams 6
- Schematic Diagram 9

**Serial No. Beginning
NE16311**

**THE ROTEL CO., LTD.
ROTEL ELECTRONICS CO., LTD.
ROTEL OF AMERICA, INC.
ROTEL HI FI LIMITED.**

1-36-8 OHOKAYAMA, MEGURO-KU, TOKYO 152, JAPAN
2ND FLOOR, EVERGLORY BLDG., NO. 305, SECTION 3,
NANKING E. ROAD, TAIPEI, TAIWAN, REPUBLIC OF CHINA
13528 SO. NORMANDIE, GARDENA, CALIF. 90249, U.S.A.
24 ERICA ROAD, STACEY BUSHES, MILTON KEYNES,
BUCKINGHAMSHIRE, ENGLAND

Alignment

Instruments: Oscilloscope, DC millivoltmeter

POWER AMP SECTION

A. DC Balance Adjustment

1. Set vertical gain control of the oscilloscope to 0.1V/cm, and vertical input switch to GND. Bring the trace to central position on the screen; then set the vertical input switch to DC position.

Before making adjustment, short-circuit pin E6 to pin TP3 (TP-4 for R-ch) on H-AF-119 p-c board, to avoid servo effect. (Fig. 1)

2. Connect the oscilloscope to pin TP3 (TP4 for R-ch) on main amp p-c board. Set volume control of the amplifier to minimum position. Turn on the power. When DC output appears on the screen (the trace will shift upwards or downwards as shown in Fig. 1), adjust potentiometer VR401 (VR402 for R-ch) on H-AF-119 p-c board so that the DC voltage present at the test point is $0V \pm 50mV$.

After completing adjustment, disconnect the ground connection of TP terminal.




Fig. 1

B. Bias (Idling Current) Adjustment

1. Connect the plus lead of DC millivoltmeter to TP5 (TP6 for R-ch) on H-AF-119 and the minus lead to TP3 (TP4 for R-ch). Set volume control to minimum position. Turn on the power.

2. Adjust potentiometer VR403 (VR404 for R-ch) on H-AF-119 p-c board so that the DC millivoltmeter reads 10mV.

PHONO SECTION

DC Balance Adjustment

1. Set vertical gain control of the oscilloscope to 0.1V/cm, and vertical input switch to GND. Bring the trace to central position on the screen; then set the vertical input switch to DC.

Before making adjustment short-circuit pin 1 (pin 2 for R-ch) to pin E on PR-123 p-c board, to avoid servo effect. (Fig. 3)

2. Connect the oscilloscope to pin 3 (pin 4 for R-ch) and pin E. Set Function Selector to PHONO (MC) position and volume control to minimum. Turn on the power.

When DC output appears on the screen (the trace will shift upwards or downwards as shown in Fig. 3), adjust potentiometer VR101 (VR102 for R-ch) on PR-123 p-c board so that the DC voltage present at




Fig. 2

pin 3 (pin 4 for R-ch) is $0V \pm 50mV$.

After completing adjustment, disconnect the ground connection of TP terminal.




Fig. 3

ADDENDA

1. Circuit pattern and connection of the units with serial number up to NE16361 are slightly different from the ones given in this booklet.
2. Numbering of test points differs:
TP3 and TP4 on this booklet are identical to TP9 and TP10 on the units with serial number up to 16361 respectively.

Specifications

Continuous Power Output40 watts* per channel, min. RMS both channels driven into 8 ohms from 20 to 20,000Hz with no more than 0.009% total harmonic distortion.
Total Harmonic Distortion. . .	(20 to 20,000Hz, from AUX) No more than 0.009% (continuous rated power output) No more than 0.005% (continuous 1/2 rated power output) No more than 0.01% (1 watt per channel power output, 8 ohms)
Intermodulation Distortion . . .	(60Hz : 7kHz = 4 : 1) No more than 0.009% (continuous power output) No more than 0.009% (continuous 1/2 rated power output) No more than 0.01% (1 watt per channel power output, 8 ohms)
Output: Speaker	A, B (8-16 ohms), A (8-16 ohms) + B (8-16 ohms)
Headphone.	8-16 ohms
Damping Factor.55 (20 to 20,000Hz, 8 ohms)
Input Sensitivity/Impedance:	
PHONO (MC)02mV/100 ohms
PHONO (MM)25mV/47 kohms
TUNER, AUX.150mV/39 kohms
TAPE MONITOR 1, 2150mV/39 kohms
Overload Level (T.H.D. 0.1%, 1kHz):	
PHONO (MC)38mV
PHONO (MM)390mV
AUX5V


Frequency Response:	
PHONO20 to 100,000Hz, $\pm 0.5dB$ (RIAA STD)
AUX5 to 70,000Hz, $+0dB, -1.0dB$
Tone Control:	
Graphic Equalizer.40, 90, 200, 450, 1k, 2.5k, 6.5k, 16kHz $\pm 12dB$
Loudness Contour	$+10dB$ (100Hz), $+4dB$ (10kHz) (volume control set at $-40dB$ position)
Signal-to-Noise Ratio (IHF, A network):	
PHONO (MC)66dB
PHONO (MM)87dB
TUNER, AUX.98dB
TAPE MONITOR 1, 298dB
Subsonic Filter	$-3dB/16Hz$
MISCELLANEOUS	
Power Requirement.120V/60Hz, 220V/50Hz, 240V/50Hz, or 120, 220, 240V/50-60Hz (switchable)
Power Consumption250 watts
Dimensions (overall)430 (W) x 91 (H) x 293 (D) mm 16-15/16" x 3-9/16" x 11-1/2"
Weight (net)72kg/15.9 lbs

- Specifications and design subject to possible modification without notice.
- *Measured pursuant to the Federal Trade Commission's Trade Regulation Rule on Power Claims for Amplifiers (applicable to the U.S.A. only).

Schematic Location	Description	Part No.
	Foot	673402027
	Screw, M3 x 6 (Ni) Bind	705213006
	Screw, M3 x 12 (Ni), Bind	705213012
	Screw, M3 x 4 (Ni), Bind	705213004
	Screw, M3 x 8 (BLZ), Bind	705223008
	Screw, M3 x 6 (Ni), Ovalcountersunk	702213006
	Screw, M4 x 8 (BLZ) w/FW, Bind	755224008
	Screw, TP3 x 10 (Ni)	726213010
	Screw, TP3 x 8 (Ni)	726213008
	Screw, TP3 x 10 (BLZ)	726223010
	Screw, TP3 x 8 (BLZ)	726223008
	Screw, TP3 x 8 (Ni), Ovalcountersunk	722213006



Schematic Location	Description	Part No.
	Screw, Tap-tight 4 x 10	765214010
	Washer, Plain M3	770500003
	Washer, Spring M3	770500010
	Washer, Spring M4	770500011
	Washer, Plain M7	770500006
	Nut, M3, Square, Tr Mtg.	770911144
	Nut, M4, Hex	770402202
	Nut, M7, Hex	770402205
	Stopper, Phone Jack	770911278
	Spacer, M3, L=8mm	770911301
	Insulation Collar, Tr Mtg.	992001111

Chassis Layout (Top View)



- | | |
|--|---|
| 1. VOLTAGE SELECTOR | 20. FUNCTION INDICATOR |
| 2. F534, FUSE | 21. FUNCTION SELECTOR |
| 3. F535, FUSE | 22. TAPE-2 INDICATOR |
| 4. SPEAKER 'A' TERMINALS | 23. TAPE-2 SWITCH |
| 5. SPEAKER 'B' TERMINALS | 24. TAPE-1 SWITCH |
| 6. MAIN AMP AND POWER SUPPLY P-C BOARD | 25. TAPE-1 INDICATOR |
| 7. Q438, R-CH POWER TRANSISTOR | 26. BALANCE CONTROL |
| 8. Q440, R-CH POWER TRANSISTOR | 27. ACOUSTIC CONTROLS |
| 9. TAPE MONITOR-2 JACKS | 28. EQUALIZER P-C BOARD |
| 10. TAPE MONITOR-1 JACKS | 29. SPEAKER 'B' SWITCH |
| 11. INPUTS JACKS | 30. SPEAKER 'A' SWITCH |
| 12. VR404, R-CH IDLING (BIAS) CURRENT ADJ | 31. POWER INDICATOR |
| 13. VR402, R-CH MAIN AMP OFF-SET (DC BALANCE) ADJ | 32. POWER SWITCH |
| 14. VR102, R-CH PHONO AMP OFF-SET (DC BALANCE) ADJ | 33. PROTECTION RELAY |
| 15. PHONO AMP P-C BOARD | 34. Q437, L-CH POWER TRANSISTOR |
| 16. VR101, L-CH PHONO AMP OFF-SET (DC BALANCE) ADJ | 35. VR403, L-CH IDLING (BIAS) CURRENT ADJ |
| 17. VOLUME CONTROL AND MUTING P-C BOARD | 36. VR401, L-CH OFF-SET (DC BALANCE) ADJ |
| 18. FUNCTION SELECTOR P-C BOARD | 37. Q439, L-CH POWER TRANSISTOR |
| 19. VOLUME CONTROL | 38. T001, POWER TRANSFORMER |

MAIN AMP AND POWER SUPPLY CIRCUIT





Not used on the unit for 220/240V SPC


To POWER TRANS (SEC)

To CHASSIS GROUND


Schematic Diagram




2SC2375
2SC2362
2SA1016
2SA1019
2SC536K NP
2SC1570
2SA929
2SA608K NP




2SA913




2SC1984



2SD600
2SB631



NJM4558D



2SC2578
2SA1103






2SK163
2SK130A



2SK246

RES
Unle
noise
K.
M.
▼



RA-700 (NO.1)

RA-700

RESISTORS

Unless otherwise specified, resistors are 1/4 watts, low noise type carbon film type with a tolerance of 5%




K Kilohm
M Megohm
▼ Uninflammable carbon film resistor, 1/2 watts




CAPACITORS

Unless otherwise specified, all capacitance values are expressed in mfd.

S Polystyrene film capacitor
MY Mylar film capacitor
—E— Electrolytic capacitor
Non mark Ceramic capacitor

- Voltage read with VTVM across the point shown and the chassis ground (line voltage: 120V)
- Voltage reading tolerance: ±20%





119 POWER SUPPLY, MAIN AMP. & PROTECTION CIRCUIT